



44in Mower Service Kit 100 Series Z Master®

Model No. 105-6173 - 240000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR.	as required	HYD.	hydraulic
ASM.	assembly	INC.	incorporated
CARR.	carriage	LH.	left hand
DEG.	degrees	NI.	nylon insert
FH.	flat head	PPH.	phillips pan head
GA.	gauge	PTH.	phillips truss head
HF.	hex flange	PTO.	power take off
HH.	hex head	RH.	right hand
HHF.	hex head flange	SFH.	slotted fillister head
HHFTF.	hex head flange thread forming	SHH.	slotted hex head
HJ.	hex jam	SHWH.	slotted hex washer head
HLH.	hex lag head	SPH.	slotted pan head
HOC.	height-of-cut	SQH.	square head
HS.	hex	SRH.	slotted round head
HSBH.	hex socket button head	STD.	standard
HSFH.	hex socket flat head	TAP.	self tapping
HS.	hex socket head	TTH.	torx truss head
HWH.	hex washer head	WH.	wing head
HWHTF.	hex washer head thread forming		


Contents

Description	Page
Deck and Wheel Gage Assembly	 3
Deck Spindle Assembly	 4
Idler and Pulley Assembly	 5
Deck and Deflector Assembly No. 106-5884	 6
Deck Decal Assembly No. 106-5883	 7



Deck and Wheel Gage Assembly


Ref	Part No.	Qty.	Description				
1	3290-357	7	Nut-HHF				
2	68-2730	5	Wheel-Gage				
3	98-5967	1	Spacer				
4	323-28	1	Screw-HH				
12	32128-17	4	Nut-Lock, Flange				
13	249-21	2	Clamp-Slotted				
14	99-3928	1	LH Cover ASM				
14:2	67-5360	1	Decal-Danger				
15	99-3929	1	RH Cover ASM				
15:2	67-5360	1	Decal-Danger				
16	99-2842	3	Spacer				
17	98-5975	3	Washer-Belleville				
20	106-5884	1	Deck And Deflector ASM				
22	3290-321	4	Screw-HWH				
23	1-373034	3	Washer				
27	100-3257-03	1	Plate-Blowout, RH				
28	100-3258-03	1	Plate-Blowout, LH				
29	12-3270	9	Screw				



Deck Spindle Assembly


Ref	Part No.	Qty.	Description				
3	54-0010	3	Blade				
4	100-3977	3	Spindle Housing ASM				
4:1	302-2	1	Fitting-Grease				
4:2	7-4150	1	Washer				
4:3	251-257	2	Bearing-Ball				
4:4	67-7580	1	Spacer-Bearing				
4:5	67-7570	1	Spacer-Spindle				
4:6	32146-20	1	Nut-Jam				
4:7	100-3975	1	Pulley And Hub ASM				
4:8	67-7590	1	Housing-Spindle				
4:9	100-3974	1	Spindle Shaft ASM				
4:11	3256-27	1	Washer-Flat				
4:12	3253-8	1	Washer-Lock				
4:13	51-4060	1	Screw-Blade				
5	32152-1	12	Nut-Lock, NI				
6	3256-2	4	Washer-Flat				
7	322-4	12	Screw-HH				
8	98-3780	1	V-Belt-Drive				

5



Deck and Deflector Assembly No. 106-5884

Ref	Part No.	Qty.	Description				
1	106-5883	1	Deck Decal ASM				
2	322-50	1	Screw-HH				
3	105-4625	1	Deflector ASM				
3:2	93-1122	1	Decal-Danger				
4	105-4622	1	Spacer				
5	104-8554	1	Spring-Torsion				
6	3296-29	1	Nut-Lock, NI				



Deck Decal Assembly No. 106-5883

Ref	Part No.	Qty.	Description				
2	104-8569	1	Decal-Warning				
3	98-5954	3	Decal-Missing, Cover				
4	99-3943	1	Decal-Routing, Belt				
5	43-8480	1	Decal-Danger				
6	93-7818	1	Decal-Torque, Blade Bolt				
7	98-3798	1	Decal-Wheel, Gage				
8	106-0704	1	Decal				
10	66-1340	1	Decal-Danger				

