

44in Finishing Kit Z100 Twin Bagger

Model No. 78496

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.


For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form \mathbf{nX} \mathbf{y} . The \mathbf{n} represents the quantity of the part, the \mathbf{X} is the multiplication symbol, and the \mathbf{y} represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number 37 are indicated.



44in Finishing Assembly

Ref. No.	Part No.	Qty.	Description
1	3274–55	8	Screw-HSBH
2	106-3021-01	1	Baffle-Rear, LH
3	32128-25	16	Nut–Flange
4	106-3015-01	1	Center Baffle ASM
5	106-3022-01	1	Baffle-Rear, RH
6	106–3023–01	1	Baffle–Discharge, Front
7	3230-18	8	Screw-CARR
8	106-3020-01	1	Baffle-Discharge,
			Rear
9	32128-43	4	Nut–Flange
10	323-7	4	Screw-HH
11	106–2098–03	1	Front Mounting Plate ASM
12	106-3038	1	Belt-V
13	105-5897	1	Double Pulley ASM
14	106-3078	1	Cover ASM
14:2	3290-321	2	Screw-HWH
14:3	249–21	1	Clamp-Slotted
14:4	32128–17	2	Nut-Lock, Flange
14:5	67-5360	1	Decal-Danger
15	106–2099–03	1	Rear Mounting Plate ASM
16	106-2095-03	1	Plate-Template
*99	55-4940-03	3	Blade

Ref. No.	Part No.	Qty.	Description

^{*} Not illustrated