



Count on it.

Parts Catalog

Road Light Kit

122cm, 132cm, or 152cm Z Master® 4000
Series Riding Mower

Model No. 02936



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Headlight Mount Assembly 4

Light Mount Kit Assembly No. 140-6698 5

Taillight Mount Assembly..... 6


Control Panel and Decal Assembly 7

Control Panel Assembly 8

Electrical, Horn and Warning Light Assembly 9


Wire Harness Assembly No. 122-2482..... 10

LH Lever Assembly No. 134-6996 11




Headlight Mount Assembly

Ref.	Part Number	Qty.	Description
1	33116-060	2	Screw-HH
2	134-6659-01	2	Light Mount ASM [red]
3	140-6772	1	RH Light ASM
3:2	140-6698	1	Light Mount Kit
4	140-6773	1	LH Light ASM
4:2	140-6698	1	Light Mount Kit
5	32105-15	2	Screw-HWH
6	134-6691	2	Cap, Square-End



Light Mount Kit Assembly No. 140-6698


<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	139-2092	1	Mount-Light
2	107-7983	1	Screw-HH
4	48-8070	2	Washer-Lock
5	33026-00	2	Nut-Hex



Taillight Mount Assembly

Ref.	Part Number	Qty.	Description
1	104-7201	10	Nut-HF, NI
2	104-8301	4	Nut-HF, NI
3	130-6549	2	Bolt-U
4	134-6518	2	Bracket-Pivot, ASM
4:1	134-6517-03	1	Pivot Bracket ASM [black]
4:2	140-6682-03	1	Pivot
4:3	32121-34	1	Pin-Roll
4:4	61-3270-03	1	Spring-Compression
4:5	134-8192	1	Washer 34 DIA X 7 DIA X 5 THK
4:6	32105-15	1	Screw-HWH
5	134-6520	1	Bracket-Pivot, ASM Wide
5:1	61-3270-03	1	Spring-Compression
5:2	134-8192	1	Washer 34 DIA X 7 DIA X 5 THK
5:3	134-6519-03	1	Pivot Bracket [bla
5:4	140-6682-03	1	Pivot

Ref.	Part Number	Qty.	Description
5:5	32105-15	1	Screw-HWH
5:6	32121-34	1	Pin-Roll
7	134-8126-03	1	Housing-Light, RH
8	134-8127-03	1	Housing-Light, LH
9	140-6835	2	Inner Mount ASM
9:2	107-1013	2	Nut-Speed
9:3	138-2760	4	Nut-Clinch, Hex
10	140-6861-03	1	Mount-Light, RH
11	140-6862-03	1	Mount-Light, LH
12	140-6863-03	2	Cover-Mount
13	3229-11	4	Screw-CARR
14	3234-4	6	Screw-HHF
15	3250-23	4	Screw-PPH
16	3274-69	8	Screw-HSBH
17	139-3205	8	Rivet-Plastic
18	139-2071	2	Light-Rear Tail/Stop/Turn




Control Panel and Decal Assembly

Ref.	Part Number	Qty.	Description
1	104-8301	3	Nut-HF, NI
2	111-6635	1	Sign-Pvc
3	120-9684	2	Nut-Lock
4	120-9693	2	Screw-PPH
7	134-7024-03	1	License-Plate Mount ASM [black]
8		1	Control-Lights, ASM ●
9	139-2074	1	Light-Plate, License (Ece)
10	09320	6	Rivet


Ref.	Part Number	Qty.	Description
11	111-6636	2	Sign-Aluminum, Round
13	104-7201	4	Nut-HF, NI
14	119-6920	2	Bolt-Carriage
15	3231-25	3	Bolt-CARR
16	111-5020	2	Reflector-Adhesive
17	1-807512	2	Bolt-CARR
18	32180-030	2	Clip-Tie
99	134-7570	3	Decal-Speed, 10 Kph

● Not serviced separately



Control Panel Assembly


Ref.	Part Number	Qty.	Description
1	134-6530-03	1	Panel, Control
2	107069	6	Clip
3	134-6932-03	1	Control-Cover
4	139-2080	1	Flasher-Dual Rate
5	1-807533	1	Bolt-CARR
6	120-4578	1	Nut-HF
7	119-7769	1	Switch-Rocker, On/None/On
8	32105-15	6	Screw-HWH
9	120-0334	1	Switch-Rocker
10	111-3472	1	Switch-Beacon
11	111-7679	1	Washer-Plain



Electrical, Horn and Warning Light Assembly


Ref.	Part Number	Qty.	Description
1	09784	2	Screw-Soc, HD
2	122-2352	1	Harness-Wire, EU Power Adaptor
2:6	121-8868	1	Fuse-Mini Blade, 20 Amp
2:7	32180-101	1	Cover-Fuse, Single
3	122-2482	1	Harness-Wire, EU Light Kit
4	134-3747	1	Screw-HHF
5	134-3762	1	Nut-Flange, NI
6	134-6996	1	LH Lever Assembly
7	110-2594	1	Horn
9	111-2195-03	1	Clamp-50MM
10	119-8095	1	Socket-Beacon

Ref.	Part Number	Qty.	Description
11	134-6548-03	1	Bracket, Beacon
12	134-5326	1	Light-Beacon ASM
13	134-3748	2	Screw-HHF
14	09270	2	Washer-Plain
15	134-3762	2	Nut-Flange, NI
17	122-1222	1	Harness-Wire
18	134-5327	1	Ferrite, Emc Suppresion
19	122-2617	1	Harness-Wire, Handle
21	HY3966	1	Tie-Cable
99	74-07-020	15	Tie-Cable
99	HY3966	10	Tie-Cable



Wire Harness Assembly No. 122-2482

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
13	116-0053	3	Cap-Plug
14	32181-015	1	Cover-Fuseblock
18	121-8861	2	Fuse-Mini Blade, 2 Amp
19	121-8864	3	Fuse-Mini Blade, 5 Amp
20	121-8866	1	Fuse-Mini Blade, 10 Amp
21	126-3991	2	Relay-Micro



LH Lever Assembly No. 134-6996

Ref.	Part Number	Qty.	Description
1	134-6995	1	Handle ASM - LH
1:1	134-6994-03	1	Handle ASM-LH [black]
1:2	134-8052	1	Grip, Control Lever
2	136-2162	1	Switch-Combination Assembly
3	132-1418	1	Cap-Switch
4	3245-42	1	Screw-Set
5	136-1921	1	Decal-Lights



Count on it.