



**Count on it.**

# Parts Catalog

## 60in Z Master® Professional 2000 Series

Riding Mower

Model No. 77299—Serial No. 411436112 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity


In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

|                                                             |    |
|-------------------------------------------------------------|----|
| Frame Assembly . . . . .                                    | 4  |
| Roll-Over Protection System Assembly No. 144-1848 . . . . . | 6  |
| Transaxle Assembly . . . . .                                | 8  |
| LH Transaxle Assembly No. 140-9489 . . . . .                | 10 |
| RH Transaxle Assembly No. 140-9490 . . . . .                | 12 |
| Control Console and Guard Assembly . . . . .                | 14 |
| Fuel Assembly . . . . .                                     | 16 |
| Fuel Tank Assembly No. 126-4724 . . . . .                   | 18 |
| Seat Mount Assembly . . . . .                               | 20 |
| Seat Assembly No. 144-3775 . . . . .                        | 22 |
| Motion Control Assembly . . . . .                           | 24 |
| LH and RH Motion Control Assembly . . . . .                 | 26 |
| Caster Assembly . . . . .                                   | 28 |
| Caster Wheel and Fork Assembly . . . . .                    | 30 |
| Rear Wheel Assembly . . . . .                               | 32 |
| Electrical Assembly . . . . .                               | 34 |
| Wire Harness Assembly No. 126-5803 . . . . .                | 36 |
| Deck Lift Assembly . . . . .                                | 38 |
| Deck Strut Assembly No. 126-8365 . . . . .                  | 40 |
| Engine, Clutch and Muffler Assembly . . . . .               | 42 |
| Deck Assembly . . . . .                                     | 44 |
| Deflector Assembly No. 120-2451 . . . . .                   | 46 |
| Deck Decal Assembly No. 126-8958 . . . . .                  | 48 |
| Attachments and Accessories . . . . .                       | 50 |

# Frame Assembly




## Frame Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|---------------------|
| 1           | 104-8300           | 2           | Nut-HF, NI           | 30          | 144-2615           | 1           | Floor Mat           |
| 8           | 144-1975           | 1           | Frame-60             | 31          | 117-2382           | 6           | Plug-Plastic        |
| 8:2         | 109-6014           | 1           | Decal-Routing, Belt  | 35          | 138-9753           | 4           | Screw               |
| 8:3         | 116-8588           | 2           | Decal-Release, Drive | 38          | 144-2628-01        | 1           | Bracket-Light [red] |
| 8:5         | 126-4363           | 2           | Decal-Warning        | 39          | 144-2604           | 1           | Bumper-Front        |
| 8:6         | 127-6618           | 1           | Strip-Seal           | 40          | 135-2015           | 2           | Screw-Shoulder      |
| 10          | 126-5491           | 2           | Isolator             | 41          | 144-2614           | 1           | Step                |
| 11          | 144-1848           | 1           | ASM-ROPS             | 42          | 138-2662           | 2           | Bumper-Rubber       |
| 12          | 144-3767           | 1           | Pan-Floor            | 43          | 32128-33           | 2           | Nut-HF              |
| 12:2        | 126-8383           | 1           | Decal-Danger         | 44          | 126-9487-03        | 2           | Bracket             |
| 21          | 126-7065           | 2           | Grommet-Rubber       |             |                    |             |                     |

# Roll-Over Protection System Assembly

## No. 144-1848




# Roll-Over Protection System Assembly

## No. 144-1848 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|--------------------|
| 1           |                    | 1           | Upper ROPS ASM ●    | 6           | 99-5107            | 2           | Nut-Lock           |
| 1:2         | 107-3069           | 1           | Decal-Warning       | 7           | 109-5337           | 2           | Bumper-ROPS        |
| 2           |                    | 1           | LH Lower ROPS ASM ● | 8           | 126-9488           | 4           | Screw-HHF          |
| 3           |                    | 1           | RH Lower ROPS ASM ● | 9           | 32128-50           | 4           | Nut-Flange         |
| 4           | 103-4553           | 2           | Pin-Fold, ROPS      | 10          | 119-4164           | 2           | Washer-Wave        |
| 5           | 126-9209           | 2           | Bolt-Shoulder       |             |                    |             |                    |

● Not serviced separately

# Transaxle Assembly






## Transaxle Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|----------------------|
| 1           | 140-9489           | 1           | LH Transaxle ASM   | 12:1        | 109-3320           | 1           | Cap-Reservoir, HYD   |
| 2           | 140-9490           | 1           | RH Transaxle ASM   | 14          | 94-7972            | 2           | Screw-HH W/Loctite ● |
| 3           | 104-8300           | 8           | Nut-HF, NI         | 15          | 126-0327           | 4           | Clamp-Hose           |
| 4           | 126-4687           | 4           | Screw-HHF          | 16          | 109-5395           | 2           | Arm-Bypass, Hydro    |
| 5           | 3230-7             | 2           | Bolt-CARR          | 17          | 3229-1             | 2           | Screw-CARR           |
| 6           | 116-5809           | 2           | Spacer-Hydro       | 18          | 108-6402           | 2           | Knob-Handle          |
| 7           | 126-5896           | 2           | Screw HHF          | 19          | 1-806003           | 2           | Pin-Cotter           |
| 8           | 116-6833           | 1           | Shaft-Spacer       | 20          | 126-5668           | 1           | Hose-Hydraulic       |
| 9           | 1-303334           | 4           | Washer-Spring      | 21          | 126-5669           | 1           | Hose-Hydraulic       |
| 10          | 126-6266           | 2           | Screw-Tph          | 24          | 3256-4             | 2           | Washer-Flat          |
| 12          | 109-2250           | 1           | Tank-HYD           |             |                    |             |                      |

● Use Pro-Lock, Nut Type (P/N 1-840022, .5ml tube) on threads.

# LH Transaxle Assembly No. 140-9489




## LH Transaxle Assembly No. 140-9489 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|------------------------|
| 1           | 109-3321           | 1           | Element-Oil Filter, HYD | 7:1         | 126-8905           | 1           | Hub-Fan                |
| 2           | 109-3278           | 1           | Adapter-Straight        | 7:2         | 126-0226           | 1           | Fan                    |
| 2:1         | 237-42             | 1           | O-Ring                  | 7:3         | 116-9714           | 1           | Nut-HJ                 |
| 3           | 109-3540           | 1           | O Ring-Seal             | 8           | 116-6214           | 1           | Cap-Axle, Long         |
| 4           | 109-5592           | 1           | Spring-Extension        | 9           | 116-6213           | 1           | Tube-Axle              |
| 5           | 116-3872           | 1           | Hub-Offset              | 10          | 120-7979           | 1           | Guard-Filter, LH       |
| 6           | 109-3536           | 1           | Nut-Hub                 | 99          | 135-3604           | 1           | Brake Shaft Seal Kit ● |
| 7           | 126-8904           | 1           | Fan And Pulley Kit      | 99          | 121-3243           | 1           | Seal Kit ●             |

● Not illustrated

# RH Transaxle Assembly No. 140-9490




## RH Transaxle Assembly No. 140-9490 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|------------------------|
| 1           | 109-3321           | 1           | Element-Oil Filter, HYD | 7:1         | 126-8905           | 1           | Hub-Fan                |
| 2           | 109-3278           | 1           | Adapter-Straight        | 7:2         | 126-0226           | 1           | Fan                    |
| 2:1         | 237-42             | 1           | O-Ring                  | 7:3         | 116-9714           | 1           | Nut-HJ                 |
| 3           | 109-3540           | 1           | O Ring-Seal             | 8           | 116-6214           | 1           | Cap-Axle, Long         |
| 4           | 109-5592           | 1           | Spring-Extension        | 9           | 116-6213           | 1           | Tube-Axle              |
| 5           | 116-3872           | 1           | Hub-Offset              | 10          | 120-7981           | 1           | Guard-Filter, RH       |
| 6           | 109-3536           | 1           | Nut-Hub                 | 99          | 121-3243           | 1           | Seal Kit ●             |
| 7           | 126-8904           | 1           | Fan And Pulley Kit      | 99          | 135-3604           | 1           | Brake Shaft Seal Kit ● |

● Not illustrated


# Control Console and Guard Assembly



## Control Console and Guard Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|---------------------|
| 1           | 126-4983           | 1           | Console-RH              | 23          | 126-9945           | 1           | Support-Console, RH |
| 2           | 126-4984           | 1           | Console-LH              | 24          | 126-5532-03        | 1           | Bracket-Console, LH |
| 5           | 144-3768           | 1           | Cover - Control, Motion | 25          | 140-4354           | 1           | Decal - HDX         |
| 5:2         | 135-2310           | 1           | Decal-Motion Control    | 26          | 140-4352           | 1           | Decal - HDX         |
| 6           | 144-3769           | 1           | Cover - Control, Motion | 29          | 104-7201           | 4           | Nut-HF, NI          |
| 6:2         | 135-2310           | 1           | Decal-Motion Control    | 30          | 104-8300           | 12          | Nut-HF, NI          |
| 7           | 144-3780           | 1           | Ctrl Panel ASM          | 31          | 117-5036           | 2           | Screw-Plastic, HWH  |
| 7:2         | 126-9115           | 1           | Decal-Panel, Control    | 32          | 120-7950           | 2           | Screw-Torx          |
| 7:3         | 144-3778           | 1           | Decal-Panel Ctrl        | 33          | 126-5544           | 4           | Screw-Torx          |
| 10          | 139-3643           | 1           | Rear Guard ASM          | 34          | 126-6266           | 4           | Screw-Tph           |
| 10:2        | 99-4693            | 1           | Decal                   | 35          | 126-6267           | 4           | Screw-TTH           |
| 10:3        | 106-5517           | 2           | Decal-Warning           | 36          | 126-6268           | 2           | Screw-TTH           |
| 10:4        | 133-8062           | 1           | Decal-Arrestor, Spark   | 37          | 126-6269           | 10          | Screw-Truss         |
| 11          | 135-5084-03        | 1           | Guard-Muffler [black]   | 38          | 126-7439           | 4           | Screw-Torx          |
| 12          | 139-3644-01        | 1           | Trim-Upper Rear         | 39          | 1-807513           | 2           | Bolt-CARR           |
| 13          | 136-1745-03        | 1           | Cover, Pod RH           | 40          | 3230-22            | 2           | Screw-CARR          |
| 14          | 136-1746-03        | 1           | Cover-LH                | 41          | 3296-2             | 2           | Nut-Lock, NI        |
| 15          | 126-9023-01        | 1           | Bracket-Guard, RH       | 47          | 126-8232           | 4           | Screw-Truss Hex Skt |
| 16          | 126-9022-01        | 1           | Bracket-Guard, LH       | 49          | 3220-3             | 1           | Nut-HJ              |
| 19          | 126-7009           | 1           | Cable-Control, Choke    | 50          | 32149-2            | 10          | Nut-Keps            |
| 20          | 126-7008           | 1           | Cable-Control, Throttle | 52          | 126-9939           | 1           | Decal-Fill, Fuel    |
| 21          | 1-603175           | 1           | Knob-Ball               | 55          | 87-6620            | 4           | Screw-Tph Thd Form  |

# Fuel Assembly






## Fuel Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|-------------------------|
| 3           | 126-8736           | 1           | Vent Hose ASM      | 7:4         | 2412-98            | 4           | Clamp-Hose              |
| 7           | 126-8740           | 1           | Fuel Hose ASM      | 8           | 135-4801           | 1           | Cap-Fuel, Ratcheting    |
| 7:1         | 109-0302           | 1           | Hose-Fuel Line 24" | 9           | 126-4724           | 1           | Tank-Fuel               |
| 7:2         | 109-0678           | 1           | Hose-Fuel          | 10          | 126-5523           | 3           | Clip                    |
| 7:3         | 1-603770           | 1           | Valve-Fuel         | 17          | 1-303287           | 1           | Tie-Cable 5 1/2 (Small) |

# Fuel Tank Assembly No. 126-4724




## Fuel Tank Assembly No. 126-4724 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|---------------------------|
| 2           | 46-6560            | 2           | Bushing                   |
| 3           | 126-9057           | 1           | Fitting-90 DEG            |
| 4           | 116-4630           | 1           | Fitting-Orifice, Straight |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 5           | 126-5528           | 1           | Pickup-Fuel        |
| 5:5         | 126-5527           | 1           | Ring-Retainer      |
| 7           | 126-5525           | 4           | Bolt               |


# Seat Mount Assembly



## Seat Mount Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|--------------------|
| 1           | 145-3690-03        | 1           | Plate-Fixed Seat     | 29          | 135-7125           | 2           | Washer-Retaining   |
| 2           | 3230-22            | 2           | Screw-CARR           | 32          | 3296-47            | 1           | Nut-Lock,NI        |
| 3           | 104-8300           | 6           | Nut-HF, NI           | 33          | 144-2612-01        | 1           | Plate-Backer       |
| 4           | 135-0505           | 2           | Bumper-Seat          | 34          | 130-8451           | 2           | Rivet-Trifold      |
| 11          | 144-3775           | 1           | Seat-Suspension Toro | 35          | 135-7047           | 1           | Bumper-Rubber      |
| 23          | 126-8151           | 1           | Decal-Aid, Service   |             |                    |             |                    |


# Seat Assembly No. 144-3775



## Seat Assembly No. 144-3775 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 126-2058           | 1           | Armrest Kit             | 5           | 82-2190            | 1           | Switch-Bail             |
| 1:1         | 110-4163           | 2           | Cushion-Rest, Arm       | 6           | 26-4840            | 4           | Spacer-Pin, Mounting    |
| 2           | 139-3612           | 1           | Seat Belt Kit           | 7           | 139-3614           | 1           | Track ASM               |
| 3           | 130-0846           | 1           | Knob-Adjuster           | 8           | 144-3776           | 1           | Cover-Back, Susp Seat   |
| 4           | 139-3613           | 1           | Cover-Skirt W/Fasteners | 9           | 144-3777           | 1           | Cover-Bottom, Susp Seat |

# Motion Control Assembly






## Motion Control Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|--------------------------|
| 1           | 104-8300           | 4           | Nut-HF, NI              | 19          | 126-9191           | 1           | RH Control Handle ASM    |
| 2           | 104-8301           | 3           | Nut-HF, NI              | 19:2        | 126-7359           | 1           | Grip                     |
| 3           | 107-1045           | 1           | Spring-Extension        | 20          | 126-9192           | 1           | LH Control Handle ASM    |
| 5           | 109-7694           | 2           | Spring-Compression      | 20:2        | 126-7359           | 1           | Grip                     |
| 6           | 112-3306           | 2           | Nut                     | 21          | 126-7217           | 2           | Linkage-Brake, Lower     |
| 7           | 115-5099           | 2           | Bolt-Pivot              | 22          |                    | 1           | LH Motion Control ASM ●  |
| 8           | 119-1415           | 4           | Pin-Cotter, Locking     | 23          |                    | 1           | RH Motion Control ASM ●  |
| 9           | 323-8              | 1           | Screw-HH                | 24          | 1-303105           | 1           | Yoke-Adjustable          |
| 10          | 119-4164           | 1           | Washer-Wave             | 26          | 1-808280           | 1           | Pin-Clevis               |
| 11          | 126-4299           | 2           | Screw-HSBH              | 27          | 32120-47           | 1           | Ring-Retaining, External |
| 12          | 126-4322           | 2           | Damper                  | 28          | 3234-42            | 4           | Screw-HHF                |
| 13          | 126-4424           | 4           | Screw-Shoulder          | 29          | 37-8771            | 2           | Bolt-Shoulder, HF        |
| 14          | 126-5813           | 1           | Shaft-Brake             | 30          | 115-9625           | 1           | Decal-Brake, Parking     |
| 15          | 126-5819           | 1           | Linkage-Brake, Upper    | 31          | 126-6266           | 2           | Screw-Tph                |
| 16          | 126-5989           | 1           | Pivot-Flange            | 32          | 126-5820           | 1           | Bearing-Spherical        |
| 17          | 126-9490           | 1           | Lever-Brake (With Grip) | 39          | 2844               | 1           | Washer                   |
| 18          | 126-6456           | 1           | Bracket-Brake           | 40          | 3218-3             | 2           | Nut-Jam                  |
| 18:2        | 126-5820           | 1           | Bearing-Spherical       |             |                    |             |                          |

● Not serviced separately

# LH and RH Motion Control Assembly




## LH and RH Motion Control Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 126-3773           | 1           | Control Arm ASM    |
| 1:2         | 126-8909           | 2           | Bushing            |
| 1:3         | 1-413152           | 2           | Bushing-Sleeve     |
| 2           | 126-7296           | 1           | Washer-Friction    |
| 3           | 126-8182           | 1           | Arm-Control        |
| 4           | 117-1240           | 1           | Washer             |
| 5           | 119-8925           | 1           | Washer-Belleville  |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|------------------------|
| 6           | 117-1198           | 1           | Bolt-Pivot             |
| 7           | 32152-2            | 1           | Nut-Lock, Cone         |
| 8           | 126-5435           | 1           | Link-Control           |
| 9           | 126-5434           | 1           | Swivel                 |
| 10          | 104-8300           | 2           | Nut-HF, NI             |
| 11          | 126-8195           | 1           | Spring-Return, Neutral |
| 12          | 3256-24            | 1           | Washer-Flat            |

# Caster Assembly




## Caster Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>             | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------------------|-------------|--------------------|-------------|--------------------|
| 1           |                    | 2           | ASM, Front Caster W/ Fork<br>● | 5           | 100-1668           | 2           | Screw-HHF          |
| 2           | 109-3678           | 4           | Bearing-Ball                   | 6           | 3256-68            | 2           | Washer-Flat        |
| 4           | 144-0375           | 2           | Cap, Grease                    | 7           | 145-3660           | 2           | Spacer-Bearing     |

● Not serviced separately

# Caster Wheel and Fork Assembly




## Caster Wheel and Fork Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|---------------------|
| 1           | 142-7827-01        | 1           | Fork-Caster              | 2:1:3       | 1-633585           | 2           | Bearing-Cone, Taper |
| 2           | 140-4896           | 1           | Semi Pneumatic ASM       | 2:1:4       | 103-3051           | 1           | Spacer-Nut          |
|             |                    |             | 13X6.50-6                | 2:1:5       | 103-0063           | 2           | Seal-Caster         |
| 2:1         |                    | 1           | ASM Whl/Brgs 13X6.50-6 ● | 2:2         | 126-5389           | 1           | Screw-HHF           |
| 2:1:2       | 126-7796           | 1           | Caster Axle ASM          | 2:3         | 99-5107            | 1           | Nut-Lock            |
| 2:1:2:1     | 126-5220           | 1           | Axle-Caster              | 2:4         | 103-2768           | 2           | Guard-Seal          |

● Not serviced separately

Rear Wheel Assembly






## Rear Wheel Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 144-6607           | 2           | Wheel And Tire ASM |
| 1:1         | 144-6606           | 1           | Wheel              |
| 1:2         | 140-7975           | 1           | Tire               |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1:3         | 232-27             | 1           | Stem-Valve         |
| 2           | 242-50             | 8           | Nut-Lug            |

# Electrical Assembly



## Electrical Assembly (continued)


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|-----------------------|
| 1           | 63-8360            | 1           | Key-Ignition          | 15          | 321-4              | 2           | Screw-HH              |
| 2           | 103-5221           | 1           | Switch-PTO            | 20          | 3256-22            | 2           | Washer-Flat           |
| 3           | 104-8300           | 2           | Nut-HF, NI            | 21          | 33094-00           | 1           | Washer-Plain          |
| 4           | 105-6849           | 1           | Screw-Forming, Thread | 22          | 33114-020          | 1           | Screw-HH              |
| 5           | 110-6765           | 1           | Switch                | 23          | 82-2190            | 2           | Switch-Bail           |
| 6           | 116-5609           | 1           | Module ASM            | 24          |                    | 1           | Battery ●■            |
| 8           | 137-4100           | 1           | Switch-Ignition       | 25          | 142-8697           | 1           | Strap, Bungee         |
| 10          | 126-5803           | 1           | Harness-Wire ▲        | 40          | 139-6395           | 1           | Harness-Wire, USB Kit |
| 11          | 126-6267           | 2           | Screw-TTH             | 41          | 140-7955           | 1           | Port-Power, USB       |
| 13          | 126-6725-03        | 1           | Tray-Battery          | 42          | 144-6974           | 1           | Harness-Wire, Jumper  |
| 14          | 32128-33           | 2           | Nut-HF                |             |                    |             |                       |

● Obtain locally.

■ Not serviced separately

▲ Use dielectric grease on all unsealed connectors and terminals only. Do not apply in sealed connectors.


**Wire Harness Assembly No. 126-5803**



## Wire Harness Assembly No. 126-5803 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|-------------------------|
| 2           | 121-8868           | 1           | Fuse-Mini Blade, 20 Amp | 7           | 103-3895           | 1           | Diode                   |
| 3           | 126-3991           | 1           | Relay-Micro             | 8           | 126-8876           | 1           | Insulator-Battery       |
| 4           | 32180-176          | 1           | Cover-Block, Fuse       | 9           | 1-543393           | 1           | Insulator-Solenoid      |
| 5           | 32180-177          | 1           | Clip-Mounting           | 10          | 121-8867           | 1           | Fuse-Mini Blade, 15 Amp |
| 6           | 116-0053           | 1           | Cap-Plug                |             |                    |             |                         |


# Deck Lift Assembly



## Deck Lift Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|----------------------|
| 1           | 126-3342-03        | 1           | Shaft-Lift, Deck        | 12:4        | 43-0940            | 2           | Spacer               |
| 2           | 126-3343-03        | 1           | Shaft-Lift, Deck (Rear) | 13          | 1-373034           | 2           | Washer               |
| 3           | 115-5065           | 4           | Bushing-Flange          | 14          | 116-0780           | 1           | Screw-Shoulder, HHF  |
| 4           | 116-2887           | 4           | Gusset-Lift, Deck       | 17          | 99-5107            | 1           | Nut-Lock             |
| 5           | 3230-22            | 8           | Screw-CARR              | 18          | 126-8365           | 1           | Deck Strut ASM       |
| 6           | 104-8300           | 8           | Nut-HF, NI              | 19          | 3231-7             | 2           | Screw-CARR           |
| 7           | 126-9181           | 2           | Pin-Clevis              | 20          | 126-4639-03        | 1           | Link-HOC             |
| 8           | 138-8491           | 2           | Clip-Pin                | 21          | 126-5221           | 1           | Spacer-Stepped       |
| 9           | 126-4535           | 1           | Bracket ASM             | 22          | 3231-42            | 1           | Screw-CARR           |
| 9:1         | 126-4784           | 1           | Decal-HOC               | 23          | 135-0313           | 1           | Screw-CARR           |
| 10          | 126-4640-03        | 1           | Angle-HOC, Lower        | 28          | 116-0886           | 1           | Spring-Extension     |
| 11          | 109-6658           | 4           | Nut-Flange, NI          | 29          | 92-7674            | 1           | Bolt-Shoulder        |
| 12          | 126-8877           | 4           | Deck Chain ASM          | 30          | 126-5401           | 1           | Pin-HOC              |
| 12:1        | 1-633447           | 1           | Chain-Lift, Deck        | 52          | 140-1249           | 1           | Plate-Transport Lock |
| 12:2        | 130-0742           | 2           | Bolt-Shoulder           | 53          | 132-4749           | 1           | Grip-Lever           |
| 12:3        | 104-8301           | 2           | Nut-HF, NI              |             |                    |             |                      |

# Deck Strut Assembly No. 126-8365






## Deck Strut Assembly No. 126-8365 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>            | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-------------------------------|-------------|--------------------|-------------|--------------------|
| 2           | 126-8360           | 4           | Bushing-Rubber,<br>Suspension | 4           | 3231-7             | 2           | Screw-CARR         |
| 3           | 108-6544           | 4           | Spacer                        | 5           | 2844               | 2           | Washer             |
|             |                    |             |                               | 6           | 104-8301           | 2           | Nut-HF, NI         |

# Engine, Clutch and Muffler Assembly



## Engine, Clutch and Muffler Assembly (continued)


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                           |
|-------------|--------------------|-------------|----------------------------------------------|
| 1           | 104-8301           | 3           | Nut-HF, NI                                   |
| 8           | 116-2456           | 2           | Pulley-Flat Idler                            |
| 9           | 116-4924           | 1           | Engine Oil Drain Hose ASM<br>■               |
| 9:1         | 353-508            | 1           | Plug-HH ●                                    |
| 9:1:1       | 237-42             | 1           | O-Ring                                       |
| 14          | 126-0973           | 1           | Idler Arm ASM                                |
| 14:2        | 1-513034           | 2           | Sleeve-Bearing                               |
| 14:3        | 302-40             | 1           | Fitting-Grease, 90 DEG                       |
| 14:4        | 32144-11           | 1           | Screw-HWH                                    |
| 20          | 116-6170           | 1           | Engine-Kawasaki,<br>Fx751V-S07-R ♦           |
| 20:1        |                    | 1           | Kawasaki 49065-2078<br>Engine Oil Filter ▲ ♦ |
| 20:2        |                    | 1           | Kawasaki 49019-0031 Fuel<br>Filter ▲ ♦       |
| 20:3        |                    | 1           | Kawasaki 11013-7039<br>Safety Filter ▲ ♦     |
| 20:4        |                    | 1           | Kawasaki 11013-7038 Air<br>Filter ▲ ♦        |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------|
| 24          | 144-6567           | 1           | Muffler              |
| 25          | 126-5358           | 1           | Sheave (W/Hub)       |
| 27          | 126-5993           | 1           | Belt-V               |
| 30          | 126-6687-03        | 1           | Anchor-Clutch        |
| 44          | 1-603384           | 1           | Bushing-Pivot, Idler |
| 45          | 1-603402           | 1           | Spring-Extension     |
| 46          | 1-603610           | 2           | Washer-Spring        |
| 47          | 1-653313           | 2           | Gasket-Exhaust       |
| 48          | 1-807259           | 1           | Key                  |
| 50          | 323-15             | 1           | Screw-HH             |
| 52          | 3217-5             | 1           | Nut-Hex              |
| 54          | 3231-29            | 2           | Screw-CARR           |
| 55          | 3256-22            | 1           | Washer-Flat          |
| 56          | 3256-4             | 1           | Washer-Flat          |
| 57          | 98-5975            | 4           | Washer-Belleville    |
| 79          | 140-5456           | 1           | Clutch-PTO           |
| 80          | 3212-10            | 1           | Screw-HH             |
| 81          | 323-7              | 4           | Screw-HH             |

● Torque to 24-26 ft-lb  
▲ Not serviced separately

■ Torque to 23-29 ft-lb  
♦ Obtain parts from [www.kawpower.com](http://www.kawpower.com)


# Deck Assembly



## Deck Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>             | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 1-373034           | 4           | Washer                         | 25          | 116-3626           | 1           | Pulley-Idler       |
| 2           | 1-413088           | 1           | Bushing-Lever, Lift            | 26          | 3296-67            | 3           | Nut-Lock, NI       |
| 3           | 1-413113           | 1           | Bushing-Idler                  | 27          | 117-7210           | 3           | Shield-Bearing     |
| 4           | 1-603299           | 3           | Roller-Scalp, Anti             | 28          | 120-2451           | 1           | Deflector ASM      |
| 5           | 51-4060            | 3           | Screw-Blade                    | 29          | 126-7629           | 3           | Shaft-Spindle      |
| 6           | 98-7912            | 2           | Tube-Spanner                   | 30          | 120-5477           | 3           | Spindle ASM        |
| 7           | 98-7913            | 2           | Tube-Spacer                    | 30:2        | 116-0720           | 2           | Bearing-Ball       |
| 8           | 92-5836            | 3           | Washer                         | 30:3        | 115-2641           | 1           | Spacer-Bearing     |
| 9           | 104-8300           | 2           | Nut-HF, NI                     | 31          | 125-1736           | 3           | Washer-Belleville  |
| 10          | 104-8301           | 13          | Nut-HF, NI                     | 32          | 126-4781-03        | 1           | Step-Deck          |
| 11          | 105-4622           | 1           | Spacer                         | 33          | 126-8958           | 1           | Deck Decal ASM     |
| 12          | 107-8541-01        | 1           | Baffle-Discharge               | 34          | 322-50             | 1           | Screw-HH           |
| 13          | 108-4052           | 1           | Spring-Torsion                 | 35          | 323-23             | 2           | Screw-HH           |
| 14          | 139-3616           | 1           | Spring - Extension             | 36          | 323-9              | 1           | Screw-HH           |
| 15          | 109-6658           | 4           | Nut-Flange, NI                 | 37          | 3230-3             | 1           | Screw-CARR         |
| 16          | 109-6938           | 1           | Cover-Belt, LH                 | 38          | 3231-27            | 6           | Screw-CARR         |
| 17          | 109-6982           | 2           | Wireform-Cover                 | 39          | 3231-31            | 2           | Screw-CARR         |
| 18          | 110-9981           | 2           | Washer-Plain                   | 40          | 3231-6             | 1           | Screw-CARR         |
| 19          | 114-0463           | 2           | Washer-Friction, Composite     | 41          | 32144-41           | 18          | Screw-Taptite      |
| 20          | 126-7684           | 1           | Bushing-Idler                  | 42          | 116-4669           | 2           | Idler-Pulley, Flat |
| 21          | 135-0363           | 3           | Sheave-Drive, Blade            | 43          | 126-7683           | 1           | Bushing-Idler      |
| 22          | 115-5054           | 1           | Arm-Idler                      | 44          | 135-1873           | 1           | Belt-Deck Drive    |
| 23          | 133-2127           | 3           | Blade-Rotary, 20.5In (Hi Flow) | 45          | 323-17             | 1           | Screw-HH           |
| 24          | 116-0094           | 1           | Cover-Belt, RH                 | 46          | 133-2129           | 1           | Tube-Shafting      |
|             |                    |             |                                | 47          | 133-2128           | 1           | Tube-Spacer        |

# Deflector Assembly No. 120-2451




## Deflector Assembly No. 120-2451 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 3231-4             | 4           | Screw-CARR         |
| 2           | 106-3246-01        | 1           | Deflector          |
| 3           | 106-3248-03        | 1           | Strap-Discharge    |
| 4           | 110-0759           | 1           | Deflector-Rubber   |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 5           | 108-4059-01        | 1           | Plate-Hinge, Rear  |
| 6           | 106-3253-01        | 1           | Plate-Hinge, Front |
| 7           | 104-8301           | 4           | Nut-HF, NI         |

Deck Decal Assembly No. 126-8958





## Deck Decal Assembly No. 126-8958 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|---------------------|
| 1           |                    | 1           | Deck Decal ASM ●         | 7           | 117-1194           | 1           | Decal-Routing, Belt |
| 3           | 93-7818            | 1           | Decal-Torque, Blade Bolt | 8           | 107-1619           | 1           | Decal               |
| 4           | 112-3858           | 1           | Decal-Scalp, Anti        | 9           | 117-3848           | 2           | Decal-Danger        |
| 5           | 112-9028           | 2           | Decal-Cover, Missing     |             |                    |             |                     |

● Not serviced separately

# Attachments and Accessories

## For 77299 60in Z Master Professional 2000 Series Riding Mower

| Product Name                                                                           | Model/Part |
|----------------------------------------------------------------------------------------|------------|
| Hypr-Oil 500 (quart) .....                                                             | 114-4713   |
| Hypr-Oil 500 (gallon).....                                                             | 114-4714   |
| Hypr-Oil 500-5 (5 gallon).....                                                         | 114-4715   |
| Cover-Hitch.....                                                                       | 126-8299   |
| Trash Container Kit .....                                                              | 126-8379   |
| Weight Caster Kit .....                                                                | 126-8639   |
| 60in Recycler Kit.....                                                                 | 126-8703   |
| Jack Kit .....                                                                         | 127-6666   |
| Engine Maintenance Kit-Kawasaki FX .....                                               | 133-1307   |
| Hi-Back Seat Cover .....                                                               | 133-1308   |
| Blade-Rotary, 20.5in (Hi Flow) .....                                                   | 133-2127   |
| Blade-Rotary, Atomic 20.5in .....                                                      | 133-2157   |
| Blade-Rotary, Recycling 20.5in.....                                                    | 133-2161   |
| Blade (6 Pack) 20.5in, Hi Flow .....                                                   | 133-2174   |
| Blade (6 Pack) 20.5in, Recycler.....                                                   | 133-2177   |
| Blade (6 Pack) 20.5in, Atomic.....                                                     | 133-2180   |
| 5 Gallon Bucket .....                                                                  | 133-2533   |
| MVP Belt And Blade Kit, Titan Hd 1500 Or 2000 Series Riding Mower With 60in Deck ..... | 135-2254   |
| Extended Control Levers Kit, Dedicated-Bagging Riding Mower.....                       | 138-6020   |
| Tweel-Turf.....                                                                        | 139-3649   |
| Asm-semi Pneumatic 13x6.50-6.....                                                      | 140-4896   |
| Tilt Sensor-Radius .....                                                               | 142-2802   |
| Kit-Light (mid-mount ZRT Mower).....                                                   | 144-1992   |
| Kit-Jack Mount .....                                                                   | 144-1993   |
| Hardtop Sun Canopy .....                                                               | 144-3719   |
| Asm-Voodoo Trac 24x12-12 [os -2.48].....                                               | 144-6986   |
| Mount-Bagger.....                                                                      | 145-1995   |
| Handle Extension Kit .....                                                             | 145-3615   |
| Bucket Mount Kit.....                                                                  | 145-3687   |
| Universal Mount Kit.....                                                               | 145-3688   |
| Trimmer Mount Kit .....                                                                | 145-3689   |
| Kit-Titan Hd Triple Threat Attachment.....                                             | 145-3691   |
| Toro Deluxe Rider Cover.....                                                           | 490-7319   |
| Spark Arrestor Screen .....                                                            | 75-6880    |
| E-Z Vac Standard Blower Kit 60-in 5d .....                                             | 78403      |
| Heavy Duty Bagger Kit .....                                                            | 78431      |
| 60in Completion Kit.....                                                               | 78435      |

**Notes:**



**Count on it.**