



Count on it.

Parts Catalog

Spring Rake

**Sand Pro®/Infield Pro® 3040 and 5040
Traction Unit**

Model No. 08752—Serial No. 414500000 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.


For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Spring Rake Assembly 4

Attachments and Accessories 6

Spring Rake Assembly



Spring Rake Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	108-3198-03	1	Hanger ASM	25	117-4689	5	Spring Rake Kit
2	3256-26	5	Washer-Flat	25:1	321-11	1	Screw-HH
3	80-2050	1	Bolt-Shoulder	25:2	3256-82	1	Washer-Flat
4	3256-25	1	Washer-Flat	25:3	120-3468	1	Rake-Spring
5	3296-48	1	Nut-Hex	25:4	117-4687	1	Washer-Cup
6	108-9429-03	1	Pivot ASM	25:5	104-7201	1	Nut-HF, NI
11	3256-3	6	Washer-Flat	26	3218-5	2	Nut-Jam
12	323-47	4	Screw-HH	27	3233-14	2	Screw-CARR
13	104-8301	4	Nut-HF, NI	28	138-2228	1	Hitch-Ball
14	100-5024	2	Pin-Clevis	30	325-10	1	Screw-HH
15	3272-12	2	Pin-Cotter	31	3296-45	1	Nut-Hex
17	84-2452	2	Chain-14 Link, Straight	32	120-3499-03	2	Bracket-Stop
19	108-9427	1	Lift Arm Adapter ASM ● ■	33	325-22	1	Screw-HH
20	147-3560	1	Drawbar-Rake	34	119-8969	1	Nut-Hex
21	121-1760	2	Spacer	35	138-2227	2	Spacer
22	80-2040	2	Hook				

● Not illustrated

■ Optional Equipment

Attachments and Accessories

For 08752 Spring Rake Sand Pro/Infield Pro 3040 and 5040 Traction Unit

Product Name	Model/Part
Lift Arm Adapter ASM	108-9427

Notes:



Count on it.