



Form No. 3386-600 Rev C

Count on it.

Parts Catalog

Door Kit with Sliding Window Workman® MDX Utility Vehicle

Model No. 07356



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents


LH and RH Door Assembly..... 4

RH Door Assembly..... 6

LH Door Assembly..... 8

Sliding Window Assembly No. 145-7613SP 10

LH and RH Door Assembly




LH and RH Door Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	121-8441	4	Washer-Spacer
2	98-3104	2	Stud-Ball
3	104-8300	6	Nut-HF, NI
4	130-6083	2	Spring-Gas, Door
5		1	RH Door Assembly ●
6		1	LH Door Assembly ●
7	125-9992	2	Adjuster-Stud

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
8	121-8393	2	Guard-Striker
9	125-9993	2	Striker-Stud
10	106-0327	2	Nut-Hex
11	73-0040	4	Washer-Thrust
12	130-5726	2	Lanyard
13	120-9471	4	Bolt-Shoulder

● Not serviced separately


RH Door Assembly



RH Door Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	130-5695	1	RH-Upper Glass ASM	15:2	121-8628	1	Cylinder-Mounting, Key
1:2	130-5417	1	Trim-Glass, Upper	15:3	121-8322	1	Grommet-Mounting, Large
2	130-5420-03	1	Panel-Door, Lower	15:4	121-8327	1	Washer
3	130-5419	1	Trim-Locking Gasket	15:5	121-8328	1	Nut
4	130-5418	1	Trim-Steel, Lower	15:6	121-8627	1	Cylinder-Mounting, End
5	121-8331	1	Gasket-Handle	15:7	121-8323	1	Grommet-Mounting, Small
6	125-9982	12	Bushing-Flange	15:8	125-9531	1	Key-Set
7	125-9676	2	Washer-Backup	16	33103-025	1	Screw-HHF
8	104-7658	5	Spacer	17	121-8390	1	Latch-RH
9	3274-55	5	Screw-HSBH	18	121-8395	1	Plate-Support, Latch
10	125-9618-03	2	Hinge-Door, RH	19	104-7201	2	Nut-HF, NI
11	125-9520	6	Screw-Shoulder, HSH	20	3234-21	2	Screw-HHF
12	127-9895-03	1	RH Door Frame ASM	21	130-5578	2	Tubing-Seal, Rubber
13	104-8300	12	Nut-HF, NI	22	109-2661	2	Screw-PPH
14	98-3104	1	Stud-Ball	23	130-5848	1	Bracket-Guard, Trim (RH)
15	121-8630	1	Handle ASM	24	120-4578	2	Nut-HF


LH Door Assembly



LH Door Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	130-5696	1	LH-Upper Glass ASM	15:5	121-8328	1	Nut
1:2	130-5417	1	Trim-Glass, Upper	15:6	121-8627	1	Cylinder-Mounting, End
2	130-5420-03	1	Panel-Door, Lower	15:7	121-8323	1	Grommet-Mounting, Small
3	130-5419	1	Trim-Locking Gasket	15:8	125-9531	1	Key-Set
4	130-5418	1	Trim-Steel, Lower	16	33103-025	1	Screw-HHF
5	121-8331	1	Gasket-Handle	17	121-8391	1	Latch-LH
6	125-9982	12	Bushing-Flange	18	121-8395	1	Plate-Support, Latch
7	125-9676	2	Washer-Backup	19	104-7201	2	Nut-HF, NI
8	104-7658	5	Spacer	20	3234-21	2	Screw-HHF
9	3274-55	5	Screw-HSBH	21	130-5578	2	Tubing-Seal, Rubber
10	125-9619-03	2	Hinge-Door, LH	22	145-7613SP	1	Window Slider Assembly
11	125-9520	6	Screw-Shoulder, HSH	23	130-5544	8	Bushing-Rubber
12	127-9885-03	1	LH Door Frame ASM	24	130-5548	8	Screw-PFH
13	104-8300	12	Nut-HF, NI	25	130-5549	8	Washer
14	98-3104	1	Stud-Ball	26	520-0006	8	Nut-Hex, Nylock
15	121-8630	1	Handle ASM	27	109-2661	2	Screw-PPH
15:2	121-8628	1	Cylinder-Mounting, Key	28	130-5847	1	Bracket-Guard, Trim (LH)
15:3	121-8322	1	Grommet-Mounting, Large	29	120-4578	2	Nut-HF
15:4	121-8327	1	Washer				

Sliding Window Assembly No. 145-7613SP



Sliding Window Assembly No. 145-7613SP (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	145-7651	1	Frame ASM
1:1	145-7650	1	Cap-End, Full
1:2	145-7648	2	Screw-Sliding Window End Cap

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1:3	145-7649	1	Cap-End, Short
2	145-7652	1	Glass ASM
2:1	145-7653	1	Latch-Slider Window



Count on it.