



**Count on it.**

**Parts Catalog**

**60in Z Master® 4000 Series  
Riding Mower**

Model No. 74055TA—Serial No. 40000000 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

|   |    |
|---|----|
| Frame Assembly                                    | 4  |
| Roll-Over Protection System Assembly No. 139-8063 | 6  |
| Hydro Assembly                                    | 8  |
| LH Transaxle Assembly No. 139-1074                | 10 |
| RH Transaxle Assembly No. 139-1075                | 12 |
| Throttle, Choke Cables and Guard Assembly         | 14 |
| Fuel System Assembly                              | 16 |
| Fuel Tank Assembly No. 139-6722                   | 18 |
| Tank Retainer Assembly                            | 20 |
| Motion Control Assembly                           | 22 |
| Left and Right Control Arm Assembly               | 24 |
| Caster Wheel Assembly                             | 26 |
| Caster Wheel and Fork Assembly                    | 28 |
| Rear Wheel Assembly                               | 30 |
| Electrical Assembly                               | 32 |
| Wire Harness Assembly No. 139-8078                | 34 |
| Deck Lift Assembly                                | 36 |
| Deck Strut Assembly No. 140-1179                  | 38 |
| Engine, Clutch and Muffler Assembly               | 40 |
| Seat Suspension Platform Assembly                 | 42 |
| Seat Assembly No. 144-2631                        | 44 |
| Decal Assembly                                    | 46 |
| Deck Assembly                                     | 48 |
| Deck Decal Assembly No. 144-6588                  | 50 |
| Spindle Assembly No. 137-9780                     | 52 |
| Deflector Assembly No. 144-2635                   | 54 |
| Idler Arm Assembly No. 139-1087                   | 56 |
| Attachments and Accessories                       | 58 |




## Frame Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|--------------------|
| 1           | 144-6590           | 1           | Frame Decal ASM     | 14          | 3234-42            | 8           | Screw-HHF          |
| 1:1         |                    | 1           | Frame-60 ●          | 15          | 131-8834           | 2           | Bumper             |
| 1:1:2       | 126-4363           | 2           | Decal-Warning       | 17          | 138-9753           | 6           | Screw              |
| 1:1:4       | 144-2687           | 1           | Decal, Belt Routing | 25          | 140-4994-01        | 1           | Bracket-Light      |
| 2           | 139-8063           | 1           | ASM-ROPS            | 28          | 140-4997-01        | 1           | Toeboard           |
| 12          | 139-6717-01        | 1           | Plate-Hydro         | 30          | 3296-42            | 2           | Nut-Lock, NI       |
| 13          | 109-6658           | 8           | Nut-Flange, NI      |             |                    |             |                    |

● Not serviced separately

# Roll-Over Protection System Assembly No. 139-8063




# Roll-Over Protection System Assembly No. 139-8063 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------------------------|-------------|--------------------|-------------|--------------------|
| 1           |                    | 1           | Upper ROPS ASM ●                     | 4           | 126-9209           | 2           | Bolt-Shoulder      |
| 1:2         | 107-3069           | 1           | Decal-Warning                        | 5           | 103-4553           | 2           | ROPS Fold Pin ASM  |
| 2           |                    | 1           | ASM-ROPS, RH<br>Suspension [black] ● | 6           | 99-5107            | 6           | Nut-Lock           |
| 3           |                    | 1           | ASM-ROPS, LH Suspension<br>[black] ● | 7           | 109-5337           | 2           | Bumper-ROPS        |
|             |                    |             |                                      | 8           | 109-9505           | 4           | Washer-Spring      |
|             |                    |             |                                      | 9           | 325-13             | 4           | Screw-HH           |

● Not serviced separately


# Hydro Assembly



## Hydro Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|---------------------|
| 1           | 139-1074           | 1           | LH Transaxle ASM        | 6           | 140-1225           | 1           | ASM-Hose, Hydraulic |
| 2           | 139-1075           | 1           | RH Transaxle ASM        | 7           | 139-8091           | 2           | Plate-Lever, Bypass |
| 3           | 3234-38            | 8           | Screw-HHF               | 8           | 119-1415           | 2           | Pin-Cotter, Locking |
| 4           | 119-9908           | 1           | Hydraulic Reservoir ASM | 15          | 104-7201           | 2           | Nut-HF, NI          |
| 4:1         | 109-3320           | 1           | Cap-Reservoir, HYD      | 18          | 140-7994           | 1           | Belt-V              |
| 5           | 3229-28            | 2           | Screw-CARR              |             |                    |             |                     |


# LH Transaxle Assembly No. 139-1074



# LH Transaxle Assembly No. 139-1074 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|-----------------------------|
| 1           | 144-6598           | 1           | Kit, Filter         | 40          | 144-6601           | 1           | Fitting-5/8 Beaded, 7/8 SAE |
| 2           | 144-6599           | 1           | Kit, Filler Cap     | 64          | 125-4684           | 1           | Spring-Extension            |
| 18          | 144-6594           | 1           | Hub-4 Bolt          | 88          | 145-3637           | 1           | Seal, Brake                 |
| 20          | 144-6595           | 1           | Nut, Slotted        | 99          | 144-6600           | 1           | Kit, Seal                   |
| 36          | 144-6597           | 1           | Kit, Fan And Pulley |             |                    |             |                             |


# RH Transaxle Assembly No. 139-1075



# RH Transaxle Assembly No. 139-1075 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|-----------------------------|
| 1           | 144-6598           | 1           | Kit, Filter         | 40          | 144-6601           | 1           | Fitting-5/8 Beaded, 7/8 SAE |
| 2           | 144-6599           | 1           | Kit, Filler Cap     | 64          | 125-4684           | 1           | Spring-Extension            |
| 18          | 144-6594           | 1           | Hub-4 Bolt          | 88          | 145-3637           | 1           | Seal, Brake                 |
| 20          | 144-6595           | 1           | Nut, Slotted        | 99          | 144-6600           | 1           | Kit, Seal                   |
| 36          | 144-6597           | 1           | Kit, Fan And Pulley |             |                    |             |                             |





# Throttle, Choke Cables and Guard Assembly



## Throttle, Choke Cables and Guard Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|-----------------------|
| 1           | 139-6719-03        | 1           | Guard-Muffler [black]   | 43          | 144-2647           | 1           | Cable-Choke Control   |
| 2           | 144-2637           | 1           | Rear Guard ASM          | 44          | 110-5727           | 1           | Throttle Control ASM  |
| 3           | 144-6551-01        | 1           | Console-RH              | 44:1        | 112-2334           | 1           | Lever-Throttle        |
| 4           | 144-2638-01        | 1           | Console-LH              | 44:2        | 110-5728           | 1           | Cable-Throttle        |
| 6           | 140-4867           | 1           | RH Cover ASM            | 45          | 1-603175           | 1           | Knob-Ball             |
| 6:2         | 99-8936            | 1           | Decal-Control, Motion   | 46          | 105-8278           | 1           | Decal                 |
| 7           | 140-4866           | 1           | LH Cover ASM            | 48          | 87-6620            | 4           | Screw-Tph Thd Form    |
| 7:2         | 99-8936            | 1           | Decal-Control, Motion   | 49          | 126-9939           | 1           | Decal-Fill, Fuel      |
| 11          | 1-807513           | 2           | Bolt-CARR               | 50          | 140-7987           | 1           | Decal-4000 Series, RH |
| 12          | 3296-2             | 2           | Nut-Lock, NI            | 51          | 140-7979           | 1           | Side Pod, LH          |
| 24          | 3230-22            | 2           | Screw-CARR              | 52          | 140-7980           | 1           | Side Pod, RH          |
| 25          | 104-8300           | 16          | Nut-HF, NI              | 53          | 140-7968           | 1           | Cup Holder            |
| 27          | 126-6267           | 4           | Screw-TTH               | 54          | 3230-18            | 4           | Screw-CARR            |
| 30          | 126-6268           | 6           | Screw-TTH               | 55          | 140-7996-03        | 1           | Plate-Cover, LH Front |
| 31          | 3220-3             | 1           | Nut-HJ                  | 58          | 140-7998-03        | 1           | Plate-Cover, RH Front |
| 32          | 139-1149           | 1           | Decal - 4000 Series, LH | 60          | 132-5064           | 4           | Rivet-Pop             |
| 37          | 140-7952-01        | 1           | Guard-Rear, LH          | 61          | 120-7950           | 8           | Screw-Torx            |
| 38          | 140-1221-01        | 1           | Guard-Rear, Top         | 62          | 140-8019           | 1           | Cupholder-RH          |
| 39          | 140-4865           | 1           | RH Rear Guard ASM       | 65          | 110-0824           | 1           | R-Clamp               |
| 39:3        | 133-8062           | 1           | Decal-Arrestor, Spark   | 66          | 144-2642           | 2           | Rod-Support, Pod      |
| 41          | 138-9753           | 6           | Screw                   | 67          | 3296-59            | 4           | Nut-Lock, NI          |


# Fuel System Assembly



## Fuel System Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|---------------------------|
| 1           | 139-6722           | 1           | Fuel Tank ASM        | 7:1         | 109-0298           | 1           | Line-Fuel                 |
| 2           | 135-4801           | 1           | Cap-Fuel, Ratcheting | 7:2         | 114-3766           | 1           | Hose-Fuel                 |
| 3           | 104-2490           | 2           | Clamp-Hose           | 7:3         | 1-603770           | 1           | Valve-Fuel                |
| 4           | 131-8834           | 2           | Bumper               | 7:4         | 2412-98            | 4           | Clamp-Hose                |
| 5           | 104-7201           | 2           | Nut-HF, NI           | 8           | 126-5523           | 3           | Clip                      |
| 6           | 139-8067           | 1           | Vent Hose ASM        | 9           | 140-4957           | 1           | ASM-Fuel Vent             |
| 6:1         | 138-3152           | 2           | Hose-Fuel            | 9:1         | 138-3152           | 1           | Hose-Fuel                 |
| 6:2         | 120-2234           | 1           | Fitting-Tee          | 9:2         | 116-4630           | 1           | Fitting-Orifice, Straight |
| 6:3         | 140-4956           | 1           | Hose-Fuel            | 9:3         | 116-4344           | 1           | Hose-Fuel                 |
| 7           | 139-8068           | 1           | Fuel Hose ASM        |             |                    |             |                           |

# Fuel Tank Assembly No. 139-6722




## Fuel Tank Assembly No. 139-6722 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|------------------------|
| 2           | 46-6560            | 4           | Bushing                |
| 3           | 140-4955           | 1           | Connector Elbow-90 DEG |
| 4           | 133-9269           | 1           | Grommet-Fuel           |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 5           | 139-8058           | 1           | Gauge-Fuel         |
| 6           | 126-9057           | 2           | Fitting-90 DEG     |
| 7           | 140-4954           | 1           | Fitting-Tee        |


# Tank Retainer Assembly



## Tank Retainer Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|------------------------|
| 4           | 104-8300           | 2           | Nut-HF, NI                 | 10          | 138-9753           | 4           | Screw                  |
| 6           | 139-6706-03        | 1           | Plate-Tank Retainer, Front | 12          | 135-0505           | 4           | Bumper-Seat            |
| 7           | 139-6707-03        | 1           | Plate-Tank Retainer, Rear  | 13          | 112-7069           | 1           | Grommet                |
| 8           | 3230-23            | 2           | Bolt-CARR                  | 16          | 109-9233           | 1           | Bumper-Push-In, Rubber |

# Motion Control Assembly




## Motion Control Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|------------------------|
| 1           | 139-6697           | 1           | Motion Control ASM-RH      | 17          | 144-2658           | 1           | Brake ASM              |
| 2           | 139-1089           | 1           | Handle ASM - RH            | 18          | 126-5820           | 2           | Bearing-Spherical      |
| 2:2         | 109-5668           | 1           | Grip-Lever, Control        | 19          | 139-6742           | 1           | Bracket-Brake          |
| 3           | 3234-42            | 4           | Screw-HHF                  | 20          | 139-6726           | 1           | Brake Lever ASM W/Grip |
| 4           | 139-6696           | 1           | Motion Control ASM-LH      | 20:2        | 109-8054           | 2           | Bushing-Flange         |
| 5           | 115-5099           | 2           | Bolt-Pivot                 | 20:3        | 132-4749           | 1           | Grip-Lever             |
| 6           | 140-8020           | 1           | Handle ASM-LH              | 21          | 139-6743           | 1           | Pivot-Handle           |
| 6:1         |                    | 1           | Handle ASM - LH ●          | 22          | 3234-29            | 1           | Screw-HHF              |
| 6:1:2       | 109-5668           | 1           | Grip-Lever, Control        | 23          | 116-2670           | 2           | Screw-Shoulder         |
| 6:2         | 125-2662           | 1           | Case ASM                   | 24          | 144-6566           | 1           | Brake Link ASM         |
| 6:3         | 121-3399           | 1           | Cap-Switch                 | 24:1        | 144-6565           | 1           | Plate-Link, Handle     |
| 6:4         | 140-1228           | 1           | Switch, Spdt (On)-Off-(On) | 24:2        | 116-4976           | 2           | Bushing-Sleeve         |
| 6:5         | 94-4496            | 2           | Screw-PPH                  | 25          | 139-6745           | 1           | Plate-Switch           |
| 6:6         | 144-0354           | 1           | Harness-Wire, Handle       | 26          | 32144-70           | 2           | Screw-HWHTF            |
| 7           | 104-8301           | 2           | Nut-HF, NI                 | 27          | 3230-23            | 2           | Bolt-CARR              |
| 8           | 126-4322           | 2           | Damper                     | 28          | 144-0353           | 2           | Brake Rod ASM          |
| 9           | 126-4424           | 4           | Screw-Shoulder             | 28:1        | 140-4952           | 1           | Rod-Brake              |
| 10          | 112-3306           | 2           | Nut                        | 28:2        | 139-6741           | 1           | Fitting-Rod            |
| 11          | 126-4299           | 2           | Screw-HSBH                 | 28:3        | 3256-3             | 1           | Washer-Flat            |
| 12          | 37-8771            | 2           | Bolt-Shoulder, HF          | 28:4        | 144-2645           | 1           | Spring-Compression     |
| 13          | 104-8300           | 6           | Nut-HF, NI                 | 28:5        | 104-8301           | 1           | Nut-HF, NI             |
| 14          | 115-9625           | 1           | Decal-Brake, Parking       | 29          | 3256-45            | 2           | Washer-Flat            |
| 15          | 3218-3             | 2           | Nut-Jam                    | 30          | 119-1415           | 4           | Pin-Cotter, Locking    |

● Not serviced separately


# Left and Right Control Arm Assembly



## Left and Right Control Arm Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|------------------------|
| 1           | 126-3773           | 1           | Control Arm ASM    | 6           | 117-1198           | 1           | Bolt-Pivot             |
| 1:2         | 126-8909           | 2           | Bushing            | 7           | 3256-24            | 1           | Washer-Plain           |
| 1:3         | 1-413152           | 2           | Bushing-Sleeve     | 8           | 32152-2            | 1           | Nut-Lock, Cone         |
| 2           | 126-7296           | 1           | Washer-Friction    | 9           | 126-5434           | 1           | Swivel                 |
| 3           | 126-8182           | 1           | Arm-Control        | 10          | 140-4949           | 1           | Link-Control           |
| 4           | 117-1240           | 1           | Washer             | 11          | 126-8195           | 1           | Spring-Return, Neutral |
| 5           | 119-8925           | 1           | Washer-Belleville  | 12          | 104-8300           | 2           | Nut-HF, NI             |

# Caster Wheel Assembly




## Caster Wheel Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|---------------------------|-------------|--------------------|-------------|--------------------|
| 1           |                    | 2           | ASM-Front Caster W/Fork ● | 4           | 3256-68            | 2           | Washer-Flat        |
| 2           | 109-3678           | 4           | Bearing-Ball              | 5           | 3234-5             | 2           | Screw-HHF          |
| 3           | 126-5897           | 2           | Spring                    | 6           | 144-0375           | 2           | Cap, Grease        |

● Not serviced separately

# Caster Wheel and Fork Assembly




## Caster Wheel and Fork Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>             | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|--------------------------------|-------------|--------------------|-------------|---------------------|
| 1           | 140-4941-01        | 1           | Caster Fork [red]              | 2:1:2       |                    | 1           | Caster Axle ASM ●   |
| 2           | 140-4943           | 1           | ASM-Pneumatic 15X6.50-6        | 2:1:2:1     | 126-5220           | 1           | Axle-Caster         |
| 2:1         |                    | 1           | ASM Whl/Brgs 15X6.5-6 ●        | 2:1:2:2     | 103-3051           | 1           | Spacer-Nut          |
| 2:1:1       | 140-4945           | 1           | Wheel And Tire ASM<br>15X6.5-6 | 2:1:3       | 1-633585           | 2           | Bearing-Cone, Taper |
| 2:1:1:1     | 139-3624           | 1           | Wheel Rim 6X4.5                | 2:1:5       | 103-0063           | 2           | Seal-Caster         |
| 2:1:1:2     | 5108               | 1           | Valve                          | 2:2         | 103-2768           | 2           | Guard-Seal          |
| 2:1:1:3     | 140-4946           | 1           | Tire                           | 2:3         | 126-5389           | 1           | Screw-HHF           |
|             |                    |             |                                | 2:4         | 99-5107            | 1           | Nut-Lock            |

● Not serviced separately


# Rear Wheel Assembly



## Rear Wheel Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 1           | 140-7984           | 2           | Wheel And Tire ASM | 1:3         | 232-27             | 1           | Stem-Valve         |
| 1:1         | 140-7970           | 1           | Wheel              | 2           | 139-3603           | 8           | Nut-Lug            |
| 1:2         | 140-7986           | 1           | Tire               |             |                    |             |                    |


# Electrical Assembly



## Electrical Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|------------------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 1-603511           | 1           | Keys-Ignition (Spare Pair)   | 14          | 33094-00           | 1           | Washer-Plain            |
| 1           | 63-8360            | 1           | Key-Ignition                 | 15          | 33114-020          | 1           | Screw-HH                |
| 2           | 139-6368           | 1           | Switch-Rocker,<br>On-None-On | 17          | 140-1200           | 1           | Harness-Wire, Deck Lift |
| 3           | 105-6849           | 1           | Screw-Forming, Thread        | 17:9        | 103-3895           | 1           | Diode                   |
| 4           | 110-6765           | 1           | Switch                       | 17:10       | 109101             | 1           | Fuse-Blade, 20 Amp      |
| 5           | 116-5609           | 1           | Module ASM                   | 19          | 140-1213           | 1           | Harness-Wire, Light Kit |
| 6           | 137-4100           | 1           | Switch-Ignition              | 21          | 139-8089           | 1           | Mount-Flush, Light      |
| 7           | 139-8078           | 1           | Harness-Wire                 | 23          | 104-2065           | 2           | Screw-HWH               |
| 8           | 32128-33           | 2           | Nut-HF                       | 25          | 140-7955           | 1           | Port-Power, USB         |
| 9           | 321-4              | 2           | Screw-HH                     | 26          | 92-8875            | 1           | Switch-Rocker           |
| 10          | 3256-22            | 2           | Washer-Flat                  | 27          | 140-4993           | 1           | Bumper-Front            |
| 11          | 82-2190            | 2           | Switch-Bail                  | 28          | 135-2015           | 2           | Screw-Shoulder          |
| 12          | 104-8162           | 1           | Battery                      | 29          | 32144-1            | 1           | Screw-Taptite           |
| 13          | 126-7627           | 1           | Strap-Bungee                 | 31          | 1-643275           | 2           | Relay                   |


# Wire Harness Assembly No. 139-8078



## Wire Harness Assembly No. 139-8078 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|-------------------------|
| 11          | 116-0053           | 3           | Cap-Plug                | 16          | 32180-176          | 1           | Cover-Block, Fuse       |
| 12          | 103-3895           | 1           | Diode                   | 17          | 32180-177          | 1           | Clip-Mounting           |
| 13          | 121-8867           | 1           | Fuse-Mini Blade, 15 Amp | 18          | 126-8876           | 1           | Insulator-Battery       |
| 14          | 121-8868           | 1           | Fuse-Mini Blade, 20 Amp | 19          | 1-543393           | 1           | Insulator-Solenoid      |
| 15          | 126-3991           | 1           | Relay-Micro             | 24          | 121-8869           | 1           | Fuse-Mini Blade, 25 Amp |


# Deck Lift Assembly



## Deck Lift Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>            | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|-------------------------------|-------------|--------------------|-------------|----------------------|
| 1           | 115-5065           | 4           | Bushing-Flange                | 14          | 1-373034           | 2           | Washer               |
| 2           | 116-2887           | 4           | Gusset-Lift, Deck             | 15          | 109-6658           | 2           | Nut-Flange, NI       |
| 3           | 3230-22            | 8           | Screw-CARR                    | 16          | 3231-7             | 2           | Screw-CARR           |
| 4           | 104-8300           | 12          | Nut-HF, NI                    | 25          | 126-5401           | 1           | Pin-HOC              |
| 6           | 140-4975-03        | 2           | Shaft-Lift, Deck              | 30          | 99-5107            | 2           | Nut-Lock             |
| 7           | 126-4639-03        | 1           | Link-HOC                      | 33          | 139-8135           | 1           | Pin-Pivot, Actuator  |
| 8           | 126-9181           | 2           | Pin-Clevis                    | 34          | 144-2667-01        | 1           | Bracket-Mount, Outer |
| 9           | 138-8491           | 3           | Clip-Pin                      | 35          | 144-2668-01        | 1           | Bracket-Mount, Inner |
| 12          | 126-8877           | 4           | Deck Chain ASM                | 36          | 3234-38            | 1           | Screw-HHF            |
| 12:1        | 1-633447           | 1           | Chain-Lift, Deck              | 37          | 3234-46            | 1           | Screw-HHF            |
| 12:2        | 130-0742           | 2           | Bolt-Shoulder                 | 38          | 99-5107            | 1           | Nut-Lock             |
| 12:3        | 104-8301           | 2           | Nut-HF, NI                    | 39          | 137-3061           | 2           | Bolt-CARR            |
| 12:4        | 43-0940            | 2           | Spacer                        | 40          | 139-8111           | 1           | Actuator-Linear      |
| 13          | 140-1179           | 1           | Deck Strut W/ Bushings<br>ASM | 41          | 3230-9             | 2           | Screw-CARR           |
|             |                    |             |                               | 51          | 139-6699           | 1           | Decal-HOC            |


# Deck Strut Assembly No. 140-1179



## Deck Strut Assembly No. 140-1179 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>            | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-------------------------------|-------------|--------------------|-------------|--------------------|
| 2           | 126-8360           | 4           | Bushing-Rubber,<br>Suspension | 4           | 3231-7             | 2           | Screw-CARR         |
| 3           | 108-6544           | 4           | Spacer                        | 5           | 2844               | 2           | Washer             |
|             |                    |             |                               | 6           | 104-8301           | 2           | Nut-HF, NI         |

# Engine, Clutch and Muffler Assembly




## Engine, Clutch and Muffler Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                          | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|---|-------------|--------------------|-------------|---------------------------|
| 1           | 126-2131           | 1           | Engine-Kawasaki,<br>Fx921V-S04-R            | 11          | 144-2671           | 1           | Idler Arm ASM             |
| 1:1         |                    | 1           | Kawasaki 49065-7007<br>Engine Oil Filter ■▲ | 11:2        | 138-2573           | 2           | Bushing-Flange            |
| 1:2         |                    | 1           | Kawasaki 11013-7044<br>Engine Air Filter ■▲ | 12          | 116-2456           | 1           | Pulley-Flat Idler         |
| 1:3         |                    | 1           | Kawasaki 11013-7045<br>Safety Filter ■▲     | 14          | 3231-42            | 1           | Screw-CARR                |
| 3           | 139-6702           | 1           | Sheave, W/Hub                               | 15          | 3231-29            | 1           | Screw-CARR                |
| 4           | 1-807259           | 1           | Key   | 16          | 139-6690           | 1           | Bushing, Idler Pivot      |
| 5           | 140-1190           | 1           | Anchor-Clutch                               | 17          | 3256-4             | 1           | Washer-Flat               |
| 6           | 98-5975            | 4           | Washer-Belleville                           | 18          | 104-8301           | 2           | Nut-HF, NI                |
| 7           | 109-6919           | 1           | Washer-Clutch                               | 22          | 116-4924           | 1           | Engine Oil Drain Hose ASM |
| 8           | 1-603610           | 2           | Washer-Spring                               | 22:1        | 353-508            | 1           | Plug-HH ●                 |
| 9           | 109-9761           | 1           | Screw-HH                                    | 22:1:1      | 237-42             | 1           | O-Ring                    |
| 10          | 323-7              | 4           | Screw-HH                                    | 23          | 140-8002           | 1           | Muffler                   |
|             |                    |             |   | 24          | 1-653331           | 1           | Spring-Idler              |
|             |                    |             |   | 25          | 116-1604           | 1           | Clutch                    |
|             |                    |             |   | 46          | 1-303334           | 4           | Washer-Spring             |
|             |                    |             |   | 47          | 33114-020          | 4           | Screw-HH                  |

● Torque to 24-26 ft-lb  
▲ Obtain parts from [www.kawpower.com](http://www.kawpower.com)

■ Not serviced separately


# Seat Suspension Platform Assembly



## Seat Suspension Platform Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|--------------------------|
| 1           | 139-6691-03        | 1           | Mount-Shock, Lower [black] | 38          | 144-0437           | 1           | Decal-Myride             |
| 2           | 136-1719           | 1           | Shock ASM-Front            | 39          | 144-2669           | 1           | Decal-Service Aid        |
| 7           | 3230-23            | 8           | Bolt-CARR                  | 41          | 105-3048           | 2           | Washer-Flat              |
| 8           | 104-8300           | 23          | Nut-HF, NI                 | 42          | 116-0648           | 2           | Screw-HH, Thread Locking |
| 10          | 140-4868           | 1           | Subframe ASM               | 43          | 127-6759-03        | 2           | Bracket-Bearing          |
| 10:2        | 132-0871           | 1           | Decal-Danger               | 44          | 127-6743           | 4           | Housing-Bearing, Flange  |
| 10:3        | 127-6745           | 2           | Bushing-Flange             | 45          | 1-653346           | 2           | Bearing                  |
| 16          | 127-6754-03        | 1           | Arm-Trailing               | 46          | 3230-10            | 4           | Bolt-CARR                |
| 18          | 99-5107            | 5           | Nut-Lock                   | 48          | 127-6768           | 3           | Screw-CARR               |
| 19          | 144-2602           | 1           | Bracket-Mounting           | 49          | 3231-22            | 3           | Screw-CARR               |
| 19:2        | 132-5067           | 1           | Decal-Adjustment, Ride     | 50          | 104-8301           | 5           | Nut-HF, NI               |
| 21          | 126-5491           | 1           | Isolator                   | 51          | 130-0733           | 4           | Pad-Rubber               |
| 22          | 133-5109           | 2           | Bearing-Sleeve             | 52          | 127-6751           | 2           | Spacer-Aluminum          |
| 23          | 131-4699           | 2           | Washer-Plastic             | 53          | 86-1990            | 2           | Washer-Thrust            |
| 24          | 133-1815           | 2           | Shock/Spring ASM           | 54          | 140-4869           | 2           | Spacer-Tube              |
| 25          | 136-9017           | 2           | Cam Lock ASM               | 55          | 133-4401           | 2           | Bolt-Shoulder            |
| 26          | 136-5636           | 2           | Knob-Lock, Cam             | 56          | 138-8491           | 1           | Clip-Pin                 |
| 27          | 3-6803             | 2           | Washer-Adjusting           | 62          | 144-0355           | 1           | Floormat-Myride          |
| 28          | 3296-45            | 2           | Nut-Hex                    | 63          | 117-2382           | 2           | Plug-Plastic             |
| 32          | 1-513658           | 2           | Bumper                     | 64          | 144-0382-03        | 1           | Plate-Badge              |
| 33          | 144-0381-01        | 1           | Floorpan                   | 65          | 144-0422-01        | 1           | Plate-Backer             |
| 35          | 126-9181           | 1           | Pin-Clevis                 | 66          | 132-5064           | 2           | Rivet-Pop                |
| 36          | 140-1197-03        | 1           | Pan-Seat                   | 67          | 126-6268           | 2           | Screw-TTH                |
| 37          | 144-2631           | 1           | Seat ASM-Standard          | 68          | 117-2749           | 6           | Nut-Push                 |


# Seat Assembly No. 144-2631



## Seat Assembly No. 144-2631 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 1           | 147-7883           | 1           | Seat Track Kit     | 5           | 145-3643           | 1           | Cover-Back, Seat   |
| 2           | 145-3641           | 1           | Armrest Kit        | 6           | 145-3644           | 1           | Cover-Bottom, Seat |
| 3           | 145-3642           | 1           | Pads-Armrest       | 7           | 82-2190            | 1           | Switch-Bail        |
| 4           | 130-2854           | 1           | Seat Belt Kit      |             |                    |             |                    |


# Decal Assembly



## Decal Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------|
| 5           | 144-0442           | 1           | Decal - HDX          |
| 6           | 144-0443           | 1           | Decal - HDX          |
| 10          | 144-6569           | 1           | Decal-Panel, Control |


# Deck Assembly



## Deck Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|----------------------|
| 1           | 144-6588           | 1           | Deck Decal ASM      | 22          | 1-373034           | 4           | Washer               |
| 2           | 137-9780           | 3           | Spindle ASM         | 23          | 109-6982           | 2           | Wireform-Cover       |
| 3           | 137-9784           | 3           | Guard-Bottom        | 24          | 116-0094           | 1           | Cover-Belt, RH       |
| 4           | 138-6045           | 3           | Shaft-Spindle       | 25          | 109-6938           | 1           | Cover-Belt, LH       |
| 5           | 103-1330           | 3           | Guard-Bearing, Top  | 26          | 144-2635           | 1           | Rubber Deflector ASM |
| 6           | 138-6059           | 3           | Sheave-Drive, Blade | 27          | 322-50             | 1           | Screw-HH             |
| 7           | 103-2802           | 3           | Washer              | 28          | 104-8300           | 2           | Nut-HF, NI           |
| 8           | 116-7306           | 3           | Nut-Hex             | 29          | 105-4622           | 1           | Spacer               |
| 9           | 140-1240           | 3           | Blade               | 30          | 108-4052           | 1           | Spring-Torsion       |
| 10          | 137-9787           | 3           | Bushing-Hex         | 31          | 3230-3             | 1           | Screw-CARR           |
| 11          | 109-9220           | 3           | Screw-Sems          | 32          | 126-4781-03        | 1           | Step-Deck            |
| 12          | 3231-27            | 6           | Screw-CARR          | 33          | 132-9424           | 2           | Pulley-Idler, Flat   |
| 13          | 107-8541-01        | 1           | Baffle-Discharge    | 34          | 139-8061           | 2           | Bushing, Idler       |
| 14          | 104-8301           | 34          | Nut-HF, NI          | 35          | 108-5388           | 1           | Screw-HH             |
| 15          | 323-23             | 1           | Screw-HH            | 36          | 3231-7             | 2           | Screw-CARR           |
| 16          | 98-7912            | 1           | Tube-Spanner        | 37          | 109-6658           | 2           | Nut-Flange, NI       |
| 17          | 1-603299           | 4           | Roller-Scalp, Anti  | 38          | 98-5967            | 1           | Spacer-Wheel         |
| 18          | 98-7913            | 1           | Tube-Spacer         | 39          | 144-0357           | 1           | Belt-V               |
| 19          | 323-17             | 1           | Screw-HH            | 40          | 139-1087           | 1           | Idler Arm ASM        |
| 20          | 133-2129           | 1           | Tube-Shafting       | 41          | 116-6317           | 1           | Spring-Extension     |
| 21          | 133-2128           | 1           | Tube-Spacer         | 42          | 3231-21            | 3           | Screw-CARR           |

# Deck Decal Assembly No. 144-6588




## Deck Decal Assembly No. 144-6588 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|------------------------|-------------|--------------------|-------------|---------------------|
| 1           |                    | 1           | Deck ASM W/Decals 60 ● | 4           | 116-8283           | 1           | Decal-Torque, Bolt  |
| 2           | 117-3848           | 2           | Decal-Danger           | 6           | 109-6035           | 1           | Decal-Routing, Belt |
| 3           | 127-0326           | 1           | Decal-Scalp, Anti      | 7           | 107-1619           | 1           | Decal               |

● Not serviced separately


# Spindle Assembly No. 137-9780



## Spindle Assembly No. 137-9780 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 2           | 116-0720           | 2           | Bearing-Ball       |
| 3           | 138-6042           | 1           | Spacer-Bearing     |


# Deflector Assembly No. 144-2635



## Deflector Assembly No. 144-2635 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 3231-4             | 4           | Screw-CARR             | 5           | 108-4059-01        | 1           | Plate-Hinge, Rear  |
| 2           | 106-3246-01        | 1           | Deflector              | 6           | 106-3253-01        | 1           | Plate-Hinge, Front |
| 3           | 106-3248-03        | 1           | Strap-Discharge        | 7           | 104-8301           | 4           | Nut-HF, NI         |
| 4           | 139-8114           | 1           | Deflector-Deck, Rubber |             |                    |             |                    |

# Idler Arm Assembly No. 139-1087



## Idler Arm Assembly No. 139-1087 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|----------------------|
| 1           | 139-1086           | 1           | Idler Arm ASM        | 7           | 109-6658           | 3           | Nut-Flange, NI       |
| 2           | 138-2573           | 2           | Bushing-Flange       | 8           | 323-15             | 1           | Screw-HH             |
| 3           | 139-8060           | 1           | Bushing, Idler       | 9           | 3231-5             | 1           | Screw-CARR           |
| 4           | 132-9424           | 1           | Pulley-Idler, Flat   | 10          | 132-4729           | 1           | Anchor-Spring, Short |
| 5           | 139-6690           | 1           | Bushing, Idler Pivot | 11          | 136-9028           | 1           | Bolt-Shoulder, HWH   |
| 6           | 1-213069           | 3           | Washer               | 12          | 104-8301           | 1           | Nut-HF, NI           |

# Attachments and Accessories

## For 74055TA 60in Z Master 4000 Series Riding Mower

| <b>Product Name</b>                | <b>Model/Part</b> |
|------------------------------------|-------------------|
| Hypr-Oil 500 (quart) .....         | 114-4713          |
| Hypr-Oil 500 (gallon).....         | 114-4714          |
| Hypr-Oil 500-5 (5 gallon).....     | 114-4715          |
| Spark Arrestor .....               | 117-3281          |
| Striper Kit.....                   | 126-7882          |
| Jack Kit.....                      | 127-6666          |
| Blade-20.5 High Flow .....         | 140-1240          |
| Blade-20.50 Atomic .....           | 140-1241          |
| Blade-20.50 Medium Flow .....      | 140-4853          |
| Blade-20.50, Low Flow .....        | 140-4854          |
| Blade-20.50 Recycler .....         | 140-4855          |
| 6 Pack-Blade, 20.5 High Flow.....  | 140-4877          |
| 6 Pack-Blade, 20.5 Med Flow .....  | 140-4878          |
| 6 Pack-Blade, 20.5 Low Flow .....  | 140-4879          |
| 6 Pack-Blade, 20.5 Atomic.....     | 140-4880          |
| 6 Pack-Blade, 20.5 Recycler.....   | 140-4881          |
| Recycler Kit-60" .....             | 144-0388          |
| Trimmer Mount .....                | 144-2665          |
| Jack Mount Kit.....                | 144-2676          |
| Asm-Semi Pneumatic 15x6.50-6 ..... | 145-1919          |
| Z 4000 Bagger Kit.....             | 78463             |
| Z 4000 60in Completion Kit.....    | 78466             |

**Notes:**



**Count on it.**