



Operator Presence Kit

Greensmaster® Flex 21

Part No. 105-5333

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.


For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.



Sheet No.:0

T-3863

Operator Presence Kit Assembly

Ref. No.	Part No.	Qty.	Description
1	105-5339	1	Bail ASM
1:2	93-9008	1	Decal-Operation, Bail
2	105-5315	2	Spacer-Bail
3	105-5331	1	Spring-Compression
4	29-6163	1	Switch-Micro
5	3250-35	2	Screw-PPH
6	3296-9	2	Nut-Lock, NI
7	3255-24	2	Washer-Lock/Ext
8	33104-050	2	Screw-HHF
9	33024-00	2	Nut-Lock
10	105-5340	1	Wire
			Harness-Presence, Operator
11	104-9794	1	Decal-Console, Ce
17	3290-378	2	Tie-Cable
18	62-5070	1	Decal-Warning

Ref. No.	Part No.	Qty.	Description