


MODEL NO. 38000-1006871 THRU 4000001 & UP

PARTS CATALOG

TORO S-120 SNOWTHROWER




HANDLE ASSEMBLY

Ref. Part No.		Description	No. Used	
1	37-6450	3450 Wire Harness		
2	37-6260	Middle Handle	1	
3	37-6410	Escutcheon Plate	1	
4	37-6480	Decal - Electric	1	
5	37-6440	Upper Tube	2	
6	38-8390	Cord Supply	1	
7	38-4590	Decal - Handle	1	
8	36-8340	Switch	1	
9	37-8000	Lockout - Switch	1	
10	37-7990	Spring Compression	1	
11	39-2460	Handle - Upper Control	1	
12	39-2470	Handle - Lower Control	1	
13	32104-121	Screw	8	

Ref. No. Part No.		Description	No. Used	
14	38-8310	Key	1	
15	37-8010	Switch Bar	1	
16	37-6320	Carriage Bolt	2	
17	3296-42	Nut	6	
18	3290-133	Screw - Round Head	4	
19	37-6190	Clamp - Middle Handle	2	
20	37-6430	Handle – Lower L.H.	1	
21	37-6470	Decal — Toro S-120	1	
22	37-6210	Shroud - S-120	1	
23	38-5800	Decal - U.L.	1	
24	37-6420	Handle – Lower R.H.	1	
25	237-120	Snap Bushing	1	
*	37-5950	100' Deluxe Extension Cord	1	

^{*}Not Illustrated



LOWER MAIN FRAME ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	37-6340	Moulding	1
2	37-6170	Vane – Inner	4
3	32104-77	Screw	2
2 3 4 5 6 7 8	2412-72	Insulated Closed Clip	1
5	32104-124	Screw	2
6	3296-42	Nut	4
7	37-6380	Bracket — Mounting	1
8	39-3130	Bracket - Vane Adjustment	1
9	3284-4	Groove Pin	1
10	42-1430	Motor	1
11	39-3140	Rod – Vane Adjustment	1
12	32121-101		1
13	39-0680	Wheel Bracket R.H.	1
14	37-5970	Linkage Vane Adjustment	1
15	37-6120	Fan	1
16	37-8080	Thrust Washer	2
17	37-6300	Side Flange Bearing	1
18	39-2190	Idler Spring	1
19	39-2170	Idler Arm	1
20	321-2	Screw	2
21	37-6460	Axle Shaft	1
22	39-0690	Wheel Bracket L.H.	1
23	37-5960	Wheel	2
24	32112-1	Push Nut	2
25	11-9760	Screw	2 1 2 4 1 1 1 1 1 1 1 1 1 2 1 1 2 6 1
26	37-6040	Drive Pulley	
27	36-7420	Ball Bearing	1

Ref. No.	Part No.	Description	No. Used
28	37-6010	Drive Belt	1
29	39-2180	Retainer – Idler Pulley	1
30	32104-130	Screw	2
31	32144-34	Screw	3
32	3290-171	Tinnerman Nut	1 2 3 3 3 1 4 2 7 2 2 1 1 1 1 1 4
33	37-6400	Cover — Belt Case	1
34	3290-321	Screw	4
35	32128-25	Nut	2
36	32104-121	Screw	7
37	39-5190	Thrust Washer	2
38	37-6070	Rotor Bushing	2
39	37-6050	Pulley - Driven	1
40	46-7500	Washer	1
41	38-8720	Scraper	1
42	32120-46	Retaining Ring	1
43	38-5710	Washer	4
44	3296-2	Nut	4
45	37-6330	Shaft — Rotor	1
46	37-0370	Screw – Thread Forming	8
47	32149-2	Nut	3
48	3229-11	Carriage Bolt	3
49	42-3900	Housing	1
50	37-6390	Blade – Rotor	2
51	37-6370	Rotor	2
52	37-6060	End Cap Rotor	4 1 8 3 3 1 2 2 1 2
53	37-6140	Vane – Outer	2
54	37-6270	Vane — Mount	1



The Toro Company warrants your TORO Product against defects in material or workmanship. During the warranty period, Toro will, at its option, replace a defective product with a new or rebuilt unit, or will repair or replace any defective parts. The following time periods from the date of purchase apply:

The cost of replacement or repair is included, but the customer pays the transportation costs.

Should you feel your TORO Product is defective and wish to rely on The Toro Promise, you may return it to:

- 1. The original place of purchase
- or 2. A TORO Electrical Service Dealer
- or 3. The Toro Service Center 1401 Industrial Rd. Hudson, WI 54016 (Postage Prepaid)

Upon return of your unit to one of the above, it will be inspected and you will be advised whether the product is defective. If defective, arrangements will be made for repair or replacement without extra charge to you.

If for any reason you are dissatisfied with the analysis of the defect or the service performed, you may contact us.

Write: TORO Service Department 8111 Lyndale Avenue South Minneapolis, MN 55420

THERE IS NO OTHER EXPRESS WARRANTY.

THE TORO COMPANY IS NOT LIABLE FOR INDIRECT OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH THE USE OF THE PRODUCT.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This Warranty applies only to parts or components which are defective and does not cover repairs necessary due to normal wear, misuse, accidents, or lack of proper maintenance. Regular, routine maintenance of the unit to keep it in proper operating condition is the responsibility of the owner.

All warranty repairs reimbursable under The Toro Promise must be performed by a TORO Electrical Service Dealer using Toro approved replacement parts.

Repairs or attempted repairs by anyone other than a TORO Electrical Service Dealer are not reimbursable under The Toro Promise. In addition, these unauthorized repair attempts may result in additional malfunctions, the correction of which is not covered by warranty.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their TORO Distributor (Dealer) to obtain guarantee policies for your country, province or state. If for any reason

you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact the TORO importer. If all other remedies fail, you may contact us at The Toro Company.

PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change apparently has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

IDENTIFICATION AND ORDERING

Model and Serial Numbers

The S-120, has two identification numbers. A model number and a serial number. The two numbers are stamped on a decal which is located on lower right handle. In any correspondence concerning the S-120, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized TORO Service Dealer, supply the following information:

- 1. Model and serial numbers of the S-120.
- 2. Part number, description, and quantity of part(s) desired.

Note: Do not order by reference number if a parts catalog is being used; use the PART NUMBER.

Keep Your TORO All Toro



Insist on Genuine Toro Parts

MAINTENANCE RECORD

Date	Hours Used	Check Scraper	Check Belt	Check Supply Cord	Preparing For Storage	Comments