



Count on it.

Parts Catalog

GeoLink® Precision Spray System Finishing Kit

**Serial number 316000000 and After Multi
Pro® 5800 Turf Sprayer**

Model No. 41675—Serial No. 400000000 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Display Cover and Modem Mount Bracket 4

Receiver and Antenna Mount Assembly..... 5

Flow Meter and Connection Manifold Assembly 6


Connection Manifold Assembly No. 136-0449 7

Wire Harness and Section Valve Assembly 8

Manifold Assembly..... 10


On/Off Manifold Valve Kit No. 127-9803..... 11

Actuator On/Off Assembly No. 140-7377 12




Display Cover and Modem Mount Bracket

Ref.	Part Number	Qty.	Description
1	321-9	4	Screw-HH
2	104-7201	4	Nut-HF, NI
3	136-0378-03	1	Bracket-Stiffener
4	136-0453	1	Cover-Display
5	131-3796	1	Nut-Standoff
6	99-7420	1	Plug-Hole
7	132-4328	2	Strip-Adhesive
8	3256-22	4	Washer-Flat
9	140-1392-03	1	Bracket-Mount, Modem
10	32105-5	2	Screw
11	138-9250	2	Spacer
12	3296-27	2	Nut-Lock, NI




Receiver and Antenna Mount Assembly

Ref.	Part Number	Qty.	Description
1	131-7241-03	1	Mount-Receiver
2	47-3460	2	U-Bolt
3	104-8301	4	Nut-HF, NI
4	3256-14	3	Washer-Flat
5	60-6910	3	Screw-HH
6	140-1388-03	1	Bracket-Mount, Antenna




Flow Meter and Connection Manifold Assembly

Ref.	Part Number	Qty.	Description
2	136-0449	1	Connection Manifold ASM
3	127-1142	1	Fitting-STR
5	127-9829	1	Clamp/Gasket Kit
5:2	127-1145	1	Gasket-Flange
6	132-4257	1	Hose
7	132-4258	1	Hose
8	2412-3	4	Clamp-Hose
9	2412-74	1	R-Clamp
10	3234-4	1	Screw-HHF
11	104-7201	1	Nut-HF, NI



Connection Manifold Assembly No. 136-0449


<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	131-0241	2	Fitting-Elb 90
2	127-9814	1	Fitting-Adapter
3	127-9829	3	Clamp/Gasket Kit
3:2	127-1145	1	Gasket-Flange
4	127-9834	1	Fitting-Tee



Wire Harness and Section Valve Assembly

Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	131-3753-03	1	Mount-Valve, GPS	10:3:1	133-0398	1	Pin-Fork
2	60-6500	4	Screw-HH	10:4	2412-36	2	Clamp-Hose
3	127-2018	4	Nut-HHF	11	131-7290	4	Hose Nozzle ASM
4	122-0824	1	Harness-Wire	11:2	130-7265	1	Shank-Nozzle, Single
4:8	100-4918	4	Diode	11:3	139-3088	1	Kit-Fitting, Qc 1/2" STR Barb
4:18	94-8002	1	Fuse-Blade, 50 Amp	11:3:1	133-0398	1	Pin-Fork
5	3234-4	8	Screw-HHF	11:4	2412-36	2	Clamp-Hose
6	104-7201	8	Nut-HF, NI	13	131-7292	2	Hose Nozzle ASM
7	3234-47	8	Screw-HHF	13:3	130-7265	2	Shank-Nozzle, Single
8	104-8300	8	Nut-HF, NI	13:4	139-3088	1	Kit-Fitting, Qc 1/2" STR Barb
9	131-7288	2	Hose Nozzle ASM	13:4:1	133-0398	1	Pin-Fork
9:2	130-7265	1	Shank-Nozzle, Single	13:5	131-3736	1	Fitting-Tee, Barb
9:3	139-3088	1	Kit-Fitting, Qc 1/2" STR Barb	13:6	2412-36	6	Clamp-Hose
9:3:1	133-0398	1	Pin-Fork	14	2412-39	2	Clamp-R
9:4	2412-36	2	Clamp-Hose	15	2412-137	2	Clamp-R, Double
10	131-7289	2	Hose Nozzle ASM	17	127-9811	3	Fitting-Cap, Female
10:2	130-7265	1	Shank-Nozzle, Single	17:1	133-0398	1	Pin-Fork
10:3	139-3088	1	Kit-Fitting, Qc 1/2" STR Barb	18		1	Manifold ASM ●

● Not serviced separately




Wire Harness and Section Valve Assembly (continued)

Ref.	Part Number	Qty.	Description
20	32180-161	3	Clip-Connector


Ref.	Part Number	Qty.	Description
21	99-7430	1	Relay-Mini
22	127-9815	1	Fitting-Cap

● Not serviced separately



Manifold Assembly

Ref.	Part Number	Qty.	Description
1	127-9803	7	On/Off Manifold Valve Kit
2	140-7377	7	Kit-Actuator Pi, On/Off
3	127-9811	7	Fitting-Cap, Female
3:1	133-0398	1	Pin-Fork
4	127-9834	1	Fitting-Tee
5	127-9815	1	Fitting-Cap
6	131-0241	1	Fitting-Elb 90
7	127-9829	9	Clamp/Gasket Kit
7:2	127-1145	1	Gasket-Flange




On/Off Manifold Valve Kit No. 127-9803

Ref.	Part Number	Qty.	Description
1	130-8248	1	Valve Stem Kit
1:1	127-1197	2	O-Ring-Stem
2	127-1194	1	Ball-Valve, 3Way
3	130-7317	2	Endcap Kit
3:1	127-1192	1	Seat-Ball
3:2	127-1188	1	O-Ring, Seat (Ball)
3:3	127-1189	1	O-Ring, Endcap
3:4	127-1187	1	O-Ring, Endcap
4	127-1196	1	Washer-Stem, Valve
5	127-1195	1	Seat-Stem, Valve

Ref.	Part Number	Qty.	Description
6	127-1190	1	Fork-Stem, Valve
99	130-7304	1	Valve Repair Kit ●
99:1	127-1197	2	O-Ring-Stem
99:2	127-1196	2	Washer-Stem, Valve
99:3	127-1195	1	Seat-Stem, Valve
99:4	127-1190	1	Fork-Stem, Valve
99:5	127-1192	2	Seat-Ball
99:6	127-1188	2	O-Ring, Seat (Ball)
99:7	127-1187	2	O-Ring, Endcap
99:8	127-1189	2	O-Ring, Endcap

● Not illustrated



Actuator On/Off Assembly No. 140-7377

Ref.	Part Number	Qty.	Description
1	140-7315	1	Actuator - On/Off
1:1	130-7301	1	Hairpin-Actuator
2	127-6979	1	Decal-Valve, Agitation
3	127-6981	1	Decal-Valve, On/Off
4	127-6982	1	Decal-Valve, Master Boom
5	127-6976	1	Decal-Valve, Bypass Adjust

Notes:

Notes:

Notes:



Count on it.