



Form No. 3459-973 Rev B

**Count on it.**

# Parts Catalog

## **Z Master® Professional 6000 Series Riding Mower with 60in TURBO FORCE® Side Discharge Mower**

Model No. 72960—Serial No. 414116589 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

Frame Assembly . . . . . 4

Roll-Over Protection System Assembly No. 116-0231 . . . . . 6

Caster Fork and Wheel Assembly . . . . . 8

Hydraulic Drive Assembly . . . . . 10

Pump Idler Assembly No. 116-1255 . . . . . 12

LH Hydro Assembly No. 135-7907 . . . . . 14

RH Hydro Assembly No. 135-7908 . . . . . 16

Rear Wheel Assembly . . . . . 18

Fuel System Assembly . . . . . 20

Fuel Tank Assembly No. 135-0643 . . . . . 22

Seat Mounting Assembly . . . . . 24

Seat Assembly No. 147-4984 . . . . . 26

Motion Control Assembly . . . . . 28

Console Assembly . . . . . 30

RH Console Assembly No. 115-7400 . . . . . 32

LH Console Assembly No. 115-7401 . . . . . 34

Electrical Assembly . . . . . 36

Deck Lift Assembly . . . . . 38

Height-of-Cut Assembly No. 109-7438 . . . . . 40

Engine, Clutch and Muffler Assembly . . . . . 42

Deck Assembly . . . . . 44

Deck Decal Assembly No. 140-1169 . . . . . 46

Rubber Deflector Assembly No. 108-2792 . . . . . 48


Idler Arm Assembly . . . . . 50

Frame Decal Assembly . . . . . 52

Park Brake Assembly . . . . . 54

Attachments and Accessories . . . . . 56


# Frame Assembly



## Frame Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|------------------------------|-------------|--------------------|-------------|-----------------------------|
| 1           | 142-7265           | 1           | Mainframe Service ASM - 60   | 8           | 104-8301           | 15          | Nut-HF, NI                  |
| 1:2         | 132-0871           | 1           | Decal-Danger                 | 9           | 3231-22            | 9           | Screw-CARR                  |
| 1:3         | 106-5517           | 2           | Decal-Warning                | 10          | 3231-21            | 4           | Screw-CARR                  |
| 1:4         | 106-2655           | 2           | Decal-Hazard, Pinched Finger | 11          | 116-5899           | 1           | RH Motion Control Cover ASM |
| 1:5         | 133-8062           | 1           | Decal-Arrestor, Spark        | 11:2        | 99-8936            | 1           | Decal-Control, Motion       |
| 2           | 115-7410           | 1           | Rear Guard ASM               | 11:3        | 116-5988           | 1           | Decal-Park Brake, CE        |
| 2:2         | 67-7320            | 1           | Decal                        | 12          | 116-0580           | 1           | LH Motion Control Cover ASM |
| 3           | 116-8898-01        | 1           | Floorpan                     | 12:2        | 99-8936            | 1           | Decal-Control, Motion       |
| 4           | 1-513658           | 2           | Bumper                       | 13          | 126-2067-03        | 1           | Guard-Muffler               |
| 5           | 1-811010           | 2           | Plug                         | 14          | 68-3640            | 1           | Decal                       |
| 6           | 116-0180           | 1           | LH Bumper ASM                | 15          | 32144-10           | 4           | Screw-HWH                   |
| 6:2         | 106-5517           | 1           | Decal-Warning                | 20          | 107-3154           | 2           | Nut-Push                    |
| 7           | 116-0057-03        | 1           | Bumper-RH                    | 22          | 1-543508           | 4           | Cup-Bearing                 |

# Roll-Over Protection System Assembly No. 116-0231



# Roll-Over Protection System Assembly No. 116-0231 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           |                    | 1           | Leg-ROPS, LH ●     |
| 2           |                    | 1           | Leg-ROPS, RH ●     |
| 3           | 109-6653           | 2           | Spacer             |
| 4           |                    | 1           | Upper ROPS ASM ●   |
| 4:2         | 107-3069           | 1           | Decal-Warning      |
| 5           | 109-5337           | 2           | Bumper-ROPS        |
| 6           | 116-0104           | 2           | Pin-Spring         |
| 7           | 99-5107            | 8           | Nut-Lock           |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|--------------------------|
| 8           | 3233-10            | 2           | Screw-CARR               |
| 9           | 325-35             | 4           | Screw-HH                 |
| 10          | 109-9505           | 4           | Washer-Spring            |
| 11          | 109-9233           | 1           | Bumper-Push-In, Rubber   |
| 12          | 117-0346           | 1           | Decal-Caution, Fuel Vent |
| 14          | 116-0960           | 2           | Spacer                   |
| 15          | 325-13             | 2           | Screw-HH                 |
| 16          | 125-8067           | 1           | Plug-Plastic             |

● Not serviced separately

# Caster Fork and Wheel Assembly



## Caster Fork and Wheel Assembly (continued)


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|
| 1           | 1-543509           | 2           | Bearing-Roller, Tapered |
| 2           | 116-5647           | 1           | Seal-Grease             |
| 3           | 1-633508           | 3           | Washer-Bellville        |
| 4           | 116-6707-01        | 1           | Caster                  |
| 5           | 127-9528           | 1           | Wheel And Axle ASM      |
| 5:1         | 103-2768           | 2           | Guard-Seal              |
| 5:2         |                    | 1           | Wheel And Bearing ASM ● |
| 5:2:1       | 1-633585           | 2           | Bearing-Cone, Taper     |
| 5:2:2       | 103-0063           | 2           | Seal-Caster             |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------|
| 5:2:3       | 103-3051           | 1           | Spacer-Nut ■         |
| 5:2:4       | 126-5361           | 1           | Axle Caster ASM      |
| 5:2:5       |                    | 1           | Wheel And Tire ASM ● |
| 5:2:5:1     | 1-633584           | 2           | Bearing-Cup          |
| 5:3         | 325-39             | 1           | Screw-HH             |
| 5:4         | 3296-23            | 1           | Nut-Lock, NI         |
| 6           | 103-4882           | 1           | Cap-Grease           |
| 7           | 3296-51            | 1           | Nut-Lock, NI         |

● Not serviced separately

■ Use Pro-Lock, Nut Type (P/N 1-840022, .5ml tube) on threads.

# Hydraulic Drive Assembly



## Hydraulic Drive Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|-----------------------------|
| 1           | 116-1255           | 1           | Pump Idler ASM          | 13          | 116-0171           | 1           | RH Hydro Guard ASM          |
| 2           | 109-6658           | 1           | Nut-Flange, NI          | 13:2        | 116-8726           | 1           | Decal-Oil, Hydro            |
| 3           | 135-7907           | 1           | Hydro-LH                | 14          | 109-9709           | 1           | Guard-Hydro, Rear Trim (LH) |
| 4           | 126-9835           | 1           | Belt-V                  | 15          | 109-9058           | 1           | Guard-Hydro, Rear (RH)      |
| 5           | 116-6317           | 1           | Spring-Extension        | 16          | 1-803035           | 2           | Rivet-Pop                   |
| 6           | 116-7558           | 1           | Cradle-Hydro            | 17          | 116-2362           | 1           | Deflector-Air Flow          |
| 7           | 116-1502           | 1           | Bolt-Shoulder, Carriage | 18          | 142-9445           | 1           | Sheave, W/Hub               |
| 8           | 126-0095           | 6           | Screw-CARR              | 19          | 1-807259           | 1           | Key                         |
| 9           | 99-5107            | 6           | Nut-Lock                | 99          | 114-4713           | 1           | Hypr-Oil 500 (Quart) ●      |
| 10          | 325-8              | 4           | Screw-HH                | 99          | 114-4714           | 1           | Hypr-Oil 500 (Gallon) ●     |
| 11          | 135-7908           | 1           | Hydro-RH                | 99          | 114-4715           | 1           | Hypr-Oil 500-5 (5 Gallon) ● |
| 12          | 116-0170           | 1           | LH Hydro Guard ASM      | 99          | 117-0390           | 1           | Filter-Hydro ●              |
| 12:2        | 116-8726           | 1           | Decal-Oil, Hydro        |             |                    |             |                             |

● Not illustrated


Pump Idler Assembly No. 116-1255



## Pump Idler Assembly No. 116-1255 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 2           | 43-0940            | 1           | Spacer             | 8           | 323-8              | 1           | Screw-HH           |
| 3           | 103-3504           | 2           | Bearing-Spherical  | 9           | 32120-10           | 2           | Ring-Snap          |
| 4           | 103-3505           | 1           | Seal-Lip, Double   | 10          | 302-19             | 1           | Fitting-Grease     |
| 5           | 103-3506           | 1           | Seal-Lip, Single   | 11          | 109-8076           | 1           | Pulley-Idler       |
| 6           | 109-6658           | 1           | Nut-Flange, NI     | 12          | 132-4724           | 1           | Pin-Anchor, Spring |
| 7           | 106-7159           | 2           | O-Ring             |             |                    |             |                    |

# LH Hydro Assembly No. 135-7907




# LH Hydro Assembly No. 135-7907 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|-----------------------------------|
| 2           | 142-3603           | 1           | Kit, 7.8 In Fan            | 17          | 116-7901           | 1           | Magnetic Plugs Service Kit        |
| 3           | 116-0234           | 1           | Pulley Kit                 | 18          | 76-1900            | 2           | O-Ring                            |
| 4           | 116-0235           | 1           | Handle                     | 19          | 116-8662           | 2           | O-Ring-Valve, Check               |
| 5           | 116-0236           | 1           | Dipstick                   | 20          | 116-8974           | 4           | Screw-HH 1/2-20 X 2 1/4           |
| 6           | 116-0237           | 1           | Gasket                     | 21          | 116-8975           | 2           | Screw-HSH 1/2-20 X 2 3/4          |
| 7           | 116-1367           | 1           | Swash Block Kit            | 22          | 116-9922           | 2           | Hydraulic Tube Kit                |
| 8           | 142-3604           | 1           | Kit, Pump Seal             | 23          | 126-7467           | 1           | Shock Valve, 16Cc Hydro           |
| 9           | 116-1369           | 1           | Motor Seal Kit             | 24          | 126-7711           | 1           | Seal-Drive, Fan                   |
| 10          | 116-1370           | 1           | Tube Seal Kit              | 25          | 142-3607           | 1           | Kit, Pump Section 16Cc LH         |
| 11          | 116-1371           | 1           | Output Shaft Seal Kit      | 26          | 142-4501           | 1           | Kit - 16Cc Port Plate, Rotate Grp |
| 12          | 116-5469           | 1           | Cup-Nose                   | 27          | 142-4458           | 1           | Shock Valve Orificed 3300         |
| 13          | 3257-42            | 1           | Key-Woodruff 5/16 X 1      | 28          | 146-3749           | 1           | Output Shaft- TI Uht Motor        |
| 15          | 142-4460           | 1           | Kit, Housing-Hydro LH      | 99          | 116-1373           | 1           | Flow Test Kit ●                   |
| 16          | 146-1948           | 1           | HYD Motor, 280Cc LH Sealed |             |                    |             |                                   |

● Not illustrated

# RH Hydro Assembly No. 135-7908




## RH Hydro Assembly No. 135-7908 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>               |
|-------------|--------------------|-------------|---------------------------|-------------|--------------------|-------------|----------------------------------|
| 1           | 135-7827           | 1           | Plate, Horse Shoe Mount   | 17          | 116-7901           | 1           | Magnetic Plugs Service Kit       |
| 2           | 142-3603           | 1           | Kit, 7.8 In Fan           | 18          | 76-1900            | 2           | O-Ring                           |
| 3           | 116-0234           | 1           | Pulley Kit                | 19          | 116-8662           | 2           | O-Ring-Valve, Check              |
| 4           | 116-0235           | 1           | Handle                    | 20          | 116-8974           | 4           | Screw-HH 1/2-20 X 2 1/4          |
| 5           | 116-0237           | 1           | Gasket                    | 21          | 116-8975           | 2           | Screw-HSH 1/2-20 X 2 3/4         |
| 6           | 116-0236           | 1           | Dipstick                  | 22          | 116-9922           | 2           | Hydraulic Tube Kit               |
| 7           | 116-1367           | 1           | Swash Block Kit           | 23          | 126-7467           | 1           | Shock Valve, 16Cc Hydro          |
| 8           | 142-3604           | 1           | Kit, Pump Seal            | 24          | 126-7711           | 1           | Seal-Drive, Fan                  |
| 9           | 116-1369           | 1           | Motor Seal Kit            | 25          | 142-3606           | 1           | Kit, Pump Section 16Cc RH        |
| 10          | 116-1370           | 1           | Tube Seal Kit             | 26          | 142-4501           | 1           | Kit - 16Cc Port Plate,Rotate Grp |
| 11          | 116-1371           | 1           | Output Shaft Seal Kit     |             |                    |             |                                  |
| 12          | 116-5469           | 1           | Cup-Nose                  | 27          | 142-4458           | 1           | Shock Valve Orificed 3300        |
| 13          | 3257-42            | 1           | Key-Woodruff 5/16 X 1     | 28          | 146-3749           | 1           | Output Shaft- TI Uht Motor       |
| 15          | 142-4461           | 1           | Kit, Housing-Hydro RH     | 99          | 116-1373           | 1           | Flow Test Kit ●                  |
| 16          | 146-1947           | 1           | HYD Motor,280Cc RH Sealed | 99          | 116-4245           | 1           | Puller-Pulley                    |

● Not illustrated


# Rear Wheel Assembly



## Rear Wheel Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 127-9520           | 2           | Wheel And Tire ASM | 2           | 242-50             | 8           | Nut-Lug                 |
| 1:1         | 127-9517           | 1           | Wheel              | 3           | 126-2055           | 2           | Decal-Torque, Wheel Hub |
| 1:2         | 1-633993           | 1           | Tire               |             |                    |             | Lug                     |
| 1:3         | 232-27             | 1           | Stem-Valve         |             |                    |             |                         |


# Fuel System Assembly



## Fuel System Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|------------------------|-------------|--------------------|-------------|----------------------|
| 1           | 135-0643           | 1           | Fuel Tank ASM          | 7           | 140-4956           | 1           | Hose-Fuel            |
| 2           | 3218-1             | 2           | Nut-Jam                | 8           | 105-1853           | 2           | Clamp-Hose           |
| 3           | 1-523420           | 2           | Bumper                 | 9           | 116-6005           | 1           | Retainer-Line, Vapor |
| 5           | 127-0583           | 1           | Fuel Manifold Vent ASM | 11          | 125-8067           | 1           | Plug-Plastic         |
| 5:2         | 109-0302           | 3           | Hose-Fuel              | 12          | 130-6409           | 1           | Decal-Rcm            |
| 5:3         | 108-5376           | 1           | Hose-Fuel              | 13          | 2412-80            | 1           | Clamp-Hose           |
| 6           | 135-5678           | 1           | Barb-Fuel              | 14          | 116-4464           | 1           | Plug-Port            |


# Fuel Tank Assembly No. 135-0643



## Fuel Tank Assembly No. 135-0643 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>              | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                |
|-------------|--------------------|-------------|---------------------------------|-------------|--------------------|-------------|-----------------------------------|
| 2           | 46-6560            | 4           | Bushing                         | 8:1         | 46-6560            | 1           | Bushing                           |
| 3           | 116-2459           | 1           | Fuel Line Kit (With Grommet)    | 9           | 116-2461           | 1           | LH Vent Line Kit (With Grommet)   |
| 3:1         | 46-6560            | 1           | Bushing                         | 9:1         | 46-6560            | 1           | Bushing                           |
| 4           | 3290-500           | 5           | Screw-PPH                       | 10          | 116-2462           | 1           | Rear Vent Line Kit (With Grommet) |
| 5           | 3253-17            | 5           | Washer-Lock                     | 10:1        | 46-6560            | 1           | Bushing                           |
| 6           | 126-3913           | 1           | Float-Sender, Fuel              | 11          | 1-603770           | 1           | Valve-Fuel                        |
| 6:1         | 126-3950           | 1           | Gasket-Sender                   | 12          | 2412-98            | 2           | Clamp-Hose                        |
| 7           | 126-1789           | 1           | Cap-Fuel, Ratcheting            | 13          | 109-0650           | 1           | Hose-Fuel                         |
| 8           | 116-2460           | 1           | RH Vent Line Kit (With Grommet) |             |                    |             |                                   |


# Seat Mounting Assembly



## Seat Mounting Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 147-4984           | 1           | Seat-Suspension          | 9:3         | 125-9383           | 1           | Decal-Service Aid  |
| 2           | 109-9034           | 4           | Isolator-Seat            | 10          | 109-9881-03        | 1           | Plate-Latch, Seat  |
| 3           | 104-8301           | 4           | Nut-HF, NI               | 11          | 3230-4             | 1           | Bolt-CARR          |
| 4           | 116-3860-03        | 1           | Plate-Tilt, Seat Support | 12          | 107-3017           | 1           | Spring-Compression |
| 5           | 3230-23            | 11          | Bolt-CARR                | 13          | 9266934            | 2           | Screw              |
| 6           | 104-8300           | 18          | Nut-HF, NI               | 14          | 140-1215           | 1           | Decal-Console      |
| 7           | 116-3859-03        | 1           | Plate-Frame, Seat        | 15          | 116-1297           | 2           | Screw-Shoulder     |
| 8           | 26-4840            | 4           | Spacer-Pin, Mounting     | 16          | 116-0070           | 1           | Rod-Prop           |
| 9           | 125-9385           | 1           | Seat Mount ASM           | 17          | 3256-23            | 1           | Washer-Plain       |

# Seat Assembly No. 147-4984




## Seat Assembly No. 147-4984 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|--------------------------|
| 1           | 140-8012           | 1           | Seat Track Set           |
| 2           | 116-5659           | 1           | Cover-Suspension Bellows |
| 3           | 140-8004           | 1           | Cover-Back               |
| 4           | 140-8005           | 1           | Cover-Cushion            |
| 5           | 116-8911           | 1           | Knob-Adjuster            |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|
| 6           | 82-2190            | 1           | Switch-Bail           |
| 7           | 147-4985           | 1           | Armrest Kit           |
| 8           | 109-9802           | 1           | Arm Rest Pad Set      |
| 9           | 126-2061           | 1           | Seat Belt Service Kit |

# Motion Control Assembly




## Motion Control Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|-----------------------------------|-------------|--------------------|-------------|------------------------|
| 1           | 116-0880           | 1           | RH Motion Control And Bushing ASM | 14          | 135-4371           | 1           | RH Handle ASM          |
| 1:2         | 109-8054           | 4           | Bushing-Flange                    | 14:2        | 109-5668           | 1           | Grip-Lever, Control    |
| 2           | 116-0881           | 1           | LH Motion Control And Bushing ASM | 15          | 135-4373           | 1           | LH Handle ASM          |
| 2:2         | 109-8054           | 4           | Bushing-Flange                    | 15:2        | 109-5668           | 1           | Grip-Lever, Control    |
| 3           | 116-0648           | 2           | Screw-HH, Thread Locking ●        | 16          | 104-8301           | 4           | Nut-HF, NI             |
| 4           | 109-4581           | 2           | Arm-Control, Pump                 | 17          | 323-7              | 4           | Screw-HH               |
| 5           | 9080046            | 2           | Screw-HH ●                        | 18          | 109-5575           | 2           | Spring-Leaf            |
| 6           | 1-303435           | 2           | Washer-Spring                     | 19          | 109-8106           | 2           | Front Pump Linkage ASM |
| 7           | 116-0027           | 2           | Damper-Control, Motion            | 19:2        | 3219-2             | 2           | Nut-Hex                |
| 8           | 104-8300           | 8           | Nut-HF, NI                        | 19:3        | 1-323245           | 2           | Spring-Compression     |
| 9           | 3230-2             | 2           | Bolt-CARR                         | 19:4        | 1-633152           | 1           | Balljoint-LH           |
| 10          | 109-5891           | 2           | Hub-Threaded                      | 19:5        | 1-543017           | 1           | Balljoint-RH           |
| 11          | 325-12             | 2           | Screw-HH                          | 20          | 109-9505           | 4           | Washer-Spring          |
| 12          | 116-0039           | 1           | Lever-Control Motion, RH          | 21          | 3256-6             | 2           | Washer-Flat            |
| 13          | 116-0040           | 1           | Lever-Control Motion, LH          | 22          | 32128-56           | 2           | Nut-HF                 |
|             |                    |             |                                   | 23          | 3256-23            | 2           | Washer-Plain           |
|             |                    |             |                                   | 24          | 3218-5             | 2           | Nut-Jam                |
|             |                    |             |                                   | 25          | 115-1794           | 2           | Screw-HHF              |

● Use Pro-Lock, Nut Type (P/N 1-840022, .5ml tube) on threads.


# Console Assembly



## Console Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|--------------------|
| 1           | 114-9836           | 1           | Control Panel ASM    | 6           | 32105-15           | 4           | Screw-HWH          |
| 1:2         | 120-5897           | 1           | Decal-Panel, Control | 7           | 115-7400           | 1           | RH Console ASM     |
| 1:3         | 114-4466           | 1           | Decal-Fuses          | 8           | 115-7401           | 1           | LH Console ASM     |


# RH Console Assembly No. 115-7400



## RH Console Assembly No. 115-7400 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|----------------------|
| 1           | 114-1538           | 1           | RH Wide Top Console ASM | 3:2         | 114-5896           | 2           | Magnet               |
| 1:2         | 117-0883           | 2           | Puck                    | 4           | 109-9083           | 1           | Fender-Wide, RH      |
| 1:3         | 107069             | 4           | Clip                    | 5           | 32144-89           | 6           | Screw-Thread Forming |
| 2           | 115-3643           | 1           | Console-Lower, RH Wide  | 6           | 117-0347           | 6           | Screw-PPH            |
| 3           | 114-1537           | 1           | Wide Lid ASM            |             |                    |             |                      |

# LH Console Assembly No. 115-7401




## LH Console Assembly No. 115-7401 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|
| 1           | 114-1539           | 1           | LH Wide Console Top ASM |
| 1:2         | 117-0883           | 2           | Puck                    |
| 2           | 115-3641           | 1           | Console-Lower, LH Wide  |
| 3           | 114-1537           | 1           | Wide Lid ASM            |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------|
| 3:2         | 114-5896           | 2           | Magnet               |
| 4           | 109-9085           | 1           | Fender-Wide, LH      |
| 5           | 32144-89           | 6           | Screw-Thread Forming |
| 6           | 117-0347           | 6           | Screw-PPH            |

# Electrical Assembly




## Electrical Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 104-8162           | 1           | Battery                    | 9           | 1-643275           | 1           | Relay                   |
| 2           | 116-6009           | 1           | Harness-Wire, Main ●       | 10          | 114-1218           | 1           | Cable-Battery, Negative |
| 2:1         | 103-3895           | 1           | Diode                      | 11          | 3234-5             | 2           | Screw-HHF               |
| 2:2         | 218-578            | 1           | Fuse-Blade, 10 Amp         | 12          | 104-8300           | 2           | Nut-HF, NI              |
| 2:3         | 109355             | 1           | Fuse-Blade, 15 Amp         | 13          | 1-303287           | 3           | Tie-Cable               |
| 2:4         | 109102             | 2           | Fuse-Blade, 25 Amp         | 14          | 82-2190            | 1           | Switch-Bail             |
| 2:5         | 116-0053           | 1           | Cap-Plug                   | 15          | 137-4100           | 1           | Switch-Ignition         |
| 3           | 117-3882           | 1           | Fuel/Hour Meter ASM        | 16          | 135-3653           | 1           | Switch, PTO 10A         |
| 4           | 1-603511           | 1           | Keys-Ignition (Spare Pair) | 17          | 104-2065           | 1           | Screw-HWH               |
| 4           | 63-8360            | 1           | Key-Ignition               | 18          | 115-3864           | 1           | Cable-Battery, Positive |
| 5           | 110-6765           | 2           | Switch                     | 19          | 3290-378           | 1           | Tie-Cable               |
| 6           | 116-0042-03        | 1           | Strap-Tie Down, Battery    | 20          | 109-2407           | 1           | Insulator-Battery       |
| 7           | 1-633651           | 2           | Bolt-Holddown              | 21          | 1-543393           | 1           | Insulator-Solenoid      |
| 8           | 1-543792           | 2           | Wingnut                    |             |                    |             |                         |

● Use dielectric grease on all unsealed connectors and terminals only. Do not apply in sealed connectors.


# Deck Lift Assembly



## Deck Lift Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|-----------------------------------------|-------------|--------------------|-------------|--------------------------|
| 1           | 86-1990            | 6           | Washer-Thrust                           | 17          | 325-12             | 2           | Screw-HH                 |
| 2           | 99-5107            | 12          | Nut-Lock                                | 18          | 325-17             | 1           | Screw-HH                 |
| 3           | 104-8301           | 12          | Nut-HF, NI                              | 19          | 3231-2             | 2           | Bolt-CARR                |
| 4           | 109-5013           | 1           | Panhard Rod ASM                         | 20          | 3231-4             | 2           | Screw-CARR               |
| 4:2         | 109-5009           | 2           | Bushing-Suspension,<br>Rubber           | 21          | 3231-7             | 4           | Screw-CARR               |
| 4:3         | 109-5010           | 2           | Spacer                                  | 22          | 3233-34            | 3           | Screw-CARR               |
| 5           | 109-7173           | 2           | Bearing-Cross Shaft, Rear               | 23          | 3296-23            | 1           | Nut-Lock, NI             |
| 6           | 116-1919-01        | 1           | Lever-Foot                              | 24          | 116-1700           | 4           | Bolt-CARR                |
| 7           | 109-7438           | 1           | HOC ASM                                 | 25          | 116-0559           | 1           | Bolt-TAP                 |
| 8           | 126-2477-03        | 1           | Decklift-Front                          | 26          | 116-2022           | 2           | Screw-HHF, Shoulder      |
| 9           | 127-0553           | 2           | Support-Bearing, Cross<br>Shaft (Rear)  | 27          | 92-7674            | 1           | Bolt-Shoulder            |
| 10          | 109-7952           | 2           | Deck Strut ASM                          | 28          | 116-0000           | 1           | Spring-Extension         |
| 10:2        | 109-5009           | 2           | Bushing-Suspension,<br>Rubber           | 29          | 109-9065           | 1           | Screw-HH                 |
| 10:3        | 109-5010           | 2           | Spacer                                  | 30          | 32128-37           | 2           | Nut-HF                   |
| 11          | 116-0797-03        | 1           | Link-Lift, Deck                         | 31          | 3256-28            | 2           | Washer-Flat              |
| 12          | 116-2645-03        | 1           | Lift-Deck, Rear                         | 32          | 116-2695           | 1           | Spacer                   |
| 13          | 116-5584           | 1           | Pin-HOC                                 | 33          | 109-8007           | 4           | Link-Adjuster, Deck Lift |
| 14          | 109-9409           | 2           | Support-Bearing, Cross<br>Shaft (Front) | 34          | 109-7840           | 4           | Adjuster-Lift, Deck      |
| 15          | 109-9410           | 2           | Bearing-Cross Shaft, Front              | 35          | 109-8353           | 4           | Trunnion                 |
| 16          | 109-9840           | 4           | Screw-Shoulder, HHF                     | 36          | 3218-5             | 4           | Nut-Jam                  |
|             |                    |             |                                         | 37          | 140-4963-01        | 1           | Weight-Toe Board         |
|             |                    |             |                                         | 38          | 3256-22            | 4           | Washer-Flat              |
|             |                    |             |                                         | 39          | 321-8              | 4           | Screw-HH                 |
|             |                    |             |                                         | 40          | 104-7201           | 4           | Nut-HF, NI               |

Height-of-Cut Assembly No. 109-7438




## Height-of-Cut Assembly No. 109-7438 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 1           | 62-1330            | 1           | Bolt-Shoulder       |
| 2           | 109-7130           | 1           | Grommet             |
| 3           | 104-8301           | 1           | Nut-HF, NI          |
| 4           | 109-7124           | 1           | Spring-Extension    |
| 5           | 109-7128           | 1           | Rod-Lock, Transport |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 6           | 116-0118           | 1           | Pawl-Transport, HOC |
| 7           | 109-7335           | 1           | HOC Plate ASM       |
| 7:2         | 126-4398           | 1           | Decal-HOC           |
| 8           | 109-8250           | 1           | Grip-Lever          |

# Engine, Clutch and Muffler Assembly



## Engine, Clutch and Muffler Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                          | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|---------------------------------------------|-------------|--------------------|-------------|--------------------|
| 1           |                    | 1           | Engine-Kawasaki,<br>Fx921V-S04-R ■▲         | 14          | 323-7              | 4           | Screw-HH           |
| 1:1         |                    | 1           | Kawasaki 49065-7007<br>Engine Oil Filter ■▲ | 15          | 109-6658           | 2           | Nut-Flange, NI     |
| 1:2         |                    | 1           | Kawasaki 11013-7044<br>Engine Air Filter ■▲ | 16          | 1-303334           | 2           | Washer-Spring      |
| 1:3         |                    | 1           | Kawasaki 11013-7045<br>Safety Filter ■▲     | 17          | 3234-5             | 2           | Screw-HHF          |
| 2           | 133-1873           | 1           | Cable-Choke                                 | 18          | 94-2413            | 2           | Nut-U              |
| 3           | 126-4185           | 1           | Clutch Kit                                  | 19          | 109-0298           | 1           | Line-Fuel          |
| 4           | 109-6919           | 1           | Washer-Plain                                | 20          | 2412-98            | 2           | Clamp-Hose         |
| 5           | 1-603610           | 2           | Washer-Spring                               | 21          | 116-1707           | 1           | Muffler            |
| 6           | 109-9761           | 1           | Screw-HH □                                  | 22          | 116-3331-01        | 1           | Belt-Guide         |
| 7           | 3231-42            | 1           | Screw-CARR                                  | 23          | 116-3318           | 1           | Spacer             |
| 8           | 116-1587           | 1           | Bracket-Muffler                             | 24          | 116-3319           | 1           | Spacer             |
| 9           | 33114-020          | 2           | Screw-HH                                    | 25          | 104-8300           | 1           | Nut-HF, NI         |
| 10          | 116-4924           | 1           | Engine Oil Drain Hose ASM<br>◆              | 26          | 323-8              | 1           | Screw-HH           |
| 10:1        | 353-508            | 1           | Plug-HH ●                                   | 27          | 322-4              | 1           | Screw-HH           |
| 10:1:1      | 237-42             | 1           | O-Ring                                      | 28          | 93-5108            | 2           | Grommet-Rubber     |
| 11          | 98-5975            | 4           | Washer-Belleville                           | 31          | 1-807513           | 2           | Bolt-CARR          |
| 12          | 133-1816           | 1           | Throttle-Control                            | 32          | 3296-2             | 2           | Nut-Lock, NI       |
| 13          | 116-3317-01        | 1           | Link-Anchor, Clutch                         | 33          | 1-603175           | 1           | Knob-Ball          |
|             |                    |             |                                             | 34          | 117-7817           | 1           | Clamp-Harness      |
|             |                    |             |                                             | 35          | 3220-3             | 1           | Nut-HJ             |
|             |                    |             |                                             | 36          | 1-633396           | 1           | Clip-Loom          |
|             |                    |             |                                             | 37          | 105-1853           | 2           | Clamp-Hose         |

● Torque to 24-26 ft-lb


▲ Obtain parts from [www.kawpower.com](http://www.kawpower.com)

◆ Use a Teflon Pipe Sealant or equivalent on threads.

□ Use Pro-Lock, Nut Type (P/N 1-840022, .5ml tube) on threads.

■ Not serviced separately

# Deck Assembly




## Deck Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|---------------------|
| 1           | 140-1169           | 1           | Deck Decal ASM       | 27          | 109-9416           | 1           | Spacer-Idler        |
| 2           | 108-5388           | 1           | Screw-HH             | 28          | 132-4734           | 1           | Pulley-Idler, Flat  |
| 3           | 104-8301           | 32          | Nut-HF, NI           | 29          | 109-2872           | 1           | Spacer-Pulley       |
| 4           | 1-603299           | 4           | Roller-Scalp, Anti   | 30          | 136-5404           | 1           | Pulley-Idler, Flat  |
| 5           | 98-5967            | 1           | Spacer-Wheel         | 31          | 108-5387           | 3           | Screw-CARR          |
| 6           | 323-23             | 2           | Screw-HH             | 32          | 3290-357           | 6           | Nut-HSF             |
| 7           | 98-7913            | 2           | Tube-Spacer          | 33          |                    | 1           | Idler Arm ASM ●     |
| 8           | 108-2792           | 1           | Rubber Deflector ASM | 34          | 114-5867           | 1           | Anchor-Spring, Tall |
| 9           | 105-4622           | 1           | Spacer               | 35          | 3231-42            | 1           | Screw-CARR          |
| 10          | 108-4052           | 1           | Spring-Torsion       | 36          | 109-6658           | 2           | Nut-Flange, NI      |
| 11          | 98-7912            | 2           | Tube-Spanner         | 37          | 3231-40            | 1           | Bolt-CARR           |
| 12          | 137-9780           | 3           | Spindle ASM          | 38          | 116-6317           | 1           | Spring-Extension    |
| 12:2        | 116-0720           | 2           | Bearing-Ball         | 39          | 132-5982           | 1           | Belt-V              |
| 12:3        | 138-6042           | 1           | Spacer-Bearing       | 40          | 109-6938           | 1           | Cover-Belt, LH      |
| 13          | 137-9784           | 3           | Guard-Bottom         | 41          | 116-0094           | 1           | Cover-Belt, RH      |
| 14          | 138-6045           | 3           | Shaft-Spindle        | 42          | 1-373034           | 4           | Washer              |
| 15          | 103-1330           | 3           | Guard-Bearing, Top   | 43          | 109-6982           | 2           | Wireform-Cover      |
| 16          | 138-6059           | 3           | Sheave-Drive, Blade  | 44          | 126-4781-03        | 1           | Step-Deck           |
| 17          | 103-2802           | 3           | Washer               | 45          | 3230-3             | 1           | Screw-CARR          |
| 18          | 116-7306           | 3           | Nut-Hex              | 46          | 104-8300           | 1           | Nut-HF, NI          |
| 19          | 140-1240           | 3           | Blade                | 47          | 138-6051-01        | 1           | Plate-Baffle        |
| 20          | 137-9787           | 3           | Bushing-Hex          | 48          | 94-7582            | 1           | Bolt-Shoulder       |
| 21          | 109-9220           | 3           | Screw-Sems           | 49          | 3231-25            | 1           | Bolt-CARR           |
| 22          | 121-8031-01        | 1           | Plate-Skid           | 50          | 109-1092           | 1           | Knob                |
| 23          | 3231-27            | 6           | Screw-CARR           | 51          | 100-4852           | 1           | Washer-Hardened     |
| 24          | 106-3216-01        | 1           | Baffle-Discharge     | 52          | 114-5842-01        | 1           | Baffle              |
| 25          | 322-50             | 1           | Screw-HH             | 53          | 92-1624            | 2           | Screw-HWH Thd Form  |
| 26          | 3296-47            | 1           | Nut-Lock, NI         |             |                    |             |                     |

● Not serviced separately

Deck Decal Assembly No. 140-1169




## Deck Decal Assembly No. 140-1169 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|--------------------------|
| 1           |                    | 1           | Deck ASM ●           | 1:6         | 107-1619           | 1           | Decal                    |
| 1:2         | 112-9028           | 3           | Decal-Cover, Missing | 1:7         | 136-5508           | 1           | Decal-Routing, Deck Belt |
| 1:3         | 127-0326           | 1           | Decal-Scalp, Anti    | 1:8         | 131-1180           | 1           | Decal-Adjustment, Baffle |
| 1:4         | 117-3848           | 2           | Decal-Danger         | 1:9         | 58-6520            | 1           | Decal-Grease             |
| 1:5         | 116-8283           | 1           | Decal-Torque, Bolt   |             |                    |             |                          |

● Not serviced separately

# Rubber Deflector Assembly No. 108-2792




## Rubber Deflector Assembly No. 108-2792 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 3231-4             | 4           | Screw-CARR         |
| 2           | 106-3246-01        | 1           | Deflector          |
| 3           | 106-3248-03        | 1           | Strap-Discharge    |
| 4           | 108-5029           | 1           | Deflector-Rubber   |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 5           | 108-4059-01        | 1           | Plate-Hinge, Rear  |
| 6           | 106-3253-01        | 1           | Plate-Hinge, Front |
| 7           | 104-8301           | 4           | Nut-HF, NI         |


# Idler Arm Assembly



## Idler Arm Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|----------------------|
| 1           | 114-5870           | 1           | Idler Arm ASM      | 5           | 98-5961            | 1           | Screw-HH             |
| 1:2         | 1-303514           | 2           | Bearing-Flanged    | 6           | 132-9425           | 1           | Pulley-Idler, Flat   |
| 1:3         | 1481               | 1           | Fitting-Grease     | 7           | 112-4212           | 1           | Mount-Pulley         |
| 2           | 109-6658           | 4           | Nut-Flange, NI     | 8           | 323-11             | 2           | Screw-HH             |
| 3           | 1-213069           | 3           | Washer             | 9           | 132-4729           | 1           | Anchor-Spring, Short |
| 4           | 114-5848           | 1           | Spacer-Plain       | 10          | 104-0151           | 1           | Spacer               |


# Frame Decal Assembly



## Frame Decal Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 120-5895           | 2           | Decal              |

# Park Brake Assembly



REAR VIEW OF  
RIGHT HAND HYDRO

## Park Brake Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>            | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|-------------------------------|-------------|--------------------|-------------|---------------------------|
| 1           | 126-4248           | 1           | Mount-Bellcrank, LH           | 20          | 119-1415           | 4           | Pin-Cotter, Locking       |
| 2           | 126-4249           | 1           | Mount-Bellcrank, RH           | 21          | 3296-6             | 1           | Nut-Nyloc 3/8-24          |
| 3           | 116-9681           | 1           | Mount-Pivot, LH               | 22          | 135-7440           | 1           | Caliper-Brake, RH         |
| 4           | 116-9682           | 1           | Mount-Pivot, RH               | 23          | 135-7441           | 1           | Caliper-Brake, LH         |
| 5           | 32144-70           | 4           | Screw-HWH 5/16-18 X 3/4<br>Tf | 24          | 135-7828           | 2           | Plate-Mount, Brake        |
| 6           | 109-8054           | 2           | Bushing-Flanged               | 25          | 3256-24            | 6           | Washer-3/8 SAE            |
| 7           | 116-9096-01        | 1           | Bracket-Mount                 | 26          | 115-7109           | 2           | Washer-Flat               |
| 8           | 135-7565           | 1           | Brake Lever ASM               | 27          | 98-9940            | 4           | Screw-HHF                 |
| 8:2         | 109-8054           | 2           | Bushing-Flanged               | 28          | 126-7587           | 2           | Rear Linkage ASM          |
| 8:3         | 132-4749           | 1           | Grip-Lever                    | 28:1        | 126-7588           | 2           | Yoke                      |
| 9           | 116-9117           | 1           | Pivot-Handle, Brake           | 28:2        | 116-9069           | 1           | Linkage, Rear             |
| 10          | 323-11             | 1           | Screw-HH 3/8-16 X 2 1/4       | 28:3        | 3220-1             | 1           | Nut-Jam 1/4-28            |
| 11          | 126-6199           | 4           | Bushing                       | 29          | 126-6200           | 2           | Spacer                    |
| 12          | 135-7800           | 1           | Shaft-Cross                   | 30          | 32120-19           | 2           | E-Ring                    |
| 13          | 135-7805           | 1           | ASM, Front Linkage            | 31          | 3230-2             | 2           | Bolt-Carriage 5/16-18 X 1 |
| 13:2        | 94-7572            | 1           | End-Tie Rod, RH               | 32          | 135-7915           | 2           | Screw-HH,                 |
| 13:3        | 3220-3             | 1           | Nut-Jam 3/8-24                | 33          | 112-0236           | 2           | Nut-Lock                  |
| 14          | 126-4251           | 2           | Bellcrank                     | 34          | 135-7890           | 2           | Screw-HH, Patch,          |
| 15          | 126-3716           | 1           | Arm-Inner, RH                 | 35          | 104-8301           | 1           | Nut-Nyloc 3/8-16 Flg      |
| 16          | 126-3715           | 1           | Arm-Inner, LH                 | 37          | 116-1399           | 2           | Locknut                   |
| 17          | 142-6328           | 2           | Mid-Link, Short               | 38          | 126-6395           | 4           | Pin-Clevis, Spring        |
| 18          | 104-8300           | 2           | Nut-Nyloc 5/16-18 Flg         | 39          | 142-2701           | 2           | Wheel Hub ASM             |
| 19          | 3256-23            | 4           | Washer-5/16 SAE               | 39:2        | 116-1696           | 4           | Stud-Wheel                |

# Attachments and Accessories

## For 72960 Z Master Professional 6000 Series Riding Mower with 60in TURBO FORCE Side Discharge Mower

| Product Name                                 | Model/Part |
|----------------------------------------------|------------|
| Turbo Baffle Kit .....                       | 107-1634   |
| Anti-Scalp Kit (Trim Side).....              | 108-4140   |
| Hitch Kit .....                              | 109-9487   |
| Hypr-Oil 500 (quart).....                    | 114-4713   |
| Hypr-Oil 500 (gallon).....                   | 114-4714   |
| Hypr-Oil 500-5 (5 gallon).....               | 114-4715   |
| Bimini Folding Shade Assembly .....          | 115-4510   |
| Roller Striper Kit.....                      | 115-7470   |
| Light Kit.....                               | 116-1154   |
| Seat Cover (W/arm rest) .....                | 117-0095   |
| Operator Controlled Discharge Chute Kit..... | 117-3600   |
| Z Stand Kit .....                            | 121-4811   |
| Seat Tilt Frame and ISO Mount Kit.....       | 121-7596   |
| Toro Rops Lock Kit.....                      | 126-4064   |
| Jack Mount Kit .....                         | 127-6665   |
| Jack Kit .....                               | 127-6666   |
| Power Deck Lift Kit .....                    | 132-5986   |
| Worklight Kit .....                          | 135-7320   |
| Bucket Mount Kit.....                        | 137-9216   |
| Trimmer Mount .....                          | 137-9769   |
| Recycler Kit .....                           | 139-6655   |
| 24x12n12 - Tweel Turf .....                  | 139-7891   |
| Blade-20.5 High Flow .....                   | 140-1240   |
| Blade-20.50 Atomic .....                     | 140-1241   |
| Blade-20.50 Medium Flow .....                | 140-4853   |
| Blade-20.50, Low Flow .....                  | 140-4854   |
| Blade-20.50 Recycler .....                   | 140-4855   |
| 6 Pack-Blade, 20.5 High Flow.....            | 140-4877   |
| 6 Pack-Blade, 20.5 Med Flow .....            | 140-4878   |
| 6 Pack-Blade, 20.5 Low Flow .....            | 140-4879   |
| 6 Pack-Blade, 20.5 Atomic.....               | 140-4880   |
| 6 Pack-Blade, 20.5 Recycler.....             | 140-4881   |
| Weight Kit, Under Toe Board.....             | 140-4958   |
| Blade-20.50 High Flow .....                  | 147-6252   |
| 6 Pack-Blade, 20.50 High Flow.....           | 147-6256   |
| Toro Rider Over Seat Bag .....               | 490-7317   |
| Toro Deluxe Rider Cover.....                 | 490-7319   |
| Toro Rider Arm Rest Bag .....                | 490-7320   |
| Spark Arrestor Screen .....                  | 75-6880    |
| Blower and Drive Kit .....                   | 78553      |
| E-Z Vac Triple Bagging System .....          | 78563      |
| E-Z Vac DFS Collection System .....          | 78567      |
| Filter Minder Gauge .....                    | 99-4664    |
| Trash Holder Kit.....                        | TC26       |

**Notes:**

**Notes:**

**Notes:**



**Count on it.**