



# 36in SFS Side Discharge Mower

Model No. 30135—2300000001 and Up

## Parts Catalog

### Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

### Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

### Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

### Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.

## Contents


| <b>Description</b>                      | <b>Page</b> | <b>Description</b>                         | <b>Page</b> |
|-----------------------------------------|-------------|--------------------------------------------|-------------|
| Decal and Deck Assembly .....           | 3           | Spindle Housing Assembly No. 27-0870 ..... | 6           |
| Carrier Frame and Caster Assembly ..... | 4           | Spindle Housing Assembly No. 54-7781 ..... | 7           |
| Spindle and Idler Assembly .....        | 5           |                                            |             |

## Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

| <b>Abbreviation</b> | <b>Meaning</b>                    | <b>Abbreviation</b> | <b>Meaning</b>          |
|---------------------|-----------------------------------|---------------------|-------------------------|
| AR .....            | as required                       | HYD .....           | hydraulic               |
| ASM .....           | assembly                          | INC .....           | incorporated            |
| CARR .....          | carriage                          | LH .....            | left hand               |
| DEG .....           | degrees                           | NI .....            | nylon insert            |
| FH .....            | flat head                         | PPH .....           | Phillips pan head       |
| GA .....            | gauge                             | PTH .....           | Phillips truss head     |
| HF .....            | hex flange                        | PTO .....           | power take off          |
| HH .....            | hex head                          | RH .....            | right hand              |
| HHF .....           | hex head flange                   | SFH .....           | slotted fillister head  |
| HLH .....           | hex lag head                      | SHH .....           | slotted hex head        |
| HJ .....            | hex jam                           | SQH .....           | square head             |
| HOC .....           | height-of-cut                     | SHWH .....          | slotted hex washer head |
| HS .....            | hex socket                        | SPH .....           | slotted pan head        |
| HSBH .....          | hex socket button head            | SRH .....           | slotted round head      |
| HSFH .....          | hex socket flat head              | STD .....           | standard                |
| HSH .....           | hex socket head                   | TAP .....           | self tapping            |
| HWH .....           | hex washer head                   | TTH .....           | Torx truss head         |
| HWHTF .....         | hex washer head<br>thread forming | WH .....            | wing head               |






Sheet No.:3

## Carrier Frame and Caster Assembly

| Ref. No. | Part No.    | Qty. | Description       |
|----------|-------------|------|-------------------|
| 1        | 74-0350     | 4    | Cushion-Rubber    |
| 4        | 17-5999-01  | 1    | Frame-Carrier     |
| 5        | 302-5       | 2    | Fitting-Grease    |
| 6        | 1-809020    | 2    | Pin               |
| 7        | 93-1166     | 2    | Spacer-Castor     |
| 8        | 100-6455-01 | 2    | Castor Fork ASM   |
| 9        | 32153-5     | 2    | Nut-Lock          |
| 11       | 100-6453    | 2    | Bushing-Spanner   |
| 12       | 100-6451    | 2    | Castor Wheel ASM  |
| 12:1     | 232-27      | 1    | Stem-Valve        |
| 12:2     | 302-11      | 1    | Fitting-Lube, 45° |
| 12:3     | 83-4740     | 1    | Bearing           |
| 12:4     | 62-5580     | 2    | Bearing-Outside   |
| 12:5     | 100-6452    | 1    | Tire-Tubeless     |
| 13       | 325-19      | 2    | Screw-HH          |
| 14       | 3-6781      | 8    | Washer-Thrust     |
| 15       | 256-156     | 2    | Bushing-Flange    |
| 16       | 74-0290     | 2    | Spring            |
| 17       | 41-8440     | 2    | Washer            |
| 18       | 3218-5      | 4    | Nut-Jam           |
| 19       | 3290-355    | 4    | Pin-Hair          |
| 20       | 74-0310     | 2    | Shaft-Adjusting   |
| 21       | 3296-45     | 2    | Nut-Lock, NI      |
| 22       | 283-55      | 4    | Pin-Clevis        |
| 23       | 85-7450     | 1    | Decal-HOC, LH     |
| 24       | 85-7460     | 1    | Decal-HOC, RH     |

| Ref. No. | Part No.   | Qty. | Description     |
|----------|------------|------|-----------------|
| 25       | 80-3340-01 | 1    | Weight-Front    |
| 26       | 322-12     | 2    | Screw-HH        |
| 27       | 3296-29    | 2    | Nut-Lock, NI    |
| 28       | 94-1291    | 4    | Bushing-Special |




Sheet No.:4

## Spindle and Idler Assembly

| Ref. No. | Part No.   | Qty. | Description         |
|----------|------------|------|---------------------|
| 1        | 3231-22    | 11   | Screw-CARR          |
| 2        | 32128-21   | 12   | Nut-HF              |
| 3        | 27-0870    | 1    | Spindle ASM         |
| 4        | 54-7781    | 1    | Spindle Housing ASM |
| 5        | 55-7660    | 1    | V-Belt              |
| 6        | 51-3530    | 1    | V-Belt-Drive, Deck  |
| 7        | 3296-29    | 2    | Nut-Lock, NI        |
| 8        | 56-4360    | 1    | Rod-Spring          |
| 9        | 3230-22    | 2    | Screw-CARR          |
| 10       | 51-3650    | 1    | Spring-Extension    |
| 11       | 323-12     | 1    | Screw-HH            |
| 12       | 3256-24    | 2    | Washer-Flat         |
| 13       | 51-3641    | 1    | Sleeve-Pivot, Idler |
| 14       | 56-4341-03 | 1    | Idler Arm ASM       |
| 15       | 51-3660    | 1    | Pulley-Idler        |
| 16       | 3211-5     | 1    | Screw-HH            |
| 17       | 3296-5     | 1    | Nut-Lock, NI        |

| Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|-------------|
|          |          |      |             |




T-3920  
Sheet No.:A1

## Spindle Housing Assembly No. 27-0870

| Ref. No. | Part No. | Qty. | Description        |
|----------|----------|------|--------------------|
| 1        | 106-0806 | 1    | Shaft ASM          |
| 2        | 302-2    | 1    | Fitting-Grease     |
| 4        | 46-8530  | 1    | Bearing ASM        |
| 5        | 27-0950  | 1    | Spacer             |
| 6        | 253-139  | 2    | Seal-Oil           |
| 7        | 61-4160  | 1    | Housing            |
| 8        | 27-0970  | 1    | Pulley And Hub ASM |
| 9        | 32146-20 | 1    | Nut-Jam            |
| 10       | 106-0776 | 1    | Washer- Pinion     |

| Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|-------------|
|          |          |      |             |



T-3919  
Sheet No.:A2

# Spindle Housing Assembly No. 54-7781

| Ref. No. | Part No.   | Qty. | Description         |
|----------|------------|------|---------------------|
| 1        | 253-139    | 2    | Seal-Oil            |
| 2        | 27-0950    | 1    | Spacer              |
| 3        | 27-0960    | 1    | Bearing ASM         |
| 4        | 27-5970    | 1    | Spacer-Set, Matched |
| 5        | 302-2      | 1    | Fitting-Grease      |
| 6        | 32146-20   | 1    | Nut-Jam             |
| 7        | 3253-7     | 1    | Washer-Lock         |
| 8        | 44-2200    | 1    | Screw-Blade         |
| 10       | 106-0800   | 1    | Spindle ASM         |
| 11       | 55-7610    | 1    | Pulley And Hub ASM  |
| 12       | 56-2390-03 | 1    | Blade               |
| 13       | 61-4160    | 1    | Housing             |
| 14       | 106-0776   | 1    | Washer- Pinion      |
| 15       | 72-9361    | 1    | Cup-Scalp, Anti     |

| Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|-------------|
|          |          |      |             |

