



52in SFS Side Discharge Mower

Model No. 30151 - 240000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


Contents

Description	Page	Description	Page
Deck and Spindle Assembly	 3	Carrier Frame Assembly	 7
Spindle Assembly No. 11-5769	 4	Castor Wheel and Tire Assembly	 8
Spindle Assembly 12-2549	 5		
Cover and Gage Wheel Assembly	 6		

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.


AR. as required	INC. incorporated
ASM. assembly	LH. left hand
CARR. carriage	NI. nylon insert
DEG. degrees	PPH. phillips pan head
FH. flat head	PTH. phillips truss head
GA. gauge	PTO. power take off
HF. hex flange	RH. right hand
HH. hex head	SFH. slotted fillister head
HHF. hex head flange	SHH. slotted hex head
HHFTF. hex head flange thread forming	SHWH. slotted hex washer head
HJ. hex jam	SPH. slotted pan head
HLH. hex lag head	SQH. square head
HOC. height-of-cut	SRH. slotted round head
HS. hex	STD. standard
HSBH. hex socket button head	TAP. self tapping
HSFH. hex socket flat head	TTH. torx truss head
HSH. hex socket head	WH. wing head
HWH. hex washer head	
HWHTF. hex washer head thread forming	
HYD. hydraulic	



Deck and Spindle Assembly


Ref	Part No.	Qty.	Description
1	106-0749	1	52in Deck ASM
1:2	43-8480	1	Decal-Danger
1:3	66-6380	1	Decal-Danger
1:4	67-5360	1	Decal-Danger
1:5	66-1340	1	Decal-Danger
1:6	68-8340	1	Decal-Torque
1:7	32148-10	2	Insert-Threaded
2	98-5967	1	Spacer-Wheel
3	68-2730	2	Wheel-Gage
4	3256-23	2	Washer-Flat
5	3296-29	2	Nut-Lock, NI
6	32128-21	21	Nut-HF
7	3211-8	1	Screw-HH
8	65-5950	1	Bushing-Pulley
9	65-5940	1	Pulley-Idler
10	51-3640	1	Sleeve
11	3256-24	8	Washer-Flat
12	323-11	1	Screw-HH
13	55-7650	1	Plate-Spring
14	51-3650	1	Spring-Extension
15	3296-5	3	Nut-Lock
16	55-7640-03	1	Idler Arm ASM
17	7-0081	1	Washer-Flat
18	55-7620	1	Guide-Belt

Ref	Part No.	Qty.	Description
19	52-4780	2	Rod-Belt
20	3231-22	20	Screw-CARR
22	105-4623	1	Deflector ASM
22:2	93-1122	1	Decal-Danger
23	105-4622	1	Spacer
24	104-8554	1	Spring-Torsion
29	11-5769	1	Spindle And Blade ASM
32	12-2549	1	Center Spindle And Blade ASM
33	322-50	2	Screw-HH




Spindle Assembly No. 11-5769

Ref	Part No.	Qty.	Description				
1	253-139	2	Seal-Oil				
2	27-0920	1	Shaft				
4	46-8530	1	Bearing ASM				
5	27-0970	1	Pulley And Hub ASM				
6	27-0990	1	Blade				
7	27-5970	1	Spacer-Set, Matched				
8	302-2	1	Fitting-Grease				
9	32146-20	1	Nut-Jam				
10	3253-27	1	Washer-Lock/sp				
11	44-2200	1	Screw-Blade				
13	61-4160	1	Housing-Spindle				
14	106-0776	1	Washer-Pinion				
15	72-9361	1	Cup-Scalp, Anti				




Spindle Assembly 12-2549

Ref	Part No.	Qty.	Description				
1	253-139	2	Seal-Oil				
3	46-8530	1	Bearing ASM				
4	27-0990	1	Blade				
5	27-5970	1	Spacer-Set, Matched				
6	302-2	1	Fitting-Grease				
7	32146-20	1	Nut-Jam				
8	3253-27	1	Washer-Lock/sp				
9	44-2200	1	Screw-Blade				
11	51-3551	1	Shaft-Spindle				
12	55-7610	1	Pulley And Hub ASM				
13	61-4160	1	Housing-Spindle				
14	106-0776	1	Washer-Pinion				
15	72-9361	1	Cup-Scalp, Anti				



Cover and Gage Wheel Assembly

Ref	Part No.	Qty.	Description				
1	51-3910-01	1	LH Cover ASM				
2	9266714	7	Screw-HWH				
3	3256-22	1	Washer-Flat				
4	62-6520	2	Knob				
5	82-5410-01	1	Cover-Center				
6	3256-24	10	Washer-Flat				
7	32151-72	2	Ring-Retaining				
8	51-3890-01	1	RH Cover ASM				
9	27-1160	1	V-Belt				
10	99-2843	1	V-Belt-Deck Drive				
11	3296-39	8	Nut-Lock, NI				
12	99-2842	4	Spacer				
13	68-2730	4	Wheel-Gage				
14	32148-10	2	Insert-Threaded				
15	106-0705	1	Decal				



Castor Wheel and Tire Assembly

Ref	Part No.	Qty.	Description
1	232-27	1	Stem-Valve
2	302-11	1	Fitting-Lube, 45 DEG
3	83-4740	1	Bearing
4	62-5580	2	Bearing-Outside
5	100-6452	1	Tire-Tubeless

NOTES

NOTES

NOTES

