




MODEL NO. 38072-8900001 & UP  
MODEL NO. 38073-8900001 & UP

# PARTS CATALOG

## 724 SNOWTHROWER



C-1278

## ENGINE ASSEMBLY


| Ref. No. | Part No. | Description                     | No. Used |
|----------|----------|---------------------------------|----------|
| 1        | 37-6900  | Cover - Belt                    | 1        |
| 2        | 43-7290  | Screw - Special                 | 1        |
| 3        | 74-1370  | Engine Pulley                   | 1        |
| 4        | 66-8060  | Molded Brake Asm.               | 1        |
| 5        | 3296-59  | Nut - Lock                      | 1        |
| 6        | 3-4244   | Idler Pulley                    | 1        |
| 7        | 3290-320 | Nut - Push On                   | 1        |
| 8        | 3256-24  | Washer - Flat                   | 1        |
| 9        | 3296-56  | Nut - Lock                      | 1        |
| 10       | 53-7570  | Spring - Auger Disengage        | 1        |
| 11       | 14-7959  | Auger Clutch<br>(Incl. Ref. #4) | 1        |
| 12       | 323-29   | Screw                           | 1        |
| 13       | 42-3560  | Bolt - Shoulder                 | 1        |

| Ref. No. | Part No. | Description                         | No. Used |
|----------|----------|-------------------------------------|----------|
| 14       |          | Engine                              | 1        |
| 15       | 63-2420  | Decal - Choke<br>(Model No. 38072)  | 1        |
| *        | 63-2430  | Decal - Choke<br>(Model No. 38073)  | 1        |
| 16       | 94-2572  | Decal - Primer<br>(Model No. 38073) | 1        |
| 17       | 63-2450  | Decal - Throttle                    | 1        |
| 18       | 66-6840  | Decal - Hot<br>(Model No. 38072)    | 1        |
| *        | 94-2576  | Decal - Hot<br>(Model No. 38073)    | 1        |
| 19       | 32144-4  | Screw - Self Tap.                   | 3        |
| 20       | 289-9    | Pipe Nipple                         | 1        |

\*Not Illustrated

© The TORO Company -1997  
All Rights Reserved

TPS




C-1278

## ENGINE ASSEMBLY (Continued)

| Ref. No. | Part No. | Description             | No. Used |
|----------|----------|-------------------------|----------|
| 21       | 288-2    | Cap                     | 1        |
| 22       | 3296-29  | Nut - Lock              | 4        |
| 23       | 3256-23  | Washer - Flat           | 5        |
| 24       | 322-4    | Screw                   | 4        |
| 25       | 37-8990  | Retainer - Belt         | 1        |
| 26       | 3255-8   | Washer -Lock Ext. Tooth | 1        |
| 27       | 3210-3   | Screw                   | 1        |

| Ref. No. | Part No. | Description       | No. Used |
|----------|----------|-------------------|----------|
| 28       | 37-9090  | V-Belt - Traction | 1        |
| 29       | 26-9672  | V-Belt - Auger    | 1        |
| †30      | 42-671   | Screw             | 3        |
| †31      | 36-180   | Washer - Lock     | 3        |
| †32      | 36-195-1 | Washer - Flat     | 3        |
| †33      | 127-19   | Guard - Muffler   | 1        |


† Order these parts from Tecumseh



# AUGER ASSEMBLY

| Ref. No. | Part No. | Description                                           | No. Used | Ref. No. | Part No. | Description                                                | No. Used |
|----------|----------|-------------------------------------------------------|----------|----------|----------|------------------------------------------------------------|----------|
| 1        | 94-2786  | Housing—Auger<br>(Model No. 38072)<br>(Incl. Ref. #3) | 1        | 14       | 3-0737   | Washer                                                     | 1        |
| *        | 94-2785  | Housing—Auger<br>(Model No. 38073)<br>(Incl. Ref. #3) | 1        | 15       | 3257-23  | Key                                                        | 1        |
| 2        | 74-1600  | Auger — R.H.                                          | 1        | 16       | 37-6890  | Pulley                                                     | 1        |
| *        | 74-1590  | Auger — L.H.                                          | 1        | 17       | 3242-4   | Screw — Set                                                | 2        |
| 3        | 53-7670  | Decal — Auger Warning<br>(Model No. 38072)            | 1        | 18       | 56-2680  | Deflector                                                  | 1        |
| *        | 94-2568  | Decal — Auger Warning<br>(Model No. 38073)            | 1        | 19       | 3230-22  | Bolt — Carriage                                            | 2        |
| 4        | 37-6990  | Shaft & Impeller                                      | 1        | 20       | 56-2670  | Chute — Wire                                               | 1        |
| 5        | 3230-18  | Bolt — Carriage                                       | 6        | 21       | 94-2793  | Chute — Discharge<br>(Model No. 38072)<br>(Incl. Ref. #22) | 1        |
| 6        | 26-6120  | Flange — Bearing Front                                | 1        | *        | 94-2792  | Chute — Discharge<br>(Model No. 38073)<br>(Incl. Ref. #22) | 1        |
| 7        | 63-3450  | Bearing — Ball                                        | 1        | 22       | 94-8079  | Decal — Discharge<br>(Model No. 38072)                     | 1        |
| 8        | 26-6110  | Flange — Bearing Rear                                 | 1        | *        | 94-2558  | Decal — Discharge<br>(Model No. 38073)                     | 1        |
| 9        | 3296-29  | Nut — Lock                                            | 13       | 23       | 3256-23  | Washer                                                     | 3        |
| 10       | 3290-340 | Washer — Belleville                                   | 2        | 25       | 37-6490  | Retainer — Chute Ring                                      | 3        |
| 11       | 3256-68  | Washer — Flat                                         | 2        | 26       | 32144-70 | Screw — Self Tap.                                          | 4        |
| 12       | 55-8950  | Plate — Friction                                      | 2        | 28       | 27-0220  | Screw — Self Tap.                                          | 6        |
| 13       | 20-4320  | Washer — Rubber                                       | 2        |          |          |                                                            |          |

\*Not Illustrated




C-0031

## AUGER ASSEMBLY (Continued)

| Ref. No. | Part No. | Description                             | No. Used |
|----------|----------|-----------------------------------------|----------|
| 29       | 3290-326 | Pushnut                                 | 1        |
| 30       | 37-8941  | Ring - Chute                            | 1        |
| 31       | 40-8160  | Skid                                    | 2        |
| 32       | 32128-20 | Nut - Flange                            | 4        |
| 33       | 32151-36 | Ring - Retaining                        | 2        |
| 34       | 5-1550   | Washer - Thrust                         | 4        |
| 35       | 37-6550  | Bearing - Auger                         | 2        |
| 36       | 74-1420  | Blade - Scraper                         | 1        |
| 37       | 3296-42  | Nut - Lock                              | 2        |
| 38       | 321-10   | Screw                                   | 2        |
| 39       | 3257-33  | Key - Woodruff                          | 1        |
| 40       | 14-2459  | Gear Case L.H.<br>(Incl. Ref. #53 & 54) | 1        |
| 41       | 281-1    | Pipe - Plug                             | 1        |
| 42       | 252-71   | Bearing - Thrust                        | 2        |
| 43       | 5-7180   | Gear                                    | 1        |
| 44       | 257-3    | Washer - Thrust                         | 1        |
| 45       | 252-76   | Bearing - Needle, Thrust                | 1        |
| 46       | 5-7170   | Gear - Worm                             | 1        |

| Ref. No. | Part No. | Description                             | No. Used |
|----------|----------|-----------------------------------------|----------|
| 47       | 3-8664   | Washer                                  | 1        |
| 48       | 32120-72 | Ring - Retaining                        | 1        |
| 49       | 256-32   | Bushing                                 | 1        |
| 50       | 252-80   | Washer - Thrust                         | 1        |
| 51       | 51-0460  | Gasket                                  | 1        |
| 52       | 14-2449  | Gear Case R.H.<br>(Incl. Ref. #53 & 54) | 1        |
| 53       | 256-237  | Bushing                                 | 2        |
| 54       | 7-0045   | Seal - Oil                              | 2        |
| 55       | 37-6801  | Shaft - Auger                           | 1        |
| 56       | 32144-41 | Screw - Self Tap.                       | 8        |
| 57       | 37-6560  | Bushing - Input                         | 1        |
| 58       | 237-87   | Seal                                    | 1        |
| 59       | 3257-23  | Key - Woodruff                          | 1        |
| 60       | 3230-1   | Bolt - Carriage                         | 9        |
| *        | 37-6961  | Gear Case Asm.                          | 1        |
| *        | 12-8789  | Bearing Assembly<br>(Incl. Ref. #6-8)   | 1        |

\*Not Illustrated




C-2371

## TRACTION ASSEMBLY

| Ref. No. | Part No.  | Description              | No. Used |
|----------|-----------|--------------------------|----------|
| 1        | 88-0850   | Pulley & Shaft           | 1        |
| 2        | 32151-103 | Ring - Snap              | 1        |
| 3        | 252-80    | Washer - Thrust          | 1        |
| 4        | 12-3270   | Screw - Tapping          | 8        |
| 5        | 88-0550   | Frame - Friction Plate   | 1        |
| 6        | 256-322   | Bushing                  | 1        |
| 7        | 66-6790   | Mount - Clutch Rod Front | 1        |
| 8        | 32144-70  | Screw - Self Tap.        | 5        |
| 9        | 88-0560   | Hub - Frame              | 1        |
| 10       | 38-7820   | Bearing                  | 1        |
| 11       | 37-9070   | Mount - Clutch Rod Rear  | 1        |
| 12       | 37-8900   | Frame - Traction         | 1        |
| 13       | 38-0800   | Plate - Friction         | 1        |
| 14       | 37-8770   | Bolt - Shoulder          | 2        |

| Ref. No. | Part No. | Description                 | No. Used |
|----------|----------|-----------------------------|----------|
| 15       | 3296-29  | Nut - Lock                  | 6        |
| 16       | 32144-4  | Screw - Self Tap.           | 6        |
| 17       | 37-6830  | Cover - Bottom              | 1        |
| 18       | 231-120  | Tire                        | 2        |
| 19       | 3290-243 | Pin - Klik                  | 2        |
| 20       | 241-131  | Rim                         | 2        |
| 21       | 232-46   | Tube                        | 2        |
| 22       | 74-1350  | Shaft - Axle                | 1        |
| 23       | 37-6850  | Bearing - Axle              | 2        |
| 24       | 32121-31 | Pin - Roll                  | 2        |
| 25       | 37-8870  | Spring-Friction Plate Frame | 1        |
| 26       | 322-2    | Screw - Hex. Hd.            | 6        |
| 27       | 37-6520  | Gear - Axle                 | 1        |
| 28       | 3-8664   | Washer - Thrust             | 2        |




C-2372

## TRACTION ASSEMBLY (Continued)

| Ref. No. | Part No. | Description                                    | No. Used |
|----------|----------|------------------------------------------------|----------|
| 1        | 32144-70 | Screw — Self Tap.                              | 4        |
| 2        | 37-6500  | Gear — Sliding                                 | 1        |
| 3        | 256-86   | Bushing                                        | 1        |
| 4        | 20-1620  | Bearing — Friction Wheel                       | 2        |
| 5        | 39-1230  | Bracket — Sliding                              | 1        |
| 6        | 37-8880  | Spring — Traction Engage                       | 1        |
| 7        | 322-2    | Screw — Hex. Hd.                               | 4        |
| 8        | 37-9160  | Intermediate Gear & Bushing<br>(Incl. Ref. #4) | 1        |
| 9        | 10-9280  | Washer — Thrust                                | 2        |
| 10       | 37-8790  | Mount — Quadrant Gear                          | 1        |
| 11       | 3296-29  | Nut — Lock                                     | 1        |
| 12       | 3296-16  | Nut — Lock                                     | 1        |
| 13       | 37-8800  | Quadrant — Gear                                | 1        |
| 14       | 37-8770  | Bolt — Shoulder                                | 1        |
| 15       | 39-1250  | Cam — Receiver                                 | 1        |
| 16       | 321-4    | Screw — Hex. Hd.                               | 1        |
| 17       | 36-4790  | Washer — Thrust                                | 2        |

| Ref. No. | Part No. | Description                | No. Used |
|----------|----------|----------------------------|----------|
| 18       | 37-6570  | Wheel — Friction           | 1        |
| 19       | 39-1520  | Hub — Friction Wheel Mount | 1        |
| 20       | 3296-48  | Nut — Lock                 | 1        |
| 21       | 37-6760  | Shaft — Pivot              | 1        |
| 22       | 32121-45 | Pin — Roll                 | 2        |
| 23       | 3257-24  | Key                        | 1        |
| 24       | 5-7570   | Washer — Thrust            | 2        |
| 25       | 37-6780  | Shaft — Hex                | 1        |
| 26       | 32128-33 | Nut — Flange               | 2        |
| 27       | 39-3060  | Rod — Lower Traction       | 1        |
| 28       | 38-4520  | Spring — Compression       | 1        |
| 29       | 32128-32 | Nut — Flange               | 1        |
| 30       | 38-4490  | Bracket — Traction         | 1        |
| 31       | 40-9680  | Spacer                     | 1        |
| 32       | 40-8350  | Screw — Shoulder           | 1        |
| 33       | 3296-42  | Nut — Lock                 | 1        |
| 34       | 43-7310  | Traction Engagement Asm.   | 1        |
| 35       | 32151-61 | Ring — Retaining           | 1        |






C-2373

## HANDLE ASSEMBLY RIGHT SIDE

| Ref. No. | Part No. | Description                         | No. Used |
|----------|----------|-------------------------------------|----------|
| 1        | 52-5561  | Handle - Right<br>(Model No. 38072) | 1        |
| *        | 52-5560  | Handle - Right<br>(Model No. 38073) | 1        |
| 2        | 52-5590  | Link - Upper                        | 1        |
| 3        | 74-1490  | Rod - Speed Selector                | 1        |
| 4        | 3272-4   | Pin - Cotter                        | 3        |
| 5        | 283-3    | Pin - Clevis                        | 1        |
| 6        | 39-3080  | Clevis                              | 1        |
| 7        | 3218-1   | Nut - Jam                           | 1        |
| 8        | 32115-5  | Retainer - Nut                      | 1        |
| 9        | 3256-23  | Washer                              | 4        |
| 10       | 43-7360  | Panel - Escutcheon                  | 1        |
| 11       | 94-9876  | Decal - 724                         | 1        |
| 12       | 32128-13 | Nut - Flange Lock                   | 1        |
| 13       | 37-9150  | Spring                              | 1        |

| Ref. No. | Part No. | Description             | No. Used |
|----------|----------|-------------------------|----------|
| 14       | 40-8130  | Spacer - Speed Selector | 1        |
| 15       | 3229-11  | Bolt - Carriage         | 2        |
| 16       | 233-21   | Knob                    | 1        |
| 17       | 37-8821  | Selector - Speed        | 1        |
| 18       | 3234-13  | Screw - Hex. Flange Hd. | 1        |
| 19       | 32151-73 | Ring - Clip             | 1        |
| 20       | 3256-24  | Washer                  | 1        |
| 21       | 63-3640  | Handle - Control        | 1        |
| 22       | 74-1360  | Grip - Handle           | 1        |
| 23       | 47-4990  | Post - Linkage Mounting | 1        |
| 24       | 52-5600  | Pin - Control Lever     | 1        |
| 25       | 39-1280  | Mount - Speed Selector  | 1        |
| 26       | 322-7    | Screw                   | 1        |
| 27       | 32128-33 | Nut - Flange Lock       | 2        |
| *        | 3290-378 | Cable Tie               | 1        |

\*Not Illustrated



C-2375


## HANDLE ASSEMBLY LEFT SIDE

| Ref. No. | Part No. | Description                                | No. Used |
|----------|----------|--------------------------------------------|----------|
| 1        | 40-8270  | Rod - Chute Control                        | 1        |
| 2        | 52-5590  | Link - Upper                               | 1        |
| 3        | 17-9120  | Mount - Wire                               | 3        |
| 4        |          | Panel - Escutcheon Ref.                    |          |
| 5        | 66-6830  | Decal - Escutcheon Back (Model No. 38072 ) | 1        |
| *        | 94-2563  | Decal - Escutcheon Back (Model No. 38073)  | 1        |
| 6        | 40-5940  | Switch - On/Off                            | 1        |
| 7        | 63-8360  | Key - Ignition                             | 1        |
| 8        | 52-5600  | Pin - Control Lever                        | 1        |
| 9        | 47-4990  | Post - Linkage Mounting                    | 1        |
| 10       | 3256-24  | Washer                                     | 1        |
| 12       | 63-3640  | Handle - Control                           | 1        |
| 13       | 3234-13  | Screw - Hex. Flange Hd.                    | 1        |
| 14       | 74-1360  | Grip - Handle                              | 1        |
| 15       | 52-5571  | Handle - Left (Model No. 38072)            | 1        |
| *        | 52-5570  | Handle - Left (Model No. 38073)            | 1        |

| Ref. No. | Part No. | Description                                   | No. Used |
|----------|----------|-----------------------------------------------|----------|
| 16       | 321-9    | Screw - Hex. Head                             | 2        |
| 17       | 3296-42  | Nut - Lock                                    | 2        |
| 18       | 3290-320 | Nut - Push                                    | 2        |
| 19       | 40-8230  | Grip - Rod                                    | 1        |
| 20       | 63-3510  | Decal - Chute Direction                       | 1        |
| 21       | 12-7739  | Bracket - Chute Control (Incl. Ref.# 20 & 22) | 1        |
| 22       | 256-249  | Nyliner                                       | 1        |
| 23       | 322-7    | Screw - Hex. Hd.                              | 1        |
| 24       | 3296-29  | Nut - Lock                                    | 2        |
| 25       | 43-7390  | Wire Harness Asm. (Incl. Ref.# 3)             | 1        |
| 26       | 322-2    | Screw - Hex. Hd.                              | 4        |
| 27       | 3290-456 | Washer - Belleville                           | 4        |
| 28       | 3290-196 | Retainer - Nut                                | 4        |
| 29       | 3230-22  | Bolt - Carriage                               | 1        |
| 30       | 3290-238 | Washer - Pyramidal                            | 1        |
| 31       | 40-8280  | Bracket - Chute Worm                          | 1        |
| 32       | 40-8250  | Gear - Worm                                   | 1        |
| *        | 3290-378 | Cable Tie                                     | 1        |

\*Not Illustrated






## CARBURETOR NO. 640082

| Ref. No. | Part No. | Description                              | No. Used |
|----------|----------|------------------------------------------|----------|
| 1        | 31834    | Shaft & Lever Assembly                   | 1        |
| 2        | 631767   | Spring – Throttle Return                 | 1        |
| 6        | 640070   | Shutter – Throttle                       | 1        |
| 7        | 650506   | Screw                                    | 2        |
| 15       | 630735   | Spring – Choke Stop                      | 1        |
| 16       | 632164   | Fitting – Fuel Inlet                     | 1        |
| 17       | 651025   | Screw – Idle                             | 1        |
| 18       | 630766   | Spring – Idle Screw                      | 2        |
| 20       | 640018   | Screw – Idle Restrictor                  | 1        |
| 20A      | 640053   | Screw – Idle Restrictor Cap              | 1        |
| 25       | 631951   | Bowl – Assembly<br>(Incl. Ref. #32 & 33) | 1        |
| 27       | 631024   | Shaft – Float                            | 1        |
| 28       | 632019   | Float – Carburetor                       | 1        |
| 29       | 631028   | Gasket – Bowl-to-Body                    | 1        |

| Ref. No. | Part No. | Description                                    | No. Used |
|----------|----------|------------------------------------------------|----------|
| 30       | 631021   | Inlet Needle – Seat & Clip<br>(Incl. Ref. #31) | 1        |
| 31       | 631022   | Clip – Inlet Needle                            | 1        |
| 32       | 27136A   | Drain Assembly – Bowl)                         | 1        |
| 33       | 27554    | Gasket – Bow Drain                             | 1        |
| 36       | 632735   | Tube – Main Nozzle                             | 1        |
| 37       | 632547   | O-Ring – Main Nozzle Tube                      | 1        |
| 40       | 640083   | Nut – High Speed Bowl                          | 1        |
| 44       | 27110    | Washer – Bowl Nut                              | 1        |
| 47       | 630748   | Welch Plug – Idle Mix Well                     | 1        |
| 48       | 631027   | Welch Plug – Atmospheric Vent                  | 1        |
| *        | 640082   | Carburetor<br>(Incl. Ref. #1-48)               | 1        |

Note: Order individual parts from your local Tecumseh dealer.  
 \* Not Illustrated

# ENGINE TECUMSEH MODEL HSK70—130282U




# ENGINE TECUMSEH MODEL HSK70-130282U

| Ref. No. | Part No. | Description                                       | No. Used | Ref. No. | Part No. | Description                                      | No. Used |
|----------|----------|---------------------------------------------------|----------|----------|----------|--------------------------------------------------|----------|
| 1        | 32586C   | Cylinder<br>(Incl. Ref. #2,20 & 72)               | 1        | 86       | 650488   | Screw                                            | 7        |
| 2        | 27652    | Dowel Pin                                         | 2        | 87       | 650493   | Screw                                            | 1        |
| 15       | 30699C   | Governor Rod<br>(Incl. Ref. #15A & 15B)           | 1        | 89       | 32589    | Flywheel Key                                     | 1        |
| 15A      | 30700    | Governor Yoke                                     | 1        | 90       | 611085   | Flywheel                                         | 1        |
| 15B      | 650494   | Screw                                             | 1        | 92       | 650815   | Belleville Washer                                | 1        |
| 16       | 33454    | Governor Lever                                    | 1        | 93       | 8116     | Flywheel Nut                                     | 1        |
| 17       | 29916    | Governor Lever Clamp                              | 1        | 100      | 34443B   | Solid State Ignition                             | 1        |
| 18       | 651028   | Screw                                             | 1        | 101      | 610118   | Spark Plug Cover                                 | 1        |
| 19       | 34663    | Speed Control Spring                              | 1        | 102      | 651024   | Solid State Mounting Stud                        | 2        |
| 20       | 32630    | Oil Seal                                          | 1        | 103      | 651007   | Screw, Torx T-15                                 | 2        |
| 25       | 36460    | Blower Housing Baffle                             | 1        | 110      | 35253    | Ground Wire                                      | 1        |
| 26       | 650561   | Screw                                             | 2        | *119     | 36453    | Cylinder Head Gasket                             | 1PK      |
| 28       | 30322    | Lock Nut                                          | 1        | 120      | 36446    | Cylinder Head<br>(Incl. 3 of 131)                | 1        |
| 30       | 35272    | Crankshaft                                        | 1        | 125      | 27878A   | Exhaust Valve<br>(Std.) (Incl. Ref. #151)        | 1        |
| 35       | 29826    | Screw                                             | 1        | 125      | 27880A   | Exhaust Valve<br>(1/32" OS) (Incl. Ref. #151)    | 1        |
| 36       | 29918    | Lock Washer                                       | 1        | 126      | 32784    | Intake Valve<br>(1/32" OS) (Incl. Ref. #151)     | 1        |
| 37       | 29216    | Lock Nut                                          | 1        | 126      | 32783    | Intake Valve<br>(Std.) (Incl. Ref. #151)         | 1        |
| 38       | 29642    | Retaining Ring                                    | 1        | 127      | 650691   | Washer                                           | 3        |
| 40       | 34517    | Piston, Pin & Ring Set<br>(.010" OS)              | 1        | 128      | 650690   | Belleville Washer                                | 3        |
| 40       | 34518    | Piston, Pin & Ring Set<br>(.020" OS)              | 1        | 130      | 650697A  | Screw                                            | 2        |
| 40       | 34519    | Piston, Pin & Ring Set<br>(Std.)                  | 1        | 130A     | 650697A  | Screw                                            | 3        |
| 41       | 32592B   | Piston & Pin Ass'y<br>(.010" OS) (Incl. Ref. #43) | 1        | 130B     | 650697A  | Screw                                            | 3        |
| 41       | 32593B   | Piston & Pin Ass'y<br>(.020" OS) (Incl. Ref. #43) | 1        | 135      | 35395    | Resistor Spark Plug<br>(RJ19LM)                  | 1        |
| 41       | 32594B   | Piston & Pin Ass'y<br>(Std.) (Incl. Ref. #43)     | 1        | 139      | 31843A   | Governor Gear Bracket                            | 1        |
| 42       | 34595    | Ring Set<br>(Std.)                                | 1        | 140      | 650965   | Screw, Torx T-25                                 | 2        |
| 42       | 34596    | Ring Set<br>(.020" OS)                            | 1        | 149      | 27882    | Valve Spring Cap                                 | 2        |
| 42       | 34597    | Ring Set<br>(.010" OS)                            | 1        | 150      | 27881    | Valve Spring                                     | 2        |
| 43       | 27888    | Piston Pin Retaining Ring                         | 2        | 151      | 32581    | Valve Spring Keeper                              | 2        |
| 45       | 32591C   | Connecting Rod Ass'y<br>(Incl. Ref. #46 & 49)     | 1        | *169     | 27896A   | Valve Cover Gasket                               | 2PK      |
| 46       | 650662C  | Connecting Rod Bolt                               | 2        | 170      | 28423    | Breather Body                                    | 1        |
| 48       | 34034    | Valve Lifter                                      | 2        | 171      | 28424    | Breather Element                                 | 1        |
| 49       | 34242    | Oil Dipper                                        | 1        | 172      | 28425    | Valve Cover                                      | 1        |
| 50       | 32115    | Camshaft (MCR)                                    | 1        | 173      | 35350    | Breather Tube                                    | 1        |
| 60       | 30622A   | Blower Housing Extension                          | 1        | 174      | 650128   | Screw                                            | 2        |
| 61       | 34126    | Grommet Mounting Bracket                          | 1        | 182      | 650517   | Screw                                            | 2        |
| 62       | 650760   | Screw                                             | 1        | 183      | 32398    | Choke Bracket                                    | 1        |
| 63       | 28545    | Grommet                                           | 1        | *184     | 31688A   | Carburetor To Intake Pipe<br>Gasket              | 1PK      |
| 65       | 650128   | Screw                                             | 1        | 186      | 34661    | Governor Link                                    | 1        |
| 69       | 30684    | Cylinder Cover Gasket                             | 1PK      | 200      | 34677    | Control Bracket<br>(Incl. Ref. #203, 204, & 206) | 1        |
| *70      | 31303C   | Cylinder Cover<br>(Incl. Ref. #71, 75, & 80)      | 1        | 203      | 31342    | Compression Spring                               | 1        |
| 71       | 31546    | Crankshaft Bushing                                | 1        | 204      | 651029   | Screw                                            | 1        |
| 72       | 27642    | Oil Drain Plug                                    | 2        | 206      | 610973   | Terminal                                         | 1        |
| 75       | 28427    | Oil Seal                                          | 1        | 207      | 34662    | Throttle Link                                    | 1        |
| 80       | 31845    | Governor Shaft                                    | 1        | 209      | 650821   | Screw                                            | 2        |
| 81       | 30590A   | Washer                                            | 1        | 215      | 35440    | Control Knob                                     | 1        |
| 82       | 30591    | Governor Gear Ass'y                               | 1        | 220      | 35439    | Control Knob                                     | 1        |
| 83       | 30588A   | Governor Spool                                    | 1        | 222      | 28820    | Screw                                            | 2        |
| 84       | 29193    | Retaining Ring                                    | 1        | *224     | 27915A   | Intake Pipe Gasket                               | 1PK      |
|          |          |                                                   |          | 260      | 36254    | Blower Housing                                   | 1        |
|          |          |                                                   |          | 262      | 29747B   | Screw, Torx T-40                                 | 2        |
|          |          |                                                   |          | 264A     | 30196    | Screw                                            | 1        |
|          |          |                                                   |          | 265      | 30939A   | Cylinder Head Cover                              | 1        |
|          |          |                                                   |          | 272      | 30196    | Screw                                            | 2        |

Note: Order individual parts from your local Tecumseh dealer.

\*Included in Gasket Set Ref. #400.

# ENGINE TECUMSEH MODEL HSK70—130282U




# ENGINE TECUMSEH MODEL HSK70—130282U

| Ref. No. | Part No. | Description             | No. Used | Ref. No. | Part No. | Description            | No. Used |
|----------|----------|-------------------------|----------|----------|----------|------------------------|----------|
| 273      | 34712    | Carburetor Flange       | 1        | 334      | 650257   | Screw                  | 2        |
| 274      | 35865    | Exhaust Manifold Gasket | 1PK      | 335      | 35060    | Carburetor Cover       | 1        |
| 275      | 32401    | Muffler                 | 1        | 336      | 650765   | Screw                  | 1        |
| 277      | 650694A  | Screw                   | 1        | 338      | 650760   | Screw                  | 1        |
| 279B     | 26073    | Washer                  | 1        | 340      | 34159    | Fuel Tank Bracket      | 1        |
| 281      | 33013    | Starter Bubble Cover    | 1        | 341      | 34158    | Fuel Tank Bracket      | 1        |
| 282      | 650760   | Screw                   | 1        | 342      | 650561   | Screw                  | 1        |
| 285      | 35287B   | Starter Cup             | 1        | 350      | 570682   | Primer Ass'y           | 1        |
| 287      | 650926   | Screw                   | 3        | 351      | 32180C   | Primer Line            | 1        |
| 290      | 29774    | Fuel Line               | 1        | 355      | 590574   | Starter Handle         | 1        |
| 291      | 30962    | Fule Line               | 1        | 370      | 36261    | Instruction Decal      | 1        |
| 292      | 26460    | Fuel Line Clamp         | 4        | 370K     | 36695    | Starter Decal          | 1        |
| 295      | 35857    | Fuel Shut—Off Valve     | 1        | 380      | 640084   | Carburetor             |          |
| 298      | 650665   | Screw                   | 2        |          |          | (Incl. Ref. #184)      | 1        |
| 299      | 650764   | "U" Type Nut            | 1        | 390      | 590742   | Rewind Starter         | 1        |
| 300      | 34186A   | Fuel Tank               |          | 396      | 33328D   | Electric Starter Motor |          |
|          |          | (Incl. Ref. #292 & 301) | 1        |          |          | (Optional)             | 1        |
| 301      | 36246    | Fuel Cap                | 1        | 400      | 33239A   | Gasket Set             | 1        |
| 305      | 35554    | Oil Fill Tube           | 1        | 420      | 730225   | Sae 30 4—Cycle Engine  |          |
| 307      | 35499    | "O" Ring                | 1        |          |          | Oil (Quart)            | 1        |
| 308      | 35540    | Fill Tube Clip          | 1        | 453      | 29538    | Engine Mounting Base   | 1        |
| 310      | 36205    | Dipstick                | 1        | 454      | 650542   | Screw                  | 4        |
| 325      | 29443    | Wire Clip               | 1        |          |          |                        |          |

Note: Order individual parts from your local Tecumseh dealer.

\*Included in Gasket Set Ref. #400.




**RECOIL STARTER NO. 590742**

| Ref. No. | Part No. | Description                 | No. Used | Ref. No. | Part No. | Description          | No. Used |
|----------|----------|-----------------------------|----------|----------|----------|----------------------|----------|
| 3        | 590740   | Retainer                    | 1        | 11       | 590647   | Starter Housing Asm. | 1        |
| 6        | 590616   | Starter Dog                 | 2        | 12       | 590535   | Starter Rope         | 1        |
| 7        | 590617   | Dog Spring                  | 2        | 13       | 590574   | Mitten Grip Handle   | 1        |
| 8        | 590645A  | Pulley & Rewind Spring Asm. | 1        | 14       | 590741   | Locking Tab          | 1        |

Note: Order individual parts from your local Tecumseh dealer.





C-1772

## ELECTRIC STARTER KIT NO. 38-7590 (OPTIONAL)

| Ref. No. | Part No. | Description                              | No. Used |
|----------|----------|------------------------------------------|----------|
| 1        | 33842    | Ring - Retainer                          | 1        |
| 2        | 33430    | Retainer - Spring                        | 1        |
| 3        | 33431    | Spring - Anti-Drift                      | 1        |
| 5A       | 35913    | Gear & Nut (Incl. Ref. #1)               | 1        |
| 6        | 35449    | Cap Assembly - Drive End (Incl. Ref. #7) | 1        |
| 7        | 35450    | "O" Ring                                 | 2        |
| 8        | 35914    | Armature                                 | 1        |
| 9        | 35457A   | Housing Assembly                         | 1        |
| 10       | 35452A   | Card Assembly - Brush                    | 1        |
| 11       | 35911    | Washer - Thrust                          | 1        |
| 13       | 590500   | Washer - Thrust                          | 1        |

| Ref. No. | Part No. | Description                               | No. Used |
|----------|----------|-------------------------------------------|----------|
| 14       | 33441    | Screw - Ground                            | 1        |
| 15       | 35453    | Cap Assy., Commutator End (Incl. Ref. #7) | 1        |
| 16       | 35454    | Box Assembly - Switch (Incl. Ref. #26)    | 1        |
| 22       | 35458    | Bolt - Case                               | 2        |
| 23       | 35456    | Screw - Grounding                         | 1        |
| 24       | 33451    | Cover - Dust                              | 1        |
| 26       | 650819   | Screw - Hex. Hd.                          | 2        |
| 29       | 32450B   | Cord - Extension, 10' 6"                  | 1        |
| 30       | 30063    | Screw - Hex. Hd.                          | 4        |
| *        | 730623   | Switch Repair Kit                         | 1        |

Note: Order individual parts from your local Tecumseh dealer.

# TORO PART NUMBER INDEX

| Part No. | Description                 | Pg. Ref.<br>No. No. Qty. | Part No. | Description              | Pg. Ref.<br>No. No. Qty. |
|----------|-----------------------------|--------------------------|----------|--------------------------|--------------------------|
| 3-0737   | Washer                      | 3 14 1                   | 42-671   | Screw                    | 2 30 3                   |
| 3-4244   | Idler Pulley                | 1 6 1                    | 42-3560  | Bolt — Shoulder          | 1 13 1                   |
| 3-8664   | Washer                      | 4 47 1                   | 43-7290  | Screw — Special          | 1 2 1                    |
| 3-8664   | Washer — Thrust             | 5 28 2                   | 43-7310  | Traction Engagement Asm. | 6 34 1                   |
| 5-1550   | Washer — Thrust             | 4 34 4                   | 43-7360  | Panel — Escutcheon       | 7 10 1                   |
| 5-7170   | Gear — Worm                 | 4 46 1                   | 43-7390  | Wire Harness Asm.        | 8 25 1                   |
| 5-7180   | Gear                        | 4 43 1                   | 47-4990  | Post — Linkage Mounting  | 8 9 1                    |
| 5-7570   | Washer — Thrust             | 6 24 2                   | 47-4990  | Post — Linkage Mounting  | 7 23 1                   |
| 7-0045   | Seal — Oil                  | 4 54 2                   | 51-0460  | Gasket                   | 4 51 1                   |
| 10-9280  | Washer — Thrust             | 6 9 2                    | 52-5560  | Handle — Right           | 7 * 1                    |
| 12-3270  | Screw — Tapping             | 5 4 8                    | 52-5561  | Handle — Right           | 7 1 1                    |
| 12-7739  | Bracket — Chute Control     | 8 21 1                   | 52-5570  | Handle — Left            | 8 * 1                    |
| 12-8789  | Bearing Assembly            | 4 * 1                    | 52-5571  | Handle — Left            | 8 15 1                   |
| 14-2449  | Gear Case R.H.              | 4 52 1                   | 52-5590  | Link — Upper             | 7 2 1                    |
| 14-2459  | Gear Case L.H.              | 4 40 1                   | 52-5590  | Link — Upper             | 8 2 1                    |
| 14-7959  | Auger Clutch                | 1 11 1                   | 52-5600  | Pin — Control Lever      | 8 8 1                    |
| 17-9120  | Mount — Wire                | 8 3 3                    | 52-5600  | Pin — Control Lever      | 7 24 1                   |
| 20-1620  | Bearing — Friction Wheel    | 6 4 2                    | 53-7570  | Spring — Auger Disengage | 1 10 1                   |
| 20-4320  | Washer — Rubber             | 3 13 2                   | 53-7670  | Decal — Auger Warning    | 3 3 1                    |
| 26-6110  | Flange — Bearing Rear       | 3 8 1                    | 55-8950  | Plate — Friction         | 3 12 2                   |
| 26-6120  | Flange — Bearing Front      | 3 6 1                    | 56-2670  | Chute — Wire             | 3 20 1                   |
| 26-9672  | V-Belt — Auger              | 2 29 1                   | 56-2680  | Deflector                | 3 18 1                   |
| 27-0220  | Screw — Self Tap.           | 3 28 6                   | 63-2420  | Decal — Choke            | 1 15 1                   |
| 36-180   | Washer — Lock               | 2 31 3                   | 63-2430  | Decal — Choke            | 1 * 1                    |
| 36-195-1 | Washer — Flat               | 2 32 3                   | 63-2450  | Decal — Throttle         | 1 17 1                   |
| 36-4790  | Washer — Thrust             | 6 17 2                   | 63-3450  | Bearing — Ball           | 3 7 1                    |
| 37-6490  | Retainer — Chute Ring       | 3 25 3                   | 63-3510  | Decal — Chute Direction  | 8 20 1                   |
| 37-6500  | Gear — Sliding              | 6 2 1                    | 63-3640  | Handle — Control         | 8 12 1                   |
| 37-6520  | Gear — Axle                 | 5 27 1                   | 63-3640  | Handle — Control         | 7 21 1                   |
| 37-6550  | Bearing — Auger             | 4 35 2                   | 63-8360  | Key — Ignition           | 8 7 1                    |
| 37-6560  | Bushing — Input             | 4 57 1                   | 66-6790  | Mount — Clutch Rod Front | 5 7 1                    |
| 37-6570  | Wheel — Friction            | 6 18 1                   | 66-6830  | Decal — Escutcheon Back  | 8 5 1                    |
| 37-6760  | Shaft — Pivot               | 6 21 1                   | 66-6840  | Decal — Hot              | 1 18 1                   |
| 37-6780  | Shaft — Hex                 | 6 25 1                   | 66-8060  | Molded Brake Asm.        | 1 4 1                    |
| 37-6801  | Shaft — Auger               | 4 55 1                   | 74-1350  | Shaft — Axle             | 5 22 1                   |
| 37-6830  | Cover — Bottom              | 5 17 1                   | 74-1360  | Grip — Handle            | 8 14 1                   |
| 37-6850  | Bearing — Axle              | 5 23 2                   | 74-1360  | Grip — Handle            | 7 22 1                   |
| 37-6890  | Pulley                      | 3 16 1                   | 74-1370  | Engine Pulley            | 1 3 1                    |
| 37-6961  | Gear Case Asm.              | 4 * 1                    | 74-1420  | Blade — Scraper          | 4 36 1                   |
| 37-6990  | Shaft & Impeller            | 3 4 1                    | 74-1490  | Rod — Speed Selector     | 7 3 1                    |
| 37-8770  | Bolt — Shoulder             | 5 14 2                   | 74-1590  | Auger — L.H.             | 3 * 1                    |
| 37-8770  | Bolt — Shoulder             | 6 14 1                   | 74-1600  | Auger — R.H.             | 3 2 1                    |
| 37-8790  | Mount — Quadrant Gear       | 6 10 1                   | 88-0550  | Frame — Friction Plate   | 5 5 1                    |
| 37-8800  | Quadrant — Gear             | 6 13 1                   | 88-0560  | Hub — Frame              | 5 9 1                    |
| 37-8821  | Selector — Speed            | 7 17 1                   | 88-0850  | Pulley & Shaft           | 5 1 1                    |
| 37-8870  | Spring—Friction Plate Frame | 5 25 1                   | 94-2558  | Decal — Discharge        | 3 * 1                    |
| 37-8880  | Spring — Traction Engage    | 6 6 1                    | 94-2563  | Decal — Escutcheon Back  | 8 * 1                    |
| 37-8900  | Frame — Traction            | 5 12 1                   | 94-2568  | Decal — Auger Warning    | 3 * 1                    |
| 37-8941  | Ring — Chute                | 4 30 1                   | 94-2572  | Decal — Primer           | 1 16 1                   |
| 37-9070  | Mount — Clutch Rod Rear     | 5 11 1                   | 94-2576  | Decal — Hot              | 1 * 1                    |
| 37-9090  | V-Belt — Traction           | 2 28 1                   | 94-2785  | Housing—Auger            | 3 * 1                    |
| 37-9150  | Spring                      | 7 13 1                   | 94-2786  | Housing—Auger            | 3 1 1                    |
| 37-9160  | Intermediate Gear & Bushing | 6 8 1                    | 94-2792  | Chute — Discharge        | 3 * 1                    |
| 38-0800  | Plate — Friction            | 5 13 1                   | 94-2793  | Chute — Discharge        | 3 21 1                   |
| 38-4490  | Bracket — Traction          | 6 30 1                   | 94-8079  | Decal — Discharge        | 3 22 1                   |
| 38-4520  | Spring — Compression        | 6 28 1                   | 94-9876  | Decal — 724              | 7 11 1                   |
| 38-7820  | Bearing                     | 5 10 1                   | 127-19   | Guard — Muffler          | 2 33 1                   |
| 39-1230  | Bracket — Sliding           | 6 5 1                    | 231-120  | Tire                     | 5 18 2                   |
| 39-1250  | Cam — Receiver              | 6 15 1                   | 232-46   | Tube                     | 5 21 2                   |
| 39-1280  | Mount — Speed Selector      | 7 25 1                   | 233-21   | Knob                     | 7 16 1                   |
| 39-1520  | Hub — Friction Wheel Mount  | 6 19 1                   | 237-87   | Seal                     | 4 58 1                   |
| 39-3060  | Rod — Lower Traction        | 6 27 1                   | 241-131  | Rim                      | 5 20 2                   |
| 39-3080  | Clevis                      | 7 6 1                    | 252-71   | Bearing — Thrust         | 4 42 2                   |
| 40-5940  | Switch — On/Off             | 8 6 1                    | 252-76   | Bearing — Needle, Thrust | 4 45 1                   |
| 40-8130  | Spacer — Speed Selector     | 7 14 1                   | 252-80   | Washer — Thrust          | 5 3 1                    |
| 40-8160  | Skid                        | 4 31 2                   | 252-80   | Washer — Thrust          | 4 50 1                   |
| 40-8230  | Grip — Rod                  | 8 19 1                   | 256-32   | Bushing                  | 4 49 1                   |
| 40-8250  | Gear — Worm                 | 8 32 1                   | 256-86   | Bushing                  | 6 3 1                    |
| 40-8270  | Rod — Chute Control         | 8 1 1                    | 256-237  | Bushing                  | 4 53 2                   |
| 40-8280  | Bracket — Chute Worm        | 8 31 1                   | 256-249  | Nyliner                  | 8 22 1                   |
| 40-8350  | Screw — Shoulder            | 6 32 1                   | 256-322  | Bushing                  | 5 6 1                    |
| 40-9680  | Spacer                      | 6 31 1                   | 257-3    | Washer — Thrust          | 4 44 1                   |

\*Not Illustrated

# TORO PART NUMBER INDEX (Cont.)

| Part No. | Description              | Pg. Ref.<br>No. No. Qty. | Part No.  | Description         | Pg. Ref.<br>No. No. Qty. |
|----------|--------------------------|--------------------------|-----------|---------------------|--------------------------|
| 281-1    | Pipe — Plug              | 4 41 1                   | 3290-340  | Washer — Belleville | 3 10 2                   |
| 283-3    | Pin — Clevis             | 7 5 1                    | 3290-378  | Cable Tie           | 7 * 1                    |
| 288-2    | Cap                      | 2 21 1                   | 3290-378  | Cable Tie           | 8 * 1                    |
| 289-9    | Pipe Nipple              | 1 20 1                   | 3290-456  | Washer — Belleville | 8 27 4                   |
| 321-4    | Screw — Hex. Hd.         | 6 16 1                   | 3296-16   | Nut — Lock          | 6 12 1                   |
| 321-9    | Screw — Hex. Head        | 8 16 2                   | 3296-29   | Nut — Lock          | 6 11 1                   |
| 321-10   | Screw                    | 4 38 2                   | 3296-29   | Nut — Lock          | 5 15 6                   |
| 322-2    | Screw — Hex. Hd.         | 6 7 4                    | 3296-29   | Nut — Lock          | 2 22 4                   |
| 322-2    | Screw — Hex. Hd.         | 5 26 6                   | 3296-29   | Nut — Lock          | 8 24 2                   |
| 322-2    | Screw — Hex. Hd.         | 8 26 4                   | 3296-29   | Nut — Lock          | 3 9 13                   |
| 322-4    | Screw                    | 2 24 4                   | 3296-42   | Nut — Lock          | 8 17 2                   |
| 322-7    | Screw                    | 7 26 1                   | 3296-42   | Nut — Lock          | 6 33 1                   |
| 322-7    | Screw — Hex. Hd.         | 8 23 1                   | 3296-42   | Nut — Lock          | 4 37 2                   |
| 323-29   | Screw                    | 1 12 1                   | 3296-48   | Nut — Lock          | 6 20 1                   |
| 3210-3   | Screw                    | 2 27 1                   | 3296-56   | Nut — Lock          | 1 9 1                    |
| 3218-1   | Nut — Jam                | 7 7 1                    | 3296-59   | Nut — Lock          | 1 5 1                    |
| 3229-11  | Bolt — Carriage          | 7 15 2                   | 32115-5   | Retainer — Nut      | 7 8 1                    |
| 3230-1   | Bolt — Carriage          | 4 60 9                   | 32120-72  | Ring — Retaining    | 4 48 1                   |
| 3230-18  | Bolt — Carriage          | 3 5 6                    | 32121-31  | Pin — Roll          | 5 24 2                   |
| 3230-22  | Bolt — Carriage          | 3 19 2                   | 32121-45  | Pin — Roll          | 6 22 2                   |
| 3230-22  | Bolt — Carriage          | 8 29 1                   | 32128-13  | Nut — Flange Lock   | 7 12 1                   |
| 3234-13  | Screw — Hex. Flange Hd.  | 8 13 1                   | 32128-20  | Nut — Flange        | 4 32 4                   |
| 3234-13  | Screw — Hex. Flange Hd.  | 7 18 1                   | 32128-32  | Nut — Flange        | 6 29 1                   |
| 3242-4   | Screw — Set              | 3 17 2                   | 32128-33  | Nut — Flange        | 6 26 2                   |
| 3255-8   | Washer — Lock Ext. Tooth | 2 26 1                   | 32128-33  | Nut — Flange Lock   | 7 27 2                   |
| 3256-23  | Washer                   | 7 9 4                    | 32144-4   | Screw — Self Tap.   | 5 16 6                   |
| 3256-23  | Washer                   | 3 23 3                   | 32144-4   | Screw — Self Tap.   | 1 19 3                   |
| 3256-23  | Washer — Flat            | 2 23 5                   | 32144-41  | Screw — Self Tap.   | 4 56 8                   |
| 3256-24  | Washer                   | 8 10 1                   | 32144-70  | Screw — Self Tap.   | 3 26 4                   |
| 3256-24  | Washer                   | 7 20 1                   | 32144-70  | Screw — Self Tap.   | 6 1 4                    |
| 3256-24  | Washer — Flat            | 1 8 1                    | 32144-70  | Screw — Self Tap.   | 5 8 5                    |
| 3256-68  | Washer — Flat            | 3 11 2                   | 32151-36  | Ring — Retaining    | 4 33 2                   |
| 3257-23  | Key                      | 3 15 1                   | 32151-61  | Ring — Retaining    | 6 35 1                   |
| 3257-23  | Key — Woodruff           | 4 59 1                   | 32151-73  | Ring — Clip         | 7 19 1                   |
| 3257-24  | Key                      | 6 23 1                   | 32151-103 | Ring — Snap         | 5 2 1                    |
| 3257-33  | Key — Woodruff           | 4 39 1                   |           |                     |                          |
| 3272-4   | Pin — Cotter             | 7 4 3                    |           |                     |                          |
| 3290-196 | Retainer — Nut           | 8 28 4                   |           |                     |                          |
| 3290-238 | Washer — Pyramidal       | 8 30 1                   |           |                     |                          |
| 3290-243 | Pin — Klik               | 5 19 2                   |           |                     |                          |
| 3290-320 | Nut — Push               | 8 18 2                   |           |                     |                          |
| 3290-320 | Nut — Push On            | 1 7 1                    |           |                     |                          |
| 3290-326 | Pushnut                  | 4 29 1                   |           |                     |                          |

## OPTIONAL EQUIPMENT

|                              |         |
|------------------------------|---------|
| 110 Vac Electric Starter Kit | 38037   |
| Tire Chain Kit               | 56-2700 |
| Drift Breaker Kit            | 37-7022 |
| Snow Cab                     | 88-0600 |

## PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

## COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province or state. If for any reason you are dissatisfied with your Distributor's

service or have difficulty obtaining guarantee information, contact the TORO importer. If all other remedies fail, you may contact us at The Toro Company.

## MAINTENANCE RECORD

[illegible]

[illegible]

