



## 48cm Recycler®

### Walk Power Lawn Mower

Model No. 20817–230000001 and Up

## Parts Catalog

### Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

### Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

### Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

### Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.


## Contents

| <b>Description</b>                             | <b>Page</b> | <b>Description</b>                       | <b>Page</b> |
|------------------------------------------------|-------------|------------------------------------------|-------------|
| Deck, Kicker, and Recycler Plug Assembly . . . | 3           | Air Cleaner Assembly                     |             |
| Engine and Blade Assembly . . . . .            | 4           | Briggs and Stratton Model 12H802–1720–B1 | 14          |
| Height of Cut and Wheel Assembly . . . . .     | 5           | Governor Assembly                        |             |
| Handle and Control Assembly . . . . .          | 6           | Briggs and Stratton Model 12H802–1720–B1 | 15          |
| Rear Bagger Assembly . . . . .                 | 7           | Muffler and Fuel Tank Assembly           |             |
| Transmission Assembly . . . . .                | 8           | Briggs and Stratton Model 12H802–1720–B1 | 16          |
| Gear Case Assembly No. 104–7593 . . . . .      | 9           | Blower Housing Assembly                  |             |
| Cylinder Assembly                              |             | Briggs and Stratton Model 12H802–1720–B1 | 17          |
| Briggs and Stratton Model 12H802–1720–B1       | 10          | Starter Assembly                         |             |
| Crankshaft Assembly                            |             | Briggs and Stratton Model 12H802–1720–B1 | 18          |
| Briggs and Stratton Model 12H802–1720–B1       | 11          | Gasket Assembly                          |             |
| Crankcase Assembly                             |             | Briggs and Stratton Model 12H802–1720–B1 | 19          |
| Briggs and Stratton Model 12H802–1720–B1       | 12          | Carburetor Overhaul Kit Assembly         |             |
| Carburetor Assembly                            |             | Briggs and Stratton Model 12H802–1720–B1 | 20          |
| Briggs and Stratton Model 12H802–1720–B1       | 13          |                                          |             |

## Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

| <b>Abbreviation</b> | <b>Meaning</b>                    | <b>Abbreviation</b> | <b>Meaning</b>          |
|---------------------|-----------------------------------|---------------------|-------------------------|
| AR . . . . .        | as required                       | HYD . . . . .       | hydraulic               |
| ASM . . . . .       | assembly                          | INC . . . . .       | incorporated            |
| CARR . . . . .      | carriage                          | LH . . . . .        | left hand               |
| DEG . . . . .       | degrees                           | NI . . . . .        | nylon insert            |
| FH . . . . .        | flat head                         | PPH . . . . .       | Phillips pan head       |
| GA . . . . .        | gauge                             | PTH . . . . .       | Phillips truss head     |
| HF . . . . .        | hex flange                        | PTO . . . . .       | power take off          |
| HH . . . . .        | hex head                          | RH . . . . .        | right hand              |
| HHF . . . . .       | hex head flange                   | SFH . . . . .       | slotted fillister head  |
| HLH . . . . .       | hex lag head                      | SHH . . . . .       | slotted hex head        |
| HJ . . . . .        | hex jam                           | SQH . . . . .       | square head             |
| HOC . . . . .       | height-of-cut                     | SHWH . . . . .      | slotted hex washer head |
| HS . . . . .        | hex socket                        | SPH . . . . .       | slotted pan head        |
| HSBH . . . . .      | hex socket button head            | SRH . . . . .       | slotted round head      |
| HSFH . . . . .      | hex socket flat head              | STD . . . . .       | standard                |
| HSH . . . . .       | hex socket head                   | TAP . . . . .       | self tapping            |
| HWH . . . . .       | hex washer head                   | TTH . . . . .       | Torx truss head         |
| HWHTF . . . . .     | hex washer head<br>thread forming | WH . . . . .        | wing head               |




Sheet No.:2

## Deck, Kicker, and Recycler Plug Assembly

| Ref. No. | Part No.    | Qty. | Description           |
|----------|-------------|------|-----------------------|
| 1        | 100-9115    | 1    | Door ASM              |
| 1:2      | 93-4105     | 1    | Decal-Danger          |
| 3        | 100-1509    | 1    | Rod-Pivot, Door       |
| 4        | 100-1505    | 1    | Recycler-Plug, Kicker |
| 5        | 100-1522    | 1    | Fitting-Washout       |
| 6        | 46-6290     | 1    | O-Ring                |
| 7        | 32144-1     | 11   | Screw-Taptite         |
| 12       | 99-6486     | 1    | Kicker-Cover, Rear    |
| 13       | 100-1506    | 1    | Ramp-Discharge        |
| 14       | 100-4352    | 2    | Screw-HWH             |
| 15       | 99-6485     | 1    | Kicker-Front          |
| 16       | 104-7579    | 1    | 48cm Deck             |
| 17       | 100-4354    | 1    | Decal-Recycler        |
| 18       | 100-3932    | 1    | Boot-HOC              |
| 19       | 99-6479     | 1    | Belt Cover            |
| 20       | 104-7594    | 1    | Spring-Torsion, Door  |
| 21       | 98-2256     | 2    | Clamp                 |
| 22       | 100-9123-03 | 1    | Bracket-Deck          |
| 24       | 100-4351    | 4    | Screw-HWH             |
| 26       | 104-7557    | 1    | Hook-Left             |
| *27      | 104-7558    | 1    | Hook-Right            |
| 28       | 104-7556    | 2    | Spacer                |

\* Not illustrated




## Engine and Blade Assembly

| Ref. No. | Part No.    | Qty. | Description                                                        |
|----------|-------------|------|--------------------------------------------------------------------|
| 1        | 32144-121   | 2    | Screw-PPH                                                          |
| 2        | 93-0243     | 1    | Shroud-Wedge,<br>Quantum                                           |
| ☆■3      |             | 1    | Engine-Quantum 6.0<br>Briggs & Stratton<br>Model<br>12H802-1720-B1 |
| 4        | 104-7577-03 | 1    | Shield-Muffler                                                     |
| 5        | 104-2065    | 3    | Screw-HWH                                                          |
| 6        | 100-1523-03 | 1    | Guide-Belt, Engine                                                 |
| 7        | 93-0232     | 1    | V-Belt                                                             |
| 8        | 32144-4     | 2    | Screw-HWH                                                          |
| 9        | 80-0510-03  | 1    | Blade-Stiffener                                                    |
| 10       | 3253-22     | 1    | Washer-Lock                                                        |
| 11       | 100-4368    | 1    | Bolt-Blade                                                         |
| 12       | 105-0525-03 | 1    | Blade-3 In 1, 48cm                                                 |
| 13       | 104-7554    | 1    | Retainer-Blade                                                     |
| 14       | 100-1102    | 1    | Pulley ASM                                                         |
| 15       | 104-0214    | 1    | Screw-Set                                                          |
| 16       | 32144-102   | 3    | Screw-HWH                                                          |
| 17       | 92-2289     | 1    | Plate-Logo                                                         |
| 18       | 100-5952    | 1    | Decal-Engine                                                       |
| 19       | 2210-316    | 1    | Stop-Rope                                                          |

| Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|-------------|
|          |          |      |             |


- Contact your local Briggs & Stratton Dealer for part replacement.



Sheet No.:4

## Height of Cut and Wheel Assembly

| Ref. No. | Part No. | Qty. | Description             | Ref. No. | Part No.    | Qty. | Description    |
|----------|----------|------|-------------------------|----------|-------------|------|----------------|
| 1        | 100-4352 | 4    | Screw-HWH               | 23       | 104-7562    | 1    | Front Axle ASM |
| 2        | 99-6487  | 1    | Handle-Deck             | 24       | 100-9116    | 1    | Rod ASM        |
| 3        | 99-6480  | 1    | Button-HOC              | 24:2     | 100-4355    | 1    | Decal-HOC      |
| 4        | 88-7540  | 1    | Washer-Backup           | 25       | 100-3939    | 2    | Palnut         |
| 5        | 99-6481  | 1    | Spring-Compression, HOC | 27       | 100-4383-03 | 1    | Cover-Handle   |
| 6        | 99-6483  | 1    | Bushing-HOC             | 28       | 614650      | 2    | Bolt-Shoulder  |
| 7        | 100-1525 | 1    | Bracket-Cable, Traction | 29       | 40-1940     | 2    | Washer         |
| 8        | 32144-1  | 6    | Screw-Taptite           |          |             |      |                |
| 9        | 92-9698  | 1    | Screw-Shoulder          |          |             |      |                |
| 10       | 99-6458  | 1    | Pipe-HOC                |          |             |      |                |
| 11       | 3296-73  | 1    | Nut-Lock, NI            |          |             |      |                |
| 12       | 100-4384 | 1    | Spring-Extension, HOC   |          |             |      |                |
| 13       | 99-6459  | 1    | Bolt-Shoulder           |          |             |      |                |
| 14       | 99-6460  | 1    | Plate-Support, HOC      |          |             |      |                |
| 15       | 99-6478  | 1    | Rear Axle ASM           |          |             |      |                |
| 16       | 99-6471  | 2    | Wheel ASM               |          |             |      |                |
| 16:1:2   | 27-6250  | 2    | Bushing                 |          |             |      |                |
| 17       | 100-4370 | 2    | Nut-Lock, Flanged       |          |             |      |                |
| 18       | 100-4366 | 2    | Cover-Smart Wheel       |          |             |      |                |
| 19       | 100-9114 | 2    | Decal-Smart Wheel       |          |             |      |                |
| 20       | 95-6543  | 2    | Cover-Wheel             |          |             |      |                |
| 21       | 99-6470  | 2    | Wheel ASM               |          |             |      |                |
| 22       | 100-1500 | 4    | Mount-Axle, Front       |          |             |      |                |




Sheet No.:5

## Handle and Control Assembly

| Ref. No. | Part No.    | Qty. | Description                    |
|----------|-------------|------|--------------------------------|
| 1        | 99-1593-03  | 1    | Bail-Brake                     |
| 2        | 99-1595     | 1    | Retainer-Cable, Brake          |
| 3        | 46-8091     | 1    | Screw-HWH                      |
| 4        | 99-6008     | 1    | Retainer-Control Rod, Traction |
| 5        | 94-4496     | 10   | Screw-PPH                      |
| 7        | 99-1589     | 1    | Lever-Traction                 |
| 8        | 99-1590     | 2    | Guide-Handle, Control          |
| 9        | 95-4453     | 1    | Screw-Handle                   |
| 10       | 99-5239     | 1    | Anchor-Cable                   |
| 11       | 100-3936    | 1    | Cable-Traction                 |
| 12       | 98-7134     | 2    | Knob-Handle                    |
| 13       | 92-2260     | 2    | Screw-Handle                   |
| 14       | 3290-378    | 2    | Tie-Cable                      |
| 15       | 100-1502-05 | 1    | Handle-Lower                   |
| 17       | 100-4396    | 2    | Knob-Adjusting, Handle         |
| 18       | 104-7553-03 | 2    | Disk-Adjusting, Handle         |
| 19       | 100-1517    | 2    | Disk-Holding, Handle           |
| 20       | 60-6690     | 2    | Capscrew                       |
| 21       | 99-1596-05  | 1    | Handle-Upper                   |
| 22       | 86-9671     | 1    | Guide-Rope                     |
| 23       | 3296-73     | 2    | Nut-Lock, NI                   |
| 24       | 3256-1      | 1    | Washer-Flat                    |
| 25       | 100-3937    | 1    | Cable-Brake                    |

| Ref. No. | Part No. | Qty. | Description           |
|----------|----------|------|-----------------------|
| 26       | 100-5970 | 1    | Cover-Handle          |
| 27       | 99-1592  | 1    | Spring-Torsion, RH    |
| 28       | 99-1588  | 1    | Bar-Control, Traction |
| 29       | 100-5950 | 1    | Decal-Automatic       |
| 30       | 99-1582  | 1    | Handle-Control        |
| 31       | 100-4351 | 4    | Screw-HWH             |




Sheet No.:8

## Rear Bagger Assembly

| Ref. No. | Part No.    | Qty. | Description   |
|----------|-------------|------|---------------|
| 1        | 104-7578    | 1    | Grass Bag ASM |
| 2        | 104-7560-03 | 1    | Bag Frame ASM |

| Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|-------------|
|          |          |      |             |






Sheet No.:A1

# Gear Case Assembly No. 104-7593

| Ref. No. | Part No.  | Qty. | Description              |
|----------|-----------|------|--------------------------|
| 1        | 104-7619  | 1    | Case-Gear                |
| 2        | 614668-03 | 1    | Cover-Case, Gear         |
| 3        | 32144-4   | 4    | Screw-HWH                |
| 4        | 32151-68  | 1    | Ring-Retaining           |
| 5        | 3256-24   | 1    | Washer-Flat              |
| 6        | 3285-19   | 2    | Pin-Groove               |
| 7        | 3296-5    | 1    | Nut-Lock, NI             |
| 8        | 36-4780   | 2    | Washer                   |
| 9        | 36-4791   | 2    | Washer-Thrust            |
| 10       | 60-8750   | 2    | Bushing                  |
| 11       | 60-8850   | 2    | Bushing-Output           |
| 12       | 614696    | 1    | Shaft-Intermediate       |
| 13       | 100-1176  | 2    | Pulley-Half              |
| 14       | 100-1048  | 1    | Bearing-Ball             |
| 15       | 62-6660   | 1    | Spacer                   |
| 16       | 104-7668  | 1    | Gear-15t Spur, 37t Bevel |
| 17       | 104-7667  | 1    | Gear-Pinion, Bevel       |
| 18       | 614596    | 1    | Gear                     |
| 19       | 100-1514  | 1    | Shaft-Output             |

| Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|-------------|
|          |          |      |             |




## Cylinder Assembly Briggs and Stratton Model 12H802-1720-B1

| Ref. No. | Part No. | Qty. | Description             |
|----------|----------|------|-------------------------|
| 1        | 493260   | 1    | Cylinder Assembly       |
| 2        | 293708   | 1    | Kit-Bushing/Seal        |
| ★3       | 299819   | 1    | Seal-Oil                |
| 5        | 691160   | 1    | Head-Cylinder           |
| ★7       | 692249   | 1    | Gasket-Cylinder Head    |
| 8        | 695250   | 1    | Breather Assembly       |
| 9        | 696125   | 1    | Gasket-Breather         |
| 10       | 691125   | 1    | Screw                   |
| 11       | 691781   | 1    | Tube-Breather           |
| 50       | 497465   | 1    | Manifold-Intake         |
| ★51      | 272199   | 1    | Gasket-Intake           |
| 54       | 691650   | 1    | Screw                   |
| 306      | 690450   | 1    | Cylinder Shield         |
| 307      | 690345   | 1    | Screw                   |
| 337      | 802592   | 1    | Plug-Spark              |
| 383      | 89838    | 1    | Wrench-Sparkplug        |
| 404      | 690272   | 1    | Washer                  |
| 615      | 690340   | 1    | Retainer-Governor Shaft |

| Ref. No. | Part No. | Qty. | Description             |
|----------|----------|------|-------------------------|
| 616      | 691308   | 1    | Crank-Governor          |
| 584      | 692342   | 1    | Cover-Breather Passage  |
| ★585     | 691879   | 1    | Gasket-Breather Passage |
| 635      | 66538    | 1    | Boot-Spark Plug         |
| 684      | 690345   | 1    | Screw                   |
| 718      | 690959   | 1    | Pin-Locating            |
| 869      | 691155   | 1    | Seat-Valve (Intake)     |
| 870      | 690380   | 1    | Seat-Valve (Exhaust)    |
| 871      | 262001   | 1    | Bushing-Guide (Exhaust) |
|          | 63709    | 1    | Bushing-Guide (Intake)  |
| 1019     | 494256   | 1    | Kit-Label               |
| 1058     | 274978   | 1    | Owner's Manual          |

★ Included in Engine Gasket Set-Ref. 358.

**Obtain Parts from Briggs and Stratton**




Assemblies include all parts shown in frames.

# **Crankshaft Assembly** **Briggs and Stratton Model 12H802-1720-B1**

| Ref. No. | Part No. | Qty. | Description                      |
|----------|----------|------|----------------------------------|
| 16       | 696009   | 1    | Crankshaft                       |
| 24       | 222698   | 1    | Flywheel Key                     |
| 25       | 499429   | 1    | Piston Assembly (Standard)       |
|          | 499430   | 1    | Piston Assembly (.010" Oversize) |
|          | 499431   | 1    | Piston Assembly (.020" Oversize) |
|          | 499432   | 1    | Piston Assembly (.030" Oversize) |
| 26       | 499425   | 1    | Ring Set (Standard)              |
|          | 499426   | 1    | Ring Set (.010" Oversize)        |
|          | 499427   | 1    | Ring Set (.020" Oversize)        |
|          | 499428   | 1    | Ring Set (.030" Oversize)        |
| 27       | 691866   | 1    | Piston Pin Lock                  |
| 28       | 499423   | 1    | Piston Pin (Standard)            |
|          | 298908   | 1    | Piston Pin (.005" Oversize)      |
| 29       | 499424   | 1    | Connecting Rod (Standard)        |

| Ref. No. | Part No. | Qty. | Description             |
|----------|----------|------|-------------------------|
| 32       | 691664   | 1    | Screw (Connecting Rod)  |
| 32A      | 695759   | 1    | Screw (Connecting Rod ) |
| 33       | 262651   | 1    | Exhaust Valve           |
| 34       | 262652   | 1    | Intake Valve            |
| 35       | 691270   | 1    | Valve Spring (Intake)   |
| 36       | 691270   | 1    | Valve Spring (Exhaust)  |
| 40       | 692194   | 1    | Valve Retainer          |
| 45       | 691811   | 1    | Tappet-Valve            |
| 146      | 690979   | 1    | Timing Key              |
| 741      | 691830   | 1    | Timing Gear             |

Obtain Parts from Briggs and Stratton



Assemblies include all parts shown in frames.


## Crankcase Assembly

### Briggs and Stratton Model 12H802-1720-B1

| Ref. No. | Part No. | Qty. | Description                            | Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|----------------------------------------|----------|----------|------|-------------|
| 4        | 493279   | 1    | Sump-Engine                            |          |          |      |             |
| ★12      | 692232   | 1    | Gasket-Crankcase<br>(.015 Thick, Std.) |          |          |      |             |
| 15       | 691680   | 1    | Plug-Oil Drain                         |          |          |      |             |
| ★20      | 399781   | 1    | Seal-Oil                               |          |          |      |             |
| 22       | 691092   | 1    | Screw<br>(Engine Sump)                 |          |          |      |             |
| 43       | 691997   | 1    | Slinger-Governor/Oil                   |          |          |      |             |
| 46       | 691449   | 1    | Camshaft                               |          |          |      |             |
| 48       | 696276   | 1    | Short Block                            |          |          |      |             |
| 287      | 690940   | 1    | Screw<br>(Dipstick Tube)               |          |          |      |             |
| 523      | 499621   | 1    | Dipstick                               |          |          |      |             |
| ★524     | 692296   | 1    | Dipstick Tube Seal                     |          |          |      |             |
| 525      | 495265   | 1    | Dipstick Tube                          |          |          |      |             |
| ★842     | 691031   | 1    | O-Ring Seal<br>(Dipstick Tube)         |          |          |      |             |
| 847      | 692047   | 1    | Dipstick/ Tube<br>Assembly             |          |          |      |             |

★ Included in Engine Gasket Set-Ref. 358.

Obtain Parts from Briggs and Stratton



Assemblies include all parts shown in frames.


# Carburetor Assembly Briggs and Stratton Model 12H802-1720-B1

| Ref. No. | Part No. | Qty. | Description                      |
|----------|----------|------|----------------------------------|
| 95       | 691636   | 1    | Screw<br>(Throttle Valve)        |
| 97       | 696565   | 1    | Shaft–Throttle                   |
| ●104     | 691242   | 1    | Pin–Float Hinge                  |
| 117      | 498978   | 1    | Jet–Main<br>(Standard)           |
| 118      | 497466   | 1    | Jet–Main<br>(High Altitude)      |
| 125      | 498170   | 1    | Carburetor                       |
| ●127     | 694468   | 1    | Plug–Welch                       |
| 130      | 696564   | 1    | Valve–Throttle                   |
| 133      | 398187   | 1    | Float–Carburetor                 |
| ●134     | 398188   | 1    | Kit–Needle/Seat                  |
| ●◆137    | 693981   | 1    | Gasket–Float Bowl                |
| ★●◆163   | 272653   | 1    | Gasket–Air Cleaner               |
| ●276     | 271716   | 1    | Washer–Sealing                   |
| 365      | 692524   | 1    | Screw<br>(Carburetor)            |
| ●◆617    | 270344   | 1    | Seal–O Ring<br>(Intake Manifold) |
| ●◆633    | 691321   | 1    | Seal–Choke/Throttle<br>Shaft     |
| 975      | 493640   | 1    | Bowl–Float                       |

| Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|-------------|
|          |          |      |             |

- Included in Carburetor Overhaul Kit—Ref. 121.
- ★ Included in Engine Gasket Set—Ref. 358.

- Obtain Parts from Briggs and Stratton**  
◆ Included in Carburetor Gasket Set—Ref. 977.



Assemblies include all parts shown in frames.

# Air Cleaner Assembly







## Briggs and Stratton Model 12H802-1720-B1

| Ref. No. | Part No. | Qty. | Description                        |
|----------|----------|------|------------------------------------|
| 159      | 691753   | 1    | Bracket-Air Cleaner Primer         |
| ★◆163    | 272653   | 1    | Gasket-Air Cleaner                 |
| 425      | 690670   | 1    | Screw (Air Cleaner Cover)          |
| 443      | 692523   | 1    | Screw (Air Cleaner Primer Base)    |
| 445      | 491588   | 1    | Filter-Air Cleaner Cartridge       |
| 529      | 691923   | 1    | Grommet                            |
| 966      | 496116   | 1    | Base-Air Cleaner Primer            |
| 968      | 692298   | 1    | Cover-Air Cleaner                  |
| 970      | 691669   | 1    | Screw (Air Cleaner Primer Bracket) |
| 976      | 694395   | 1    | Primer-Carburetor                  |

| Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|-------------|
|          |          |      |             |
|          |          |      |             |
|          |          |      |             |
|          |          |      |             |
|          |          |      |             |
|          |          |      |             |
|          |          |      |             |
|          |          |      |             |
|          |          |      |             |

● Included in Carburetor Overhaul Kit-Ref. 121.  
★ Included in Engine Gasket Set-Ref. 358.

**Obtain Parts from Briggs and Stratton**  
◆ Included in Carburetor Gasket Set-Ref. 977.




Assemblies include all parts shown in frames.

**Governor Assembly**  
**Briggs and Stratton Model 12H802-1720-B1**

| Ref. No. | Part No. | Qty. | Description                   |
|----------|----------|------|-------------------------------|
| 188      | 690877   | 1    | Screw<br>(Control Bracket)    |
| 202      | 691829   | 1    | Link—Mechanical Governor      |
| 209      | 691852   | 1    | Spring—Governor               |
| 222      | 692467   | 1    | Bracket—Control               |
| 227      | 690783   | 1    | Lever—Governor Control        |
| 333      | 802574   | 1    | Armature—Magneto              |
| 334      | 691061   | 1    | Screw<br>(Magneto Armature)   |
| 356      | 692390   | 1    | Wire—Stop                     |
| 505      | 231082   | 1    | Nut (Governor Control Lever)  |
| 562      | 92613    | 1    | Bolt (Governor Control Lever) |
| 621      | 692310   | 1    | Switch—Stop                   |
| 668      | 493823   | 1    | Spacer                        |
| 745      | 691648   | 1    | Screw<br>(Brake)              |
| 851      | 493880   | 1    | Terminal—Spark Plug           |
| 922      | 691831   | 1    | Spring—Brake                  |
| 923      | 691994   | 1    | Brake                         |

| Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|-------------|
|          |          |      |             |

## Obtain Parts from Briggs and Stratton




Assemblies include all parts shown in frames.

**Muffler and Fuel Tank Assembly**  
**Briggs and Stratton Model 12H802-1720-B1**

| Ref. No. | Part No. | Qty. | Description                           | Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|---------------------------------------|----------|----------|------|-------------|
| 81       | 691740   | 1    | Lock-Muffler Screw                    |          |          |      |             |
| 187      | 691050   | 1    | Line-Fuel<br>(Cut to Required Length) |          |          |      |             |
| 190      | 690940   | 1    | Screw<br>(Fuel Tank)                  |          |          |      |             |
| 300      | 692038   | 1    | Muffler                               |          |          |      |             |
| 601      | 95162    | 1    | Clamp-Hose                            |          |          |      |             |
| 613      | 691340   | 1    | Screw<br>(Muffler)                    |          |          |      |             |
| 670      | 692294   | 1    | Spacer-Fuel Tank                      |          |          |      |             |
| 676      | 493871   | 1    | Deflector-Muffler                     |          |          |      |             |
| 677      | 690661   | 1    | Screw<br>(Muffler Deflector)          |          |          |      |             |
| 957      | 692046   | 1    | Cap-Fuel Tank                         |          |          |      |             |
| 972      | 499618   | 1    | Tank-Fuel                             |          |          |      |             |
| 1059     | 692311   | 1    | Kit-Screw/Washer                      |          |          |      |             |

Obtain Parts from Briggs and Stratton




Assemblies include all parts shown in frames.

**Blower Housing Assembly**  
**Briggs and Stratton Model 12H802-1720-B1**

| Ref. No. | Part No. | Qty. | Description                        | Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|------------------------------------|----------|----------|------|-------------|
| 23       | 692315   | 1    | Flywheel                           |          |          |      |             |
| 37       | 694086   | 1    | Guard-Flywheel                     |          |          |      |             |
| 78       | 691108   | 1    | Screw<br>(Flywheel Guard)          |          |          |      |             |
| 304      | 493293   | 1    | Housing-Blower                     |          |          |      |             |
| 305      | 691108   | 1    | Screw<br>(Blower Housing)          |          |          |      |             |
| 332      | 690877   | 1    | Nut<br>(Flywheel)                  |          |          |      |             |
| 363      | 19069    | 1    | Puller-Flywheel                    |          |          |      |             |
| 455      | 695161   | 1    | Cup-Flywheel                       |          |          |      |             |
| 921      | 697343   | 1    | Cover-Blower Housing               |          |          |      |             |
| 969      | 690700   | 1    | Screw<br>(Blower Housing<br>Cover) |          |          |      |             |
| 1036     | 695111   | 1    | Label-Emission                     |          |          |      |             |

Obtain Parts from Briggs and Stratton



# Starter Assembly



## Briggs and Stratton Model 12H802-1720-B1

| Ref. No. | Part No. | Qty. | Description                              |
|----------|----------|------|------------------------------------------|
| 55       | 691421   | 1    | Housing—Rewind Starter                   |
| 58       | 280399   | 1    | Rope—Starter<br>(Cut to Required Length) |
| 60       | 281434   | 1    | Grip—Starter Rope                        |
| 65       | 690837   | 1    | Screw<br>(Rewind Starter)                |
| 456      | 692299   | 1    | Plate—Pawl Friction                      |
| 459      | 281505   | 1    | Ratchet—Pawl                             |
| 592      | 690800   | 1    | Nut<br>(Rewind Starter)                  |
| 597      | 691696   | 1    | Screw<br>(Pawl Friction Plate)           |
| 608      | 497680   | 1    | Starter—Rewind                           |
| 689      | 691855   | 1    | Spring—Friction                          |
| 1210     | 498144   | 1    | Pulley/Spring<br>Assembly<br>(Pulley)    |
| 1211     | 498144   | 1    | Pulley/Spring<br>Assembly<br>(Spring)    |

| Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|-------------|
|          |          |      |             |

## Obtain Parts from Briggs and Stratton





Assemblies include all parts shown in frames.

# Carburetor Overhaul Kit Assembly Briggs and Stratton Model 12H802-1720-B1

| Ref. No. | Part No. | Qty. | Description                   |
|----------|----------|------|-------------------------------|
| ●104     | 691242   | 1    | Pin—Float Hinge               |
| 121      | 498260   | 1    | Kit—Carburetor Overhaul       |
| ●127     | 694468   | 1    | Plug—Welch                    |
| ●134     | 398188   | 1    | Kit—Needle/Seat               |
| ●◆137    | 693981   | 1    | Gasket—Float Bowl             |
| ★●◆163   | 272653   | 1    | Gasket—Air Cleaner            |
| ●276     | 271716   | 1    | Washer—Sealing                |
| ★●◆617   | 270344   | 1    | Seal—O Ring (Intake Manifold) |
| ●◆633    | 691321   | 1    | Seal—Choke/Throttle Shaft     |
| 977      | 498261   | 1    | Gasket Set—Carburetor         |

| Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|-------------|
|          |          |      |             |

- Included in Carburetor Overhaul Kit—Ref. 121.
- ★ Included in Engine Gasket Set—Ref. 358.

- Obtain Parts from Briggs and Stratton**  
◆ Included in Carburetor Gasket Set—Ref. 977.

## Maintenance Record

[illegible]

## Maintenance Record

[illegible]

## Maintenance Record

[illegible]

