



48cm Rear-Bagging Mower

Model No. 20816-230000001 and Up

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.


Contents

Description	Page	Description	Page
Deck and Kicker Assembly	3	Governor Assembly	
Engine and Blade Assembly	4	Briggs and Stratton Model 12F802–1770–B1	13
Height–Of–Cut and Wheel Assembly	5	Air Cleaner Assembly	
Lower Handle and Adjusting Knob Assembly ..	6	Briggs and Stratton Model 12F802–1770–B1	14
Upper Handle and Control Assembly	7	Muffler and Fuel Tank Assembly	
Grass Bag Assembly	8	Briggs and Stratton Model 12F802–1770–B1	15
Rear Axle Assembly	9	Flywheel and Blower Housing Assembly	
Cylinder and Cylinder Head Assembly		Briggs and Stratton Model 12F802–1770–B1	16
Briggs and Stratton Model 12F802–1770–B1	10	Starter Assembly	
Crankcase / Crankshaft / Piston / and Valve		Briggs and Stratton Model 12F802–1770–B1	17
Assembly		Gasket Assembly	
Briggs and Stratton Model 12F802–1770–B1	11	Briggs and Stratton Model 12F802–1770–B1	18
Carburetor Overhaul Kit Assembly			
Briggs and Stratton Model 12F802–1770–B1	12		

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.


Abbreviation	Meaning	Abbreviation	Meaning
AR	as required	INC	incorporated
ASM	assembly	LH	left hand
CARR	carriage	NI	nylon insert
DEG	degrees	PPH	Phillips pan head
FH	flat head	PTH	Phillips truss head
GA	gauge	PTO	power take off
HF	hex flange	RH	right hand
HH	hex head	SFH	slotted fillister head
HHF	hex head flange	SHH	slotted hex head
HLH	hex lag head	SQH	square head
HJ	hex jam	SHWH	slotted hex washer head
HOC	height-of-cut	SPH	slotted pan head
HS	hex socket	SRH	slotted round head
HSBH	hex socket button head	STD	standard
HSFH	hex socket flat head	TAP	self tapping
HSH	hex socket head	TTH	Torx truss head
HWH	hex washer head	WH	wing head
HWHTF	hex washer head thread forming		



Sheet No.:2

Deck and Kicker Assembly

Ref. No.	Part No.	Qty.	Description
1	100-9115	1	Door ASM
1:2	93-4105	1	Decal-Danger
2	100-1509	1	Rod-Pivot
6	32144-1	9	Screw-Taptite
8	99-6486	1	Cover-Kicker, Rear
9	100-1506	1	Ramp-Discharge
10	100-4352	2	Screw-HWH
11	106-4189	1	Kicker
12	104-7579	1	Deck
13	106-5792	1	Decal-Deck
14	100-3932	1	Boot-HOC
15	99-6479	1	Cover-Belt
16	104-7594	1	Spring-Torsion
17	98-2256	2	Clamp
18	100-9123-03	1	Bracket-Deck
20	100-4351	4	Screw-HWH
21	104-7557	1	Hook-Left
22	104-7558	1	Hook-Right
23	104-7556	2	Spacer




Sheet No.:3

Engine and Blade Assembly

Ref. No.	Part No.	Qty.	Description
1	32144-97	2	Screw-Plastite
2	105-8564	1	Shroud-Quantum
☆3		1	Engine-B & S 12F802-1770-B1
4	104-7577-03	1	Shield-Muffler
5	104-2065	3	Screw-HWH
9	80-0510-03	1	Stiffener-Blade
10	3253-22	1	Washer-Lock
11	100-4368	1	Bolt-Blade
12	106-5781-03	1	Blade
13	104-7554	1	Retainer-Blade
16	32144-102	3	Screw-HWH
17	92-2289	1	Plate-Logo
18	106-5789	1	Decal
19	2210-316	1	Stop-Rope

Ref. No.	Part No.	Qty.	Description


☆ Not serviced separately



Sheet No.:4

Height-Of-Cut and Wheel Assembly

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	100-4352	4	Screw-HWH	24:2	100-4355	1	Decal-HOC
2	99-6487	1	Handle-Deck	25	100-3939	2	Palnut
3	99-6480	1	Button-HOC	26	100-4383-03	1	Cover-Handle
4	88-7540	1	Washer-Backup	27	614650	2	Bolt-Shoulder
5	99-6481	1	Spring-Compression, HOC	28	40-1940	2	Washer
6	99-6483	1	Bushing-HOC				
8	32144-1	5	Screw-Taptite				
9	92-9698	1	Screw-Shoulder				
10	99-6458	1	Pipe-HOC				
11	3296-73	1	Nut-Lock, NI				
12	100-4384	1	Spring-Extension, HOC				
13	99-6459	1	Bolt-Shoulder				
14	99-6460	1	Plate-Support, HOC				
15	99-6478	1	Rear Axle ASM				
16	100-1516	2	Wheel ASM				
16:2	27-6250	2	Bushing				
17	100-4370	2	Nut-Lock, Flanged				
18	100-4366	2	Cover-Smart Wheel				
19	106-5785	2	Decal-Wheel				
20	95-6543	2	Cover-Wheel				
21	99-6470	2	Wheel ASM				
22	100-1500	4	Mount-Axle, Front				
23	104-7562	1	Front Axle ASM				
24	100-9116	1	Rod ASM				




Sheet No.:5

Lower Handle and Adjusting Knob Assembly

Ref. No.	Part No.	Qty.	Description
12	98-7134	2	Knob-Handle
13	92-2260	2	Screw-Handle
14	3290-378	2	Tie-Cable
15	100-1502-05	1	Handle-Lower
17	100-4396	2	Knob-Adjusting, Handle
18	104-7553-03	2	Disk-Adjusting, Handle
19	100-1517	2	Disk-Holding, Handle
20	60-6690	2	Capscrew
31	100-4351	4	Screw-HWH

Ref. No.	Part No.	Qty.	Description




Sheet No.:7

Upper Handle and Control Assembly

Ref. No.	Part No.	Qty.	Description
1	100-1520-05	1	Handle-Upper
2	3296-73	2	Nut-Lock, NI
3	3256-1	1	Washer-Flat
4	92-7729	1	Anchor-Upper, Cable
5	95-4453	1	Screw-Handle
6	100-4364	1	Cable-Brake
7	95-4457	1	Guide-Rope
8	100-4358-03	1	Brake Bail ASM


Ref. No.	Part No.	Qty.	Description



Rear Axle Assembly

Ref. No.	Part No.	Qty.	Description
3	65-2720	2	Klipring-Locking
10	100-1513	2	Cover-Gear
11	32144-1	4	Screw-Taptite
12	100-9118	2	Bushing ASM
12:1	99-6463	1	Bushing-Drive Shaft
12:2	302-56	1	Fitting-Grease
14	100-1512	1	Shaft-Pivot

Ref. No.	Part No.	Qty.	Description



Assemblies include all parts shown in frames.

Cylinder and Cylinder Head Assembly Briggs and Stratton Model 12F802-1770-B1

Ref. No.	Part No.	Qty.	Description
1	493260	1	Cylinder Assembly
2	293708	1	Bearing/Seal Kit (Magneto Side)
★3	299819	1	Oil Seal (Magneto Side)
5	691160	1	Cylinder Head
Δ★7	692249	1	Cylinder Head Gasket
8	695250	1	Breather Assembly
Δ★9	272481	1	Breather Gasket
10	691125	1	Screw (Breather Assembly)
11	691781	1	Breather Tube
13	690912	1	Screw (Cylinder Head)
50	497465	1	Intake Manifold
★51	272199	1	Intake Gasket
54	691650	1	Screw (Intake Manifold)
287	690940	1	Screw (Dipstick Tube)
306	690450	1	Cylinder Shield
307	690345	1	Screw (Cylinder Shield)
337	802592	1	Sparkplug
383	89838	1	Sparkplug Wrench
523	495264	1	Dipstick
★524	692296	1	Dipstick Tube Seal

Ref. No.	Part No.	Qty.	Description
525	495265	1	Dipstick Tube
584	692342	1	Breather Passage Cover
★585	691879	1	Breather Passage Gasket
635	66538	1	Sparkplug Boot
684	690345	1	Screw (Breather Passage Cover)
★842	691031	1	O Ring Seal (Dipstick Tube)
847	692017	1	Dipstick/Tube Assembly
869	691155	1	Valve Seat (Intake)
870	690380	1	Valve Seat (Exhaust)
871	262001	1	Guide Bushing (Exhaust)
	63709	1	Guide Bushing (Intake)
1019	494256	1	Label Kit
1058	274265	1	Owner's Manual


Δ Included in Valve Gasket Set-Ref. 1095.

★ Included in Engine Gasket Set-Ref. 358.

● Included in Carburetor Overhaul Kit-Ref. 121.

◆ Included in Carburetor Gasket Set-Ref. 977

Obtain Parts from Briggs and Stratton



Assemblies include all parts shown in frames.

Crankcase / Crankshaft / Piston / and Valve Assembly Briggs and Stratton Model 12F802-1770-B1

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
4	493279	1	Engine Sump	28	499423	1	Piston Pin (Standard)
★12	692232	1	Crankcase Gasket		298908	1	Piston Pin (.005" O.S.)
15	691680	1	Oil Drain Plug	29	499424	1	Connecting Rod (Standard)
16	695376	1	Crankshaft				
★20	399781	1	Oil Seal (PTO Side)	32	691664	1	Screw (Connecting Rod)
22	691092	1	Screw (Engine Sump)	32A	695759	1	Screw (Connecting Rod)
24	222698	1	Flywheel Key	33	262651	1	Exhaust Valve
25	499429	1	Piston Assembly (Standard)	34	262652	1	Intake Valve
	499430	1	Piston Assembly (.010" Oversize)	35	691270	1	Valve Spring (Intake)
	499431	1	Piston Assembly (.020" Oversize)	36	691270	1	Valve Spring (Exhaust)
	499432	1	Piston Assembly (.030" Oversize)	40	692194	1	Valve Retainer
26	499425	1	Ring Set (Standard)	43	691997	1	Governor/Oil Slinger
	499426	1	Ring Set (.010" Oversize)	45	690548	1	Valve Keeper
	499427	1	Ring Set (.020" Oversize)	46	691449	1	Camshaft
	499428	1	Ring Set (.030" Oversize)	146	690979	1	Timing Key
27	691866	1	Piston Pin Lock	741	691830	1	Timing Gear


△ Included in Valve Gasket Set—Ref. 1095.

★ Included in Engine Gasket Set—Ref. 358.

Obtain Parts from Briggs and Stratton

● Included in Carburetor Overhaul Kit—Ref. 121.

◆ Included in Carburetor Gasket Set—Ref. 977.



Assemblies include all parts shown in frames.

Carburetor Overhaul Kit Assembly Briggs and Stratton Model 12F802-1770-B1

Ref. No.	Part No.	Qty.	Description
95	691636	1	Screw (Throttle Valve)
97	493267	1	Throttle Shaft
●104	691242	1	Float Hinge Pin
117	494870	1	Main Jet (Standard)
	497315	1	Main Jet (High Altitude)
125	498170	1	Carburetor
●127	694468	1	Welch Plug
130	691203	1	Throttle Valve
133	398187	1	Carburetor Float
●134	398188	1	Needle/Seat Kit
●◆137	693981	1	Float Bowl Gasket
★●◆163	272653	1	Air Cleaner Gasket
●276	271716	1	Sealing Washer
365	692524	1	Screw (Carburetor)
●◆617	270344	1	O Ring Seal (Intake Manifold)
●◆633	691321	1	Choke/Throttle Shaft Seal
975	493640	1	Float Bowl

Ref. No.	Part No.	Qty.	Description

Δ Included in Valve Gasket Set—Ref. 1095.


★ Included in Engine Gasket Set—Ref. 358.

Obtain Parts from Briggs and Stratton

12

- Included in Carburetor Overhaul Kit—Ref. 121.

◆ Included in Carburetor Gasket Set—Ref. 977.



Assemblies include all parts shown in frames.

Governor Assembly

Briggs and Stratton Model 12F802-1770-B1

Ref. No.	Part No.	Qty.	Description
188	690877	1	Screw (Control Bracket)
202	691829	1	Mechanical Governor Link
209	691852	1	Governor Spring
222	692467	1	Control Bracket
227	690783	1	Governor Control Lever
333	802574	1	Magneto Armature
334	691061	1	Screw (Magneto Armature)
404	690272	1	Washer (Governor Crank)
505	231082	1	Nut (Governor Control Lever)
562	92613	1	Screw (Governor Control Lever)
615	690340	1	Governor Shaft Retainer
616	691306	1	Governor Crank
621	692310	1	Stop Switch
★668	493823	1	Spacer (Includes 2)
745	691648	1	Screw (Brake)

Ref. No.	Part No.	Qty.	Description
851	493880	1	Sparkplug Terminal
922	691831	1	Brake Spring
923	691994	1	Brake


△ Included in Valve Gasket Set-Ref. 1095.

★ Included in Engine Gasket Set-Ref. 358.

Obtain Parts from Briggs and Stratton

● Included in Carburetor Overhaul Kit-Ref. 121.

◆ Included in Carburetor Gasket Set-Ref. 977.



Assemblies include all parts shown in frames.


Air Cleaner Assembly
Briggs and Stratton Model 12F802-1770-B1

Ref. No.	Part No.	Qty.	Description
159	691753	1	Air Cleaner Primer Bracket
★◆163	272653	1	Air Cleaner Gasket
425	690670	1	Screw (Air Cleaner Cover)
443	692523	1	Screw (Air Cleaner Primer Base)
445	491588	1	Air Cleaner Cartridge Filter
529	691923	1	Grommet
966	496116	1	Air Cleaner Primer Base
968	692298	1	Air Cleaner Cover
970	691669	1	Screw (Air Cleaner Primer Bracket)
976	694395	1	Carburetor Primer

Ref. No.	Part No.	Qty.	Description

△ Included in Valve Gasket Set-Ref. 1095.
★ Included in Engine Gasket Set-Ref. 358.

◆ Included in Carburetor Overhaul Kit-Ref. 121.
◆ Included in Carburetor Gasket Set-Ref. 977.




Assemblies include all parts shown in frames.

Muffler and Fuel Tank Assembly Briggs and Stratton Model 12F802-1770-B1

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
81	691740	1	Muffler Screw Lock				
187	691050	1	Fuel Line				
			(Cut to Required Length)				
190	690940	1	Screw (Fuel Tank)				
300	496106	1	Muffler				
601	95162	1	Hose Clamp				
613	691340	1	Screw (Muffler)				
670	692294	1	Fuel Tank Spacer				
676	493871	1	Muffler Deflector				
677	690661	1	Screw (Muffler Deflector)				
957	397974	1	Fuel Tank Cap				
972	495224	1	Fuel Tank				
1059	692311	1	Screw/Washer Kit				

△ Included in Valve Gasket Set-Ref. 1095.
★ Included in Engine Gasket Set-Ref. 358.
Obtain Parts from Briggs and Stratton

● Included in Carburetor Overhaul Kit-Ref. 121.
◆ Included in Carburetor Gasket Set-Ref. 977.



1036 EMISSIONS LABEL

Assemblies include all parts shown in frames.


**Flywheel and Blower Housing Assembly
Briggs and Stratton Model 12F802-1770-B1**

Ref. No.	Part No.	Qty.	Description
23	692315	1	Flywheel
37	694086	1	Flywheel Guard
78	691108	1	Screw (Flywheel Guard)
304	493293	1	Blower Housing
305	691108	1	Screw (Blower Housing)
332	690877	1	Nut (Flywheel)
356	692390	1	Stop Wire
363	19069	1	Flywheel Puller
455	691219	1	Flywheel Cup
1036	695111	1	Emissions Label

Ref. No.	Part No.	Qty.	Description

△ Included in Valve Gasket Set-Ref. 1095.
★ Included in Engine Gasket Set-Ref. 358.
Obtain Parts from Briggs and Stratton
16

● Included in Carburetor Overhaul Kit-Ref. 121.
◆ Included in Carburetor Gasket Set-Ref. 977.







Assemblies include all parts shown in frames.

Starter Assembly
Briggs and Stratton Model 12F802-1770-B1

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
55	691421	1	Rewind Starter Housing				
58	280399	1	Starter Rope				
60	281434	1	Starter Rope Grip				
65	690837	1	Screw (Rewind Starter)				
456	692299	1	Pawl Friction Plate				
459	281505	1	Pawl Ratchet				
592	690800	1	Nut (Rewind Starter)				
597	691696	1	Screw (Pawl Friction Plate)				
608	497680	1	Rewind Starter				
689	691855	1	Friction Spring				
1210	498144	1	Pulley/Spring Assembly (Pulley)				
1211	498144	1	Pulley/Spring Assembly (Spring)				

△ Included in Valve Gasket Set-Ref. 1095.
★ Included in Engine Gasket Set-Ref. 358.
Obtain Parts from Briggs and Stratton

● Included in Carburetor Overhaul Kit-Ref. 121.
◆ Included in Carburetor Gasket Set-Ref. 977.

358 ENGINE GASKET SET**977 CARBURETOR
GASKET SET****1095 VALVE
GASKET SET****121 CARBURETOR
OVERHAUL KIT**

Assemblies include all parts shown in frames.

Gasket Assembly

Briggs and Stratton Model 12F802-1770-B1

Ref. No.	Part No.	Qty.	Description
★3	299819	1	Oil Seal (Magneto Side)
★Δ7	692249	1	Cylinder Head Gasket
★Δ9	272481	1	Breather Gasket
★12	692232	1	Crankcase Gasket
★20	399781	1	Oil Seal (PTO Side)
★51	272199	1	Intake Gasket
●104	691242	1	Float Hinge Pin
121	498260	1	Carburetor Overhaul Kit
●127	694468	1	Welch Plug
●134	398188	1	Needle/Seat Kit
●◆137	693981	1	Float Bowl Gasket
★◆◆163	272653	1	Air Cleaner Gasket
●276	271716	1	Sealing Washer
358	497316	1	Engine Gasket Set
★524	692296	1	Dipstick Tube Seal
★585	691879	1	Breather Passage Gasket
●◆617	270344	1	O Ring Seal (Intake Manifold)
●◆633	691321	1	Choke Throttle Shaft Seal
★668	493823	1	Spacer (Includes 2)

Ref. No.	Part No.	Qty.	Description
★842	691031	1	O Ring Seal (Dipstick Tube)
977	498261	1	Carburetor Gasket Set
1095	498528	1	Valve Gasket Set

Δ Included in Valve Gasket Set-Ref. 1095.

★ Included in Engine Gasket Set-Ref. 358.

Obtain Parts from Briggs and Stratton

● Included in Carburetor Overhaul Kit-Ref. 121.

◆ Included in Carburetor Gasket Set-Ref. 977.

Maintenance Record

[illegible]

