



**Count on it.**

**Parts Catalog**

**eS3000SD 72V**

**TORO® 76cm**

**Model No. 75500—Serial No. 321000001 and Up**



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity


In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

Deck Assembly .....	4
Chassis Assembly .....	6
Transmission Assembly .....	8
Transmission Assembly No. 134-6166 .....	10
Front Wheel Assembly .....	12
Steering Assembly .....	14
Steering Rack Assembly No. 134-6201 .....	16
Steering Rod Assembly No. 134-6202 .....	18
Body Styling Assembly .....	20
Battery Controller Assembly .....	22
Light Assembly .....	24
Seat Assembly .....	26
Deck Lift Assembly .....	28


# Deck Assembly



## Deck Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	134-6133	1	Welded Deck ASM	20	134-5725	2	Blade, Deck
2	134-5706	4	Wheel, Deck	21	134-5726	2	Washer, Blade
3	09703	4	Bolt-HH	22	134-5727	2	Nut, Blade
4	ZWP1H000U	12	Washer-Plain	23	ZDH1E016U	6	Screw-HH
5	134-5709	8	Insert, Deck Wheel	24	09470	6	Washer
6	09441	8	Nut-Hex, NI	25	09430	6	Nut-Nyloc
7	134-5712	1	Cover, Deck Chute	26	134-3739	12	Screw-HHF
8	134-5378	1	Chute, Deck	27	ZWP1F000U	20	Washer
9	134-5714	1	Bracket, Discharge Flap	29	134-6145	1	Rear HOC Lifting ASM
10	134-5715	1	Rod, Discharge Flap	30	134-7178	4	Bolt, Flange
11	134-5716	1	Spring, Discharge Flap	32	09479	4	Washer-Plain
12	09570	2	Bolt-Carriage	33	134-6148	1	Rod, Front Deck Moutning (Short)
13	09438	22	Nut-Nyloc				
14	134-5719	4	Bolt	34	134-5739	2	Rod, Front Deck Moutning
15	134-6596	1	Deck Chute Clip, ASM	36	134-6149	1	Mounting Bracket ASM, Deck
16	134-5721	2	Top Cover, Deck Motor				
17	134-5722	2	Bottom Cover, Deck Motor	37	134-5742	2	Pin, Split
18	134-5723	2	Motor, Deck	45	134-6069	2	Decal - No Spray
19	134-5724	2	Hub, Blade Motor	46	134-6027	2	Decal - Deck Warning


# Chassis Assembly



## Chassis Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	134-6508	1	Bumper Bar, ASM	9	134-5752	2	Mounts, Side Pannel
2	134-5745	2	Cap, Bumper Bar	10	09361	4	Screw-HH
3	134-3746	4	Screw-HHF	11	09438	12	Nut-Nyloc
4	09441	4	Nut-Hex, NI	12	134-7193	4	Bolt
5	134-5748	1	Front Plate, Main Chassis	14	134-5756	1	Top Cover, Chassis
6	134-5749	2	Bolt, Flange	18	134-6026	1	Decal - Charging Port
7	134-5750	2	Nut	19	134-6031	1	Decal - Danger
8	134-6297	1	Chassis ASM				

# Transmission Assembly






## Transmission Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	134-5761	6	Nut	30	134-6189	1	Braking Switch ASM
2	134-6306	1	Bobby Pin	31	134-6193	1	Hand Brake, Hub ASM
3	09441	11	Nut-Hex, NI	32	134-6196	1	Hand Brake, Handle ASM
4	134-6465	1	Washer	33	134-6200	1	Switch ASM
5	134-6466	1	Shaft, Throttle	33:1	134-5831	1	Cover, Switch
6	134-5786	2	Rod, Brake Connection	33:2	134-5832	2	Bolt
7	134-5787	5	Bobby Pin	33:3	09658	2	Washer
8	134-5788	2	Pin, Brake Connection (Flat)	33:4	134-5834	2	Nut
9	134-5789	2	Nut , Brake Adjustment	33:6	134-6473	1	Housing, Braking Switch
10	134-5791	1	Pin, Brake Cable	34	134-6458	1	Pedal Throttle
11	134-5792	6	Mounting, Brake Rod	35	09438	1	Nut-Nyloc
12	134-5793	3	Plate, Brake Mouting	37	09470	4	Washer
13	134-5796	1	Cover, Wire	39	09631	4	Bolt
15	134-5812	2	Plate, Pedal Mouting	41	ZBH1E035U	1	Bolt
16	134-5813	4	Block, Pedal Holder	42	ZDH1E016U	4	Screw-HH
17	134-5814	2	Clip	43	ZWP1F000U	4	Washer
18	134-5815	1	Spring, Pedal	44	134-6514	1	Throttle Sensor
19	134-6506	1	Cable, Pedal Brake	45	134-6471	1	Bushing, Parking Brake
22	134-6507	1	Cable, Hand Brake	46	134-6472	1	ASM, Switch Pivot
24	134-6166	1	Transmission Assembly	47	09363	2	Screw-HH
25	134-6178	1	Rear Transision ASM	48	09681	6	Bolt
26	134-6182	1	Insert, Wire (Small)	49	134-7225	4	Nut
28	134-6184	1	Brake Pedal ASM	50	134-6164	2	Tyre, Wheel
29	134-6188	2	Cover, Pedal	51	134-7214	2	Hub, Rear Wheel


# Transmission Assembly No. 134-6166



# Transmission Assembly No. 134-6166 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	134-6167	1	Semi Axle ASM (RH)	3	134-6304	1	Reduction Gearbox ASM
2	134-6172	1	Semi Axle ASM (LH)	4	134-6177	1	Rear Motor ASM


# Front Wheel Assembly



## Front Wheel Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	134-3765	2	Nut-Flange, NI	11	134-6183	1	Front Axle ASM
3	134-6598	1	Mount Front Wheel	12	134-5742	2	Pin, Split
4	134-5802	2	Washer	14	134-6450	2	Washer
5	134-5803	2	Bottom Bush, Axle	15	134-6597	1	Mount Front Wheel
6	134-5804	2	Top Small Bush, Axle	16	134-6164	2	Tyre, Wheel
8	134-5807	1	Pin, Front Axle Tilt	17	134-7218	2	Hub, Wheel (Front)
9	134-5808	2	Stopper, Front Axle Tilt				


# Steering Assembly



## Steering Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	134-6201	1	Steering Rack ASM	8	134-6202	1	Steering Rod ASM
2	134-5849	4	Mounting Block, Steering Rack	9	134-7189	1	Steering Wheel
3	134-5850	2	Plate, Mounting Block	10	134-5864	4	Bolt
4	ZBH1H080U	4	Bolt	11	134-5865	4	Nut
5	ZWP1H000U	4	Washer-Plain	13	09488	1	Washer
6	09441	4	Nut-Hex, NI	14	ZNN1L000U	1	Nut-Nyloc
7	134-5855	1	Washer	15	134-7188	1	Cover, Steering Wheel

# Steering Rack Assembly No. 134-6201






# Steering Rack Assembly No. 134-6201 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	134-5846	1	Steering Rack	10	134-5848	2	Ziptie
2	134-5742	2	Pin, Split	11	ZDH1E012U	2	Screw-HH
3	134-5842	2	Nut	12	09644	2	Washer-Spring
4	09480	2	Washer-Lock	13	09470	2	Washer
5	09479	2	Washer-Plain	14	134-5856	1	Clip, Steering Rack
6	134-5843	2	Cover, Pivot	15	134-6341	2	Adjuster, Tie Rod
7	134-5844	2	Rod End	16	134-6411	1	Tie Rod, Main
8	134-5845	2	Nut, Adjustment	17	134-6412	2	End, Tie Rod
9	134-5847	2	Bellows, Steering Rack	18	134-6413	1	Shaft, Steering Rack


# Steering Rod Assembly No. 134-6202



## Steering Rod Assembly No. 134-6202 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	134-5857	1	Connection, Steering Rack	7	134-5866	2	Bearing, Steering
2	134-5858	1	Lower Rod, Steering Rack	8	134-5867	2	Clip, Steering Bearing
3	134-6599	1	Universal Joint	11	134-6338	3	Washer, Lock
4	134-5861	1	Cover, Upper Steering Rod	12	134-6339	3	Bolt, Steering
5	134-5862	1	Upper Rod, Steering				
6	134-5863	1	Plate, Mounting Steering Rod				


# Body Styling Assembly



## Body Styling Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	134-5380	1	Front Panel, Steering Column	18	134-5373	1	Cover, Top/Rear
2	134-5379	1	Front Panel Moutning, Steering Column	19	134-5376	1	Cover, Middle/Rear
3	134-7690	6	Bolt	20	134-5374	1	Cover, RH/Bottom
4	134-5872	15	Clip, Bolt	21	134-5375	1	Cover, LH/Bottom
5	134-5381	1	RH Panel, Steering Column	22	134-5880	34	Washer
6	134-5382	1	LH Panel, Steering Column	23	134-5881	5	Washer
7	134-7193	12	Bolt	24	134-5882	4	Washer, Bent
8	09438	12	Nut-Nyloc	25	134-5883	3	Mountng Bracket, Rear Panel
9	134-5719	30	Bolt	26	134-5884	6	Bolt PH
10	134-6501	1	Panel Floor, LH	27	134-5885	5	Bolt PH
11	134-6502	1	Panel Floor, RH	28	134-6070	1	Decal - Erider Battery
12	134-6515	7	Cap Bolt	29	134-6071	1	Decal - Toro Logo
13	134-3739	4	Screw-HHF	30	134-6072	1	Decal - Toro Logo
14	134-5879	4	Nut	31	134-6030	1	Decal - HOC
15	134-5372	1	Cover, LH/Middle	32	134-6029	1	Decal - Parking Brake
16	134-5370	1	Cover, Top	33	134-6032	1	Decal - Brake
17	134-5371	1	Cover, RH/Middle	34	134-6033	1	Decal - Traction
				38	134-6505	4	Bolt


# Battery Controller Assembly



## Battery Controller Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	134-5834	8	Nut	17	134-5928	1	Buzzer
2	134-5886	6	Battery	19	134-6205	1	Cutting Controller
3	134-5887	2	Stap, Battery	20	134-6206	1	Power Connector ASM
4	134-6512	2	Holder, Battery	21	134-6237	2	Bolt
5	134-5902	1	Cutting Controller	23	HY09698	4	Nut-Nyloc
6	134-5903	1	Driving Controller	24	134-6712	1	Charger
9	134-5906	8	Flat Bush, Rubber	26	134-8675	1	Wiring Harness, Controler Connector
10	134-5907	8	Bush, Rubber	27	134-8676	1	Wiring Harness, Battery Connector
11	134-5908	2	Spring Washer	28	134-8796	1	Wiring Harness, Battery/Charging Wire
12	134-5911	8	Bolt	29	134-8797	1	Wiring Harness, Fuse Wire
14	134-5915	2	Bolt				
15	134-5918	1	Insert, Rubber Cable Large				
16	134-5920	2	Bolt				

# Light Assembly






## Light Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	134-5383	1	Casing, Light (Right, Front)	11	134-5900	2	Bolt
2	134-5384	1	Casing, Light (Left, Front)	12	134-6595	1	Control Box, ASM
3	134-5385	2	Bracket, LED Lights	13	134-5919	1	Insert, Rubber Cable Small
4	134-5889	1	Plate, Switches	14	134-5925	1	Plate, Lights
5	134-5890	6	Bolt	15	134-5927	4	Bolt
6	134-5891	1	USB Switch	16	134-6203	2	Direction Switch ASM
7	134-5892	1	Button, Reverse Mow And Nut	17	134-6204	1	Cutter Button ASM
8	134-5893	1	Button, Cruise Control And Nut	18	134-6237	2	Bolt
9	134-5898	1	Switch, Ignition And Nut	20	HY09698	4	Nut-Nyloc
10	134-5899	1	Indicator, Battery Level	21	134-6028	1	Decal - Control Panel
				22	134-8673	1	Wiring Harness, Control Panel


# Seat Assembly



## Seat Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	134-6509	1	Seat	15	134-3763	1	Nut-Flange, NI
2	134-5930	1	Mounting Plate, Seat	16	134-3749	1	Screw-HHF
3	134-6511	1	Seat Slide ASM, RH	17	134-5945	1	Shaft, Spring
4	134-6510	1	Seat Slide ASM, LH	18	134-5946	1	Small Spring, Seat
5	134-6332	1	Seat Base, ASM	21	134-5949	1	Washer
7	03469	12	Washer-Spring	22	134-5950	1	Plate, Spring Seat
8	ZWP1H000U	14	Washer-Plain	23	134-5951	1	Seat Sensor
9	09441	5	Nut-Hex, NI	24	134-6335	2	Nut, Seat
10	134-3747	2	Screw-HHF	25	134-6334	12	Bolt Seat, Slide Mount
12	134-5940	1	Spring, Seat	26	134-5936	1	Adjustment Spring, Seat
13	134-3751	1	Screw-HHF	27	134-5937	1	Adjustment Lever Cap, Seat
14	09479	1	Washer-Plain	28	ZNH1H000U	4	Nut-Hex

# Deck Lift Assembly



## Deck Lift Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	134-6251	1	HOC Plate ASM	15	134-5968	1	Long Plate, HOC
2	134-6252	1	HOC Lever ASM	16	134-5969	1	Adjustment, HOC
4	134-5956	1	Spring, HOC Lever	17	134-3747	2	Screw-HHF
5	134-5957	4	Bush, HOC Shaft	18	ZWP1H000U	2	Washer-Plain
6	134-5958	5	Clip, HOC Shaft	19	09441	7	Nut-Hex, NI
7	134-5959	1	HOC Shaft	20	134-7178	4	Bolt, Flange
8	134-5960	1	Shaft, HOC Lever	21	09681	1	Bolt
9	134-5962	2	Clip, HOC Lever Shaft	22	134-5973	1	Plain Nut
10	134-6254	1	HOC Rotation Plate ASM (Small)	23	134-5974	1	Short Shaft, HOC Lever
11	134-5963	3	Bush, HOC Shaft	24	09479	4	Washer-Plain
12	134-5966	1	Short Plate, HOC	25	134-6414	1	Washer
14	134-5967	1	Plate, Rotation Large (HOC)	26	134-5953	1	HOC, Grip

**Notes:**

**Notes:**



**Count on it.**