



Mid-Size Mower

ProLine Gear 13HP with 32in Side Discharge Mower

Model No. 30316—230000001 and Up

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.


Contents

Description	Page	Description	Page
Fuel Tank and Idler Bracket Assembly	3	Cylinder Head, Valves And Breather (Kohler CV13T–PS–21524)	14
Transmission and Idler Pulley Assembly	4	Ignition / Electrical (Kohler CV13T–PS–21524)	15
Brake, Wheel Pulley and Wheel Assembly	5	Blower Housing And Baffles (Kohler CV13T–PS–21524)	16
Handle and Control Panel Assembly	6	Starter System (Kohler CV13T–PS–21524)	17
Engine Assembly	7	Fuel System (Kohler CV13T–PS–21524)	18
Carrier Frame Assembly	8	Engine Controls (Kohler CV13T–PS–21524)	19
Deck Assembly	9	Air Cleaner Assembly (Kohler CV13T–PS–21524)	20
Spindle Assembly	10	Exhaust (Kohler CV13T–PS–21524)	21
Decal and Mulcher Cover Assembly	11		
Crankcase Assembly (Kohler CV13T–PS–21524)	12		
Oil Pan / Lubrication (Kohler CV13T–PS–21524)	13		

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

Abbreviation	Meaning	Abbreviation	Meaning
AR	as required	HYD	hydraulic
ASM	assembly	INC	incorporated
CARR	carriage	LH	left hand
DEG	degrees	NI	nylon insert
FH	flat head	PPH	Phillips pan head
GA	gauge	PTH	Phillips truss head
HF	hex flange	PTO	power take off
HH	hex head	RH	right hand
HHF	hex head flange	SFH	slotted fillister head
HLH	hex lag head	SHH	slotted hex head
HJ	hex jam	SQH	square head
HOC	height-of-cut	SHWH	slotted hex washer head
HS	hex socket	SPH	slotted pan head
HSBH	hex socket button head	SRH	slotted round head
HSFH	hex socket flat head	STD	standard
HSH	hex socket head	TAP	self tapping
HWH	hex washer head	TTH	Torx truss head
HWHTF	hex washer head thread forming	WH	wing head




Sheet No.:2

Fuel Tank and Idler Bracket Assembly

Ref. No.	Part No.	Qty.	Description
1	88-3980	1	Gas Cap ASM
1:3	88-4010	1	Gasket-Cap, Gas
2	106-0730	1	Fuel Tank ASM
2:2	103-2605	1	Fitting-Fuel, Bulkhead
5	3296-39	8	Nut-Lock, NI
6	74-0040	4	Spacer-Pivot, Idler
7	51-4370	1	Spring-Torsion, RH
8	51-4380	1	Spring-Torsion, LH
9	32103-25	2	Nut-Wing
10	3256-23	10	Washer-Flat
11	52-2890	2	Bushing-Nylon
12	3290-307	4	Pin-Hair
13	74-0230-01	1	Bracket-Idler, RH
14	74-0220-01	1	Bracket-Idler, LH
15	74-0521	2	Fitting-Rod
16	283-6	2	Pin-Clevis
17	67-6370-01	1	Bracket-Support, RH
18	67-6380-01	1	Bracket-Support, LH
19	323-16	2	Screw-HH
20	323-6	6	Screw-HH
21	3296-23	2	Nut-Lock, NI
22	95-2800	2	Pulley-Idler
23	95-2801	2	Spacer-Pulley
24	51-4450	2	Screw-Leveler
25	68-9690	2	Fitting-Rod
26	237-124	1	Grommet

Ref. No.	Part No.	Qty.	Description
29	105-4670-01	1	Frame ASM
30	322-4	4	Screw-HH
31	3253-4	2	Washer-Lock
33	95-2814	1	Decal-Shut Off, Fuel
34	106-0649-01	1	Frame-Upper, Painted
36	98-0776	1	Decal-Caution
37	104-8121	2	Stud-Threaded
38	1-633349	2	Spring-Tank, Fuel
39	3296-47	2	Nut-Lock, NI




Sheet No.:3

Transmission and Idler Pulley Assembly

Ref. No.	Part No.	Qty.	Description
1	98-3274-03	1	Lever-Shift
2	47-1970	1	Grip
3	3296-42	4	Nut-Lock, NI
4	32120-64	1	Ring-Snap, External
5	1-323252	2	Bearing-Shaft
6	321-4	4	Screw-HH
7	104-1102	2	Shaft-Output
9	3257-5	3	Key-Woodruff
10	3245-3	2	Screw-Set, HS
11	105-2698	2	Pulley-Transmission
12	51-4220	2	Guard-Coupler
13	98-0789	2	Coupler
14	302-5	2	Fitting-Grease
15	3245-1	1	Screw-Set, HSH
16	51-4190	1	Pulley-Driven
17	26-9671	1	V-Belt
18	323-9	1	Screw-HH
19	51-4810	1	Pulley-Idler
20	3256-24	1	Washer-Flat
21	32128-21	1	Nut-HF
22	322-2	4	Screw-HH
23	3253-4	4	Washer-Lock
24	1-323500	1	Transmission
25	3296-6	1	Nut-Lock, NI
26	98-5975	1	Washer-Belleville
27	1-323379	1	Washer

Ref. No.	Part No.	Qty.	Description
28	32151-62	2	Ring-Retaining
29	3256-24	1	Washer-Flat
30	1-323254	2	Flange-Output
31	95-1526	1	Shield-Trailing
32	95-1529	1	Rod-Shield
33	104-8102-01	1	Plate-Gate, Shift
34	98-3256	1	Decal-Speed, Ground




Sheet No.:4

Brake, Wheel Pulley and Wheel Assembly

Ref. No.	Part No.	Qty.	Description
1	51-4580	2	Rod-Brake
2	3290-307	2	Pin-Hair
3	67-6400-01	1	Arm-Brake, RH
4	67-6420-01	1	Arm-Brake, LH
5	32151-40	2	Ring-Retaining
6	32151-56	2	Ring-Retaining, External
7	51-4660-01	2	Plate-Link, Brake
8	51-4650-01	2	Link-Brake
9	93-1163	2	Wheel & Tire ASM
9:1	231-94	1	Tire-Front
9:2	93-1181	1	Wheel ASM
9:3	92-1746	2	Bearing-Ball
9:4	302-57	1	Fitting-Grease
9:5	232-27	1	Stem-Valve
10	10-8110	8	Washer-Thrust
11	32151-91	2	Ring-Retaining
12	51-4291	2	V-Belt
13	51-4170	8	Spacer-Pulley
14	51-4160-03	4	Pulley-Wheel
15	51-4180-03	2	Drum-Brake
16	3253-4	8	Washer-Lock
17	51-4700	2	Band-Brake
18	322-7	8	Screw-HH
19	51-4230	2	Washer-Wheel
20	32151-72	4	Ring-Retaining

Ref. No.	Part No.	Qty.	Description




Sheet No.:5

Handle and Control Panel Assembly

Ref. No.	Part No.	Qty.	Description
1	82-7690-03	1	Bar-Control
2	82-2290	1	Decal-Bar, Control
3	3296-2	5	Nut-Lock
4	82-7680-03	1	Bail
5	32105-1	1	Screw-SHH
6	106-5477-03	1	Control Pivot ASM
7	82-2280	1	Decal-Handle, Reverse
8	3272-11	2	Pin-Cotter
9	105-3158-03	1	Upper Handle ASM
11	104-8140	1	Switch-PTO
12	63-8360	2	Key-Ignition
14	3296-42	1	Nut-Lock, NI
16	93-1187-03	1	Panel-Bottom
17	104-8141	1	Module-Delay
18	321-2	1	Screw-HH
19	283-55	2	Pin-Clevis
21	74-0630	1	Control-Throttle
23	29-5560	1	Switch-On/Off
23:1	218-461	1	Nut-HH
23:2	3254-5	1	Washer-Tooth
24	3290-378	2	Tie-Cable
25	104-8136	1	Harness-Wire
26	2412-120	2	R-Clamp
27	32104-76	4	Screw
28	104-8177-03	1	Panel-Control

Ref. No.	Part No.	Qty.	Description
29	104-7050	1	Housing-Manual
30	32128-21	4	Nut-HF
31	3234-11	4	Screw-HHF
32	32105-14	4	Screw
33	106-5499	1	Decal-Control Panel
34	105-0884	1	Decal-Danger
35	82-7632	2	Rod-Control
36	218-595	1	Connector-Body
37	51-4850-03	1	Lever-Brake, Parking
38	52-2010	1	Decal-Lever, Parking
39	82-2190	1	Switch-Bail
40	3290-307	2	Pin-Hair
41	237-141	2	Grommet-Rubber
42	98-4387	1	Decal-Protection, Ear
43	104-7048	1	Cap-Housing




Sheet No.:6

Engine Assembly

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
☆1		1	Engine—Kohler, Cv13t—Ps—21524	30	47-2966	1	Hose—Fuel
2	32144-19	1	Screw—Forming, Thread	31	1-603770	1	Valve—Fuel
3	2412-87	1	Clamp—Cable				
4	56-6360	1	Filter—Fuel				
5	2412-98	5	Clamp				
6	47-2982	2	Hose—Fuel				
7	2412-108	1	Clamp—Worm				
8	12-3270	1	Screw				
9	3255-7	1	Washer—Lock/Ext				
10	3256-23	1	Washer—Flat				
12	33114-025	4	Screw—HH				
13	51-4540-03	1	Retainer—Clutch				
14	74-0930-01	1	Guard—Pulley				
15	3212-9	1	Screw—HH				
16	112843	1	Washer				
17	105-2635	1	Clutch/Brake				
18	608006	1	Key—Square				
19	105-0827	1	Pulley—Drive				
26	74-0950	2	Elbow—Street, 90°				
27	289-20	1	Nipple—Pipe				
28	288-4	1	Cap—Pipe				
29	106-0699	1	Decal—Warning, Hot Surfaces				

☆ Not serviced separately




Sheet No.:7

Carrier Frame Assembly

Ref. No.	Part No.	Qty.	Description
☆1		1	Frame—Carrier
2	94—1291	4	Bushing—Special
3	74—0330	4	Pad—Rubber
4	3269—24	16	Rivet
5	32151—91	2	Ring—Retaining
6	3—6781	4	Washer—Thrust
7	93—1166	2	Spacer—Castor
8	325—18	2	Screw—HH
9	67—6220	2	Spanner
10	93—1164—01	2	Fork—Caster
11	32153—5	2	Nut—Lock
12	63—8400	2	Caster—Wheel & Tire
12:1	62—5580	2	Bearing—Outside
12:2	63—8580	1	Bearing—Roller
12:3	302—11	1	Fitting—Lube, 45°
13	67—6570	4	Spacer—Wheel
14	302—5	2	Fitting—Grease
15	256—156	2	Bushing—Flange
16	74—0290	2	Spring
17	41—8440	2	Washer
18	3218—5	4	Nut—Jam
19	74—0310	2	Shaft—Adjusting
20	3296—45	2	Nut—Lock, NI
21	3234—6	6	Screw—HHF
22	32128—23	6	Nut—HF

Ref. No.	Part No.	Qty.	Description

☆ Not serviced separately




Sheet No.:8

Deck Assembly

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
☆1		1	Deck ASM				
☆2		1	Spindle ASM				
5	32153-2	1	Nut-Lock, Side-Deform				
6	28-8010	1	Spring				
7	44-5930	1	Deflector ASM				
7:2	54-9220	1	Decal-Danger				
8	28-7350	1	Post-Pivot				
9	67-6180	1	Strip-Magnetic				
10	3234-29	2	Screw-HHF				
11	67-6160-01	1	Cover				
12	104-8587	1	Knob				
13	3256-24	1	Washer-Flat				
14	32151-72	1	Ring-Retaining				
15	74-0570	1	Guide-Belt				
16	3290-355	4	Pin-Hair				
17	67-6140	2	Rod-Support				
18	3296-29	24	Nut-Lock, NI				
19	322-4	24	Screw-HH				
20	92-5419-03	4	Ring-Recycler				
21	3290-496	2	Nut-Retainer				
22	80-2630-03	4	Kicker				
23	67-6920	1	V-Belt				


☆ Not serviced separately



Spindle Assembly

Ref. No.	Part No.	Qty.	Description
1	104-6325	2	Bearing
2	32146-20	1	Nut-Jam
3	3253-23	1	Washer-Lock/Sp
4	51-4060	1	Screw-Blade
5	67-6060	1	Housing-Spindle
6	67-6070	1	Spacer-Bearing
7	67-6080	1	Spacer
8	7-3522	1	Cup-Anti Scalp
9	7-4150	1	Washer
10	74-0580	1	Pulley ASM
11	80-4430	1	Blade-Recycler
12	82-4750	1	Spacer-Blade
13	105-4607	1	Shaft-Spindle

Ref. No.	Part No.	Qty.	Description




Sheet No.:9

Decal and Mulcher Cover Assembly

Ref. No.	Part No.	Qty.	Description
1	66-1340	1	Decal-Danger
2	67-5360	1	Decal-Danger
3	105-2625	1	Decal-Safety STD
4	68-8340	1	Decal-Torque
5	93-1159	1	Decal-HOC
6	106-0719	1	Decal-Proline
7	67-6170	1	Decal
8	54-0910	1	Decal-Hot
9	66-6380	1	Decal-Danger
10	92-5422	1	Mulcher Cover ASM
10:1	28-8070	1	Lanyard
10:2	28-8130	1	Pin-Locking, Chute
10:3	3256-49	1	Washer-Flat
10:4	3290-282	1	Rivet-Pop, Steel
11	322-11	1	Screw-HH
12	3256-23	2	Washer-Flat
13	3296-29	1	Nut-Lock, NI

Ref. No.	Part No.	Qty.	Description




Crankcase Assembly (Kohler CV13T-PS-21524)

Ref. No.	Part No.	Qty.	Description
1	12 032 03	1	Seal-Crankshaft
2	12 522 33	1	Shortblock
3	12 445 02	1	Strap-Lifting
4	M-0839025	1	Screw M8x1.25x22
5	12 380 17	4	Dowel-Locating
6	12 755 49	1	Kit-Camshaft INC 7-8
7	12 089 31	1	Spring-Actuating
8	12 422 07	A/R	Shim-Camshaft A/R
8	12 422 08	1	Shim-Camshaft A/R
8	12 422 09	A/R	Shim-Camshaft A/R
8	12 422 10	A/R	Shim-Camshaft A/R
8	12 422 11	A/R	Shim-Camshaft A/R
8	12 422 12	A/R	Shim-Camshaft A/R
8	12 422 13	A/R	Shim-Camshaft A/R
9	12 144 27	1	Shaft-Balance
10	12 847 01	1	Set Piston w/Ring STD
10	12 847 02	1	Set-Piston w/Ring .25
10	12 847 03	1	Set-Piston w/Ring .50
11	12 018 02	2	Retainer-Piston Pin
12	12 108 01	1	Ring Set STD
12	12 108 02	1	Ring Set .25
12	12 108 03	1	Ring Set .50
13	12 067 05	1	Rod Connecting STD
13	12 067 06	1	Rod Connecting .25

Ref. No.	Part No.	Qty.	Description
14	12 380 01	1	Pin-Governor Regulating
15	12 043 05	1	Gear-Governor ASM
16	M-0631005	1	Washer-Governor
17	12 144 02	1	Shaft-Governor Gear
18	52 139 09	1	Plug-Cup
19	12 755 64	1	Kit - Shaft-Governor Cross (Incl. Ref.#23)
20	X-25-102	1	Washer-Flat
21	12 032 01	1	Seal-Governor Shaft
22	M-0631015	1	Washer-Governor Shaft
23	12 154 05	1	Clip - Hitch Pin
24	12 014 30	1	Crankshaft ASM
25	12 139 01	1	Plug-Cup
*	12 030 02	1	Bearing - Crankshaft 0.25
*	12 030 03	1	Bearing - Crankshaft 0.50
*	12 755 83	1	Set - Gasket

* Not Illustrated

Obtain parts from Kohler




Oil Pan / Lubrication (Kohler CV13T-PS-21524)

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	12 038 01	1	Dipstick INC 2-3	22	24 086 16	11	Screw-M8X1.25X45
2	25 755 13	1	Kit-Oil Cap INC 3	23	24 068 17	1	Screw-M5X1.25X45
3	12 153 03	1	O Ring-Fill Cap				
4	12 153 02	1	O Ring-Upper Fill Tube				
5	12 123 04	1	Tube-Oil Fill				
6	M-0545020	1	Screw M5x0.8x20				
7	12 153 01	2	O Ring-Lower Fill Tube				
8	25 162 07	1	Screen-Oil				
9	12 096 03	1	Cover-Oil Pickup Screen				
10	M-0545016	1	Screw M5x0.8x16				
11	52 050 02	1	Filter-Oil				
12	12 755 45	1	Pan - Oil (Incl. Ref. #13, 14, 17-20)				
13	25 462 09	1	Valve - Oil Pressure				
14	X-75-2	2	Plug-1/4nptf				
15	X-75-1	2	Plug-1/8nptf				
16	X-75-10	2	Plug-SH 3/8 NPTF				
17	12 393 01	1	Pump-Oil				
18	12 153 06	1	O Ring-Oil Pump Cover				
19	12 096 34	1	Cover-Oil Pump				
20	M-0545016	3	Screw M5x0.8x16				
21	12 032 03	1	Seal-Crankshaft				

*Not illustrated

Obtain parts from Kohler




Cylinder Head, Valves And Breather (Kohler CV13T-PS-21524)

Ref. No.	Part No.	Qty.	Description
1	12 351 02	2	Lifter-Valve
2	12 755 81	1	Kit-Cylinder Head
3	12 411 01	2	Rod-Push
4	12 041 08	1	Gasket-Cylinder Head
5	12 017 01	1	Valve-Intake STD
5	12 017 02	1	Valve-Intake .25
6	12 016 01	1	Valve-Exhaust STD
6	12 016 02	1	Valve-Exhaust .25
7	12 318 19	1	Head - Cylinder
8	12 468 05	1	Washer-Flat
9	12 112 13	1	Spacer-Head Bolt Exhaust
10	12 086 15	5	Screw M10x1.5x80
11	12 089 01	1	Spring-Valve
12	12 173 01	2	Cap-Valve Spring
13	12 755 03	2	Kit-Retainer
14	X-426-9	2	Clamp-Hose
15	12 326 03	1	Hose-Breather
16	M-0645020	3	Screw-HH M6x1.0x20
17	12 096 07	1	Cover-Valve w/Nipple
18	24 023 05	1	Seal-Valve Spring
19	M-0640034	2	Screw M6x1.0x34
20	12 599 03	2	Pivot - Rocker Arm
21	25 186 01	2	Arm-Rocker

Ref. No.	Part No.	Qty.	Description
22	M-0545010	1	Screw M5x0.8x10
23	12 018 01	1	Retainer-Breather
24	12 402 02	1	Reed-Breather

*Not illustrated


Obtain parts from Kohler



Ignition / Electrical (Kohler CV13T-PS-21524)

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	12 086 14	1	Screw-Flywheel Mounting	*	25 518 29	1	Lead-Black
2	12 486 03	1	Washer-Flat	*	24 126 71	1	Bracket - Stator Wire
3	12 162 03	1	Screen-Grass				
4	M-0639016	4	Screw M6x1.0x16				
5	12 112 01	4	Spacer-Fan				
6	12 157 02	1	Fan				
7	X-42-15	1	Key				
8	236602	1	Connector-Regulator				
9	12 403 01	1	Rectifier-Unregulated				
10	X-22-11	2	Washer - Lock				
11	M-0639016	2	Screw M6x1.0x16				
12	41 155 03	1	Connector				
13	12 025 15	1	Flywheel ASM				
14	M-0548025	4	Screw M5x0.8x25				
15	54 755 09	1	Kit - Stator-15 Amp (Incl. Bracket P/N #24 126 71)				
16	12 132 02	1	Spark Plug				
17	X-728-1	2	Clip-Kill Lead				
18	M-0545010	1	Screw M5x0.8x10				
19	12 584 02	1	Module-Ignition				
20	M-0545020	2	Screw M5x0.8x20				
*	X-25-5	1	Washer				
	12 518 01	1	Lead-White				
*	25 518 05	1	Lead-Black				

* Not illustrated
Obtain parts from Kohler




Blower Housing And Baffles (Kohler CV13T-PS-21524)

Ref. No.	Part No.	Qty.	Description
1	M-0545010	15	Screw M5x0.8x10
2	12 096 29	1	Cover-Starter
3	12 027 37	1	Housing-Blower
4	12 063 05	1	Baffle-Carburetor
5	12 063 08	1	Baffle-Cyl. Head
6	12 313 03	1	Grommet-Blower
7	12 063 01	1	Baffle-Cylinder
8	12 146 07	1	Plate-Blower Housing
*	12 133 66	1	Decal-Horsepower

Ref. No.	Part No.	Qty.	Description


* Not illustrated
Obtain parts from Kohler



Starter System (Kohler CV13T-PS-21524)

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	12 165 01	1	Starter Incl 3–9				
2	M–0545010	5	Screw M5x0.8x10				
3	12 081 01	1	Housing–Starter				
4	12 160 01	1	Rope–Starter				
5	25 166 01	1	Handle–Recoil				
6	12 089 06	1	Spring & Keeper				
7	12 093 01	1	Pulley				
8	12 757 06	1	Kit–Dog Replacement (incl. Ref.#9)				
9	41 086 09	1	Screw–Posidrive				
10	15 109 01	1	Cup–Driver				
*	12 113 07	1	Decal–Starting				

* Not illustrated
Obtain parts from Kohler




Fuel System (Kohler CV13T-PS-21524)

Ref. No.	Part No.	Qty.	Description
1	M-0641060	2	Nut M6x1.0
2	M-0629122	2	Stud M6x1.0x110
3	12 853 78	1	Kit-Carburetor w/Gaskets
4	12 041 02	1	Gasket-Air Cleaner
5	12 053 78	1	Carburetor ASM
6	12 041 01	2	Gasket-Carburetor
7	12 265 04	1	Deflector-Heat
8	47 154 01	1	Clip-Cable
9	12 313 01	1	Grommet
*	12 757 02	1	Kit-Float
*	12 757 08	1	Kit-Choke Repair
*	12 757 03	1	Kit-Carburetor Repair

Ref. No.	Part No.	Qty.	Description

* Not illustrated


Obtain parts from Kohler



Engine Controls (Kohler CV13T-PS-21524)

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	12 079 07	1	Linkage-Choke				
2	12 237 01	1	Clamp-Cable				
3	M-0664020	2	Screw M6X1.0X20				
4	M-0645016	1	Screw-HH M6x1.0x16				
5	12 536 01	1	Control-Speed				
6	SM-0443025	1	Screw				
7	12 089 11	1	Spring				
8	12 089 23	1	Spring-Choke Return				
9	12 089 19	1	Spring-Governor				
10	12 755 83	1	Kit - Governor Lever (Incl. Ref.#11-13)				
11	12 100 07	1	Nut				
12	52 211 04	1	Bolt - Round HD				
13	12 090 26	1	Lever-Governor				
14	25 158 08	1	Bushing-Linkage				
15	12 079 01	1	Linkage-Throttle				
16	25 158 11	1	Bushing-Linkage				

Obtain parts from Kohler




Air Cleaner Assembly (Kohler CV13T-PS-21524)

Ref. No.	Part No.	Qty.	Description
1	12 734 02	1	Kit—Air Cleaner (Incl. Ref.# 2–11)
2	25 341 03	1	Knob—Cover
3	12 096 16	1	Cover—Air Cleaner
4	12 083 12	1	Precleaner—Element
5	12 100 01	1	Nut—Wing
6	12 083 10	1	Element—Air Cleaner (Incl. Ref.#7)
7	12 032 11	1	Seal
8	12 094 07	1	Base—Air Cleaner (Incl. Ref.#9, 10)
9	12 072 04	1	Stud—Mounting Plate
10	12 086 01	1	Screw—Mounting Plate
11	12 041 02	1	Gasket—Air Cleaner
*	12 113 04	1	Decal—Air Cleaner

Ref. No.	Part No.	Qty.	Description

* Not illustrated
Obtain parts from Kohler



Exhaust (Kohler CV13T-PS-21524)

Ref. No.	Part No.	Qty.	Description
1	12 068 03	1	Muffler
2	M-0829033	2	Stud M8x1.25x20
3	12 755 30	1	Kit-Bracket (Incl. Ref.#4-9)
4	M-0650012	2	Screw
5	X-25-52	2	Washer
6	12 041 03	1	Gasket – Exhaust
7	12 126 55	1	Bracket-Muffler
8	12 468 01	1	Washer
9	12 086 13	1	Screw
10	M-0645025	1	Screw
11	12 445 06	1	Strap-Lifting

* Not illustrated
Obtain parts from Kohler

Maintenance Record

[illegible]

Maintenance Record

[illegible]

