

LAWN-BOY®

Silver Series® Walk Behind Lawnmower Model No. 10357-230000001 and Up

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.

Contents

Description	Page
Housing, Handle Bracket and Wheel Assembly . .	3
Gear Case Assembly No. 104-7671	4
Gear Case and Wheel Assembly	5
Engine Assembly	6
Handle Assembly	7
Battery and Switch Assembly	8
Engine Assembly	
Tecumseh Model No. LEV120-362006A	9
Engine Assembly	
Tecumseh Model No. LEV120-362006A	10


Description	Page
Engine Assembly (continued)	
Tecumseh Model No. LEV120-362006A	11
Recoil Starter Assembly No. 590702	
(Optional	
Tecumseh Model No. LEV120-362006A	12
Recoil Starter Assembly No. 590739	
Tecumseh Model No. LEV120-362006A	13
Carburetor Assembly No. 640303	
Tecumseh Model No. LEV120-362006A	14
Electric Starter Kit No. 35709	
Tecumseh Model No. LEV120-362006A	15

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

Abbreviation	Meaning
AR	as required
ASM	assembly
CARR	carriage
DEG	degrees
FH	flat head
GA	gauge
HF	hex flange
HH	hex head
HHF	hex head flange
HLH	hex lag head
HJ	hex jam
HOC	height-of-cut
HS	hex socket
HSBH	hex socket button head
HSFH	hex socket flat head
HSH	hex socket head
HWH	hex washer head
HWHTF	hex washer head thread forming

Abbreviation	Meaning
HYD	hydraulic
INC	incorporated
LH	left hand
NI	nylon insert
PPH	Phillips pan head
PTH	Phillips truss head
PTO	power take off
RH	right hand
SFH	slotted fillister head
SHH	slotted hex head
SQH	square head
SHWH	slotted hex washer head
SPH	slotted pan head
SRH	slotted round head
STD	standard
TAP	self tapping
TTH	Torx truss head
WH	wing head




Sheet No.:2

Housing, Handle Bracket and Wheel Assembly

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	40-1940	2	Washer	28	322-3	6	Screw-HH
2	95-7403-03	2	Bracket-Height Adjustment, Wheel	29	92-8647	1	Shield-Trailing
3	92-7731	2	Plate-Baffle	30	3296-29	6	Nut-Lock, NI
4	92-4890	2	Washer-Wheel	32	92-1008	2	Knob-Lever, Height Adjustment
5	92-4881-03	2	Plate-Height, Adjustment	33	614687	2	Arm-Front Spring
10	98-4477	1	Deck ASM	34	614672	2	Bolt-Shoulder
10:3	43-8480	1	Decal-Danger	35	92-1099	2	Bolt-Shoulder
10:4	613765	1	Nut-Cage	36	684776	2	Wheel & Tire ASM
10:6	99-6018	1	Decal-Warning	*	95-7052	1	Plate-Opening, Chute
10:7	92-2914	1	Decal-HOC, LH				
10:8	92-2915	1	Decal-HOC, RH				
10:9	93-7250	1	Decal-Warning				
10:10	94-1610	2	Grommet-Plastic				
10:13	614677	2	Screw-Sems				
17	92-8630	1	Plate-Mulch				
18	98-8332	1	Knob				
19	105-8602	1	RH Bracket ASM				
21	95-7068	1	Cover-Drive				
22	92-9665	1	Screw				
23	65-5221	2	Screw-HWHTF				
24	92-7728-03	1	Guide-Transmission				
25	605120	1	Grommet				
26	104-7671	1	Gear Case ASM				
27	105-8604	1	LH Bracket ASM				


* Not illustrated



Gear Case Assembly No. 104-7671

Ref. No.	Part No.	Qty.	Description
1	104-7619	1	Case-Gear
2	614668-03	1	Cover-Case, Gear
3	32144-4	4	Screw-HWH
4	32151-68	1	Ring-Retaining
5	3256-24	1	Washer-Flat
6	3285-19	2	Pin-Groove
7	3296-5	1	Nut-Lock, NI
8	36-4780	2	Washer
9	36-4791	2	Washer-Thrust
10	60-8750	2	Bushing
11	60-8850	2	Bushing
12	614696	1	Shaft-Intermediate
13	614669	2	Half-Pulley
14	100-1048	1	Bearing-Ball
15	62-6660	1	Spacer
16	104-7668	1	Gear-15t Spur, 37t Bevel
17	104-7667	1	Gear-Pinion, Bevel
18	614596	1	Gear
19	104-7670	1	Shaft-Output

Ref. No.	Part No.	Qty.	Description




Gear Case and Wheel Assembly

Ref. No.	Part No.	Qty.	Description
1	92-1057	2	Bolt-Shoulder
2	92-1042	2	Wheel & Tire ASM
2:3:1	27-6250	2	Bushing
3	65-2720	4	Klipring-Locking
4	65-4740	4	Washer-Thrust, Keyed
5	66-6050	1	Key-Rocking, LH
*6	66-6040	1	Key-Rocking, RH
7	65-4710	2	Ring-Friction
8	92-7746	2	Rear Height Adjustment Arm ASM
8:2	70-9760	1	Bushing
8:3	47-2900	1	Bushing
8:4	302-56	1	Fitting-Grease
9	92-1008	2	Knob-Lever, Height Adjustment
10	614447	2	Spacer-Axle Shaft
11	32144-85	2	Screw-HWH
12	92-1004	2	Rear Spring Arm ASM
13	603773	2	Nut
14	65-4730	2	Washer-Arm, Pivot
15	65-4760	2	Washer-Clutch
16	65-4750	2	Gear-Pinion
17	65-4720	2	Spring-Compression
18	94-1609	2	Cover-Wheel

Ref. No.	Part No.	Qty.	Description
19	614426	2	Washer-Stepped
20	93-7381	1	V-Belt

* Not illustrated




Sheet No.:5

Engine Assembly

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	105-8579	1	Bolt-Blade,Sems				
2	612543-03	1	Blade				
3	92-1024-03	1	Guide-Belt				
4	104-7955	1	Decal-Deck				
5	95-5569	1	Muffler Guard ASM				
5:1	65-2690	1	Decal-Surface, Hot				
7	32144-85	1	Screw-HWH				
8	98-1593	1	Applique				
9	106-8303	1	Decal-Recoil, Lb				
10	92-1701	1	Stop-Rope				
☆11		1	Engine-Tecumseh Model Lev120-362006a				
12	93-4196-03	1	Shield-Grass				
13	95-1726	3	Screw-Taptite W/Patch				
14	106-3950	1	Driver-Blade, ASM				
15	106-6826	1	Spacer				

☆ Not serviced separately



Sheet No.:6

Handle Assembly


Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	104-1013	1	Guard-Cable				
2	614643-05	1	Handle-Lower				
3	100-5989	1	Brake Cable ASM				
4	93-7383	1	Guide-Rope				
5	321-50	1	Screw-HH				
6	100-1045-05	1	Handle-Upper				
7	92-5412	2	Stop-Pivot				
8	93-4184-03	1	Bail-Brake				
10	92-1001-03	1	Bail-Control				
11	3296-73	2	Nut-Lock, NI				
12	3256-1	1	Washer-Flat				
13	100-5982	1	Cable-Ground Speed				
14	92-7729	1	Anchor-Upper, Cable				
15	92-2266	1	Screw-Handle				
16	106-4161	2	Knob-Handle				
17	614697	2	Screw				
18	93-7380	1	Anchor-Cable				

Battery and Switch Assembly

Ref. No.	Part No.	Qty.	Description

8

Engine Assembly Tecumseh Model No. LEV120-362006A



Engine Assembly Tecumseh Model No. LEV120-362006A

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	37465	1	Cylinder (Incl. 2, 20 & 150)	110B	36954	1	Wire Ass'y
2	26727	2	Dowel Pin	*119	36787	1	Cylinder Head Gasket
6	33734	1	Breather Element	120	37714	1	Cylinder Head
7	36557	1	Breather Ass'y. (Incl. 6 & 12A)	125	36780	1	Exhaust Valve (1/32" OS) (Incl. 151)
12	36775	1	Breather Tube	125	37288	1	Exhaust Valve (Std.) (Incl. 151)
12A	36558	1	Breather Cover & Tube (Incl. 12B)	126	37289	1	Intake Valve (Std.)(Incl. 151 & 151A)
12B	36694	1	Breather Tube Elbow	130	6021A	8	Screw, 5/16-18 x 1-7/16"
14	28277	1	Washer	135	35395	1	Resistor Spark Plug (RJ19LM)
15	30589	1	Governor Rod (Incl. 14)	150	31672	2	Valve Spring
16	34839A	1	Governor Lever	151	31673	2	Valve Spring Cap
17	31335	1	Governor Lever Clamp	151A	40017	1	Intake Valve Seal
18	651018	1	Screw, T-15, 8-32 x 19/64"	166	37813	1	Engine Shroud (Green)
19	36281	1	Extension Spring	*169	36783	1	Valve Cover Gasket
20	32600	1	Oil Seal	172	36784	1	Valve Cover
30	37692	1	Crankshaft	174	30200	2	Screw, 10-24 x 9/16"
40	40027	1	Piston, Pin & Ring Set (Std.)	178	29752	2	Nut & Lock Washer, 1/4-28
41	40042	1	Piston & Pin Ass'y. (Std.) (Incl. 43)	182	6201	2	Screw, 1/4-28 x 7/8"
42	40006	1	Ring Set (Std.)	*184	26756	1	Carburetor To Intake Pipe Gasket
43	20381	2	Piston Pin Retaining Ring	185	37466	1	Intake Pipe
45	36777	1	Connecting Rod Ass'y. (Incl. 46)	186	32653	1	Governor Link
46	32610A	2	Connecting Rod Bolt	189	650839	2	Screw, 1/4-20 x 3/8"
48	27241	2	Valve Lifter	191	36559A	1	S.E. Brake Bracket (Incl. 195)
50	37460	1	Camshaft (Exhaust MCR) (Inc. 104)	195	610973	1	Terminal
52	29914	1	Oil Pump Ass'y	207	34336A	1	Throttle Link
*69	37609	1	Mounting Flange Gasket	216	33086	1	R.P.M. Adjusting Lever
70	37608	1	Mounting Flange (Incl. 72-83,306,309A & 311A)	223	650451	2	Screw, 1/4-20 x 1"
72	37614	1	Oil Drain Plug	*224	36786	1	Intake Pipe Gasket
75	27897	1	Oil Seal	238	650932	2	Screw, 10-32 x 49/64"
80	30574A	1	Governor Shaft	*239	34338	1	Air Cleaner Gasket
81	30590A	1	Washer	241	36919	1	Air Cleaner Collar
82	30591	1	Governor Gear Ass'y. (Incl. 81)	245	36905	1	Air Cleaner Filter
83	30588A	1	Governor Spool	250	37122	1	Air Cleaner Cover
86	650488	6	Screw, 1/4-20 x 1-1/4"	260	37693A	1	Blower Housing
89	611004	1	Flywheel Key	261	30200	2	Screw, 10-24 x 9/16"
90	37787	1	Flywheel	262	650831	2	Screw, 1/4-20 x 1/2"
92	650815	1	Belleville Washer	275	37498	1	Muffler
93	650816	1	Flywheel Nut	277	650988	2	Screw, 1/4-20 x 2-9/32"
100	34443C	1	Solid State Ignition	285	35000A	1	Starter Cup
101	610118	1	Spark Plug Cover	287	650926	2	Screw, 8-32 x 21/64"
103	651007	2	Screw, T-15, 10-24 x 15/16"	290	29774	1	Fuel Line
104	37480	1	Cam Bushing	292	26460	2	Fuel Line Clamp
110	37047	1	Ground Wire	298	28763	2	Screw, 10-32 x 35/64"
110A	36953	1	Wire Ass'y	300	35586A	1	Fuel Tank (Incl. 292 & 301)
				301	36246	1	Fuel Cap Ass'y
				305	35647	1	Oil Fill Tube


Obtain Parts from Local Tecumseh Dealer. * Included in Repair Kit No. 632809.

Engine Assembly (continued)

Tecumseh Model No. LEV120-362006A

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
*306	37610	1	"O"-Ring				
307	35499	1	"O"-Ring				
309	650562	1	Screw, 10-32 x 1/2"				
309A	650783	1	Screw, 10-24 x 3/4"				
310	35648	1	Dipstick				
311A	37611	1	Hold Down Bracket				
313	34080	1	Spacer				
325	35249	1	Wire Clip				
325	37152	1	Wire Clip				
325A	29443	1	Wire Clip				
347	650898A	1	Screw, 10-32 x 27/32"				
361	650831	2	Screw, 1/4-20 x 1/2"				
370A	36261	2	Lubrication Decal				
370C	37695	1	Primer Decal (3 X)				
370D	35977	1	Warning Decal				
380	640303	1	Carburetor (Incl. 184)				
390	590739	1	Rewind Starter				
			(NOTE: This engine could have been built with 590702 starter.)				
395	35709	1	Electric Starter Motor (12 Volt)				
400	37613	1	Gasket Set (Incl. Items Marked PK in Notes)				
416	37530	1	Spark Arrestor Kit (Optional)				
	750876	1	Short Block Asm				

Obtain Parts from Local Tecumseh Dealer. * Included in Repair Kit No. 632809.




Sheet No.:
T-xxxx

Recoil Starter Assembly No. 590702 (Optional)
Tecumseh Model No. LEV120-362006A

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
0	590702	0	Recoil Starter				
1	590599A	1	Spring Pin (Incl. 4)				
2	590600	1	Washer				
3	590696	1	Retainer				
4	590601	1	Washer				
5	590697	1	Brake Spring				
6	590698	2	Starter Dog				
7	590699	2	Dog Spring				
8	590700	1	Pulley & Rewind Spring Ass'y.				
11	590703A	1	Starter Housing Ass'y. (40 degree grommet)				
12	590535	1	Starter Rope (98" X 9/64" dia.)				
13	590701	1	Starter Handle				

Obtain Parts from Local Tecumseh Dealer




Sheet No.:
T-xxxx

Recoil Starter Assembly No. 590739
Tecumseh Model No. LEV120-362006A

Ref. No.	Part No.	Qty.	Description
0	590739	1	Rewind Starter
3	590740	1	Retainer
6	590616	2	Starter Dog
7	590617	2	Dog Spring
8	590618A	1	Pulley & Rewind Spring Ass'y
11	590638A	1	Starter Housing Ass'y (40 degree grommet)
12	590535	1	Starter Rope (Length 98" x 9/64" dia.)
13	590701	1	Starter Handle
14	590760	1	Spring Clip

Obtain Parts from Local Tecumseh Dealer




Sheet No.:

T-xxxx

Carburetor Assembly No. 640303 Tecumseh Model No. LEV120-362006A

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
0	640303	1	Carburetor (Incl. 184 of Engine Parts List)	*31	631022	1	Spring Clip
1	631615	1	Throttle Shaft & Lever Assembly	35	640259	1	PrimerBulb (Red)/Retainer Ring
2	631767	1	Throttle Return Spring	36	640019	1	Main Nozzle Tube
*4	631184	1	Dust Seal Washer	36A	632766	1	Bowl Vent Tube Extension
*5	631183	1	Dust Seal	*37	632547	2	O-Ring, Main Nozzle Tube
6	640070	1	Throttle Shutter	40	640087	1	High Speed Bowl Nut
*7	650506	1	Shutter Screw	*44	27110A	1	Bowl Nut Washer
16	631807	1	Fuel Fitting	*47	630748	1	Welch Plug, Idle Mixture Well
17	651025	1	Throttle Crack Screw/Idle SpeedScrew	*48	631027	2	Welch Plug, Atmospheric Vent
18	630766	1	Tension Spring	60	632809	1	Repair kit (Incl. Items Marked * in Notes)
20	640018	1	Idle Restrictor Screw				
* 20A	640200	1	Idle Restrictor Screw Cap				
25	631867	1	Float Bowl				
*27	631024	1	Float Shaft				
28	632802	1	Float (Plastic)				
*29	631028	1	Float Bowl O-Ring				
*30	632807	1	Inlet Needle, Seat, & Clip (Incl. 31)				

Obtain Parts from Local Tecumseh Dealer. * Included in Repair Kit No. 632809



Sheet No.:
T-xxxx

Electric Starter Kit No. 35709
Tecumseh Model No. LEV120-362006A

Ref. No.	Part No.	Qty.	Description
0	35709	1	Electric Starter (12 Volt)
1	34955	1	Retainer Ring
2	34950	1	Spring Retainer
3	34954	1	Spring
4A	34949A	1	Gear
5B	34943	1	Drive End Cap Ass'y.
6	33450	2	Lock Nut
7	34944	1	Armature
8	34945	1	Housing Ass'y.
10A	590500	1	Thrust Washer
11C	35714	1	Commutator End Cap Ass'y. (Incl. brushes)
12	34947	2	Bolt, 10-32 x 3-3/16"
13	34946	1	Pinion Driver
14	34951	1	Cup Washer
15	34952	1	Retainer Ring
16	34948	1	Washer
17	34953	1	Drive Nut
18	590608	1	Washer

Obtain Parts from Local Tecumseh Dealer.

LAWN-BOY®