



Count on it.

Parts Catalog

GeoLink® Precision Spray System Finishing Kit

**Serial number 415400000 and After Multi
Pro® 5800 Turf Sprayer**

Model No. 41708—Serial No. 400000000 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Monitor and Modem Mount Assembly..... 4

Antenna Mount Assembly..... 5

Manifold Connection Assembly..... 6


Manifold Valve and Hose Assembly..... 7

Hose Assembly No. 131-7292..... 8

Manifold Valve Assembly..... 9


3-Way Valve Assembly No. 147-3183..... 10

Actuator On/Off Assembly No. 140-7377..... 11




Monitor and Modem Mount Assembly

Ref.	Part Number	Qty.	Description
1	114-0282	8	Screw-HH
2	104-7201	8	Nut-HF, NI
3	136-0378-03	1	Bracket-Stiffener
4	147-0617-03	1	Mount-Monitor
5	99-7420	1	Plug-Hole
6	3256-22	4	Washer-Flat
7	140-7381	1	Modem-Mount ASM
7:2	140-7369	4	Magnet
7:3	3290-55	4	Rivet-Pop
8	3290-424	2	Screw-SHH
9	138-9250	2	Spacer
10	138-0719	2	Nut-HF




Antenna Mount Assembly

Ref.	Part Number	Qty.	Description
1	144-6009-03	1	Bracket-Mount, Agi2
2	47-3460	2	U-Bolt
3	104-8301	4	Nut-HF, NI
4	43-5920	4	Washer-Lock, Spring
5	120-4579	4	Screw-HHF
6	147-3178	1	Antenna Mount, ASM
6:2	140-7369	2	Magnet
6:3	3290-55	2	Rivet-Pop



Manifold Connection Assembly

Ref.	Part Number	Qty.	Description
1	161-4139	1	Manifold-Connection ASM
1:1	127-9834	1	Fitting-Tee
1:2	127-9814	2	Fitting-Adapter
1:3	131-0241	2	Fitting-Elb 90
1:4	127-1185	1	Fitting-Cap, Port
1:5	127-9829	5	Clamp/Gasket Kit
1:5:2	127-1145	1	Gasket-Flange
2	107-8704	1	Hosebarb
3	132-4258	2	Hose
4	121-1759	1	Spacer
5	3234-29	1	Screw-HHF
6	104-8300	1	Nut-HF, NI
7	2412-3	4	Clamp-Hose
8	2412-74	1	R-Clamp




Manifold Valve and Hose Assembly

Ref.	Part Number	Qty.	Description
1	147-4683-03	1	Mount-Valve, GPS [black]
2	321-23	4	Screw-HH
3	3256-22	8	Washer-Flat
4	122-0824	1	Harness-Wire
4:8	100-4918	4	Diode
4:18	94-8002	1	Fuse-Blade, 50 Amp
5	104-7201	4	Nut-HF, NI
6	3234-47	8	Screw-HHF
7	104-8300	8	Nut-HF, NI
8	131-7288	2	Hose Nozzle ASM
8:2	130-7265	1	Shank-Nozzle, Single
8:3	139-3088	1	Kit-Fitting, Qc 1/2" STR Barb
8:3:1	133-0398	1	Pin-Fork
8:4	2412-36	2	Clamp-Hose
9	131-7289	2	Hose Nozzle ASM
9:2	130-7265	1	Shank-Nozzle, Single
9:3	139-3088	1	Kit-Fitting, Qc 1/2" STR Barb
9:3:1	133-0398	1	Pin-Fork
9:4	2412-36	2	Clamp-Hose


Ref.	Part Number	Qty.	Description
10	131-7290	4	Hose Nozzle ASM
10:2	130-7265	1	Shank-Nozzle, Single
10:3	139-3088	1	Kit-Fitting, Qc 1/2" STR Barb
10:3:1	133-0398	1	Pin-Fork
10:4	2412-36	2	Clamp-Hose
11	131-7292	2	Hose Nozzle ASM
12	2412-39	2	Clamp-R
13	2412-137	2	Clamp-R, Double
14		1	Manifold ASM-Geolink, Mp5800 ●
15	32180-161	3	Clip-Connector
16	99-7430	1	Relay-Mini
18	161-4185-03	2	Bracket-Bypass
19	3256-2	2	Washer-Flat
20	140-7369	4	Magnet
21	147-4691	4	Screw-PFH
22	3256-21	4	Washer-Flat
23	3296-1	4	Nut-Lock

● Not serviced separately



Hose Assembly No. 131-7292


<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
3	130-7265	2	Shank-Nozzle, Single
4	139-3088	1	Kit-Fitting, Qc 1/2" STR Barb
4:1	133-0398	1	Pin-Fork
5	131-3736	1	Fitting-Tee, Barb
6	2412-36	6	Clamp-Hose



Manifold Valve Assembly


Ref.	Part Number	Qty.	Description
1	147-3187	10	Kit-Qf, Manifold Tee
1:1	147-3185	1	Pin-Fork, Qf Small
1:2	147-3186	1	Pin-Fork, Qf Large
1:3	147-3188	1	Seal-Manifold, Qf Series
2	147-3189	2	Kit-Qf, Flange-M100 Female
2:1	147-3186	1	Pin-Fork, Qf Large
3	127-9834	1	Fitting-Tee
4	147-3193	1	Kit Qf, Plug-Male W/O Port
4:1	147-3188	1	Seal-Manifold, Qf Series
5	147-3183	10	Kit-Tx2 - 3Way Manifold

Ref.	Part Number	Qty.	Description
6	131-0241	1	Fitting-Elb 90
7	140-7377	10	Kit-Actuator Pi, On/Off
8	127-9811	10	Fitting-Cap, Female
8:1	133-0398	1	Pin-Fork
9	127-9829	3	Clamp/Gasket Kit
9:2	127-1145	1	Gasket-Flange
10	161-4187	1	Kit Qf, Plug-Male W/Port
10:1	147-3188	1	Seal-Manifold, Qf Series
11	131-3709	1	Coupler



3-Way Valve Assembly No. 147-3183

Ref.	Part Number	Qty.	Description
1	127-1194	1	Ball-Valve, 3Way
2	130-7317	2	Endcap Kit
2:1	127-1192	1	Seat-Ball
2:2	127-1188	1	O-Ring, Seat (Ball)
2:3	127-1189	1	O-Ring, Endcap
2:4	127-1187	1	O-Ring, Endcap
3	130-8248	1	Valve Stem Kit
3:1	127-1197	2	O-Ring-Stem
4	127-1190	1	Fork-Stem, Valve
5	127-1195	1	Seat-Stem, Valve
6	127-1196	1	Washer-Stem, Valve
7	127-1187	1	O-Ring, Endcap



Actuator On/Off Assembly No. 140-7377

Ref.	Part Number	Qty.	Description
1		1	Actuator - On/Off ●
1:1	130-7301	1	Hairpin-Actuator
2	127-6979	1	Decal-Valve, Agitation
3	127-6981	1	Decal-Valve, On/Off
4	127-6982	1	Decal-Valve, Master Boom
5	127-6976	1	Decal-Valve, Bypass Adjust

● Not serviced separately



Count on it.