Form No. 3468-584 Rev A

TORO®

Count on it.

# Parts Catalog

# Ultra Buggy® 2500

**Model No. 68038—Serial No. 416646980 and Up**

Register at www.Toro.com.
Original Instructions (EN)

*3468-584* A

# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

**Understanding Reference Numbers**

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

**Service Assembly Reference Numbers**

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

**Reference Numbers Indicating Quantity**

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

Engine and Fuel Tank Assembly . . . . . 4
Pump Adaptor and Mounting Assembly . . . . . 6
Piston Pump and Bracket Assembly . . . . . 7
Hydraulic Piston Pump Assembly No. ST50957 . . . . . 8
Gear Motor and Cylinder Assembly . . . . . 9
Hydraulic Motor Assembly No. ST50926 . . . . . 10
Main Frame Assembly . . . . . 11
Brake and Hopper Assembly . . . . . 12
Steering Handle and Axle Assembly . . . . . 13
Wheel and Brake Assembly . . . . . 14
Front Wheel and Hub Assembly . . . . . 15
Hub Assembly No. 139-1328 . . . . . 16
Hydraulic Tank and Dump Pedal Assembly . . . . . 17
Hydraulic Hard Line Routing Assembly . . . . . 19
Hydraulic Hose and Fitting Assembly . . . . . 20

**© 2024—The Toro® Company**
**8111 Lyndale Avenue South**
**Bloomington, MN 55420**



**Contact us at www.Toro.com.**
**Printed in the USA.**
**All Rights Reserved**

# Engine and Fuel Tank Assembly



# Engine and Fuel Tank Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 147-7038 | 1 | Engine-Honda, Gx390 ● |
| 2 | 33005-00 | 4 | Nut-HF |
| 3 | ST50553-03 | 1 | Deflector-Exhaust |
| 4 | 125-0519 | 2 | Screw-Self Tapping |
| 5 | ST45910-03 | 1 | Bracket-Switch, Stop Fuel |
| 6 | 104-2628 | 1 | Screw |
| 7 | 115-8733 | 1 | Screw-HSH |
| 8 | 125-4966 | 1 | Hang Tag-Run, Stop |
| 9 | ST58582 | 1 | Fuel Shut Off Valve ASM |
| 10 | 119-7444 | 2 | Screw-HSBH |
| 11 | 127-2810 | 2 | Fuel Hose Kit |
| 11:1 | 2412-98 | 2 | Clamp-Hose |
| 12 | 130-2101 | 1 | Tank ASM |
| 13 | 130-2117 | 1 | Gauge-Fuel |
| 14 | 33104-025 | 4 | Screw-HHF |
| 15 | ST39056 | 1 | Valve-Strainer |
| 16 | 33095-00 | 4 | Washer-Flat |
| 17 | 33115-050 | 4 | Screw-HH |
| 18 | 114-0284 | 1 | Grommet |
| 19 | 119-3547 | 1 | Valve-Vent, Fuel |
| 20 | 108-9698 | 1 | Hose-Fuel |
| 21 | 2412-80 | 2 | Clamp-Hose |
| 22 | 125-4958 | 1 | Decal-Operation |
| 23 | 127-2880 | 1 | Harness-Wire, Shut Down T |
| 24 | ST36144 | 1 | Filter-Fuel |
| 25 | 127-5595-03 | 1 | Plate-Tank Stand Off |
| 26 | 127-5598-03 | 1 | Plate-Tank Stand Off |
| 27 | 3290-378 | 1 | Tie-Cable |

● Obtain parts from www.honda-engines.com




# Pump Adaptor and Mounting Assembly

| *Ref.* | *Part Number* | *Qty.* | *Description* |
|---|---|---|---|
| 1 | ST32432 | 1 | Adaptor-Motor, Pump |
| 2 | 3274-1 | 4 | Screw-HSH |
| 3 | ST37547 | 1 | Coupling-Engine |
| 4 | ST37548 | 1 | Insert-Coupling |
| 5 | ST45154 | 1 | Coupling-Pump |
| 6 | ST45093 | 1 | Key-Square |
| 7 | 3234-32 | 4 | Screw-HHF |
| 8 | ST50952-03 | 1 | Plate-Mounting, Cable |
| 9 | ST50953-03 | 1 | Cover-Control, Pump |
| 11 | 32128-14 | 2 | Nut-HF |
| 12 | 99-6810 | 4 | Screw-HHF |
| 13 | ST57909 | 1 | Plug-Button |




# Piston Pump and Bracket Assembly

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 125-6369 | 1 | Bracket-Control, Pump |
| 2 | 33105-070 | 2 | Screw-HHF |
| 4 | 33095-00 | 2 | Washer-Flat |
| 5 | 125-8557 | 1 | Control-Pivot Right |
| 6 | 125-8555 | 1 | Control-Pivot Left |
| 7 | 3256-24 | 4 | Washer-Plain |
| 8 | 323-18 | 4 | Screw-HH |
| 9 | ST50948 | 2 | Spacer-Pivot |
| 10 | ST43873 | 2 | Wheel And Bearing ASM |
| 11 | ST50955 | 2 | Cover-End, Cable |
| 12 | 3217-5 | 4 | Nut-Hex |

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 13 | 3274-64 | 6 | Screw-HSH |
| 14 | 3256-22 | 4 | Washer-Flat |
| 15 | ST50991 | 2 | Spring-Extension, Control Pump |
| 16 | ST50951 | 1 | Plate-Arm, Control |
| 17 | 33104-025 | 2 | Screw-HHF |
| 18 | 33004-00 | 1 | Nut-HF |
| 19 | ST50954 | 1 | Plate-Pump, Control |
| 20 | 33114-025 | 2 | Screw-HH |
| 21 | 33024-00 | 2 | Nut-Lock, NI |
| 22 | ST50957 | 1 | HYD Piston Pump ASM |




# Hydraulic Piston Pump Assembly No. ST50957

| *Ref.* | *Part Number* | *Qty.* | *Description* |
|---|---|---|---|
| 1 | 100-6110 | 1 | Overhaul Seal Kit |
| 2 | 127-3867 | 1 | Cylinder Block Kit |
| 3 | 100-6112 | 1 | Plate-Valve |




# Gear Motor and Cylinder Assembly

| *Ref.* | *Part Number* | *Qty.* | *Description* |
|---|---|---|---|
| 1 | ST50926 | 2 | HYD Gear Motor ASM |
| 3 | 33106-100 | 8 | Screw-HHF |
| 4 | 33026-00 | 8 | Nut-Hex |
| 5 | ST50501 | 1 | HYD Cylinder ASM |
| 6 | ST50959 | 2 | Cable-Control |
| 7 | 3220-3 | 2 | Nut-HJ |




# Hydraulic Motor Assembly No. ST50926

| *Ref.* | *Part Number* | *Qty.* | *Description* |
|---|---|---|---|
| 1 | 127-5568 | 1 | Seal Kit |
| 1:1 | | 1 | Seal-Dust ● |
| 1:2 | | 1 | Seal-Housing ● |
| 1:3 | | 1 | Ring-Back Up, Metal ● |
| 1:4 | | 1 | Shim-Back Up ● |
| 1:5 | | 1 | Seal-Back Up ● |
| 1:6 | | 1 | Seal-Shaft ● |
| 1:7 | | 2 | Seal-Body ● |
| 1:8 | | 1 | Seal-Endcover ● |
| 1:9 | | 1 | Bearing-Housing, Rear ● |
| 2 | 127-5569 | 1 | Nut-Shaft |
| 3 | 127-5570 | 1 | Key-Shaft |

● Not serviced separately




# Main Frame Assembly

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 127-2834 | 1 | Main Frame ASM |
| 1:2 | 125-4959 | 2 | Decal-Warning, Crushing |
| 1:3 | 133-8062 | 1 | Decal-Spark Arrestor |
| 2 | 125-8233-03 | 1 | Guard-Splash |
| 3 | 3234-42 | 2 | Screw-HHF |
| 4 | ST38095 | 1 | Lever |
| 5 | 33104-045 | 3 | Screw-HHF |
| 6 | 125-8696-03 | 1 | Step-Platform |
| 7 | 125-8235-03 | 1 | Pedal-Brake |
| 8 | ST45113 | 1 | Shaft-Pivot, Step |
| 9 | ST45249 | 2 | Spacer-Brake |
| 10 | 3256-27 | 2 | Washer-Flat |
| 11 | 3272-13 | 6 | Pin-Cotter |
| 12 | 33098-00 | 1 | Washer-Flat |
| 13 | ST45055 | 1 | Spring-Compression |
| 14 | ST45056 | 1 | Pin-Lockout, Step |
| 15 | ST81122 | 1 | Pin |
| 16 | ST81124 | 1 | Ring-Split |
| 17 | 127-2833 | 1 | Engine Cowl ASM |
| 17:2 | 125-4963 | 1 | Decal-Surface, Hot |
| 17:3 | 127-2855 | 1 | Decal-Warning |
| 18 | ST47182 | 4 | Latch-Rubber |
| 19 | ST81130 | 4 | Screw-HSBH |
| 22 | 125-8190 | 1 | Decal-Brake Pedal |
| 24 | 127-5590 | 1 | Trim-Splash Guard |
| 25 | 130-2844 | 1 | Decal-Dump |
| 27 | 125-4967 | 4 | Decal-Lift Here |




# Brake and Hopper Assembly

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 140-7666-03 | 1 | Hopper Base ASM [black] |
| 2 | ST45096 | 1 | Shaft-Pivot |
| 3 | 3256-28 | 2 | Washer-Flat |
| 4 | 3272-13 | 6 | Pin-Cotter |
| 5 | 302-5 | 7 | Fitting-Grease |
| 6 | ST47001 | 7 | Cap-Plug |
| 7 | 139-7240 | 1 | Hopper-Mortar, ASM |
| 7:2 | 147-3262 | 2 | Decal-Tub, Ultra Buggy |
| 8 | ST80740 | 6 | Bolt-Elevator |
| 9 | 104-8301 | 6 | Nut-HF, NI |
| 10 | ST50925 | 1 | Shaft-Pivot, Lever (Brake) |
| 11 | 3256-6 | 3 | Washer-Flat |
| 12 | ST50571-03 | 1 | Lever-Brake |
| 13 | 3256-24 | 2 | Washer-Plain |
| 14 | ST81110 | 1 | Pin-Clevis |
| 15 | 3272-10 | 1 | Pin-Cotter |
| 16 | ST45129 | 1 | Clevis-Half |

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 17 | ST45128 | 1 | Clevis-Half (Notched) |
| 18 | 3220-2 | 2 | Nut-Jam |
| 19 | 32120-47 | 1 | Ring-Retaining, External |
| 20 | ST45199 | 1 | Cable-Brake, Buggy |
| 21 | ST50995 | 2 | Rod-Brake, Front |
| 22 | 3219-1 | 4 | Nut-Hex |
| 23 | 103509 | 4 | Yoke |
| 24 | ST45222 | 1 | Rod-Brake |
| 25 | 3220-3 | 2 | Nut-HJ |
| 26 | 1-633131 | 2 | Yoke-Linkage, Brake |
| 27 | 3256-23 | 2 | Washer-Plain |
| 28 | 3253-4 | 2 | Washer-Lock |
| 29 | 103-5752 | 2 | Stud-Ball |
| 30 | ST36571 | 1 | Spring-Gas |
| 31 | ST57435 | 1 | Plate-Pivot, Spring (Gas) |
| 32 | 33105-025 | 2 | Screw-HHF |
| 35 | 125-6694 | 3 | Decal-Tie Down |




# Steering Handle and Axle Assembly

| *Ref.* | *Part Number* | *Qty.* | *Description* |
|---|---|---|---|
| 1 | ST50941-03 | 1 | Handle-Steering |
| 2 | ST47125 | 2 | Grip-Handle |
| 3 | ST50937 | 2 | Handle-Control, |
| 4 | ST50938 | 4 | Bushing-Lever, Control |
| 5 | ST81220 | 4 | Pin-Clevis |
| 6 | 32151-86 | 4 | E-Ring |
| 7 | 3256-22 | 4 | Washer-Flat |
| 8 | 33115-050 | 2 | Screw-HH |
| 9 | 33005-00 | 2 | Nut-HF |
| 10 | ST80309 | 1 | Pin |
| 11 | ST37358-03 | 1 | Axle-Steering |

| *Ref.* | *Part Number* | *Qty.* | *Description* |
|---|---|---|---|
| 12 | ST32161 | 2 | Bearing-Roller |
| 13 | ST81109 | 1 | Washer-Thrust |
| 14 | ST36934 | 1 | Plate-Cover, Bearing |
| 15 | ST81108 | 1 | Nut |
| 16 | 3272-13 | 2 | Pin-Cotter |
| 17 | ST45930 | 1 | Spherical Bearing ASM |
| 18 | 32128-26 | 2 | Nut-HF |
| 19 | 3234-29 | 2 | Screw-HHF |
| 20 | 125-4961 | 1 | Decal-Reverse |
| 21 | 125-4960 | 1 | Decal-Forward |






LH Brake Assembly

# Wheel and Brake Assembly

| *Ref.* | *Part Number* | *Qty.* | *Description* |
|---|---|---|---|
| 1 | ST50927 | 1 | LH Brake ASM |
| 1:1 | 127-5562 | 1 | 5 Lug Hub ASM |
| 1:2 | 127-5563 | 8 | Bolt |
| 1:3 | 127-5564 | 4 | Washer-Lock |
| 1:4 | 127-5565 | 1 | Brake-LH |
| 1:5 | 127-5567 | 1 | Block-Brake Mount |
| 2 | ST50928 | 1 | RH Brake ASM |
| 2:1 | 127-5562 | 1 | 5 Lug Hub ASM |
| 2:2 | 127-5563 | 8 | Bolt |
| 2:3 | 127-5564 | 4 | Washer-Lock |
| 2:4 | 127-5566 | 1 | Brake-RH |
| 2:5 | 127-5567 | 1 | Block-Brake Mount |
| 6 | ST50923 | 2 | Plate-Linkage, Brake |

| *Ref.* | *Part Number* | *Qty.* | *Description* |
|---|---|---|---|
| 7 | 3234-29 | 4 | Screw-HHF |
| 8 | 32128-26 | 4 | Nut-HF |
| 10 | 127-5569 | 2 | Nut-Shaft |
| 11 | ST50994 | 2 | Spacer-Wheel, 5 Bolt |
| 12 | ST45197 | 4 | Wheel ASM (With Foam) |
| 13 | ST80045 | 10 | Nut-Lug |
| 14 | ST45080 | 2 | Spacer-Wheel |
| 15 | ST80423 | 4 | Pin-Rod, Connecting |
| 16 | ST81114 | 10 | Bolt-Lug |
| 17 | ST81014 | 2 | Washer-Flat |
| 18 | 100-7607 | 2 | Washer-Lock |
| 19 | ST45106 | 2 | Pin-Quick Release |




# Front Wheel and Hub Assembly

| *Ref.* | *Part Number* | *Qty.* | *Description* |
|---|---|---|---|
| 1 | 139-1328 | 2 | Hub ASM |
| 2 | ST45176 | 2 | Wheel ASM (With Foam) |
| 3 | 3256-28 | 2 | Washer-Flat |
| 4 | ST80054 | 2 | Nut |




# Hub Assembly No. 139-1328

| *Ref.* | *Part Number* | *Qty.* | *Description* |
|---|---|---|---|
| 1 | 139-1327 | 1 | Hub-4In |
| 1:1 | ST39190 | 4 | Stud-Wheel |
| 2 | ST32233 | 2 | Bearing-Roller |
| 3 | ST80045 | 4 | Nut-Lug |
| 4 | ST34573 | 1 | Cap-Dust |
| 5 | ST32052 | 1 | Seal-Hub, Wheel |




# Hydraulic Tank and Dump Pedal Assembly

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 127-7506 | 1 | Tank-Hydraulic |
| 2 | ST38521 | 1 | Breather-Filler |
| 3 | ST39088 | 1 | Strainer |
| 4 | 3234-24 | 4 | Screw-HHF |
| 5 | ST38534 | 1 | Glass Sight ASM |
| 6 | ST46774 | 1 | Plug |
| 7 | 125-8717-03 | 1 | Bracket-Filter, Oil |
| 8 | 3234-47 | 4 | Screw-HHF |
| 9 | ST45150 | 1 | Filter-Return |
| 10 | 117-8304 | 2 | Screw-HHF |
| 11 | 127-2832 | 1 | Heat Sheild ASM |
| 11:2 | 125-4963 | 1 | Decal-Surface, Hot |
| 12 | 32128-26 | 3 | Nut-HF |
| 13 | 137-0578-03 | 1 | Pivot |
| 14 | ST32466 | 2 | Bearing |
| 15 | 136-4582-03 | 1 | Guide-Shaft |
| 16 | 136-4578-03 | 1 | Lever-Control, Valve |
| 17 | ST57532 | 1 | Directional HYD Valve ASM |
| 18 | 137-0568 | 1 | Plate-Lever, Foot Control |
| 19 | 92-2739 | 1 | Pin-Clevis |
| 20 | ST36978 | 1 | Pin-Clevis |

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 21 | 52-6430 | 1 | Washer |
| 22 | 3272-1 | 2 | Pin-Cotter |
| 23 | 32105-18 | 1 | Screw-HHF |
| 24 | 321-33 | 1 | Screw-HH |
| 25 | ST34687 | 1 | Grip-Handle |
| 26 | 3234-29 | 1 | Screw-HHF |
| 27 | 104-7201 | 1 | Nut-HF, NI |
| 28 | ST81076 | 1 | Pin |
| 29 | ST45973-03 | 1 | Mount-Pedal |
| 30 | ST80639 | 1 | Washer-Belleville |
| 31 | ST80957 | 1 | Screw-HSBH |
| 32 | 104-8301 | 1 | Nut-HF, NI |
| 33 | 33115-040 | 1 | Screw-HH |
| 34 | 33015-00 | 1 | Nut-Hex |
| 35 | 322-5 | 3 | Screw-HH |
| 36 | ST45963-03 | 1 | Pedal-Dump |
| 37 | 1-633131 | 2 | Yoke-Linkage, Brake |
| 38 | 3220-3 | 2 | Nut-HJ |
| 39 | ST36744 | 1 | Rod-Linkage |
| 40 | ST45959 | 1 | Tread-Skid |
| 41 | ST35445 | 1 | Element-HYD Oil, 10 Micron |




# Hydraulic Tank and Dump Pedal Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 43 | 125-4962 | 1 | Decal-P Brake |

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 44 | 127-5591 | 1 | Trim-Filter Bracket |
| 48 | 3272-11 | 1 | Pin-Cotter |




# Hydraulic Hard Line Routing Assembly

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | ST50971 | 1 | Fitting-HYD |
| 2 | 340-3 | 1 | Fitting-Straight |
| 2:1 | 237-22 | 1 | O-Ring |
| 2:2 | 237-79 | 1 | O-Ring |
| 3 | 125-8566 | 1 | HYD Tube ASM |
| 4 | 340-77 | 2 | Fitting-Elbow, 90 DEG |
| 4:1 | 237-22 | 1 | O-Ring |
| 4:2 | 237-42 | 1 | O-Ring |
| 5 | 125-8564 | 1 | HYD Tube ASM |
| 6 | 125-8565 | 1 | HYD Tube ASM |
| 7 | 125-8567 | 1 | HYD Tube ASM |

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 8 | 125-8568 | 1 | HYD Tube ASM |
| 9 | ST50985 | 1 | Clamp-Twin |
| 10 | ST37530 | 2 | Clamp-Twin |
| 11 | ST50990 | 1 | Rod-Clamp, Hose |
| 12 | 104-8300 | 1 | Nut-HF, NI |
| 13 | 3256-3 | 2 | Washer-Flat |
| 14 | 322-6 | 1 | Screw-HH |
| 15 | 98-9921 | 2 | Fitting-Straight |
| 15:1 | 237-145 | 1 | O-Ring |
| 15:2 | 237-79 | 1 | O-Ring |
| 16 | ST46679 | 1 | Fitting-HYD |




# Hydraulic Hose and Fitting Assembly

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | ST50971 | 1 | Fitting-HYD |
| 2 | ST46679 | 1 | Fitting-HYD |
| 3 | 125-8561 | 1 | HYD Hose ASM |
| 4 | 340-54 | 1 | Elbow-45 DEG |
| 4:1 | 237-22 | 1 | O-Ring |
| 4:2 | 237-78 | 1 | O-Ring |
| 5 | 340-133 | 1 | Fitting-STR |
| 5:1 | 237-79 | 1 | O-Ring |
| 5:2 | 237-21 | 1 | O-Ring |
| 6 | 125-8562 | 1 | HYD Hose ASM |
| 7 | 340-103 | 1 | Fitting-HYD, 45 DEG |
| 7:1 | 237-78 | 1 | O-Ring |
| 7:2 | 237-21 | 1 | O-Ring |
| 8 | 353-988 | 1 | Plug-Hex |
| 8:1 | 237-79 | 1 | O-Ring |
| 9 | 340-4 | 1 | Fitting-Straight |
| 9:1 | 237-30 | 1 | O-Ring |
| 9:2 | 237-79 | 1 | O-Ring |

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 10 | 125-8560 | 1 | HYD Hose ASM |
| 11 | 340-98 | 1 | Fitting-Elbow, 90 DEG |
| 11:1 | 237-79 | 1 | O-Ring |
| 11:2 | 237-30 | 1 | O-Ring |
| 12 | 354-120 | 1 | Fitting-Elbow, 90 |
| 12:1 | 237-79 | 1 | O-Ring |
| 13 | 98-8153 | 1 | Hose-Return |
| 14 | 2412-141 | 2 | Clamp-Drive, Worm |
| 15 | ST37528 | 1 | Fitting-HYD |
| 16 | 340-112 | 2 | Fitting-Elbow, 90 |
| 16:1 | 237-22 | 1 | O-Ring |
| 17 | 125-8569 | 1 | HYD Hose ASM |
| 17:2 | | 1 | Fitting-Straight,Rgd ● |
| 17:2:1 | 237-22 | 11 | O-Ring |
| 18 | 125-8570 | 1 | HYD Hose ASM |
| 18:2 | | 1 | Fitting-Straight,Rgd ● |
| 18:2:1 | 237-22 | 11 | O-Ring |
| 19 | ST37529 | 1 | Clamp-Twin |

● Not serviced separately




# Hydraulic Hose and Fitting Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 20 | 3256-3 | 1 | Washer-Flat |
| 21 | 322-6 | 1 | Screw-HH |
| 23 | 340-66 | 2 | Fitting-Straight |
| 23:1 | 237-80 | 1 | O-Ring |
| 23:2 | 237-58 | 1 | O-Ring |
| 24 | ST50975 | 2 | Fitting-HYD |

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 25 | 125-8559 | 2 | HYD Hose ASM |
| 26 | 340-6 | 2 | Fitting-Straight |
| 26:1 | 237-30 | 1 | O-Ring |
| 26:2 | 237-80 | 1 | O-Ring |
| 27 | 3290-378 | 3 | Tie-Cable |

● Not serviced separately

## Notes:

## Notes:

**Count on it.**