

LAWN-BOY®

Silver Pro Series®

Walk-Behind Mower

Model No. 10323—230000001 and Up

Model No. 10324—230000001 and Up

Model No. 10324C—230000001 and Up

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.

Contents

| Description | Page | Description | Page |
|--|-------------|----------------------------------|-------------|
| Housing, Handle Bracket And Wheel Assembly | 3 | Grass Bagging Assembly | 9 |
| Gear Case Assembly No. 104-7672 | 5 | Engine Assembly No. 98-1393 | 10 |
| Engine And Blade Assembly | 6 | Short Block Assembly No. 95-7636 | 12 |
| Rear Axle Assembly | 7 | Carburetor Assembly No. 98-7042 | 13 |
| Handle And Controls Assembly | 8 | | |


Accessories

| Description | Model / Part No. | Description | Model / Part No. |
|--------------------|-------------------------|-------------------------|-------------------------|
| Side Bagging Kit | 89817 | Leaf Shredder Kit | 89860 |
| Leaf Bag | 89804 | Leaf Bag Kit with Chute | 89811 |

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

| Abbreviation | Meaning | Abbreviation | Meaning |
|---------------------|-----------------------------------|---------------------|-------------------------|
| AR | as required | INC | incorporated |
| ASM | assembly | LH | left hand |
| CARR | carriage | NI | nylon insert |
| DEG | degrees | PPH | Phillips pan head |
| FH | flat head | PTH | Phillips truss head |
| GA | gauge | PTO | power take off |
| HF | hex flange | RH | right hand |
| HH | hex head | SFH | slotted fillister head |
| HHF | hex head flange | SHH | slotted hex head |
| HLH | hex lag head | SQH | square head |
| HJ | hex jam | SHWH | slotted hex washer head |
| HOC | height-of-cut | SPH | slotted pan head |
| HS | hex socket | SRH | slotted round head |
| HSBH | hex socket button head | STD | standard |
| HSFH | hex socket flat head | TAP | self tapping |
| HSH | hex socket head | TTH | Torx truss head |
| HWH | hex washer head | WH | wing head |
| HWHTF | hex washer head thread forming | | |




Sheet No.:2

Housing, Handle Bracket And Wheel Assembly

| Ref. No. | Part No. | Qty. | Description |
|----------|------------|------|---------------------------------------|
| 1 | 40-1940 | 2 | Washer |
| 2 | 95-7403-03 | 2 | Bracket-Height Adjustment, Wheel |
| 3 | 92-7731 | 2 | Plate-Baffle |
| 4 | 92-4890 | 2 | Washer-Wheel |
| 5 | 92-4881-03 | 2 | Plate-Height, Adjustment |
| 10 | 104-7639 | 1 | Housing-Service (only on: 10324c) |
| 10 | 98-4472 | 1 | Deck ASM (only on: 10323, 10324) |
| 10:3 | 56-6270 | 1 | Decal-Danger (only on: 10324c) |
| 10:3 | 43-8480 | 1 | Decal-Danger (only on: 10323, 10324) |
| 10:4 | 613765 | 1 | Nut-Cage |
| 10:6 | 99-6018 | 1 | Decal-Warning (only on: 10323, 10324) |
| 10:6 | 104-7629 | 1 | Decal-Warning (only on: 10324c) |
| 10:7 | 92-2914 | 1 | Decal-HOC, LH (only on: 10323, 10324) |
| 10:7 | 104-7616 | 1 | Decal-HOC,LH (only on: 10324c) |
| 10:8 | 104-7617 | 1 | Decal-HOC,RH (only on: 10324c) |

| Ref. No. | Part No. | Qty. | Description |
|----------|------------|------|---------------------------------------|
| 10:8 | 92-2915 | 1 | Decal-HOC, RH (only on: 10323, 10324) |
| 10:9 | 93-7250 | 1 | Decal-Warning (only on: 10323, 10324) |
| 10:9 | 104-7627 | 1 | Decal-Warning (only on: 10324c) |
| 10:10 | 94-1610 | 2 | Grommet-Plastic |
| 10:11 | 104-7634 | 1 | Decal-Manual (only on: 10324c) |
| 14 | 614677 | 2 | Screw-Sems (only on: 10323) |
| 17 | 92-8630 | 1 | Plate-Mulch |
| 18 | 98-8332 | 1 | Knob |
| 19 | 105-8602 | 1 | RH Bracket ASM |
| 21 | 95-7413 | 1 | Cover-Drive |
| 22 | 92-9665 | 1 | Screw |
| 23 | 65-5221 | 2 | Screw-HWHTF |
| 24 | 95-1732-03 | 1 | Guide-Transmission |
| 25 | 605120 | 1 | Grommet |
| 26 | 104-7672 | 1 | Gear Case ASM |
| 27 | 105-8604 | 1 | LH Bracket ASM |
| 28 | 322-3 | 6 | Screw-HH |




Sheet No.:7
C-2955

Grass Bagging Assembly

| Ref. No. | Part No. | Qty. | Description |
|----------|-----------|------|---|
| 1 | 100-6361 | 1 | Bag & Adapter ASM. (only on: 10324, 10324c) |
| 1:1 | 614700 | 1 | Strap-Tie (only on: 10324, 10324c) |
| 1:2 | 100-6362 | 1 | Replacement Bag ASM. (only on: 10324, 10324c) |
| 1:3 | 684727-03 | 1 | Adapter (only on: 10324, 10324c) |
| 2 | 613455 | 1 | Hanger-Wire (only on: 10324, 10324c) |
| 3 | 613462-03 | 2 | Clamp-Hanger (only on: 10324, 10324c) |
| 4 | 684729 | 1 | Chute & Support ASM (only on: 10324, 10324c) |
| 4:1 | 614589 | 1 | Nut-Cap (only on: 10324, 10324c) |
| 4:2 | 614591 | 1 | Support-Chute (only on: 10324, 10324c) |

| Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|-------------|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |



Sheet No.:2

Engine Assembly No. 98-1393

| Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|------------------------|
| 1 | 95-7636 | 1 | Short Block ASM |
| 2 | 94-5776 | 1 | Head-Cylinder |
| 3 | 94-5778 | 1 | Gasket-Head |
| 4 | 94-5779 | 2 | Stud |
| 5 | 94-5780 | 2 | Bolt - Head |
| 6 | 50-1170 | 1 | Plug-Spark |
| 7 | 94-5795 | 2 | Gasket-Intake |
| 8 | 612507 | 2 | Screw |
| 9 | 95-1861 | 1 | Hose-Primer |
| 11 | 95-5574 | 1 | Filter-Air |
| 12 | 95-5577 | 1 | Cover-Filter, Air |
| 13 | 610383 | 1 | Retainer-Cover, Filter |
| 14 | 130743 | 1 | Nut |
| 15 | 316959 | 1 | Washer-Lock |
| 16 | 95-1786 | 1 | Cup-Starter |
| 17 | 95-1866 | 1 | Flywheel |
| 18 | 99-2911 | 1 | Module-Ign. |
| 18:2 | 99-6719 | 1 | Lead-Tension, High |
| 19 | 613208 | 4 | Screw |
| 20 | 95-1868 | 1 | Shroud-Recoil |
| 20:2 | 99-6713 | 1 | Recoil And Decal ASM |
| 20:3 | 613773 | 1 | Rope |
| 20:4 | 3290-321 | 4 | Screw-HWH |
| 20:5 | 3296-2 | 4 | Nut-Lock |
| 21 | 700094 | 2 | Screw-HH |
| 22 | 146501 | 2 | Nut |

| Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|-------------------------|
| 23 | 95-1870 | 1 | Screw-Shoulder |
| 24 | 95-1871 | 1 | Screw-HWH |
| 25 | 93-4312 | 1 | Brake Plate ASM |
| 26 | 84-7820 | 1 | Plate-Brake |
| 27 | 3290-459 | 2 | Rivet-Plastic |
| 28 | 92-2925 | 1 | Strap-Insulation |
| 29 | 60-9010 | 1 | Strap-Ground |
| 30 | 100-2929 | 1 | Stop-Strap, Ground |
| 31 | 12-5450 | 1 | Screw |
| 32 | 98-7037 | 1 | Lead Wire-Switch, Brake |
| 33 | 607199 | 1 | Key |
| 35 | 95-1778 | 1 | Gasket-Exhaust |
| 36 | 95-1878 | 1 | Pulley |
| 37 | 104-0214 | 1 | Screw-Set, Cone Point |
| 38 | 92-1043 | 1 | V-Belt |
| 39 | 95-5588 | 1 | Air Base ASM |
| 40 | 95-5578 | 1 | Tunnel-Inlet |
| 41 | 95-7613 | 1 | Gasket-Filter |
| 42 | 3290-456 | 4 | Washer-Belleliver |
| *51 | 609790 | 1 | Sealer-Loctite 50cc |
| 53 | 98-1388 | 1 | Shield-Carburetor |

* Not illustrated

LAWN-BOY®