



Front Axle Shaft Replacement Kit for Reelmaster[®] 5000 Series Traction Units

Part No. 106–7099

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.


For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.



Sheet No.:0

Front Axle Replacement Kit Assembly

Ref. No.	Part No.	Qty.	Description
1	100–3840	1	Shaft–Axle, LH
1	100–3841	1	Shaft–Axle, RH
2	100–3847	2	Retainer–Bearing
3	100–3842	2	Seal–Oil
4	21–8180	2	Bearing ASM
5	100–3845	2	Seal–Grease
6	100–3848	2	O–Ring
7	100–3849	2	Cap–Bearing
8	100–3850	2	Zerk–Special
9	106–9205	10	Stud–Wheel
10	106–9209–03	2	Drum–Brake
11	242–50	10	Nut–Lug
12	106–9206	2	Decal–Torque, Wheel

Ref. No.	Part No.	Qty.	Description