



Form No. 3408-596 Rev E

**Count on it.**

# Parts Catalog

## GrandStand® Multi Force® Snow Machine

Model No. 74527—Serial No. 400000000 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

Ground Drive Assembly ..... 4

RH Transaxle Assembly No. 136-4102 ..... 6

LH Transaxle Assembly No. 136-4103 ..... 8

Motion Control Assembly ..... 10

Control Handle Assembly No. 132-5157 ..... 12

Control Handle Assembly No. 132-5158 ..... 14

Parking Brake Assembly ..... 16

Frame Assembly ..... 18

Wheel, Tire and Bearing Assembly No. 130-4558 ..... 20

Platform Assembly ..... 22


Engine Assembly ..... 24

Fuel Tank Assembly ..... 26

Wire Harness Assembly ..... 28

Attachments and Accessories ..... 30


# Ground Drive Assembly



## Ground Drive Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>               | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 136-4103           | 1           | LH Transmission ASM              | 19          | 132-1135           | 1           | Tank-HYD           |
| 2           | 136-4102           | 1           | RH Transmission ASM              | 19:1        | 133-8677           | 1           | Cap-Vented         |
| 3           | 131-1131-03        | 1           | Support-Transaxle                | 20          | 3229-25            | 3           | Screw-CARR         |
| 4           | 93-2569            | 4           | Screw-HHF                        | 21          | 104-7201           | 3           | Nut-HF, NI         |
| 5           | 116-4701           | 16          | Screw-HHF                        | 22          | 131-7427           | 1           | HYD Hose ASM       |
| 6           | 104-8301           | 18          | Nut-HF, NI                       | 23          | 109-0309           | 1           | Hose-Fuel          |
| 7           | 131-7405-03        | 1           | Plate-Skid, Transmission<br>(RH) | 24          | 92-2379            | 1           | Clamp-Hose         |
| 8           | 131-7404-03        | 1           | Plate-Skid, Transmission<br>(LH) | 25          | 131-7469           | 1           | Rod-Bypass, RH     |
| 9           | 117-5351           | 1           | Spacer                           | 26          | 131-7470           | 1           | Rod-Bypass, LH     |
| 10          | 1-413088           | 1           | Bushing-Lever, Lift              | 27          | 108-2992           | 2           | Pin-Hair           |
| 11          | 131-1175           | 1           | Arm-Idler                        | 28          | 32180-030          | 1           | Clip-Tie           |
| 12          | 114-0463           | 2           | Washer-Friction, Composite       | 29          | 133-4603           | 2           | Snow Tire ASM      |
| 13          | 110-9981           | 1           | Washer-Plain                     | 29:1        | 132-4721           | 1           | Tire               |
| 14          | 3234-39            | 1           | Screw-HHF                        | 29:2        | 132-4722           | 1           | Rim                |
| 15          | 93-1622            | 1           | Pulley-Idler                     | 30          | 242-50             | 8           | Nut-Lug            |
| 16          | 3231-4             | 1           | Screw-CARR                       | 31          | 132-7584           | 2           | Spacer-Hex         |
| 17          | 132-1184           | 1           | Spring-Extension                 | 32          | 104-8300           | 2           | Nut-HF, NI         |
| 18          | 131-1124           | 1           | Belt-V                           | 33          | 3290-250           | 2           | Pin-Cotter         |
|             |                    |             |                                  | 34          | 2412-141           | 2           | Clamp-Drive, Worm  |
|             |                    |             |                                  | 35          | 3290-378           | 1           | Tie-Cable          |

# RH Transaxle Assembly No. 136-4102




# RH Transaxle Assembly No. 136-4102 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 132-4737           | 1           | Nut-Lock                | 8:2         |                    | 1           | Arm-Brake ■        |
| 2           | 132-4738           | 1           | Fan                     | 8:3         |                    | 1           | Pin-Roll ■         |
| 3           | 132-4739           | 1           | Pulley                  | 8:4         |                    | 1           | Shaft-Brake ■      |
| 4           | 136-5402           | 1           | Seal Kit                | 8:5         |                    | 1           | Actuator-Brake ■   |
| 4:1         | 100-6926           | 1           | Cap-Sealing             | 8:6         |                    | 1           | Disc-Brake ■       |
| 4:2         | 132-4736           | 1           | O-Ring                  | 8:7         |                    | 1           | Shoe-Brake ■       |
| 4:3         |                    | 1           | Cap-Seal ■              | 8:8         |                    | 1           | Shim Kit ■         |
| 4:4         |                    | 2           | Seal-Washer ■           | 9           | 132-4735           | 1           | Cap-Oil            |
| 4:5         |                    | 1           | Packing ■               | 10          | 132-4746           | 1           | Drain Bolt Kit     |
| 4:6         | 132-4744           | 1           | Seal-Shaft              | 10:1        |                    | 1           | Seal-Washer ■      |
| 4:7         |                    | 2           | O-Ring ■                | 11          | 136-5401           | 1           | Lever-Control, RH  |
| 4:8         |                    | 1           | Seal-Oil ■              | 12          | 132-4747           | 1           | Sleeve             |
| 4:9         | 121-0959           | 1           | Sealant                 | 13          | 132-4748           | 1           | Washer             |
| 4:10        | 132-4745           | 1           | Seal-Axle               | 14          | 136-5406           | 1           | Axle Flange Kit    |
| 4:11        |                    | 1           | Packing ■               | 14:1        |                    | 1           | Flange ■           |
| 5           | 104-3265           | 1           | Pin                     | 14:2        |                    | 1           | Key-Woodruff ■     |
| 6           | 132-4700           | 1           | Lever-Bypass            | 14:3        |                    | 1           | Washer ■           |
| 7           | 133-1461           | 1           | Expansion Fitting Kit   | 14:4        | 137-4128           | 1           | Nut-Lock           |
| 7:1         | 136-4051           | 2           | Seal-Fitting, Expansion | 14:5        |                    | 1           | Nut-Cap ■          |
| 7:2         |                    | 1           | Fitting ■               | 14:6        | 139-5588           | 1           | Axle ●             |
| 7:3         |                    | 1           | Bolt-Flange ■           | 15          | 132-4743           | 1           | Hydro Filter Kit   |
| 8           | 133-1462           | 1           | RH Brake Kit            | 15:1        | 136-5409           | 2           | Filter             |
| 8:1         |                    | 1           | O-Ring ■                | 15:2        | 136-5410           | 2           | O-Ring             |

● Not illustrated

■ Not serviced separately

# LH Transaxle Assembly No. 136-4103





# LH Transaxle Assembly No. 136-4103 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 132-4737           | 1           | Nut-Lock                | 8:1         |                    | 1           | O-Ring ■           |
| 2           | 132-4738           | 1           | Fan                     | 8:2         |                    | 1           | Arm-Brake ■        |
| 3           | 132-4739           | 1           | Pulley                  | 8:3         |                    | 1           | Pin-Roll ■         |
| 4           | 136-5407           | 1           | Seal Kit                | 8:4         |                    | 1           | Shaft-Brake ■      |
| 4:1         | 100-6926           | 1           | Cap-Sealing             | 8:5         |                    | 1           | Actuator-Brake ■   |
| 4:2         | 132-4736           | 1           | O-Ring                  | 8:6         |                    | 1           | Disc-Brake ■       |
| 4:3         |                    | 1           | Cap-Seal ■              | 8:7         |                    | 1           | Shoe-Brake ■       |
| 4:4         |                    | 2           | Seal-Washer ■           | 8:8         |                    | 1           | Shim Kit ■         |
| 4:5         |                    | 1           | Packing ■               | 9           | 132-4735           | 1           | Cap-Oil            |
| 4:6         | 132-4744           | 1           | Seal-Shaft              | 10          | 132-4746           | 1           | Drain Bolt Kit     |
| 4:7         |                    | 2           | O-Ring ■                | 10:1        |                    | 1           | Seal-Washer ■      |
| 4:8         |                    | 1           | Seal-Oil ■              | 11          | 136-5401           | 1           | Lever-Control, RH  |
| 4:9         |                    | 2           | O-Ring ■                | 12          | 132-4747           | 1           | Sleeve             |
| 4:10        |                    | 4           | O-Ring ■                | 13          | 132-4748           | 1           | Washer             |
| 4:11        |                    | 2           | O-Ring ■                | 14          | 136-5406           | 1           | Axle Flange Kit    |
| 4:12        | 121-0959           | 1           | Sealant                 | 14:1        |                    | 1           | Flange ■           |
| 4:13        | 132-4745           | 1           | Seal-Axle               | 14:2        |                    | 1           | Key-Woodruff ■     |
| 4:14        |                    | 1           | Packing ■               | 14:3        |                    | 1           | Washer ■           |
| 5           | 104-3265           | 1           | Pin                     | 14:4        | 137-4128           | 1           | Nut-Lock           |
| 6           | 132-4700           | 1           | Lever-Bypass            | 14:5        |                    | 1           | Nut-Cap ■          |
| 7           | 133-1461           | 1           | Expansion Fitting Kit   | 14:6        | 139-5588           | 1           | Axle ●             |
| 7:1         | 136-4051           | 2           | Seal-Fitting, Expansion | 15          | 136-5408           | 1           | Manifold           |
| 7:2         |                    | 1           | Fitting ■               | 16          | 132-4743           | 1           | Hydro Filter Kit   |
| 7:3         |                    | 1           | Bolt-Flange ■           | 16:1        | 136-5409           | 2           | Filter             |
| 8           | 133-1468           | 1           | Brake Kit,Left          | 16:2        | 136-5410           | 2           | O-Ring             |

● Not illustrated

■ Not serviced separately


# Motion Control Assembly



## Motion Control Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|------------------------|-------------|--------------------|-------------|---------------------------|
| 1           | 132-5157           | 1           | LH Control Handle ASM  | 9:3         | 103-1167           | 1           | Joint-Ball End, LH        |
| 1:2         | 131-3562           | 1           | Bearing-Sleeve         | 9:4         | 132-7515           | 1           | Rod-Control               |
| 2           | 132-5158           | 1           | RH Control Handle ASM  | 9:5         | 3256-45            | 2           | Washer-Flat               |
| 2:8         | 131-3562           | 1           | Bearing-Sleeve         | 10          | 130-1807           | 1           | RH Control Rod ASM        |
| 3           | 119-0222           | 2           | Grip                   | 10:1        | 92-7008            | 1           | End-Rod, Female           |
| 4           | 103-9928           | 2           | Bearing                | 10:2        | 103-1167           | 1           | Joint-Ball End, LH        |
| 5           | 120-3288           | 1           | Tab-Pivot, LH          | 10:3        | 132-7515           | 1           | Rod-Control               |
| 6           | 3229-1             | 4           | Screw-CARR             | 11          | 3231-28            | 2           | Screw-CARR                |
| 7           | 104-7201           | 6           | Nut-HF, NI             | 12          | 104-8301           | 4           | Nut-HF, NI                |
| 8           | 120-3287           | 1           | Tab-Pivot, RH          | 13          | 3256-24            | 2           | Washer-Plain              |
| 9           | 130-1803           | 1           | LH Control Rod ASM     | 14          | 132-7538           | 1           | Bracket-Adjustment, Speed |
| 9:1         | 1-603807           | 1           | Spring-Return, Neutral | 15          | 126-1499           | 2           | Cam                       |
| 9:2         | 92-7008            | 1           | End-Rod, Female        | 16          | 323-7              | 2           | Screw-HH                  |

Control Handle Assembly No. 132-5157





## Control Handle Assembly No. 132-5157 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|----------------------------|
| 1           | 132-5115           | 1           | Pivot-Control, Motion (LH) |
| 2           | 131-3562           | 1           | Bearing-Sleeve             |
| 3           | 132-5114-03        | 1           | Lever-LH                   |
| 4           | 323-10             | 1           | Screw-HH                   |
| 5           | 104-8301           | 1           | Nut-HF, NI                 |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 6           | 110-7191           | 2           | Washer-Thrust      |
| 7           | 116-2670           | 1           | Screw-Shoulder     |
| 8           | 104-8300           | 1           | Nut-HF, NI         |
| 9           | 132-5146           | 1           | Spring-Extension   |


Control Handle Assembly No. 132-5158



## Control Handle Assembly No. 132-5158 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 120-8490           | 1           | Pivot-Control, Motion (RH) | 6           | 116-2670           | 1           | Screw-Shoulder     |
| 2           | 130-1825-03        | 1           | Lever-RH                   | 7           | 104-8300           | 1           | Nut-HF, NI         |
| 3           | 104-8301           | 1           | Nut-HF, NI                 | 8           | 131-3562           | 1           | Bearing-Sleeve     |
| 4           | 323-10             | 1           | Screw-HH                   | 9           | 132-5146           | 1           | Spring-Extension   |
| 5           | 110-7191           | 2           | Washer-Thrust              |             |                    |             |                    |


# Parking Brake Assembly



## Parking Brake Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|--------------------|
| 1           | 132-5170           | 1           | Brake Handle ASM     | 7           | 32144-4            | 2           | Screw-HWH          |
| 2           | 3230-23            | 5           | Bolt-CARR            | 8           | 132-1187           | 1           | Clamp-Cable        |
| 3           | 104-8300           | 6           | Nut-HF, NI           | 9           | 132-7582           | 1           | Mount-Cable, Brake |
| 4           | 132-5168           | 1           | RH Brake Caliper ASM | 10          | 1-633268           | 1           | Grip-Lever         |
| 5           | 132-5169           | 1           | LH Brake Caliper ASM | 11          | 131-1195           | 2           | Cable-Brake        |
| 6           | 104-8301           | 2           | Nut-HF, NI           |             |                    |             |                    |


# Frame Assembly



## Frame Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>            | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|-------------------------------|-------------|--------------------|-------------|--------------------------|
| 3           | 131-1510-01        | 1           | Frame                         | 26          | 1-543509           | 4           | Bearing-Roller, Tapered  |
| 6           | 131-1523-01        | 1           | Tube-Castor, Short            | 27          | 116-5647           | 2           | Seal-Grease              |
| 7           | 131-1524-01        | 1           | Tube-Castor, Long             | 28          | 1-633508           | 6           | Washer-Bellville         |
| 8           | 132-7537           | 1           | Tower Decal ASM               | 29          | 103-4882           | 2           | Cap-Grease               |
| 8:2         | 131-3524           | 1           | Decal-Level, Oil              | 34          | 3296-51            | 2           | Nut-Lock, NI             |
| 8:4         | 116-8775           | 1           | Decal-Fill, Fuel              | 35          | 3290-271           | 2           | Rivet-Pop                |
| 8:5         | 136-5438           | 1           | Decal-Caution                 | 36          | 3233-7             | 4           | Screw-CARR               |
| 8:6         | 131-3526           | 1           | Decal-Controls                | 37          | 99-5107            | 4           | Nut-Lock                 |
| 8:7         | 131-3528           | 1           | Decal-Fuse                    | 39          | 133-4662-03        | 1           | A-Frame                  |
| 9           | 3234-42            | 4           | Screw-HHF                     | 40          | 127-0649-01        | 2           | Bracket-Cylinder         |
| 10          | 104-8301           | 12          | Nut-HF, NI                    | 41          | 3231-44            | 4           | Screw-CARR               |
| 11          | 131-7455           | 1           | Plate-Striker                 | 43          | 302-40             | 1           | Fitting-Grease, 90 DEG   |
| 12          | 3229-11            | 1           | Screw-CARR                    | 50          | 136-5428           | 2           | Plug-Plastic             |
| 13          | 104-7201           | 1           | Nut-HF, NI                    | 52          | 132-7578-01        | 1           | Guard-Fan, RH            |
| 14          | 105-4886           | 4           | Nut-Tinnerman                 | 53          | 132-7598-01        | 1           | Guard-Fan, LH            |
| 15          | 3230-5             | 3           | Bolt-CARR                     | 58          | 133-5320-01        | 1           | Bracket-Lock             |
| 16          | 104-8300           | 7           | Nut-HF, NI                    | 59          | 133-2021           | 1           | Pin-Hitch                |
| 17          | 107-3844           | 3           | Washer                        | 60          | 87-8460            | 2           | Bumper-Rubber            |
| 18          | 130-4558           | 2           | Wheel/Tire And Bearing<br>ASM | 61          | 92-2762            | 1           | Pin-Hair                 |
| 19          | 132-5161-01        | 1           | Tube-Mount, Fuel Tank         | 62          | 126-5060           | 1           | Decal-Logo, Toro         |
| 20          | 132-1145-03        | 1           | Bracket-Cross                 | 77          | 133-4648           | 1           | Decal Service-Multiforce |
| 21          | 117-3591           | 2           | Decal-Commercial              | 78          | 116-6758           | 1           | Spacer                   |
| 22          | 114-1925           | 2           | Bumper-Rubber                 | 81          | 32151-29           | 4           | Ring-Retaining           |
| 23          | 114-1926           | 2           | Bumper-Rubber                 | 82          | 10-8110            | 4           | Washer-Thrust            |
| 24          | 121-7988-01        | 2           | Fork-Caster                   | 83          | 136-5429           | 2           | Shaft-Pivot              |
| 25          | 1-811010           | 2           | Plug                          | 84          | 127-0369           | 4           | Bushing                  |
|             |                    |             |                               | 85          | 3256-62            | 2           | Washer-Flat              |

# Wheel, Tire and Bearing Assembly No. 130-4558




# Wheel, Tire and Bearing Assembly No. 130-4558 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|--------------------|
| 1           |                    | 1           | Wheel And Bearing ASM ● | 1:5         | 130-4563           | 1           | Wheel And Tire ASM |
| 1:1         | 1-633585           | 2           | Bearing-Cone, Taper     | 2           | 103-2768           | 2           | Guard-Seal         |
| 1:2         | 103-0063           | 2           | Seal-Caster             | 3           | 3296-45            | 1           | Nut-Hex            |
| 1:3         | 103-3051           | 1           | Spacer-Nut ■            | 4           | 325-20             | 1           | Screw-HH           |
| 1:4         | 126-5359           | 1           | Caster Axle ASM         |             |                    |             |                    |

● Not serviced separately

■ Use Pro-Lock, Nut Type (P/N 1-840022, .5ml tube) on spacer nut


# Platform Assembly



## Platform Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 120-8499-03        | 1           | Hinge-Pad                  | 14          | 3231-2             | 2           | Bolt-CARR          |
| 2           | 117-9739           | 1           | Pad-Cushion                | 15          | 3231-27            | 2           | Screw-CARR         |
| 3           | 3256-23            | 4           | Washer-Plain               | 16          | 120-8475-01        | 1           | Platform           |
| 4           | 121-7999           | 4           | Screw-HH, Patch            | 17          | 126-7157           | 1           | Mat-Platform       |
| 5           | 114-0463           | 4           | Washer-Friction, Composite | 18          | 136-5669-01        | 1           | Clamp-Shield       |
| 6           | 133-1426           | 2           | Knob                       | 19          | 32144-70           | 2           | Screw-HWHTF        |
| 7           | 116-2886           | 2           | Slide-Bushing              | 20          | 119-8650           | 1           | Pin-Latch          |
| 8           | 3253-4             | 2           | Washer-Lock                | 21          | 114-5348           | 1           | Spring             |
| 9           | 131-4535           | 2           | Nut-Acorn                  | 22          | 1-603175           | 1           | Knob-Ball          |
| 10          | 111044             | 4           | Spacer                     | 23          | 132-7583           | 2           | Bushing-Flanged    |
| 11          | 114-1915-01        | 2           | Link-Pad                   | 24          | 104-8301           | 2           | Nut-HF, NI         |
| 12          | 3256-4             | 6           | Washer-Flat                | 25          | 323-11             | 2           | Screw-HH           |
| 13          | 3296-59            | 4           | Nut-Lock, NI               |             |                    |             |                    |


# Engine Assembly



## Engine Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 131-1159           | 1           | Engine-Kohler, Ecv749 | 21          | 32144-70           | 2           | Screw-HWHTF             |
| 1:4         | 116-5395           | 1           | Sensor-Oxygen         | 22          | 132-5152           | 1           | Throttle ASM            |
| 2           | 98-5975            | 4           | Washer-Belleville     | 23          | 1-807533           | 2           | Bolt-CARR               |
| 3           | 126-0983           | 4           | Screw-BHTF            | 24          | 32128-17           | 2           | Nut-Lock, Flange        |
| 5           | 132-1168           | 1           | Bracket-Muffler       | 25          | 1-603175           | 1           | Knob-Ball               |
| 6           | 3234-42            | 2           | Screw-HHF             | 26          | 131-3550           | 1           | Muffler Guard ASM       |
| 8           | 104-8301           | 2           | Nut-HF, NI            | 29          | 94-2579            | 1           | Decal                   |
| 9           | 133-4634           | 1           | Muffler-Kohler        | 30          | 131-3530-03        | 1           | Bracket-Mounting, Guard |
| 12          | 3234-17            | 4           | Screw-HHF             | 31          | 106-9758           | 1           | Screw-CARR              |
| 13          | 32128-25           | 4           | Nut-HF                | 32          | 3230-23            | 4           | Bolt-CARR               |
| 14          | 1-807259           | 1           | Key                   | 33          | 104-8300           | 5           | Nut-HF, NI              |
| 15          | 120-8498           | 1           | Pulley                | 34          | 3290-378           | 2           | Tie-Cable               |
| 16          | 136-5411           | 1           | Spacer-Clutch         | 35          | 133-4657           | 1           | Hose ASM                |
| 17          | 107-4136           | 1           | Washer-Flat           | 35:2        | 353-508            | 1           | Plug-HH                 |
| 18          | 1-603610           | 1           | Washer-Spring         | 35:2:1      | 237-42             | 1           | O-Ring                  |
| 19          | 3212-6             | 1           | Screw-HH              |             |                    |             |                         |


# Fuel Tank Assembly



## Fuel Tank Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|--------------------|
| 1           | 132-7560           | 1           | Fuel Tank ASM         | 2           | 110-8255           | 1           | Hose-Fuel          |
| 1:2         | 46-6560            | 2           | Bushing               | 3           | 98-2952            | 1           | Fitting-Straight   |
| 1:3         | 115-7788           | 1           | Cap-Fuel              | 4           | 132-7576           | 1           | Hose-Fuel          |
| 1:4         | 104-5228           | 1           | Fitting-Elbow, 90 DEG | 5           | 132-7545           | 1           | Fuel Line ASM      |
| 1:5         | 132-7559           | 1           | *obs* Fuel Tube ASM   |             |                    |             |                    |

# Wire Harness Assembly



## Wire Harness Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 136-5422           | 1           | Harness-Wire               | 14          | 117-2222           | 1           | Switch-Ignition    |
| 2           | 82-2190            | 2           | Switch-Bail                | 15          | 63-8360            | 1           | Key-Ignition       |
| 3           | 104-8162           | 1           | Battery                    | 16          | 3253-3             | 1           | Washer-Lock        |
| 4           | 130-6635-01        | 1           | Bracket-Hold Down, Battery | 17          | 3217-5             | 1           | Nut-Hex            |
| 5           | 104-7201           | 2           | Nut-HF, NI                 | 18          | 3290-500           | 1           | Screw-PPH          |
| 6           | 1-633651           | 2           | Bolt-Holddown              | 19          | 3256-14            | 1           | Washer-Flat        |
| 7           | 112-7063           | 1           | Cable-Battery, Black       | 20          | 3296-2             | 1           | Nut-Lock, NI       |
| 8           | 130-6570           | 1           | Module-Meter, Hour         | 21          | 1-643275           | 1           | Relay              |
| 9           | 3256-23            | 2           | Washer-Plain               | 22          | 67-1300            | 1           | Decal              |
| 10          | 322-3              | 2           | Screw-HH                   | 23          | 1-643267           | 1           | Indicator-LED, Red |
| 11          | 115-3864           | 1           | Cable-Battery, Positive    | 24          | 133-4654           | 1           | Switch-Plunger     |
| 12          | 109-5715           | 2           | Nut-HHF, Smooth            | 99          | 3290-378           | 4           | Tie-Cable          |
| 13          | 114-0279           | 1           | Switch-PTO, On-On          |             |                    |             |                    |

# Attachments and Accessories

## For 74527 GrandStand Multi Force Snow Machine

| Product Name                                 | Model/Part  |
|----------------------------------------------|-------------|
| Air Cleaner Filter.....                      | 100-4556    |
| Filter Air Safety .....                      | 103-1326    |
| Blade-Recycler, 18in.....                    | 105-7779-03 |
| Blade-Hi Flow, 18in.....                     | 105-7781-03 |
| Blade-Med Flow, 18in .....                   | 105-7794-03 |
| Blade-Low Flow, 18in.....                    | 105-7795-03 |
| Blade-Atomic, 18in .....                     | 105-7796-03 |
| Turbo Baffle Kit .....                       | 107-1634    |
| Blade-Hi Flow, 18in (6 Pack).....            | 108-1117    |
| Blade-Atomic, 18in (6 Pack) .....            | 108-1118    |
| Blade-Lo Flow, 18in (6 Pack) .....           | 110-0406    |
| Blade-Recycler, 18in (6 Pack).....           | 110-0408    |
| Blade-Med Flow, 18in (6 Pack) .....          | 110-0409    |
| Hypr-Oil 500 (quart).....                    | 114-4713    |
| Hypr-Oil 500 (gallon).....                   | 114-4714    |
| Hypr-Oil 500-5 (5 gallon).....               | 114-4715    |
| Recycler Kit .....                           | 115-7467    |
| Brake Hub Puller.....                        | 116-6518    |
| Harness Wire Splitter.....                   | 121-5988    |
| Spark Plug .....                             | 130-8380    |
| Fuel Filter.....                             | 130-8381    |
| Toro Premium Fuel Treatment 12oz Bottle..... | 131-6572    |
| Blade And Belt Kit-52 In.....                | 132-4741    |
| Hydro Filter Kit .....                       | 132-4743    |
| Speed Setting Tool.....                      | 132-7595    |
| Chute Gate Kit W/ Bag.....                   | 133-1434    |
| Trash Bag Assembly.....                      | 133-1435    |
| Roller Striper Kit.....                      | 133-1436    |
| Light Kit.....                               | 133-1437    |
| Electric Accessory Port.....                 | 133-1438    |
| HOC Set Blocks.....                          | 133-1439    |
| Anti-Scalp Kit, 48/52 Grandstand Deck.....   | 133-1440    |
| Trimmer Rack .....                           | 133-1441    |
| Hydro Oil Change Kit .....                   | 133-1457    |
| Strobe Light Kit .....                       | 133-1495    |
| 5 Gallon Bucket .....                        | 133-2533    |
| Snow Tires.....                              | 133-4603    |
| Wheel Weight Kit .....                       | 133-5386    |
| Quick-Attach-Male .....                      | 136-0513    |
| Hydraulic Cap Lock Kit.....                  | 136-5420    |
| Case Drain Kit.....                          | 136-7436    |
| Multiforce EC Float Kit .....                | 136-8350    |
| Broom Rubber Flap Kit .....                  | 137-3920    |
| Lift Cylinder Lock Kit .....                 | 137-4106    |
| Pneumatic Castor Wheel Kit.....              | 137-4136    |
| Bagger Enhancement Kit.....                  | 139-1529    |

## Attachments and Accessories (continued)

|                                                                          |           |
|--------------------------------------------------------------------------|-----------|
| Idler Kit, Blower Kit for GrandStand Multi Force Mower .....             | 139-1546  |
| Starter Fuse Kit, GrandStand Mower .....                                 | 139-5555  |
| 18x8.5x10 X-Tweel Turf.....                                              | 139-7890  |
| 6in Hose Kit, E-Z Vac Twin Bagger, 2016 and After Grandstand Mower ..... | 139-7930  |
| Blower Upgrade Kit, Twin Bagger, 2016 and After Grandstand Mower .....   | 139-7940  |
| Soft Bag (3 Bushel).....                                                 | 30104     |
| 10W30 4-Cycle Engine Oil (32oz Bottle).....                              | 38280     |
| Toro 4-Cycle SAE 30 Oil (32oz Bottle) .....                              | 38903     |
| Twin Bagger Kit.....                                                     | 78524     |
| Blower Drive 52in.....                                                   | 78526     |
| Pro Force Blower .....                                                   | 78593     |
| Grandstand Multi Force Broom.....                                        | 78596     |
| 48in Snowthrower, Multi-Force .....                                      | 78598     |
| Grandstand Multi Force High-Flow Kit .....                               | 78601     |
| Dethatcher, 46in Multi Force .....                                       | 78690     |
| Dethatcher Mount .....                                                   | 78691     |
| Aerator, 38in Multi Force.....                                           | 78694     |
| Aerator Mount, Multi Force .....                                         | 78695     |
| Leaf Plow Without Mount.....                                             | 78697     |
| Spark Arrestor .....                                                     | 98-9099   |
| Filter-Oil .....                                                         | 98020     |
| Kit-Grandstand, Filter, Winter .....                                     | HYD14084  |
| Snow Deflector .....                                                     | MSC04587B |
| Straight Blade, ATV Plow Shoe Kit.....                                   | MSC13040  |
| Blade Extension Kit,6in,STB .....                                        | MSC13850B |
| Grandstand Low Flow Hydraulics Kit .....                                 | MSC13950  |
| Grandstand Side Plow Kit .....                                           | MSC13960  |
| Kit-Plow Side,4'0"STB,Grandstand.....                                    | MSC14780  |
| Blade Crate (Snowplow), ATV Poly S .....                                 | STB13567B |
| Blade Crate (snowplow),4'0,atv Poly S.....                               | STB13759B |
| Urethane Edge Kit .....                                                  | STB13801  |
| Plug-Quick Connect.....                                                  | T56152150 |
| Cap-Connect, Quick .....                                                 | T56152152 |



**Count on it.**