



Count on it.

Parts Catalog


Heater Kit

Workman® UTX Passenger Utility Vehicle


Model No. 08120




Heater Kit Assembly




HEATER ASSEMBLY




ELECTRICAL AND ROTARY CONTROL CABLE ASSEMBLY




HEATER CONTROL ASSEMBLY



COOLANT COMPONENT ASSEMBLY



MIDDLE HOSE AND VENT ASSEMBLY



OUTER HOSE, LOWER HOSE AND VENT ASSEMBLY

Heater Kit Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	145-2173-03	1	Mount-Bracket, Hvac	11	120-5035	1	Cable-Control, Heater
2		1	Box-Heater ASM ■	12	122-1775	1	Harness-Wire, UTV, Heater
2:1	145-7962	1	Filter-Air	12:5	109355	1	Fuse-Blade, 15 Amp
2:99	161-5214	1	Evaporator 12V Super K Kombi Unit ●	12:6	32180-019	1	Cover-Fuse, Single
2:99	161-5221	1	Thermostat 12-24V Electronic ●	13	145-7958	2	Adapter-Y, 2 Inch
2:99	161-5233	1	Resistor 12V Rxst L1 ●	14	144-2318	8	Hose-Vent
2:99	161-5236	1	12V Blower ●	15	144-2248	6	Clamp-Sc Band
3	1-807512	8	Bolt-CARR	16	3334-945	16	Tie-Cable
4	104-7201	8	Nut-HF, NI	17	122-0150	1	Switch, Rotary
5	32144-70	2	Screw-HWHTF	18	144-3572	1	Control-Rotary, Linear
6	140-2691	6	Vent-Hvac, Adjustable	19	145-2159	2	Knob-Rotary Control
7	130-6146	3	Hose-Heater	20	3274-39	4	Screw-HSBH
9	147-8097	1	Valve-Water, 4 Port	21	138-0719	4	Nut-HF
10	145-2154	1	Heater Control ASM	22	139-8960	1	Screw-Torx PH Thd Roll
10:1	145-2229	1	Decal-Control Panel, Heat	23	130-0588	2	Nut-Switch

● Not illustrated

■ Not serviced separately



Count on it.