



Form No. 3471-185 Rev A

Count on it.

Parts Catalog

Recycler® S55AWST

55cm Lawn Mower with SmartStow®

Model No. 21774—Serial No. 417400000 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Housing Assembly 4

Grass Bag Assembly 6

Decal Assembly 8

Engine and Blade Assembly 10


Front Wheel and Height-of-Cut Assembly 12

Rear Wheel and Height-of-Cut Assembly 14

Handle Assembly 16

Attachments and Accessories 18


Housing Assembly



Housing Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	145-1526	1	Housing ASM	14	32104-120	2	Screw-PPH
1:2	112-8760	1	Decal-Danger	16	139-5476	1	ASM-Rear Door, In Mold
2	115-4667-01	1	Baffle-Front	18	139-5478	1	Spring-Torsion, LH
3	137-3099	13	Screw-Plastite, HWH	19	139-5479	1	Spring-Torsion, RH
4	139-5440	1	Baffle-Rear, Rwd	30	139-5457	1	Bumper-Front
7	140-4038	3	Screw-Shldr,HWH	31	139-5467	3	Screw-Plastic, HWH
9	140-2368	1	ASM-Chute, In Mold	32	144-0211	1	ASM-Intake, Awd
10	139-5443	1	Deflector-Recycle	33	140-2384	1	Cover-Intake, Bottom
11	139-5444	1	Knob-Recycle	34	140-2389	1	Cover-Belt, Lower (Awd)
12	139-5445	1	Latch-Recycle	35	145-1488	1	Decal-Vortex Awd
13	140-4192	1	Spring-Compression				


Grass Bag Assembly



Grass Bag Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	139-5470-03	1	ASM-Frame, Bag
2	147-0597	1	ASM-Bag, Grass


Decal Assembly



Decal Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
3	112-8760	1	Decal-Danger
10	140-4183	1	Decal
11	140-4184	2	Decal

Engine and Blade Assembly




Engine and Blade Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
7		1	Engine-Briggs,104M020130F1 ●■	22	108-3766-03	1	Support-Blade
11	121-5844	3	Screw-Thd Form, HWH	24	125-2466	1	Bolt-Blade
15	106-3999	1	Spacer-Driver	31	161-3169	1	Decal-Shroud
16	130-6705	1	Driver-Blade	34	133-8198	1	Decal-Level, Fuel
21	131-9683-03	1	Blade	35	2210-316	1	Stop-Rope

● Not serviced separately

■ Obtain parts from www.briggsandstratton.com


Front Wheel and Height-of-Cut Assembly



Front Wheel and Height-of-Cut Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	115-1956-05	2	Plate-HOC,Front Fsvq	14	110-7191	2	Washer-Thrust
2	137-3052	4	Screw-HH	15	131-0896	2	Gear-Pinion, 13T
3	119-4038	4	Nut-Hex	16	32151-61	2	Ring-Retaining
4	105-1809	2	Arm-Spring	18	140-2364	2	ASM-Cover, Wheel (Dk Gray)
5	110-0549	2	Knob-HOC	18:2	614426	1	Washer-Stepped
6	137-9128	2	Arm-Pivot, Front	19	140-2358	2	ASM-8" Wheel, Fwd (Bushings)
7	104-8699	2	Bearing-Ball	20	614650	2	Bolt-Shoulder
8	131-0836	2	Retainer-Bearing, HOC	25	104-0858	1	Bolt-Shoulder
9	32151-36	2	Ring-Retaining	26	139-1724	1	Nut-Lock
10	137-4823	1	Transmission	27	140-4193	1	Spring-Extension
11	71-9450	1	V-Belt				
12	114-7978-03	1	Bracket-Transmission				
13	120-9676	3	Screw-Plastite				


Rear Wheel and Height-of-Cut Assembly



Rear Wheel and Height-of-Cut Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	144-6477-05	1	Plate-HOC, LH	19	32151-61	2	Ring-Retaining
2	139-6592-05	1	Plate-HOC, RH (2 Hole)	20	140-2362	2	ASM-Cover, Gear (Dk Gray)
3	137-3052	4	Screw-HH	20:2	614426	1	Washer-Stepped
4	119-4038	4	Nut-Hex	22	140-2350	2	ASM-9.65" Wheel, Geared
5	100-1445	2	Bolt-CARR	23	614650	2	Bolt-Shoulder
6	139-1724	2	Nut-Lock	24	130-6709	1	Cover-Belt, Rear
7	132-4486	2	Arm-Spring	25	137-3099	2	Screw-Plastite, HWH
8	110-0549	2	Knob-HOC	26	139-6597	1	Shield-Trailing
9	139-5451	2	Arm-Pivot, Rear	29	140-2370	1	Transmission-Awd
10	108-9779	2	Retainer-Bushing, HOC	30	140-2380	1	Belt-Awd, 34.50
11	104-8699	2	Bearing-Ball	31	140-2371-03	1	Guide-Belt, Awd
12	108-9782	2	Bushing-Sleeve	32	140-2369	4	Pad-Smart Stow
16	120-9676	3	Screw-Plastite	33	137-9137	4	Screw-PPH
17	110-7191	2	Washer-Thrust	34	139-1700	1	Screw-HWH, Thd Roll
18	131-5399	2	Gear-Pinion, 15T	35	139-1692	2	Screw-PTH

Handle Assembly



Handle Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
5	144-0227-05	1	Handle-Curved, Awd	34	139-6568	1	Bottom-Handle, LH
6	139-6588	2	Bolt-Shoulder, Handle	35	94-4496	10	Screw-PPH
7	119-4038	1	Nut-Hex	36	145-5879-03	1	Bail-Brake
9	117-5976	2	Knob-Handle	37	139-6594	1	Cable-Brake, Pp B&s
12	138-3249	2	Quick Release ASM	38	144-0222	1	Screw-CARR
12:1	140-4157	1	Nut-Push	40	139-6582	1	Anchor-Cable, Awd
12:2	138-3248	1	Lever-Release	42	140-2391	1	Cable-Traction, Front (Awd)
12:3	138-3253	1	Anchor-Spring	43	140-2392	1	Cable-Traction, Rear (Awd)
12:4	115-2858	1	Spring-Compression	45	136-5922	1	Clamp-Cable
12:5	140-4158	1	Rod-Release	46	136-9075	1	Washer-Curved
20	140-2367	1	Guide-Curved, LH (Rwd)	47	137-3094	2	Nut-Hex
21	140-2366	1	Guide-Curved, RH (Rwd)	48	86-9671	1	Guide-Rope
24	139-5464	1	Rod-Control, Traction	50	114-7988	1	Guide-Cable
25	140-2378	1	Lever-Traction, Awd	56	140-2379	1	Linkage-Equalizer
26	144-0219	1	Spacer-Lever, Traction	57	144-0213	1	Yoke-Cable
27	120-9683	1	Washer-Plain	58	144-0212	1	Bolt-Equalizer
30	140-4194	1	Spring-Torsion	59	137-3085	1	Nut-Hex
32	139-6569	1	Handle-Personal Pace, Curved	60	145-1459	1	Decal - Ads, Handle
33	139-6567	1	Bottom-Handle, RH	63	139-6577	2	Pin-Handle, Pp
				64	131-4551	1	Cover-Handle

Attachments and Accessories

For 21774 Recycler® S55AWST 55cm Lawn Mower with SmartStow®

Product Name	Model/Part
22 Inch Atomic Blade	59534P
Traction Assist Handle Kit	144-6377
Lawnmower Cover	490-7462
Lawn Striping Kit with 22in Roller	20601
Bag-Walk Behind (Toro)	490-7318
Fuel Stabilizer .05 oz	130-2393
Summer Oil-Case of 24 (20oz Bottles)	38916
4-Cycle Fuel, Snow And Lawn 32oz Can	131-3823
Toro Premium Fuel Treatment 12oz Bottle	131-6572
Oil-30/10W-30 Synthetic (Quart)	138-6053
Toro 4-Cycle SAE 30 Oil (32oz Bottle)	38903
Chute ASM	147-8696

Notes:



Count on it.