







MODEL NO. 41420-40001 & UP

PARTS
CATALOG


TOPDRESSER 5000






HOPPER

Ref	Part No.	Description	Qty	Ref	Part No.	Description	Qty
1	42560	Tube Bracket	2	41	92-8298	Main Wire Harness	1
2	20-24-AGD	HHCS 5/16 x 3/4" UNC	2	42	42457	"L"-Bolt	2
3	42559	Manual Tube	1	43	24-10-BD	Flatwasher, 5/16" S.A.E.	4
4	20-5-AGD	HHCS, 1/4 x 1" NC	4	44	22-12-AJD	Hex Nut, 5/16" NC	5
5	24-9-BD	Flatwasher, 1/4" S.A.E.	4	45	20-85-AGD	HHCS, 1/2 x 1" NC	4
6	23-9-GD	Lock Washer, 1/4"	4	46	20-49-AGD	HHCS, 3/8 x 1-1/2" NC	2
7	92-8296	Spreader Chain Shield	1	47	42401	Bearing	1
8	92-3983	Insert Anchor 1/4" w/ Setting Tool	2	48	23-11-GD	Lockwasher, 3/8"	2
9	22-12-AJD	Hex Nut, 5/16" UNC	6	49	22-13-AJD	Hex Nut, 3/8" NC	2
10	23-10-GD	Lock Washer, 5/16"	10	50	41230	Tube Clamp	1
11	92-0341	Hitch Pin	1	51	92-8318	U-Bolt	2
12	30908	Cotter Pin	1	52	92-8317	Spindle Assembly - R.H.	1
13	22-11-AJD	Hex Nut, 1/4" UNC	2		92-8320	Spindle Assembly - L.H.	1
14	92-0270	Swivel Jack (w/o Bracket)	1	53	92-8330	Brake Cluster - R.H.	1
15	92-3616	Crank Assembly (f/w 92-0270)	1		92-8329	Brake Cluster - L.H.	1
16	92-3615	Retaining Ring (f/w 92-0270)	1	54	42406	Drive Sprocket w/ Set Screw	2
17	92-3617	Plunger Assembly (f/w 92-0270)	1	55	314243	Square Key, 1/4 x 2"	2
18	20-26-AGD	HHCS, 5/16" x 1" UNC	4	56	42454	Gear Box Assembly	1
19	42458	Front Bearing Plate	2	57	92-8136	Frame Assembly	1
20	42402	Bearing	2	58	92-8503	Grease Seal	2
21	22-15-AJD	Hex Nut, 1/2" NC	10	59	92-8504	Inner Bearing	2
22	23-13-GD	Lock Washer, 1/2"	10	60	92-8505	Inner Cup	2
23	25-100-AGD	Carriage Bolt, 1/2 x 1" NC	6	61	92-8506	Hub/Drum	2
24	42403	Idle Shaft Weldment	1	62	92-8508	Outer Race	2
25	42404	Drag Chain Sprocket	1	63	92-8510	Outer Bearing	2
26	20-132-AGD	HHCS, 5/8 x 4-1/2" UNC	3	64	92-8512	Spindle Washer	2
27	92-8166	Clevis, 1"	1	65	92-8513	Spindle Nut	2
28	22-17-AJFD	Hex Nut, 5/8"	3	66	92-8511	Cotter Pin	2
29	20-97-AGD	HHCS, 1/2" x 4	2	67	92-8514	Grease Cap	2
30	20-121-AGD	HHCS, 5/8" x 1-1/2" UNC	4	68	92-8332	Hub Drum Assembly	2
31	42411	Drag Chain Bar w/ Link	AR	69	92-8168	Wheel Assembly	2
32	93-6278	Drag Chain Assembly	1		92-8169	Tire	2
33	42409	Drag Chain Link, Pins & Cotters	AR		92-8170	Rim	2
34	42410	Pin w/ Cotter Key	AR		92-8366	Valve Stem	2
35	42408	Drag Chain Link	AR	70	92-8509	Wheel Nut	16
36	23-15-GD	Lock Washer, 1/2"	4	71	92-3994	Decal - Load Capacity	2
37	22-17-AJD	Hex Nut, 5/8"	4	72	92-3993	Decal - Hills/Slopes	1
38	22-18-AJFD	Lock Nut, 3/4"	8	73	92-8308	Decal - Warning Tongue	1
39	34-140-AMVD	Self-Tapping Scr., 1/4 x 5/8" UNC	4	74	87-0420	Decal - Power Off	2
40	92-8442	Tube Clamp	4	75	66-1210	Decal - Toro (7.0 x 10.96)	2



LINKAGE & SPINNER


Ref	Part No.	Description	Qty	Ref	Part No.	Description	Qty
1	92-8515	Engine Shroud	1	33	93-6275	Electric Clutch	1
2	28-10-D	Cotter Pin 3/32 x 1	3	34	92-8314	Ring Terminal	1
3	24-10-BD	Flat Washer 5/16"	4	35	93-6169	Key, 1/4" x 1/4" x 1"	1
4	93-6190	Engine Shroud Support	1	36	92-8524	Throttle Control Box	1
5	762035	Strap Ass'y	2	37	93-6168	Driver Pulley	1
6	92-8337	Gas Tank	1	38	93-6277	V-Belt	1
7	92-8520	Trim	2	39	93-6276	Driven Pulley	1
8	20-26-AGD	HHCS, 5/16 x 1" UNC	4	40	23-9-GD	Lockwasher 1/4"	3
9	92-8310	Foam Strip	2	41	42399	Drive Sprocket	1
10	24-10-BD	Flat Washer 5/16"	4	42	20-5-AD	HHCS 1/4 x 3/4" NC	3
11	92-8335	Tank Mounting Bracket	1	43	42407	Roller Chain w/ Master Link	1
12	93-6192	Grommet	1	44	20-55-AD	HHCS 3/8 x 3" UNC	1
13	22-12-AJD	Hex Nut 5/16" UNC	7	45	93-6188	Idler	1
14	42457	L-Bolt	1	46	93-6189	Spacer	1
15	93-6283	Flange Nut 5/16"	1	47	356308	Flat Washer 3/8" USS	1
16	92-8294	Gasline Hose 1/4" ID	2	48	24-11-BD	Flat Washer 3/8"	6
17	93-0918	Fuel Filter	1	49	22-13-AJFD	Hex Nut 3/8" UNC	2
18	97406	Hose Clamp	3	50	93-6191	Sprocket	1
19	20-28-AGD	HHCS 5/16" x 1-1/2 UNC	7	51	42416	Bearing	2
20	92-8527	Throttle Control Mount Bracket	1	52	42464	Bearing Bracket Weldment	1
21	92-8367	Bumper	2	53	24-12-BD	Flat Washer 7/16 S.A.E.	4
22	22-15-AJD	Hex Nut 1/2"	4	54	23-12-GD	Lock Washer 7/16"	4
23	20-47-AGD	HHCS 3/8 x 1 UNC	2	55	20-67-AGD	HHCS 7/16 x 1-1/2" UNC	4
24	23-11-GD	Lock Washer 3/8"	2	56	42405	Hand Knob	2
25	22-13-AJD	Hex Nut 3/8" UNC	2	57	42412	Spinner Weldment	1
26	22-12-AJFD	Hex Nut 5/16" UNC	6	58	314224	Square Key 1/4 x 1"	1
27	92-8297	Bumper Mount Angle	2	59	42413	Spinner Shaft	1
28	93-6202	Clutch Retainer	1	60	42414	Disc Weldment	1
29	93-6279	Clutch Cover	1	61	20-51-AGD	HHCS, 3/8 x 2" UNC	1
30	20-30-AD	HHCS 5/16" x 2" UNC	1	62	42369	Decal - Spreader Spinner	1
31	23-10-GD	Lock Washer 5/16"	3	63	92-8309	Decal - Personal Injury	1
32	24-10-AD	Flat Washer 5/16" USS	4				



CONTROL BOX ASSEMBLY (92-8300)

Ref	Part No.	Description	Qty
1	92-8304	Electric Brake Controller	1
2	92-8314	Ring Terminal	1
3	42811	Grommet	4
4	92-8363	Decal - Switches	1
5	41276	Push On Terminal .25	3
6	41176	Decal - Ignition	1
7	31872	Key Switch w/Key	1
8	92-0251	Fuse Holder	1
9	92-0289	Fuse - 30 Amp	1
10	92-8302	Control Panel	1
11	40-6410	Warning Light	1
12	30955	Toggle Switch Boot	3
13	92-8301	Panel Adjuster Kit	1
14	22-7-AJD	Hex Nut No. 6	4
15	23-5-GD	Lockwasher No. 6	4
16	42801	Hatch Holder	1
17	21-60-AGOD	32 x 1/2" No. 6 UNC	4
18	30954	Momentary Switch	1
19	92-0250	Toggle Switch	1
20	92-8312	Wire Ass'y (Controller to Pos.)	1
21	30953	Toggle Switch	1
22	92-8305	Positive Power Cable	1


Ref	Part No.	Description	Qty
23	92-8311	Brake Switch Wire Harness	1
24	41019	Solenoid	1
25	92-8306	Negative Power Cable	1
26	92-8307	Positive to Solenoid	1
27	22-11-AJD	Hex Nut 1/4"-20 UNC	6
28	23-9-GD	Lockwasher 1/4"	10
29	24-9-AD	Flatwasher 1/4"	2
30	20-3-AGD	HHCS 1/4 x 3/4" UNC	6
31	92-8394	Decal - Positive	1
32	20-48-AGD	HHCS 3/8 x 1-1/4 UNC	2
33	24-11-AD	Flatwasher 3/8"	4
34	22-13-AJD	Hex Nut 3/8-16 UNC	2
35	22-13-AVD	Wing Nut 3/8 UNC	2
36	22-9-AJD	Hex Nut No. 10-24	4
37	23-7-GD	Lockwasher 3/16	4
38	92-8395	Decal - Negative	1
39	92-8303	Control Box Wire Harness	1
40	21-98-AGOD	Mach. Scr. No. 10 x 5/8 RD. HD.	4
41	92-8356	Control Box Mount Bracket	1
42	24-9-BD	Flatwasher, 1/4"	8
43	20-2-AGD	HHCS, 1/4 x 5/8"	4



ACTUATOR

Ref	Part No.	Description	Qty
1	92-8321	Actuator Pivot Brkt. Ass'y	2
2	22-14-AJD	Hex Nut 7/16" UNC	4
3	328967	Cotter Pin	5
4	42195	Clevis Pin 1/2 x 2"	2
5	94485	Clamp Ass'y	2
6	92-3757	Boom Actuator	1
7	21-96-BMD	Mach. Scr. No. 10 x 1/2" UNF	4
8	25-25-AGD	Carriage Bolt 5/16 x 3/4 UNC	2
9	92-0306	Limit Switch Angle	2
10	22-9-BJD	Hex Nut No. 10	4
11	92-0305	Limit Switch	2
12	92-0304	Switch Guide Bracket	1
13	41446	Handle	1


Ref	Part No.	Description	Qty
14	29-110-D	Spring Pin 1/4" x 1"	2
15	92-0370	Limit Switch Plate	2
16	22-12-AJD	Hex Nut 5/16" UNC	1
17	22-11-AJD	Hex Nut 1/4" UNC	4
18	92-0297	Limit Switch Mounting Brkt.	1
19	20-67-AGD	HHCS 7/16 x 1-1/4" UNC	4
20	24-12-AD	Flat Washer 7/16"	8
21	92-0024	Clevis Pin	1
22	92-8175	Actuator Crank	1
23	92-0299	Switch Spacer	1
24	92-8295	Clevis Pin 1/2 x 1"	2
25	92-8181	Linkage Strap	1
26	93-6172	Flow Control Gate	1



42454 GEAR BOX ASSEMBLY


Ref	Part No.	Description	Qty
1	Not Svcd	Housing	1
2	42418	Cover	1
3	42419	Worm Gear-Bronze	1
4	42420	Worm	1
5	42421	Bearing Cone	2
6	42422	Bearing Cone	2
7	42423	Bearing Cup	4
8	42424	Snap Ring Input	1
9	42425	Snap Ring Output	1
10	42426	Snap Ring	4
11	20-45-AD	Capscrew, 3/8" x 3/4" H.H.	4
12	42428	Shaft-Input	1

Ref	Part No.	Description	Qty
13	42429	Shaft-Output	1
14	27-25-C	Woodruff Key - Hard	1
15	27-21-C	Woodruff Key - Hard	1
16	42432	Seal Input	1
17	42433	Seal Output	1
18	42434	Plug, 1/8"-27 NPTF	1
19	42435	Plug, Level, 3/8"-18 NPTF	1
20	361011	Zerk, 1/4"-28 NF	1
21	42437	Gasket, Cover (Not Shown)	1
22	42438	Plug, Vent, 1/8"-27 NPTF	1
23	42439	Cap	2
24	42453	Shim (Not Shown)	AR



THROTTLE CONTROL BOX

Ref	Part No.	Description	Qty
1	3217-32	Hex Nut No. 4-40	2
2	92-8527	Mounting Bracket	1
3	92-8524	Control Box	1
4	92-8528	Throttle Wire	1
5	92-8529	Push-On Retainer	1
6	92-8525	Linear Actuator	1
7	3290-404	RD. HD. Screw No. 4-40 x 3/4"	4
8	3250-17	RD. HD. Screw No. 8 x 3/4"	2
9	92-8526	Terminal Block	1
10	3296-1	Lock Nut No. 8-32	2




BRAKE CLUSTER 92-8330 (RH)
BRAKE CLUSTER 92-8329 (LH)

Ref	Part No.	Description	Qty
1	92-8468	Shoe & Lining Assembly	1
2	92-8469	Lever Assembly, RH	1
	92-8470	Lever Assembly, LH	1
3	92-8471	Magnet Assembly - Red Wire	1
4	92-8472	Retaining Clip	1
5	92-8473	Magnet Spring	1
6	92-8474	Wire Loom	1
7	92-8475	Loom Retaining Clip	1
8	92-8476	Grommet, Lead Wire	1
9	92-8477	Adjuster Assembly, RH	1
	92-8478	Adjuster Assembly, LH	1
10	92-8479	Auto Adj. Lever, RH	1
	92-8480	Auto Adj. Lever, LH	1
11	92-8481	Cable Assembly	1
12	92-8482	Auto Adj. Pulley	1
13	92-8483	Retaining Ring	3
14	92-8484	Adj. Pivot Pin	3
15	92-8485	Lever - Bias	1

Ref	Part No.	Description	Qty
16	92-8486	Pin Pulley	1
17	92-8487	Adjusting Spring	1
18	92-8488	Retractor Spring	1
19	92-8489	Magnet Lever Ret. Washer	1
20	92-8490	Retaining "C" Ring	1
21	92-8491	Shoe Hold Down Bolt	1
22	92-8492	Shoe Hold Down Washer	1
23	92-8493	Slotted Hex Nut	1
24	92-8494	Cotter Pin	1
25	92-8495	Adj. Lever Shim Washer	1
26	92-8496	Slipper Block	1
27	92-8497	Dust Cover	1
28	92-8498	Grommet	1
29	92-8499	Bolt, Flange	4
30	92-8500	Strain Relief	1
31	92-8501	Strain Relief Adapter	1
32	92-8502	Adj. Socket	1

BRAKE SWITCH



Ref	Part No.	Description	Qty
1	92-8357	Switch Mount Bracket	1
2	92-8361	Switch Mount Strap	1
3	22-11-AGD	Hex Nut 1/4" UNC	2
4	23-9-GD	Lock Washer 1/4"	2
5	24-9-BD	Flat Washer 1/4"	4
6	92-8362	Rectangle Mount Strap	1
7	20-6-AGD	HHCS 1/4" x 1-1/4" UNC	2
8	92-0305	Limit Switch	1
9	21-98-AGOD	Machine Screw #10 x 5/8" RD. HD.	2
10	95672	Hose Strap	2
11	21146	Hose Clamp	2
12	23-7-GD	Lock Washer 3/16"	2
13	22-9-AJD	Hex Nut No. 10	2

MAINTENANCE RECORD

[illegible]