



Form No. 3433-861 Rev J

**Count on it.**

# Parts Catalog

## **Z Master® Professional** **96in Air Cool Riding Mower**

Model No. 74090—Serial No. 400000000 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity


In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

|                                                   |    |
|---------------------------------------------------|----|
| Frame Assembly                                    | 4  |
| Mainframe Assembly No. 142-2671                   | 6  |
| ROPS Assembly                                     | 8  |
| Roll-Over Protection System Assembly No. 116-0231 | 10 |
| Caster Fork and Wheel Assembly                    | 12 |
| Hydraulic Drive Assembly                          | 14 |
| LH Hydro Assembly No. 135-7909                    | 16 |
| RH Hydro Assembly No. 135-7910                    | 18 |
| Pump Idler Assembly No. 116-1255                  | 20 |
| Rear Wheel Assembly                               | 22 |
| Park Brake Assembly                               | 24 |
| Fuel Tank Assembly                                | 26 |
| Fuel Tank Assembly No. 135-0643                   | 28 |
| Seat Mounting Assembly                            | 30 |
| Seat Assembly No. 140-8003                        | 32 |
| Seat Assembly No. 125-3107                        | 34 |
| Motion Control Assembly                           | 36 |
| Fender, Console and Control Assembly              | 38 |
| RH Console Assembly No. 115-7400                  | 40 |
| LH Console Assembly No. 115-7401                  | 42 |
| Electrical Assembly                               | 44 |
| Deck Lift Assembly                                | 46 |
| Power Unit Assembly No. 135-1582                  | 48 |
| Hood and Oil Cooler Assembly                      | 50 |
| Frame Decal Assembly                              | 52 |
| Engine Assembly                                   | 54 |
| Deck and Discharge Tunnel Assembly                | 56 |
| Discharge Tunnel Assembly                         | 58 |
| LH Wing Deck Assembly                             | 60 |
| LH Wing Deck Decal Assembly No. 142-5475          | 62 |
| Rear Caster Wheel Assembly                        | 64 |
| Caster Fork and Wheel Assembly                    | 66 |
| RH Wing Deck Assembly                             | 68 |
| RH Wing Deck Decal Assembly No. 142-5477          | 70 |
| Center Deck Belt Drive Assembly                   | 72 |
| Idler Assembly No. 126-9435                       | 74 |
| Idler Assembly No. 126-9438                       | 76 |
| Deck Idler Assembly No. 126-1720                  | 78 |
| Center Folding Deck Hydraulic Assembly            | 80 |
| Deck Fold Assembly                                | 82 |
| Center Deck Cutting Assembly                      | 84 |
| Attachments and Accessories                       | 86 |


Frame Assembly



## Frame Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>             | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|--------------------------------|-------------|--------------------|-------------|------------------------|
| 1           | 142-2671           | 1           | Mainframe ASM                  | 6:2         | 99-8936            | 1           | Decal-Control, Motion  |
| 2           | 116-8898-01        | 1           | Floorpan                       | 7           | 68-3640            | 1           | Decal                  |
| 3           | 1-513658           | 2           | Bumper                         | 8           | 32144-10           | 4           | Screw-HWH              |
| 4           | 1-811010           | 2           | Plug                           | 11          | 104-8300           | 10          | Nut-HF, NI             |
| 5           | 116-5899           | 1           | RH Motion Control Cover<br>ASM | 12          | 135-4947           | 1           | Mud Flap               |
| 5:2         | 99-8936            | 1           | Decal-Control, Motion          | 13          | 135-4950-03        | 1           | Bracket-Mud Flap, LH   |
| 5:3         | 116-5988           | 1           | Decal-Park Brake, CE           | 14          | 135-4952-03        | 2           | Support-Mud Flap, Rear |
| 6           | 116-0580           | 1           | LH Motion Control Cover<br>ASM | 15          | 135-4955-03        | 1           | Bracket-Mud Flap, RH   |
|             |                    |             |                                | 16          | 135-4957           | 1           | Mud Flap               |
|             |                    |             |                                | 18          | 3230-2             | 10          | Bolt-CARR              |

# Mainframe Assembly No. 142-2671




## Mainframe Assembly No. 142-2671 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>              |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|---------------------------------|
| 1           |                    | 1           | Mainframe ASM ●    | 1:4         | 106-2655           | 2           | Decal-Hazard, Pinched<br>Finger |
| 1:2         | 132-0871           | 1           | Decal-Danger       | 1:5         | 133-8062           | 1           | Decal-Spark Arrestor            |
| 1:3         | 106-5517           | 2           | Decal-Warning      |             |                    |             |                                 |

● Not serviced separately

# ROPS Assembly






## ROPS Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 1           | 116-0231           | 1           | ROPS ASM           | 8           | 135-6860           | 1           | Hood-Air Dam       |
| 5           | 135-7232-03        | 1           | Bracket-Air Dam    | 9           | 127-2610           | 9           | Screw-CARR         |
| 6           | 104-9082           | 2           | U-Bolt             | 10          | 104-7201           | 9           | Nut-HF, NI         |
| 7           | 104-8301           | 4           | Nut-HF, NI         |             |                    |             |                    |

Roll-Over Protection System Assembly No. 116-0231




# Roll-Over Protection System Assembly No. 116-0231 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------------|
| 1           |                    | 1           | Leg-ROPS, LH ●     | 8           | 3233-10            | 2           | Screw-CARR               |
| 2           |                    | 1           | Leg-ROPS, RH ●     | 9           | 325-35             | 4           | Screw-HH                 |
| 3           | 109-6653           | 2           | Spacer             | 10          | 109-9505           | 4           | Washer-Spring            |
| 4           |                    | 1           | Upper ROPS ASM ●   | 11          | 109-9233           | 1           | Bumper-Push-In, Rubber   |
| 4:2         | 107-3069           | 1           | Decal-Warning      | 12          | 117-0346           | 1           | Decal-Caution, Fuel Vent |
| 5           | 109-5337           | 2           | Bumper-ROPS        | 14          | 116-0960           | 2           | Spacer                   |
| 6           | 116-0104           | 2           | Pin-Spring         | 15          | 325-13             | 2           | Screw-HH                 |
| 7           | 99-5107            | 8           | Nut-Lock           | 16          | 125-8067           | 1           | Plug-Plastic             |

● Not serviced separately

# Caster Fork and Wheel Assembly



## Caster Fork and Wheel Assembly (continued)


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|
| 1           | 135-0750-01        | 1           | Fork-Caster           |
| 2           |                    | 1           | Wheel And Axle ASM ●  |
| 2:1         | 127-9526           | 1           | Wheel And Bearing ASM |
| 2:1:1       | 1-633585           | 2           | Bearing-Cone, Taper   |
| 2:1:2       | 103-0063           | 2           | Seal-Caster           |
| 2:1:3       | 103-3051           | 1           | Spacer-Nut ■          |
| 2:1:4       | 126-5361           | 1           | Axle Caster ASM       |
| 2:1:5       | 127-9527           | 1           | Wheel And Tire ASM    |
| 2:1:5:1     | 1-633584           | 2           | Bearing-Cup           |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|----------------------------|
| 2:2         | 103-2768           | 2           | Guard-Seal                 |
| 2:3         | 325-39             | 1           | Screw-HH                   |
| 2:4         | 3296-23            | 1           | Nut-Lock, NI               |
| 3           | 135-0355           | 1           | Seal-Grease                |
| 4           | 103-9028           | 2           | Bearing-Roller, Cone Taper |
| 5           | 3256-8             | 1           | Washer-Flat                |
| 6           | 1-633508           | 6           | Washer-Bellville           |
| 7           | 3296-51            | 1           | Nut-Lock, NI               |
| 8           | 126-9369           | 1           | Cap-Grease                 |

● Not serviced separately

■ Use Pro-Lock, Nut Type (P/N 1-840022, .5ml tube) on threads.

# Hydraulic Drive Assembly




## Hydraulic Drive Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|-----------------------------|-------------|--------------------|-------------|-----------------------------|
| 1           | 116-7558           | 1           | Cradle-Hydro                | 14          | 109-9058           | 1           | Guard-Hydro, Rear (RH)      |
| 2           | 135-7910           | 1           | Hydro-RH                    | 15          | 116-2362           | 1           | Deflector-Air Flow          |
| 3           | 135-7909           | 1           | Hydro-LH                    | 16          | 1-803035           | 2           | Rivet-Pop                   |
| 4           | 126-0095           | 6           | Screw-CARR                  | 17          | 126-9835           | 1           | Belt-V                      |
| 5           | 99-5107            | 6           | Nut-Lock                    | 18          | 109-9905           | 1           | Sheave                      |
| 6           | 325-8              | 4           | Screw-HH                    | 19          | 1-807259           | 1           | Key                         |
| 7           | 116-1255           | 1           | Pump Idler ASM              | 99          | 114-4713           | 1           | Hypr-Oil 500 (Quart) ●      |
| 8           | 116-1502           | 1           | Bolt-Shoulder, Carriage     | 99          | 117-0390           | 1           | Filter-Hydro ●              |
| 9           | 109-6658           | 1           | Nut-Flange, NI              | 99          | 114-4714           | 1           | Hypr-Oil 500 (Gallon) ●     |
| 10          | 116-6317           | 1           | Spring-Extension            | 99          | 114-4715           | 1           | Hypr-Oil 500-5 (5 Gallon) ● |
| 11          | 116-0170           | 1           | LH Hydro Guard ASM          | 99          | 116-3270           | 1           | Hydro Service Kit ●         |
| 11:2        | 116-8726           | 1           | Decal-Oil, Hydro            | 99:1        | 114-4713           | 4           | Hypr-Oil 500 (Quart) ●      |
| 12          | 116-0171           | 1           | RH Hydro Guard ASM          | 99:2        | 109-3388           | 1           | Belt                        |
| 12:2        | 116-8726           | 1           | Decal-Oil, Hydro            | 99:3        | 117-0390           | 2           | Filter-Hydro ●              |
| 13          | 109-9709           | 1           | Guard-Hydro, Rear Trim (LH) |             |                    |             |                             |

● Not illustrated

# LH Hydro Assembly No. 135-7909






# LH Hydro Assembly No. 135-7909 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|-----------------------------------|
| 1           | 135-7827           | 1           | Plate, Horse Shoe Mount | 17          | 116-7901           | 1           | Magnetic Plugs Service Kit        |
| 2           | 142-3603           | 1           | Kit, 7.8 In Fan         | 18          | 76-1900            | 2           | O-Ring                            |
| 3           | 116-0234           | 1           | Pulley Kit              | 19          | 116-8662           | 2           | O-Ring-Valve, Check               |
| 4           | 116-0235           | 1           | Handle                  | 20          | 116-8974           | 4           | Screw-HH 1/2-20 X 2 1/4           |
| 5           | 116-0236           | 1           | Dipstick                | 21          | 116-8975           | 2           | Screw-HSH 1/2-20 X 2 3/4          |
| 6           | 116-0237           | 1           | Gasket                  | 22          | 116-9922           | 2           | Hydraulic Tube Kit                |
| 7           | 116-1367           | 1           | Swash Block Kit         | 23          | 126-7466           | 1           | Valve-Shock                       |
| 8           | 142-3604           | 1           | Kit, Pump Seal          | 24          | 126-7711           | 1           | Seal-Drive, Fan                   |
| 9           | 116-1369           | 1           | Motor Seal Kit          | 25          | 142-3607           | 1           | Kit, Pump Section 16Cc LH         |
| 10          | 116-1370           | 1           | Tube Seal Kit           | 26          | 142-4501           | 1           | Kit - 16Cc Port Plate, Rotate Grp |
| 11          | 116-1371           | 1           | Output Shaft Seal Kit   | 27          | 142-4459           | 1           | Shock Valve Orificed 3800         |
| 12          | 116-5469           | 1           | Cup-Nose                | 28          | 99-3090            | 1           | Shaft-Coupling                    |
| 13          | 3257-42            | 1           | Key-Woodruff 5/16 X 1   | 99          | 116-4245           | 1           | Puller-Pulley ●                   |
| 15          | 142-4460           | 1           | Kit, Housing-Hydro LH   | 99          | 116-1373           | 1           | Flow Test Kit ●                   |
| 16          | 142-3616           | 1           | Kit, Motor Tg310Cc LH   |             |                    |             |                                   |

● Not illustrated

# RH Hydro Assembly No. 135-7910




## RH Hydro Assembly No. 135-7910 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|-----------------------------------|
| 1           | 135-7827           | 1           | Plate, Horse Shoe Mount | 17          | 116-7901           | 1           | Magnetic Plugs Service Kit        |
| 2           | 142-3603           | 1           | Kit, 7.8 In Fan         | 18          | 76-1900            | 2           | O-Ring                            |
| 3           | 116-0234           | 1           | Pulley Kit              | 19          | 116-8662           | 2           | O-Ring-Valve, Check               |
| 4           | 116-0235           | 1           | Handle                  | 20          | 116-8974           | 4           | Screw-HH 1/2-20 X 2 1/4           |
| 5           | 116-0236           | 1           | Dipstick                | 21          | 116-8975           | 2           | Screw-HSH 1/2-20 X 2 3/4          |
| 6           | 116-0237           | 1           | Gasket                  | 22          | 116-9922           | 2           | Hydraulic Tube Kit                |
| 7           | 116-1367           | 1           | Swash Block Kit         | 23          | 126-7466           | 1           | Valve-Shock                       |
| 8           | 142-3604           | 1           | Kit, Pump Seal          | 24          | 126-7711           | 1           | Seal-Drive, Fan                   |
| 9           | 116-1369           | 1           | Motor Seal Kit          | 25          | 142-3606           | 1           | Kit, Pump Section 16Cc RH         |
| 10          | 116-1370           | 1           | Tube Seal Kit           | 26          | 142-4501           | 1           | Kit - 16Cc Port Plate, Rotate Grp |
| 11          | 116-1371           | 1           | Output Shaft Seal Kit   | 27          | 142-4459           | 1           | Shock Valve Orificed 3800         |
| 12          | 116-5469           | 1           | Cup-Nose                | 28          | 99-3090            | 1           | Shaft-Coupling                    |
| 13          | 3257-42            | 1           | Key-Woodruff 5/16 X 1   | 99          | 116-1373           | 1           | Flow Test Kit ●                   |
| 15          | 142-4461           | 1           | Kit, Housing-Hydro RH   | 99          | 116-4245           | 1           | Puller-Pulley ●                   |
| 16          | 142-3617           | 1           | Kit, Motor Tg310Cc RH   |             |                    |             |                                   |

● Not illustrated


Pump Idler Assembly No. 116-1255



## Pump Idler Assembly No. 116-1255 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 2           | 43-0940            | 1           | Spacer             | 8           | 323-8              | 1           | Screw-HH           |
| 3           | 103-3504           | 2           | Bearing-Spherical  | 9           | 32120-10           | 2           | Ring-Snap          |
| 4           | 103-3505           | 1           | Seal-Lip, Double   | 10          | 302-19             | 1           | Fitting-Grease     |
| 5           | 103-3506           | 1           | Seal-Lip, Single   | 11          | 109-8076           | 1           | Pulley-Idler       |
| 6           | 109-6658           | 1           | Nut-Flange, NI     | 12          | 132-4724           | 1           | Pin-Anchor, Spring |
| 7           | 106-7159           | 2           | O-Ring             |             |                    |             |                    |

# Rear Wheel Assembly




## Rear Wheel Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 127-9521           | 2           | Wheel And Tire ASM |
| 1:1         | 1-633993           | 1           | Tire               |
| 1:2         | 127-9522           | 1           | Wheel              |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1:3         | 232-27             | 1           | Stem-Valve         |
| 2           | 242-50             | 8           | Nut-Lug            |
| 3           | 135-7898           | 2           | Decal-Wheel Hub    |

# Park Brake Assembly






## Park Brake Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|---------------------|
| 1           | 135-4893           | 1           | Mount-Bellcrank, LH | 19          | 135-7440           | 1           | Caliper-Brake, RH   |
| 2           | 135-4895           | 1           | Mount-Bellcrank, RH | 20          | 135-7828           | 2           | Plate-Mount, Brake  |
| 3           | 116-9681           | 1           | Mount-Pivot, LH     | 21          | 115-7109           | 2           | Washer-Flat         |
| 4           | 116-9682           | 1           | Mount-Pivot, RH     | 22          | 98-9940            | 4           | Screw-HHF           |
| 5           | 32144-70           | 4           | Screw-HWHTF         | 23          | 126-7587           | 2           | Rear Linkage ASM    |
| 6           | 109-8054           | 2           | Bushing-Flange      | 23:1        | 126-7588           | 2           | Yoke                |
| 7           | 116-9096-01        | 1           | Bracket-Mount       | 23:2        | 116-9069           | 1           | Linkage, Rear       |
| 8           | 135-7565           | 1           | Brake Lever ASM     | 23:3        | 3220-1             | 1           | Nut-Jam             |
| 8:2         | 109-8054           | 2           | Bushing-Flange      | 24          | 126-6395           | 4           | Pin-Clevis, Spring  |
| 8:3         | 132-4749           | 1           | Grip-Lever          | 25          | 126-6200           | 2           | Spacer              |
| 9           | 116-9117           | 1           | Pivot-Handle, Brake | 26          | 32120-19           | 2           | E-Ring              |
| 10          | 323-11             | 1           | Screw-HH            | 27          | 3230-2             | 2           | Bolt-CARR           |
| 11          | 126-6199           | 4           | Bushing             | 28          | 135-7915           | 4           | Screw-HH,           |
| 12          | 135-7800           | 1           | Shaft-Cross         | 29          | 112-0236           | 4           | Nut-Lock            |
| 13          | 135-4859           | 1           | Front Linkage ASM   | 30          | 104-8301           | 1           | Nut-HF, NI          |
| 13:2        | 94-7572            | 1           | End-Tie Rod, RH     | 31          | 135-7583           | 2           | Link-Mid            |
| 13:3        | 3220-3             | 1           | Nut-HJ              | 32          | 3256-23            | 5           | Washer-Plain        |
| 14          | 135-4896           | 2           | Bellcrank,          | 33          | 119-1415           | 4           | Pin-Cotter, Locking |
| 15          | 126-3716           | 1           | Arm-Inner, RH       | 34          | 135-7441           | 1           | Caliper-Brake, LH   |
| 16          | 126-3715           | 1           | Arm-Inner, LH       | 35          | 116-1399           | 2           | Locknut             |
| 17          | 104-8300           | 2           | Nut-HF, NI          | 36          | 142-2701           | 2           | Wheel Hub ASM       |
| 18          | 3296-6             | 1           | Nut-Lock            | 36:2        | 116-1696           | 4           | Stud-Wheel          |


# Fuel Tank Assembly



## Fuel Tank Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|------------------------|-------------|--------------------|-------------|----------------------------|
| 1           | 135-0643           | 1           | Fuel Tank ASM          | 7           | 116-5087           | 1           | Hose-Fuel                  |
| 2           | 3218-1             | 2           | Nut-Jam 1/4-20         | 8           | 105-1853           | 1           | Clamp-Hose                 |
| 3           | 1-523420           | 2           | Bumper                 | 9           | 116-6005           | 1           | Retainer-Line, Vapor       |
| 5           | 127-0583           | 1           | Fuel Manifold Vent ASM | 11          | 126-0224           | 1           | Insulation-Foam, Fuel Tank |
| 5:2         | 109-0302           | 3           | Hose-Fuel Line 24"     | 12          | 126-0032-01        | 1           | Guard-Exhaust              |
| 5:3         | 108-5376           | 1           | Hose-Fuel              | 13          | 125-8067           | 1           | Plug-Plastic               |
| 6           | 116-5072           | 1           | Fitting-Straight       |             |                    |             |                            |


# Fuel Tank Assembly No. 135-0643



## Fuel Tank Assembly No. 135-0643 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>              | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                |
|-------------|--------------------|-------------|---------------------------------|-------------|--------------------|-------------|-----------------------------------|
| 3           | 116-2459           | 1           | Fuel Line Kit (With Grommet)    | 8:1         | 46-6560            | 1           | Bushing                           |
| 3:1         | 46-6560            | 1           | Bushing                         | 9           | 116-2461           | 1           | LH Vent Line Kit (With Grommet)   |
| 4           | 3290-500           | 5           | Screw-PPH                       | 9:1         | 46-6560            | 1           | Bushing                           |
| 5           | 3253-17            | 5           | Washer-Lock                     | 10          | 116-2462           | 1           | Rear Vent Line Kit (With Grommet) |
| 6           | 126-3913           | 1           | Float-Sender, Fuel              | 10:1        | 46-6560            | 1           | Bushing                           |
| 6:1         | 126-3950           | 1           | Gasket-Sender                   | 11          | 1-603770           | 1           | Valve-Fuel                        |
| 7           | 126-1789           | 1           | Cap-Fuel, Ratcheting            | 12          | 2412-98            | 2           | Clamp-Hose                        |
| 8           | 116-2460           | 1           | RH Vent Line Kit (With Grommet) | 13          | 109-0650           | 1           | Hose-Fuel                         |


# Seat Mounting Assembly



## Seat Mounting Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 140-8003           | 1           | Seat-Suspension          | 9:3         | 125-9383           | 1           | Decal-Service Aid  |
| 2           | 109-9034           | 4           | Isolator-Seat            | 10          | 109-9881-03        | 1           | Plate-Latch, Seat  |
| 3           | 104-8301           | 4           | Nut-HF, NI               | 11          | 3230-4             | 1           | Bolt-CARR          |
| 4           | 116-3860-03        | 1           | Plate-Tilt, Seat Support | 12          | 107-3017           | 1           | Spring-Compression |
| 5           | 3230-23            | 11          | Bolt-CARR                | 13          | 9266934            | 2           | Screw              |
| 6           | 104-8300           | 18          | Nut-HF, NI               | 14          | 119-2507           | 1           | Decal              |
| 7           | 116-3859-03        | 1           | Plate-Frame, Seat        | 15          | 116-1297           | 2           | Screw-Shoulder     |
| 8           | 26-4840            | 4           | Spacer-Pin, Mounting     | 16          | 116-0070           | 1           | Rod-Prop           |
| 9           | 125-9385           | 1           | Seat Mount ASM           | 17          | 3256-23            | 1           | Washer-Plain       |

# Seat Assembly No. 140-8003






## Seat Assembly No. 140-8003 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|--------------------------|
| 1           | 140-8012           | 1           | Seat Track Set           |
| 2           | 116-5659           | 1           | Cover-Suspension Bellows |
| 3           | 140-8004           | 1           | Cover-Back               |
| 4           | 140-8005           | 1           | Cover-Cushion            |
| 5           | 116-8911           | 1           | Knob-Adjuster            |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|
| 6           | 82-2190            | 1           | Switch-Bail           |
| 7           | 109-9803           | 1           | Arm Rest Set          |
| 8           | 109-9802           | 1           | Arm Rest Pad Set      |
| 9           | 126-2061           | 1           | Seat Belt Service Kit |

# Seat Assembly No. 125-3107




## Seat Assembly No. 125-3107 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|--------------------------|
| 1           | 116-8910           | 1           | Seat Track Set           |
| 2           | 125-3112           | 1           | Cover-Back               |
| 3           | 125-3111           | 1           | Cover-Cushion            |
| 4           | 116-8911           | 1           | Knob-Adjuster            |
| 5           | 116-5659           | 1           | Cover-Suspension Bellows |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|
| 6           | 126-2061           | 1           | Seat Belt Service Kit |
| 7           | 109-9802           | 1           | Arm Rest Pad Set      |
| 8           | 109-9803           | 1           | Arm Rest Set          |
| 9           | 82-2190            | 1           | Switch-Bail           |

# Motion Control Assembly




## Motion Control Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|-----------------------------------|-------------|--------------------|-------------|------------------------|
| 1           | 116-0880           | 1           | RH Motion Control And Bushing ASM | 14:2        | 109-5668           | 1           | Grip-Lever, Control    |
| 1:2         | 109-8054           | 4           | Bushing-Flange                    | 15          | 135-4373           | 1           | LH Handle ASM          |
| 2           | 116-0881           | 1           | LH Motion Control And Bushing ASM | 15:2        | 109-5668           | 1           | Grip-Lever, Control    |
| 2:2         | 109-8054           | 4           | Bushing-Flange                    | 16          | 104-8301           | 4           | Nut-HF, NI             |
| 3           | 116-0648           | 2           | Screw-HH, Thd Lock ●              | 17          | 323-7              | 4           | Screw-HH               |
| 4           | 109-4581           | 2           | Arm-Control, Pump                 | 18          | 109-5575           | 2           | Spring-Leaf            |
| 5           | 9080046            | 2           | Screw-HH ●                        | 19          | 109-8106           | 2           | Front Pump Linkage ASM |
| 6           | 1-303435           | 2           | Washer-Spring                     | 19:2        | 3219-2             | 2           | Nut-Hex                |
| 7           | 116-0027           | 2           | Damper-Control, Motion            | 19:3        | 1-323245           | 2           | Spring-Compression     |
| 8           | 104-8300           | 8           | Nut-HF, NI                        | 19:4        | 1-633152           | 1           | Balljoint-LH           |
| 9           | 3230-2             | 2           | Bolt-CARR                         | 19:5        | 1-543017           | 1           | Balljoint-RH           |
| 10          | 109-5891           | 2           | Hub-Threaded                      | 20          | 109-9505           | 4           | Washer-Spring          |
| 11          | 325-12             | 2           | Screw-HH                          | 21          | 3256-6             | 2           | Washer-Flat            |
| 12          | 116-0039           | 1           | Lever-Control Motion, RH          | 22          | 32128-56           | 2           | Nut-HF                 |
| 13          | 116-0040           | 1           | Lever-Control Motion, LH          | 23          | 3256-23            | 2           | Washer-Plain           |
| 14          | 135-4371           | 1           | RH Handle ASM                     | 24          | 3218-5             | 2           | Nut-Jam                |
|             |                    |             |                                   | 25          | 115-1794           | 2           | Screw-HHF              |

● Use Pro-Lock, Nut Type (P/N 1-840022, .5ml tube) on threads.


# Fender, Console and Control Assembly



## Fender, Console and Control Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|---------------------|
| 1           | 115-7400           | 1           | RH Console ASM     | 3:3         | 136-5530           | 1           | Decal-Control Panel |
| 2           | 115-7401           | 1           | LH Console ASM     | 3:4         | 136-5531           | 1           | Decal-Horizon       |
| 3           | 135-7079           | 1           | Control Panel ASM  | 4           | 32105-15           | 4           | Screw-HWH           |
| 3:2         | 135-7057           | 1           | Decal-Console      |             |                    |             |                     |

# RH Console Assembly No. 115-7400






## RH Console Assembly No. 115-7400 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|----------------------|
| 1           | 114-1538           | 1           | RH Wide Top Console ASM | 3:2         | 114-5896           | 2           | Magnet               |
| 1:2         | 117-0883           | 2           | Puck                    | 4           | 109-9083           | 1           | Fender-Wide, RH      |
| 1:3         | 107069             | 4           | Clip                    | 5           | 32144-89           | 6           | Screw-Thread Forming |
| 2           | 115-3643           | 1           | Console-Lower, RH Wide  | 6           | 117-0347           | 6           | Screw-PPH            |
| 3           | 114-1537           | 1           | Wide Lid ASM            |             |                    |             |                      |

# LH Console Assembly No. 115-7401




## LH Console Assembly No. 115-7401 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|
| 1           | 114-1539           | 1           | LH Wide Console Top ASM |
| 1:2         | 117-0883           | 2           | Puck                    |
| 2           | 115-3641           | 1           | Console-Lower, LH Wide  |
| 3           | 114-1537           | 1           | Wide Lid ASM            |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------|
| 3:2         | 114-5896           | 2           | Magnet               |
| 4           | 109-9085           | 1           | Fender-Wide, LH      |
| 5           | 32144-89           | 6           | Screw-Thread Forming |
| 6           | 117-0347           | 6           | Screw-PPH            |


# Electrical Assembly



## Electrical Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>              |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|---------------------------------|
| 2           | 135-4471           | 1           | Harness-Wire        | 9           | 126-9976           | 1           | Module-Horizon                  |
| 3           | 104-8301           | 2           | Nut-HF, NI          | 10          | 126-5092           | 4           | Screw-PPH                       |
| 4           | 110-6765           | 2           | Switch              | 11          | 3256-24            | 1           | Washer-Plain                    |
| 5           | 82-2190            | 1           | Switch-Bail         | 12          | 1-303335           | 2           | Tie-Plastic                     |
| 6           | 126-6285           | 1           | Ignition Switch ASM | 13          | 100-1535           | 1           | Switch-Rocker,<br>(On)-Off-(On) |
| 6:2         | 108-8660           | 1           | Nut-Mounting        | 14          | 1-807512           | 1           | Bolt-CARR                       |
| 6:3         | 106-5270           | 1           | Ignition Key Set    | 15          | 32128-33           | 1           | Nut-HF                          |
| 6:4         | 108-8659           | 1           | Washer-Backup       | 16          | 126-1592           | 1           | Screw-HHF                       |
| 7           | 126-6187           | 1           | Switch-PTO, Sealed  | 17          | 135-4440           | 1           | Strap                           |
| 8           | 135-3427           | 1           | Module-Mcu          |             |                    |             |                                 |

# Deck Lift Assembly




## Deck Lift Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|--------------------------------------|-------------|--------------------|-------------|----------------------------|
| 1           | 135-1216-03        | 1           | Lift-Deck, Front                     | 26          | 126-7841           | 1           | Lift Cylinder ASM          |
| 2           | 116-2645-03        | 1           | Lift-Deck, Rear                      | 26:1        | 142-2767           | 1           | Kit, CYL Repair ●          |
| 3           | 109-9409           | 2           | Support-Bearing, Cross Shaft (Front) | 27          | 109-2017           | 1           | Adapter, Straight          |
| 4           | 127-0553           | 2           | Support-Bearing, Cross Shaft (Rear)  | 28          | 135-1582           | 1           | Power Unit                 |
| 5           | 109-9410           | 2           | Bearing-Cross Shaft, Front           | 29          | 109-0760           | 3           | Adapter, 90°               |
| 6           | 109-7173           | 2           | Bearing-Cross Shaft, Rear            | 30          | 135-3330           | 2           | Hose-HYD, HP               |
| 7           | 116-1700           | 4           | Bolt-CARR                            | 31          | 135-3331           | 1           | Hose-HYD, HP               |
| 8           | 99-5107            | 15          | Nut-Lock                             | 32          | 2412-138           | 2           | R-Clamp                    |
| 9           | 3231-9             | 1           | Screw-CARR                           | 33          | 142-2158-03        | 1           | Mount-Power Unit           |
| 10          | 3231-7             | 3           | Screw-CARR                           | 34          | 322-4              | 1           | Screw-HH                   |
| 11          | 104-8301           | 11          | Nut-HF, NI                           | 35          | 135-1215           | 1           | Spacer-Pivot               |
| 12          | 109-8353           | 4           | Trunnion                             | 36          | 325-11             | 3           | Screw-HH                   |
| 13          | 109-8007           | 4           | Link-Adjuster, Deck Lift             | 37          | 104-8300           | 1           | Nut-HF, NI                 |
| 14          | 109-7840           | 4           | Adjuster-Lift, Deck                  | 40          | 3231-26            | 2           | Screw-CARR                 |
| 15          | 3218-5             | 4           | Nut-Jam                              | 42          | 3290-461           | 4           | Washer-Spring              |
| 16          | 109-9840           | 4           | Screw-Shoulder, HHF                  | 43          | 3234-29            | 4           | Screw-HHF                  |
| 17          | 3256-28            | 2           | Washer-Flat                          | 44          | 109-5013           | 1           | Panhard Rod ASM            |
| 18          | 116-0797-03        | 1           | Link-Lift, Deck                      | 44:2        | 109-5009           | 2           | Bushing-Suspension, Rubber |
| 19          | 116-2022           | 2           | Screw-HHF, Shoulder                  | 44:3        | 109-5010           | 2           | Spacer                     |
| 20          | 126-7866           | 1           | HOC ASM                              | 45          | 86-1990            | 6           | Washer                     |
| 20:2        | 126-9275           | 1           | Decal-HOC                            | 46          | 325-17             | 1           | Screw-HH                   |
| 20:3        | 135-1432           | 1           | Decal-HOC, Outer                     | 47          | 3233-34            | 1           | Screw-CARR                 |
| 21          | 116-0559           | 1           | Bolt-TAP                             | 48          | 109-7952           | 2           | Deck Strut ASM             |
| 22          | 3296-23            | 1           | Nut-Lock, NI                         | 48:2        | 109-5009           | 2           | Bushing-Suspension, Rubber |
| 23          | 116-5584           | 1           | Pin-HOC                              | 48:3        | 109-5010           | 2           | Spacer                     |
| 24          | 3233-26            | 2           | Screw-CARR, Shortneck                | 49          | 325-12             | 2           | Screw-HH                   |
| 25          | 32151-91           | 1           | Ring-Retaining                       |             |                    |             |                            |

● Not illustrated

Power Unit Assembly No. 135-1582






## Power Unit Assembly No. 135-1582 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           |
|-------------|--------------------|-------------|-----------------------------|-------------|--------------------|-------------|------------------------------|
| 1           | 135-7603           | 1           | Base Assy, M3298, 3.0 Mtr   | 12          | 135-7614           | 1           | Parts Kit,Dbl Po Ck          |
| 2           | 135-7604           | 1           | P Assy,Kit,I,M3298,-100     |             |                    |             | Vlv,4Inman                   |
| 3           | 135-7605           | 2           | Pin, Dowel, 1/4 X 3/4       | 13          | 135-7615           | 1           | Counterbalance, 08,          |
| 4           | 135-7606           | 1           | Valve,Relief,Vm01,210-320   |             |                    |             | 5000-PSI                     |
|             |                    |             | Bar                         | 14          | 135-7616           | 2           | Coil, 12Vdc, 16W, Rect,      |
| 5           | HYD09361           | 1           | Inlet Tube,Bu               |             |                    |             | Deutsch                      |
| 6           | 135-7608           | 1           | Tube, Return, 90DEG,        | 15          | HYD13624           | 1           | Power Unit Solenoid          |
|             |                    |             | 1/8NPTF                     |             |                    |             | Kit,ATV/Ms-UTV               |
| 7           | 135-7609           | 1           | Parts Kit,Resv,Stl,3.375 X  | 16          | HYD13634           | 1           | Clamp,Hose,Worm              |
|             |                    |             | 7.0                         |             |                    |             | GR,2.3-3.25                  |
| 8           | 135-7610           | 1           | Shaft, Intermediate, Micro, | 17          | 135-7619           | 1           | Wire Assy, Cntrl, 16Awg,     |
|             |                    |             | DC                          |             |                    |             | Hs, Ring                     |
| 9           | 135-7611           | 1           | Motor, DC, 12V, 3In, 1 Term | 18          | 135-7620           | 1           | Cable, Insulated, W/Lugs,    |
| 10          | 135-7612           | 1           | Parts Kit,Manifold          |             |                    |             | 5In, 6GA                     |
|             |                    |             | Assy,M3200                  | 19          | 135-7880           | 1           | Parts Kit, Seal, 4W/3P Valve |
| 11          | 135-7613           | 1           | Cartridge, 4W/3P, 3000PSI,  | 99          | 135-2834           | 1           | Ruby Tran-1 Gal ●■           |
|             |                    |             | Mc, #8                      | 99          | 142-4398           | 1           | Cap-Powerunit ●■             |

● Not illustrated

■ Optional Equipment


# Hood and Oil Cooler Assembly



## Hood and Oil Cooler Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|--------------------------|
| 1           | 135-3340-03        | 1           | Casting-Lower, Rear   | 24          | 103-2898           | 2           | Latch-Rubber             |
| 2           | 135-3344-03        | 2           | Plate-Mount           | 25          | 135-3353           | 2           | Stop-Hood                |
| 3           | 126-8672           | 2           | Latch-Catch           | 26          | 120-4654           | 4           | Screw-HHF                |
| 4           | 135-1459           | 1           | Tube-Exhaust          | 27          | 104-7201           | 12          | Nut-HF, NI               |
| 5           | 135-3317-03        | 1           | Mount-Cooler          | 28          | 18-2130            | 1           | Clamp                    |
| 6           | 135-3345           | 1           | Hood                  | 29          | 3231-5             | 11          | Screw-CARR               |
| 7           | 135-3324-03        | 1           | Screen-Intake         | 30          | 104-8301           | 11          | Nut-HF, NI               |
| 8           | 135-3332-03        | 2           | Screen-Intake         | 31          | 135-4438-03        | 2           | Bracket-Mount, Slide     |
| 9           | 135-4437-03        | 1           | Cap-Perforation, Hood | 32          | 135-3321-03        | 2           | Slide-Hood               |
| 10          | 120-6737           | 57          | Plug-Plastic          | 33          | 52-2900            | 2           | Washer-Plastic           |
| 11          | 135-1223           | 1           | Cooler-Oil            | 34          | 135-7984           | 2           | Clamp-Hose               |
| 12          | 3229-8             | 4           | Screw-CARR            | 35          | 135-3347           | 4           | Pin                      |
| 13          | 95-6448            | 4           | Spacer                | 36          | 135-3319           | 1           | Foam-Inlet, Air          |
| 14          | 135-2391-03        | 1           | Mount-Fan             | 37          | 32120-47           | 4           | Ring-Retaining, External |
| 15          | 135-0877           | 1           | Fan                   | 38          | 104-0395           | 4           | Plug-Plastic             |
| 16          | 3230-22            | 4           | Screw-CARR            | 39          | 135-7203           | 1           | Mount-Hose               |
| 17          | 104-8300           | 15          | Nut-HF, NI            | 40          | 135-7442           | 1           | Hose-Air Intake          |
| 18          | 3256-4             | 4           | Washer-Flat           | 41          | 115-1794           | 2           | Screw-HHF                |
| 19          | 3234-29            | 4           | Screw-HHF             | 42          | 32128-20           | 2           | Nut-HF                   |
| 20          | 135-4892           | 1           | Support-Hood, RH      | 43          | 3229-3             | 4           | Screw-CARR               |
| 21          | 135-4874           | 1           | Support-Hood, LH      | 44          | 135-7312           | 1           | Barrier-Heat             |
| 22          | 120-1959           | 1           | Clamp                 | 45          | 135-7836           | 1           | Clamp                    |
| 23          | 3230-10            | 5           | Bolt-CARR             | 46          | 106-5517           | 1           | Decal-Warning            |


# Frame Decal Assembly



## Frame Decal Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 120-5895           | 2           | Decal              |

# Engine Assembly




## Engine Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|-----------------------------|
| 1           |                    | 1           | Engine-Kohler Ecv980 ●■ | 20          | 109-9761           | 1           | Screw-HH                    |
| 2           | 98-5975            | 4           | Washer-Belleville       | 21          | 116-3331-01        | 1           | Belt-Guide                  |
| 3           | 323-7              | 5           | Screw-HH                | 22          | 116-3318           | 1           | Spacer                      |
| 4           | 103-1390           | 1           | Bushing                 | 23          | 322-4              | 2           | Screw-HH                    |
| 5           | 135-7298           | 1           | Oil Drain Hose ASM      | 24          | 104-8300           | 2           | Nut-HF, NI                  |
| 5:2         | 353-508            | 1           | Plug-HH                 | 25          | 93-5108            | 2           | Grommet-Rubber              |
| 5:2:1       | 237-42             | 1           | O-Ring                  | 26          | 116-3319           | 1           | Spacer                      |
| 6           | 116-9048           | 1           | Bracket-Muffler         | 27          | 3231-42            | 1           | Screw-CARR                  |
| 7           | 126-0359           | 2           | Gasket-Exhaust          | 28          | 116-3317-01        | 1           | Link-Anchor, Clutch         |
| 8           | 126-4645           | 1           | Muffler                 | 29          | 109-6658           | 2           | Nut-Flange, NI              |
| 9           | 126-5620           | 1           | Bracket-Muffler, Front  | 30          | 135-7326           | 1           | Baffle ASM                  |
| 10          | 116-9626           | 4           | Nut-Flange, Lock        | 31          | 68-9410            | 1           | Screw-HHF                   |
| 11          | 1-303435           | 4           | Washer-Spring           | 32          | 135-7731-03        | 1           | Mount-Regulator             |
| 12          | 116-4295           | 4           | Screw-HH                | 33          | 135-4434           | 1           | Regulator And Rectifier ASM |
| 13          | 94-2413            | 3           | Nut-U                   | 34          | 127-8639           | 2           | Screw-HHF                   |
| 14          | 3234-5             | 3           | Screw-HHF               | 35          | 104-7201           | 2           | Nut-HF, NI                  |
| 15          | 105-1853           | 1           | Clamp-Hose              | 36          | 2412-98            | 2           | Clamp-Hose                  |
| 17          | 126-4185           | 1           | Clutch Kit              | 37          | 109-0303           | 1           | Hose-Fuel                   |
| 18          | 109-6919           | 1           | Washer-Plain            | 38          | 93-9155            | 3           | Velcro                      |
| 19          | 1-603610           | 2           | Washer-Spring           |             |                    |             |                             |

● Not serviced separately

■ Obtain parts from [www.kohlerplus.com](http://www.kohlerplus.com)

# Deck and Discharge Tunnel Assembly






## Deck and Discharge Tunnel Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|-----------------------------------|-------------|--------------------|-------------|---------------------------|
| 1           |                    | 1           | Discharge-Tunnel ASM,<br>96-Gas ● | 3           |                    | 1           | ASM-Deck, RH Wing [gas] ● |
| 2           |                    | 1           | ASM-Deck, LH Wing [gas] ●         | 4           |                    | 1           | ASM-Deck, Ctr 96 [toro] ● |

● Not serviced separately


# Discharge Tunnel Assembly



## Discharge Tunnel Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|-----------------------------|
| 1           | 104-8300           | 12          | Nut-Nyloc 5/16-18 Flg | 7           | 135-3789           | 1           | Flap-Rubber                 |
| 2           | 126-4424           | 2           | Screw-Shoulder        | 8           | 135-5932-03        | 1           | Panel-Discharge             |
| 3           | 135-0608           | 1           | Bearing-Strap, Nylon  | 9           | 135-7041-03        | 1           | Bracket-Tunnel Hanger LH    |
| 4           | 135-2090-03        | 1           | Bracket-Flap, LH      | 10          | 135-7042-03        | 1           | Bracket-Tunnel Hanger RH    |
| 5           | 135-2657-03        | 1           | Panel-Discharge       | 11          | 135-7046-03        | 1           | Support-LH Flap Rd96        |
| 6           | 135-3769           | 1           | Flap-Discharge        | 12          | 3230-10            | 12          | Bolt-Carriage 5/16-18 X 7/8 |

# LH Wing Deck Assembly




## LH Wing Deck Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-----------------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 142-5475           | 1           | LH Wing Deck ASM            | 28          | 92-1298            | 4           | Pin-Lynch               |
| 2           | 140-0986           | 1           | Ring-Spacer, Housing        | 29          | 126-2956           | 1           | Screw-HHF               |
| 3           | 137-9780           | 1           | Spindle ASM                 | 30          | 126-9757-01        | 1           | Plate-Fill              |
| 3:2         | 116-0720           | 2           | Bearing-Ball                | 31          | 3231-2             | 6           | Bolt-CARR               |
| 3:3         | 138-6042           | 1           | Spacer-Bearing              | 32          | 135-3461-01        | 1           | Baffle-Block            |
| 4           | 126-2960           | 1           | Idler-V                     | 33          | 3230-16            | 2           | Screw-CARR              |
| 5           | 1-633456           | 1           | Bushing, Idler              | 34          | 135-0618-03        | 1           | Support-Flap, LH        |
| 6           | 103-1330           | 1           | Guard-Bearing, Top          | 35          | 135-1849           | 1           | Guard-Tire, LH          |
| 7           | 126-7685           | 1           | Idler-Pulley                | 36          | 104-8300           | 4           | Nut-HF, NI              |
| 8           | 126-8043           | 2           | Shield-Dust                 | 37          | 3256-23            | 1           | Washer-Plain            |
| 9           | 3234-42            | 1           | Screw-HHF                   | 38          | 322-3              | 1           | Screw-HH                |
| 10          | 137-9784           | 1           | Guard-Bottom                | 39          | 3231-5             | 2           | Screw-CARR              |
| 11          | 138-6045           | 1           | Shaft-Spindle               | 40          | 107-1664           | 1           | Lever ASM               |
| 12          | 140-1246           | 1           | Blade-24.50 Mulch           | 40:1        | 106-3239           | 1           | Screw-Lock              |
| 13          | 126-6442           | 1           | Belt-V                      | 40:2        | 107-1644           | 1           | Cap-Lock                |
| 14          |                    | 1           | Rear Caster Wheel ASM ●     | 40:3        | 106-3241           | 1           | Lever-Lock              |
| 15          | 3231-12            | 7           | Bolt-CARR                   | 40:4        | 3296-29            | 1           | Nut-Lock, NI            |
| 16          | 137-9787           | 1           | Bushing-Hex                 | 41          | 135-2611-01        | 1           | Bracket-Retainer, Cover |
| 17          | 135-2433           | 1           | LH HOC Channel ASM          | 42          | 99-5107            | 1           | Nut-Lock                |
| 17:2        | 126-8597           | 2           | Decal-HOC, LH               | 43          | 98-5975            | 5           | Washer-Belleville       |
| 17:3        | 135-2422           | 2           | Plate-Guide, HOC (LH)       | 44          | 3231-11            | 1           | Screw-CARR              |
| 17:4        | 135-2423           | 2           | Plate-Guide, HOC (RH)       | 45          | 135-2424           | 1           | Spacer                  |
| 18          | 135-2436-01        | 1           | Tube-HOC, LH                | 46          | 109-9220           | 1           | Screw-Sems              |
| 19          |                    | 1           | Caster Wheel ASM ●          | 47          | 135-2073           | 2           | Pin-HOC                 |
| 20          | 99-7203            | 1           | Screw-HH                    | 48          | 114-1925           | 1           | Bumper-Rubber           |
| 21          | 126-6115           | 1           | Spacer-Wheel                | 49          | 110-9380           | 1           | Screw-HWH               |
| 22          | 135-2653-03        | 1           | Bracket-Shield Mount, Outer | 50          | 3234-11            | 3           | Screw-HHF               |
| 23          | 103-8415           | 2           | Roller-Anti-Scalp           | 51          | 1-811010           | 2           | Plug                    |
| 24          | 109-6658           | 24          | Nut-Flange, NI              | 52          | 140-1185           | 1           | Sheave-Drive, Blade     |
| 25          | 126-1503           | 2           | Spring                      | 53          | 30-8770            | 1           | Washer                  |
| 26          | 135-7455           | 2           | Pin, Spring                 | 54          | 116-7306           | 1           | Nut-Hex                 |
| 27          | 135-6170           | 1           | LH Wing Shield ASM          | 55          | 112-1479           | 1           | Skid-Bumper, Deck       |
| 27:2        | 93-6687            | 1           | Decal-No Step               | 56          | 104-8301           | 2           | Nut-HF, NI              |
| 27:3        | 135-3165           | 2           | Decal-Cover, Scratch        | 57          | 3231-31            | 2           | Screw-CARR              |
| 27:4        | 135-6706           | 2           | Plate                       | 58          | 103-2802           | 1           | Washer                  |
| 27:5        | 133-7130           | 4           | Rivet-Pop                   | 59          | 135-2459-01        | 1           | Baffle-Depth, LH        |

● Not serviced separately

# LH Wing Deck Decal Assembly No. 142-5475




## LH Wing Deck Decal Assembly No. 142-5475 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>             |
|-------------|--------------------|-------------|--------------------------------|
| 2           | 112-9028           | 1           | Decal-Cover, Missing           |
| 3           | 135-0664           | 1           | Decal-Danger, Thrown<br>Object |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|----------------------------|
| 4           | 116-8283           | 1           | Decal-Torque, Bolt         |
| 5           | 135-0670           | 1           | Decal-Warning, Pinch Point |
| 6           | 32148-10           | 3           | Nut-Clinch                 |

# Rear Caster Wheel Assembly






## Rear Caster Wheel Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|
| 1           | 1-543509           | 2           | Bearing-Roller, Tapered |
| 2           | 1-633508           | 3           | Washer-Bellville        |
| 3           | 135-3218           | 2           | Guard, Seal             |
| 4           | 103-4882           | 1           | Cap-Grease              |
| 5           | 135-3793-01        | 1           | Fork-Caster             |
| 6           |                    | 1           | Wheel And Tire ASM ●    |
| 6:1         | 135-2646           | 1           | Wheel                   |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 6:2         | 112-7065           | 1           | Tire               |
| 6:3         | 126-7904           | 1           | Axle-Caster        |
| 6:4         | 116-4004           | 2           | Bearing            |
| 7           | 325-20             | 1           | Screw-HH           |
| 8           | 3296-45            | 1           | Nut-Hex            |
| 10          | 3296-51            | 1           | Nut-Lock, NI       |
| 11          | 1-543511           | 1           | Seal-Grease        |

● Not serviced separately

# Caster Fork and Wheel Assembly



## Caster Fork and Wheel Assembly (continued)


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>            |
|-------------|--------------------|-------------|-------------------------------|
| 1           | 135-3794-01        | 1           | Fork-Caster                   |
| 2           | 130-4558           | 1           | Wheel/Tire And Bearing<br>ASM |
| 2:1         |                    | 1           | Wheel And Bearing ASM ●       |
| 2:1:1       | 1-633585           | 2           | Bearing-Cone, Taper           |
| 2:1:2       | 103-0063           | 2           | Seal-Caster                   |
| 2:1:3       | 103-3051           | 1           | Spacer-Nut ■                  |
| 2:1:4       | 126-5359           | 1           | Caster Axle ASM               |
| 2:1:5       | 130-4563           | 1           | Wheel And Tire ASM            |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|
| 2:2         | 103-2768           | 2           | Guard-Seal              |
| 2:3         | 3296-45            | 1           | Nut-Hex                 |
| 2:4         | 325-20             | 1           | Screw-HH                |
| 3           | 103-4882           | 1           | Cap-Grease              |
| 4           | 1-543509           | 2           | Bearing-Roller, Tapered |
| 5           | 1-633508           | 3           | Washer-Bellville        |
| 6           | 3296-51            | 1           | Nut-Lock, NI            |
| 7           | 1-543511           | 1           | Seal-Grease             |

● Not serviced separately

■ Use Pro-Lock, Nut Type (P/N 1-840022, .5ml tube) on spacer nut

# RH Wing Deck Assembly




## RH Wing Deck Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-----------------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 142-5477           | 1           | RH Wing Deck ASM            | 33          | 126-1503           | 2           | Spring                  |
| 2           | 137-9780           | 1           | Spindle ASM                 | 34          | 135-7455           | 2           | Pin, Spring             |
| 2:2         | 116-0720           | 2           | Bearing-Ball                | 35          | 135-6171           | 1           | RH Wing Shield ASM      |
| 2:3         | 138-6042           | 1           | Spacer-Bearing              | 35:2        | 93-6687            | 1           | Decal-No Step           |
| 3           | 137-9784           | 1           | Guard-Bottom                | 35:3        | 135-3165           | 2           | Decal-Cover, Scratch    |
| 4           | 135-5595           | 1           | RH HOC Channel ASM          | 35:4        | 135-6706           | 1           | Plate                   |
| 4:2         | 135-2422           | 2           | Plate-Guide, HOC (LH)       | 35:5        | 135-6707           | 1           | Plate-Front             |
| 4:3         | 135-2423           | 2           | Plate-Guide, HOC (RH)       | 35:6        | 133-7130           | 4           | Rivet-Pop               |
| 4:4         | 146-5612           | 2           | Decal-Height Of Cut-RH      | 36          | 92-1298            | 4           | Pin-Lynch               |
| 5           | 135-3788-01        | 1           | Tube-HOC, RH                | 37          | 126-8043           | 2           | Shield-Dust             |
| 6           | 1-633456           | 1           | Bushing, Idler              | 38          | 3234-42            | 1           | Screw-HHF               |
| 7           | 126-7685           | 1           | Idler-Pulley                | 39          | 126-2956           | 1           | Screw-HHF               |
| 8           | 126-2960           | 1           | Idler-V                     | 40          | 135-3540-01        | 1           | Baffle-Block, RH Wing   |
| 9           | 138-6045           | 1           | Shaft-Spindle               | 41          | 3256-23            | 1           | Washer-Plain            |
| 10          | 140-1246           | 1           | Blade-24.50 Mulch           | 42          | 322-3              | 1           | Screw-HH                |
| 11          | 3231-12            | 7           | Bolt-CARR                   | 43          | 3231-4             | 1           | Screw-CARR              |
| 12          | 137-9787           | 1           | Bushing-Hex                 | 44          | 3231-5             | 1           | Screw-CARR              |
| 13          | 104-8301           | 2           | Nut-HF, NI                  | 45          | 3231-2             | 3           | Bolt-CARR               |
| 14          | 109-6658           | 22          | Nut-Flange, NI              | 46          | 3231-25            | 1           | Bolt-CARR               |
| 15          |                    | 1           | Wheel And Tire ASM ●        | 47          | 98-5975            | 2           | Washer-Belleville       |
| 15:1        | 135-2646           | 1           | Wheel                       | 48          | 103-1330           | 1           | Guard-Bearing, Top      |
| 15:2        | 112-7065           | 1           | Tire                        | 49          | 107-1664           | 1           | Lever ASM               |
| 15:3        | 126-7904           | 1           | Axle-Caster                 | 49:1        | 106-3239           | 1           | Screw-Lock              |
| 15:4        | 116-4004           | 2           | Bearing                     | 49:2        | 107-1644           | 1           | Cap-Lock                |
| 16          | 135-2424           | 1           | Spacer                      | 49:3        | 106-3241           | 1           | Lever-Lock              |
| 17          |                    | 1           | Caster Wheel ASM ●          | 49:4        | 3296-29            | 1           | Nut-Lock, NI            |
| 18          | 112-1479           | 1           | Skid-Bumper, Deck           | 50          | 140-1185           | 1           | Sheave-Drive, Blade     |
| 19          | 135-3218           | 2           | Guard, Seal                 | 51          | 103-2802           | 1           | Washer                  |
| 20          | 325-20             | 1           | Screw-HH                    | 52          | 116-7306           | 1           | Nut-Hex                 |
| 21          | 3296-45            | 1           | Nut-Hex                     | 53          | 99-5107            | 1           | Nut-Lock                |
| 22          | 99-7203            | 1           | Screw-HH                    | 54          | 135-2073           | 2           | Pin-HOC                 |
| 23          | 3231-11            | 1           | Screw-CARR                  | 55          | 135-2611-01        | 1           | Bracket-Retainer, Cover |
| 24          | 126-6115           | 1           | Spacer-Wheel                | 56          | 110-9380           | 1           | Screw-HWH               |
| 25          | 135-2068           | 1           | Guard-Tire                  | 57          | 114-1925           | 1           | Bumper-Rubber           |
| 26          | 135-2067-03        | 1           | Support-Flap, RH            | 58          | 3230-22            | 2           | Screw-CARR              |
| 27          | 103-8415           | 2           | Roller-Anti-Scalp           | 59          | 140-0986           | 1           | Ring-Spacer, Housing    |
| 28          | 3230-16            | 2           | Screw-CARR                  | 60          | 1-811010           | 1           | Plug                    |
| 29          | 104-8300           | 8           | Nut-HF, NI                  | 61          | 30-8770            | 1           | Washer                  |
| 30          | 109-9220           | 1           | Screw-Sems                  | 62          | 3231-31            | 2           | Screw-CARR              |
| 31          | 135-2653-03        | 1           | Bracket-Shield Mount, Outer | 63          | 135-2460-01        | 1           | Baffle-Depth, RH        |
| 32          | 126-6447           | 1           | Belt-V                      |             |                    |             |                         |

● Not serviced separately

# RH Wing Deck Decal Assembly No. 142-5477




## RH Wing Deck Decal Assembly No. 142-5477 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>             |
|-------------|--------------------|-------------|--------------------------------|
| 2           | 112-9028           | 1           | Decal-Cover, Missing           |
| 3           | 135-0664           | 1           | Decal-Danger, Thrown<br>Object |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|----------------------------|
| 4           | 135-0670           | 1           | Decal-Warning, Pinch Point |
| 5           | 136-9042           | 1           | Decal                      |

# Center Deck Belt Drive Assembly






## Center Deck Belt Drive Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 135-3764           | 1           | Deck ASM                 | 7           | 103-2916           | 2           | Guard-Top          |
| 1:2         | 109-6036           | 1           | Decal-Roller, Anti-Scalp | 8           | 109-6658           | 7           | Nut-Flange, NI     |
| 1:3         | 112-9028           | 4           | Decal-Cover, Missing     | 9           | 116-6317           | 3           | Spring-Extension   |
| 1:4         | 135-1097           | 1           | Decal-Belt Routing       | 10          | 126-9438           | 1           | Idler ASM          |
| 1:5         | 32148-10           | 6           | Nut-Clinch               | 11          | 126-9187           | 2           | Pulley-Idler, Flat |
| 1:6         | 136-9041           | 1           | Decal                    | 12          | 126-2956           | 4           | Screw-HHF          |
| 2           | 1-633456           | 5           | Bushing, Idler           | 13          | 98-5975            | 5           | Washer-Belleville  |
| 3           | 126-2960           | 2           | Idler-V                  | 14          | 126-1720           | 1           | Deck Idler ASM     |
| 4           | 126-9435           | 1           | Idler ASM                | 15          | 3231-44            | 1           | Screw-CARR         |
| 5           | 116-1502           | 2           | Bolt-Shoulder, Carriage  | 16          | 116-9639           | 1           | Pulley-Idler, Flat |
| 6           | 126-8043           | 5           | Shield-Dust              | 17          | 126-6440           | 1           | V-Belt             |

# Idler Assembly No. 126-9435




## Idler Assembly No. 126-9435 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>               |
|-------------|--------------------|-------------|----------------------------------|
| 1           |                    | 1           | ASM-Idler Arm 96Rd LH<br>[red] ● |
| 2           | 106-7159           | 2           | O-Ring                           |
| 3           | 103-3504           | 2           | Bearing-Spherical                |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 4           | 32120-10           | 2           | Ring-Snap          |
| 5           | 103-3506           | 1           | Seal-Lip, Single   |
| 6           | 103-3505           | 1           | Seal-Lip, Double   |

● Not serviced separately

# Idler Assembly No. 126-9438




## Idler Assembly No. 126-9438 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|-----------------------------|
| 1           |                    | 1           | ASM-Idler Arm, 96Rd [red] ● |
| 2           | 106-7159           | 2           | O-Ring                      |
| 3           | 103-3504           | 2           | Bearing-Spherical           |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 4           | 32120-10           | 2           | Ring-Snap          |
| 5           | 103-3506           | 1           | Seal-Lip, Single   |
| 6           | 103-3505           | 1           | Seal-Lip, Double   |

● Not serviced separately


# Deck Idler Assembly No. 126-1720



## Deck Idler Assembly No. 126-1720 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 1           | 43-0940            | 1           | Spacer             | 11          | 109-7409           | 1           | Screw-Shoulder, HH |
| 2           | 103-2916           | 1           | Guard-Top          | 12          | 104-3396           | 1           | Screw-HH           |
| 3           | 103-3504           | 2           | Bearing-Spherical  | 13          | 32120-10           | 2           | Ring-Snap          |
| 4           | 103-3505           | 1           | Seal-Lip, Double   | 14          | 302-19             | 1           | Fitting-Grease     |
| 5           | 103-3506           | 1           | Seal-Lip, Single   | 15          | 88-4590            | 1           | Bolt-Shoulder      |
| 6           | 126-9196           | 1           | Idler-Pulley, Flat | 16          | 104-8300           | 1           | Nut-HF, NI         |
| 7           | 106-7159           | 2           | O-Ring             | 17          | 126-1704           | 1           | Spring-Belt        |
| 9           | 126-0423           | 1           | Pin-Spring, Anchor | 18          | 126-9195           | 1           | Shield-Guard, Dust |
| 10          | 109-6658           | 3           | Nut-Flange, NI     |             |                    |             |                    |

# Center Folding Deck Hydraulic Assembly






## Center Folding Deck Hydraulic Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|-----------------------------|-------------|--------------------|-------------|----------------------------|
| 1           | 109-0760           | 4           | Adapter, 90°                | 9           | 135-1552           | 1           | Harness-Wire               |
| 2           | 109-6658           | 2           | Nut-Flange, NI              | 10          | 142-6789           | 1           | Hose ASM                   |
| 3           | 115-5300           | 2           | Proximity Switch ASM        | 11          | 135-4526           | 1           | Hose ASM                   |
| 3:1         | 117-3207           | 2           | Nut-Hex                     | 12          | 135-5077           | 2           | Fitting-Straight           |
| 3:2         | 117-3208           | 2           | Washer-Lock, Internal Tooth | 13          | 135-5922           | 1           | Plate-Proximity, LH        |
| 4           | 126-8417           | 4           | Pin-Cotter, Locking         | 14          | 135-5923           | 1           | Plate-Proximity, RH        |
| 5           | 126-8448           | 2           | Pin-Cylinder                | 15          | 3231-28            | 2           | Screw-CARR                 |
| 6           | 126-9000           | 2           | Deck Fold Cylinder ASM      | 16          | 3290-378           | 4           | Tie-Cable                  |
| 6:1:1       | 142-2768           | 1           | Kit, CYL Repair ●           | 17          | 32180-030          | 3           | Clip-Tie                   |
| 6:2         | 126-8439           | 1           | Bushing                     | 18          | 135-6586           | 1           | Bracket-Guard, Switch (RH) |
| 6:3         | 126-8440           | 1           | Bushing                     | 19          | 110-9380           | 2           | Screw-HWH                  |
| 7           | 142-3762           | 2           | Pin-Cylinder                | 20          | 120-1959           | 3           | Clamp                      |
| 8           | 142-6790           | 1           | Hose ASM                    | 21          | 9266934            | 3           | Screw                      |

● Not illustrated


# Deck Fold Assembly



## Deck Fold Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|------------------------|
| 1           | 99-5293            | 4           | Spring-Torsion          | 15          | 142-5424           | 1           | ASM-Fold Arm, LH       |
| 2           | 103-4813           | 2           | Spring                  | 15:2        | 142-4794           | 4           | Bushing-Flanged        |
| 3           | 104-8300           | 4           | Nut-HF, NI              | 16          | 135-2628-01        | 1           | Bracket-Deck Stop, LH  |
| 4           | 109-6658           | 7           | Nut-Flange, NI          | 17          | 135-2629-01        | 1           | Bracket-Deck Stop, RH  |
| 5           | 110-9380           | 2           | Screw-HWH               | 18          | 135-2630-01        | 2           | Cover-Wing             |
| 6           | 116-6639           | 4           | Pin-Cotter, Locking     | 19          | 135-2651-01        | 1           | Shield-Center, LH      |
| 7           | 117-2382           | 4           | Plug-Plastic            | 20          | 135-2652-01        | 1           | Shield-Center, RH      |
| 8           | 126-4424           | 8           | Screw-Shoulder          | 21          | 135-6174-03        | 1           | Panel-Shield Hinge, RH |
| 9           | 135-6903-01        | 1           | Panel-Step              | 22          | 135-6178-03        | 1           | Panel-Shield Hinge, LH |
| 10          | 142-4813           | 8           | ASM-Deck Pin            | 23          | 283-55             | 2           | Pin-Clevis             |
| 11          | 126-9764           | 4           | Plate-Retainer, Bearing | 24          | 3230-16            | 4           | Screw-CARR             |
| 12          | 135-0584           | 4           | Strap-Bearing, Nylon    | 25          | 3231-12            | 6           | Bolt-CARR              |
| 13          | 135-1023           | 2           | Cover-Rod, Pivot        | 26          | 3234-42            | 1           | Screw-HHF              |
| 14          | 142-5423           | 1           | ASM-Fols Arm, RH        | 27          | 3290-355           | 2           | Pin-Hair               |
| 14:2        | 142-4794           | 4           | Bushing-Flanged         |             |                    |             |                        |

# Center Deck Cutting Assembly



## Center Deck Cutting Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|---------------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 98-5975            | 6           | Washer-Belleville         | 17          | 135-3462-01        | 1           | Baffle-Block, LH Ctr    |
| 2           | 99-7203            | 4           | Screw-HH                  | 18          | 135-1036-01        | 1           | Bracket-Antiscalp, Rear |
| 3           | 103-2802           | 2           | Washer                    | 19          | 135-1827-01        | 1           | Baffle-Center           |
| 4           | 137-9787           | 2           | Bushing-Hex               | 20          | 135-3463-01        | 1           | Baffle-Block, RH Ctr    |
| 5           | 140-1246           | 2           | Blade-24.50 Mulch         | 21          | 126-7140           | 1           | Spacer-Wheel, Short     |
| 6           | 103-8415           | 9           | Roller-Anti-Scalp         | 22          | 135-2459-01        | 1           | Baffle-Depth, LH        |
| 7           | 104-8300           | 6           | Nut-HF, NI                | 23          | 135-2460-01        | 1           | Baffle-Depth, RH        |
| 8           | 109-6658           | 39          | Nut-Flange, NI            | 24          | 135-2658           | 1           | Flap-Discharge          |
| 9           | 109-9220           | 2           | Screw-Sems                | 25          | 135-2659           | 1           | Flap-Discharge          |
| 10          | 138-6045           | 2           | Shaft-Spindle             | 26          | 135-3760-03        | 1           | Support-Flap            |
| 11          | 137-9780           | 2           | Spindle ASM               | 27          | 135-3761-03        | 1           | Support-Flap, RH        |
| 11:2        | 116-0720           | 2           | Bearing-Ball              | 28          | 140-0986           | 2           | Ring-Spacer, Housing    |
| 11:3        | 138-6042           | 1           | Spacer-Bearing            | 29          | 323-38             | 1           | Screw-HH                |
| 12          | 116-7306           | 2           | Nut-Hex                   | 30          | 3230-16            | 6           | Screw-CARR              |
| 13          | 126-6115           | 4           | Spacer-Wheel              | 31          | 3231-12            | 18          | Bolt-CARR               |
| 14          | 140-1186           | 2           | Sheave-Double Blade Drive | 32          | 3231-2             | 3           | Bolt-CARR               |
| 15          | 135-0601-01        | 1           | Baffle-Center, Rear (RH)  | 33          | 3234-11            | 6           | Screw-HHF               |
| 16          | 135-0603-01        | 1           | Plate-Block, Front        |             |                    |             |                         |

# Attachments and Accessories

## For 74090 Z Master Professional 96in Air Cool Riding Mower

| Product Name                           | Model/Part |
|----------------------------------------|------------|
| Hypr-Oil 500 (quart) .....             | 114-4713   |
| Hypr-Oil 500 (gallon).....             | 114-4714   |
| Hypr-Oil 500-5 (5 gallon).....         | 114-4715   |
| Bimini Folding Shade Assembly .....    | 115-4510   |
| Light Kit.....                         | 116-1154   |
| Seat Cover (W/arm rest) .....          | 117-0095   |
| Seat Tilt Frame and ISO Mount Kit..... | 121-7596   |
| Sunshade Kit .....                     | 126-8077   |
| Jack Kit .....                         | 127-6666   |
| Jack Mount Kit .....                   | 135-1768   |
| Light Flasher Kit.....                 | 135-2892   |
| Worklight Kit .....                    | 135-7320   |
| Kit - Service Tool.....                | 137-9220   |
| Blade-24.50 Mulch.....                 | 140-1246   |
| Weight Kit, Under Toe Board.....       | 140-4958   |
| Kit-96 Rear Discharge Baffle .....     | 142-3000   |
| Toro Rider Over Seat Bag .....         | 490-7317   |
| Toro Deluxe Rider Cover.....           | 490-7319   |
| Toro Rider Arm Rest Bag .....          | 490-7320   |
| Filter Minder Gauge .....              | 99-4664    |

**Notes:**



**Count on it.**