



Count on it.

Parts Catalog

Basket Kit

**27in DPA Reel Mower for Reelmaster®
3100-D Series Traction Unit**

Model No. 03185



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Front Basket Assembly 4

Basket Assembly 5


Rear Basket Mount Assembly 6

Rear Basket Assembly No. 130-4740..... 7

Top Basket Assembly No. 105-6875..... 8

Engine Roller Assembly 9

Hydraulic Guard Assembly 10




Front Basket Assembly

Ref.	Part Number	Qty.	Description
1	3234-30	2	Screw-HHF
2	3256-71	4	Washer-Flat
3	75-3920	2	Guide-Basket
4	117-0986-03	4	Plate-Basket
5	104-8300	8	Nut-HF, NI
6	115-8259	2	Basket ASM
7	119-1639-03	2	Bar-Cutoff
8	32105-18	8	Screw-HHF
9	104-8301	4	Nut-HF, NI
10	32121-11	2	Pin-Roll
11	110-4068	2	Washer-Plastic
12	75-3950-03	2	Bracket-Basket Lock

Ref.	Part Number	Qty.	Description
12	127-0264-01	2	Bracket-Basket HD Lock ●
13	75-3960	2	Spring-Torsion, LH (Yellow)
14	108-9087	2	Collar-Basket
15	3234-36	2	Screw-HHF
16	3296-42	8	Nut-Lock, NI
17	119-0608-03	2	Deflector
18	32105-8	4	Screw-SHH
19	3296-2	4	Nut-Lock, NI
20	3230-2	8	Bolt-CARR
21	147-1000	1	Kit - Rm Grass Basket Hardware ●


● Optional Equipment



Basket Assembly

Ref.	Part Number	Qty.	Description
1		1	Trim Basket Sub ASM ●
1:2	114-5442	1	Strip-Basket
1:3	3269-4	4	Rivet-Pop
2	115-8261-03	1	Bracket-Inner, LH
3	115-8262-03	1	Bracket-Inner, RH
4	115-0854-03	1	Handle-Basket
5	321-8	4	Screw-HH
6	3234-42	2	Screw-HHF
7	110-9626	2	Pin-Basket
8	115-0888-03	1	Bracket-Stop, RH
9	115-0889-03	1	Bracket-Stop, LH
10	3229-30	6	Screw-CARR
11	3269-11	4	Rivet-Pop
13	104-7201	10	Nut-HF, NI
14	3256-49	4	Washer-Plain

● Not serviced separately




Rear Basket Mount Assembly

Ref.	Part Number	Qty.	Description
4	119-0602-03	1	Bracket-Basket, RH
5	119-0604-03	1	Bracketr-Basket, LH
6	130-4740	1	Rear Basket ASM
7	3230-2	4	Bolt-CARR
8	322-11	2	Screw-HH
9	104-8300	6	Nut-HF, NI
11	117-0986-03	2	Plate-Basket
18	147-1000	1	Kit - Rm Grass Basket Hardware
18:1	3234-30	1	Screw-HHF

Ref.	Part Number	Qty.	Description
18:2	3256-71	2	Washer-Flat
18:3	75-3920	1	Guide-Basket
18:4	110-4068	1	Washer-Plastic
18:5	127-0264-01	1	Bracket-Basket HD Lock
18:6	75-3950-03	1	Bracket-Basket Lock ●
18:7	75-3960	1	Spring-Torsion, LH (Yellow)
18:8	75-3970	1	Spring-Torsion, RH
18:9	108-9087	1	Collar-Basket
18:10	3234-36	1	Screw-HHF
18:11	32121-11	1	Pin-Roll


● Optional Equipment



Rear Basket Assembly No. 130-4740


Ref.	Part Number	Qty.	Description
1	110-9626	2	Pin-Basket
2	3269-21	30	Rivet-Pop
3	119-0632	2	Fuel Line Assembly
4	119-0623-03	1	Bracket-RH
5	119-0624-03	1	Bracket-LH
6	119-0627	4	Spacer
7	3231-6	2	Screw-CARR
8	66-9302	2	Screw-HHF Lock
10	104-7201	3	Nut-HF, NI
11	32153-4	4	Nut-Hex, Side Deform
12	105-6875	1	Basket Top ASM
13	3256-55	8	Washer-Flat

Ref.	Part Number	Qty.	Description
15	119-0637-03	1	Handle-Basket
16	140-5617	1	Strap-Latch
17	3290-379	4	Tie-Cable
19	108-6182	4	Screw-Shoulder
20	3256-49	18	Washer-Plain
21	119-0644-03	1	Handle-Basket Rear
22	119-0636-03	1	Bracket-Basket Lip
23	3229-1	3	Screw-CARR
24	120-5141-03	1	Handle-Basket, RH
25	130-0053-03	1	Support-Basket (RH)
26	130-0054-03	1	Support-Basket (LH)
27	3269-7	4	Rivet-Pop, Steel




Top Basket Assembly No. 105-6875

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	105-6887-03	1	Support-Top
3	3269-23	14	Rivet-Pop
4	125-5634	1	Strap-Wear
5	105-6899	1	Hinge-Cover



Engine Roller Assembly

Ref.	Part Number	Qty.	Description
1	325-14	1	Screw-HH
2	33104-016	2	Screw-HHF
3	125-5633-03	1	Bracket-Roller Stop
4	75-5390	1	Roller
5	3296-23	1	Nut-Lock, NI



Hydraulic Guard Assembly

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	121-3537-03	1	Guard-Hydro
2	3234-17	1	Screw-HHF

Notes:



Count on it.