



**Count on it.**

# Parts Catalog

## **GrandStand® Mower**

### **HD 60in TURBO FORCE® Cutting Unit**

Model No. 72512—Serial No. 416360000 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

60 Inch Deck Assembly ..... 4

Deck Decal Assembly No. 139-8101 ..... 6

Spindle Assembly No. 137-9780 ..... 8

Deflector Assembly No. 120-2451 ..... 10

Ground Drive Assembly ..... 12

LH Transmission Assembly No. 138-5838 ..... 14

RH Transmission Assembly No. 138-5839 ..... 16

Overflow Hose Assembly ..... 18

Motion Control Assembly ..... 20

Control Handle Assembly No. 132-5157 ..... 22

Control Handle Assembly No. 132-5158 ..... 24

Parking Brake Assembly ..... 26

Deck Lift Assembly ..... 28

HOC Lever Assembly No. 161-6735 ..... 30

HOC Link Assembly No. 130-6615 ..... 32

Frame Assembly ..... 34

Wheel and Bearing Assembly ..... 36

Platform Assembly ..... 38


Engine Assembly ..... 40

Fuel Tank Assembly ..... 42

Electrical Assembly ..... 44

Attachments and Accessories ..... 46


## 60 Inch Deck Assembly



## 60 Inch Deck Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 139-8101           | 1           | 60 Deck ASM                | 26          | 104-8300           | 2           | Nut-HF, NI              |
| 2           | 137-9780           | 3           | Spindle ASM                | 27          | 108-4052           | 1           | Spring-Torsion          |
| 3           | 138-6059           | 3           | Sheave-Drive, Blade        | 28          | 98-7912            | 2           | Tube-Spanner            |
| 4           | 109-6982           | 4           | Wireform-Cover             | 29          | 104-0892           | 2           | Spacer-Axle, Rear       |
| 5           | 109-6936           | 2           | Cover-Belt, LH             | 30          | 98-5967            | 1           | Spacer-Wheel            |
| 6           | 114-5204-01        | 1           | Bracket-Wheel, LH          | 31          | 323-23             | 2           | Screw-HH                |
| 7           | 114-5208-01        | 1           | Bracket-Wheel, Center      | 32          | 145-3450           | 1           | Gs Torsion Idler ASM li |
| 8           | 114-5213-01        | 1           | Bracket-Wheel, RH          | 33          | 127-1971           | 1           | Pulley-Idler            |
| 9           | 1-603299           | 4           | Roller-Scalp, Anti         | 34          | 323-20             | 1           | Screw-HH                |
| 10          | 117-5758-03        | 3           | Bracket-Cover              | 35          | 114-1908-01        | 1           | Skid                    |
| 11          | 117-9701-01        | 1           | Baffle ASM                 | 36          | 130-6647-01        | 1           | Bracket-Skid            |
| 12          | 139-8106-01        | 1           | Plate-Baffle, Formed [red] | 37          | 109-2872           | 1           | Spacer-Pulley           |
| 13          | 130-6594-01        | 1           | Baffle-Discharge           | 38          | 3231-44            | 1           | Screw-CARR              |
| 14          | 3231-2             | 8           | Bolt-CARR                  | 39          | 136-5404           | 1           | Pulley-Idler, Flat      |
| 15          | 104-8301           | 47          | Nut-HF, NI                 | 40          | 132-5153           | 1           | Shield-Dust             |
| 16          | 120-2451           | 1           | Deflector ASM              | 41          | 3231-25            | 1           | Bolt-CARR               |
| 17          | 140-1240           | 3           | Blade                      | 42          | 100-4852           | 1           | Washer-Hardened         |
| 18          | 131-1123           | 1           | Belt-V                     | 43          | 94-7582            | 1           | Bolt-Shoulder           |
| 19          | 32144-70           | 3           | Screw-HWHTF                | 44          | 137-9784           | 3           | Guard-Bottom            |
| 20          | 92-1624            | 6           | Screw-HWH Thd Form         | 45          | 103-1330           | 3           | Guard-Bearing, Top      |
| 21          | 109-6658           | 1           | Nut-Flange, NI             | 46          | 138-6045           | 3           | Shaft-Spindle           |
| 22          | 137-9787           | 3           | Bushing-Hex                | 47          | 103-2802           | 3           | Washer                  |
| 23          | 109-9220           | 3           | Screw-Sems                 | 48          | 116-7306           | 3           | Nut-Hex                 |
| 24          | 105-4622           | 1           | Spacer                     | 49          | 109-1092           | 1           | Knob                    |
| 25          | 322-50             | 2           | Screw-HH                   |             |                    |             |                         |

Deck Decal Assembly No. 139-8101




## Deck Decal Assembly No. 139-8101 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 2           | 133-4604           | 2           | Decal-Danger       |
| 3           | 107-1619           | 1           | Decal              |
| 4           | 116-8283           | 1           | Decal-Torque, Bolt |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|---------------------------|
| 5           | 131-3507           | 1           | Decal-Belt, Tension (CE)  |
| 6           | 138-1147           | 1           | Decal - Baffle Adjustment |
| 7           | 112-3858           | 1           | Decal-Scalp, Anti         |


# Spindle Assembly No. 137-9780



## Spindle Assembly No. 137-9780 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 2           | 116-0720           | 2           | Bearing-Ball       |
| 3           | 138-6042           | 1           | Spacer-Bearing     |

# Deflector Assembly No. 120-2451




## Deflector Assembly No. 120-2451 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 3231-4             | 4           | Screw-CARR         |
| 2           | 106-3246-01        | 1           | Deflector          |
| 3           | 106-3248-03        | 1           | Strap-Discharge    |
| 4           | 110-0759           | 1           | Deflector-Rubber   |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 5           | 108-4059-01        | 1           | Plate-Hinge, Rear  |
| 6           | 106-3253-01        | 1           | Plate-Hinge, Front |
| 7           | 104-8301           | 4           | Nut-HF, NI         |

# Ground Drive Assembly




## Ground Drive Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|------------------------|
| 1           | 138-5838           | 1           | LH Transmission ASM        | 20          | 3229-25            | 3           | Screw-CARR             |
| 2           | 138-5839           | 1           | RH Transmission ASM        | 21          | 104-7201           | 3           | Nut-HF, NI             |
| 3           | 131-1131-03        | 1           | Support-Transaxle          | 22          |                    | 1           | Gs Overflow Hose ASM ■ |
| 4           | 93-2569            | 4           | Screw-HHF                  | 23          | 109-0309           | 1           | Hose-Fuel              |
| 5           | 116-4701           | 16          | Screw-HHF                  | 24          | 92-2379            | 1           | Clamp-Hose             |
| 6           | 104-8301           | 18          | Nut-HF, NI                 | 25          | 131-7469           | 1           | Rod-Bypass, RH         |
| 7           | 138-1108-03        | 1           | Plate-Skid                 | 26          | 131-7470           | 1           | Rod-Bypass, LH         |
| 9           | 117-5351           | 1           | Spacer                     | 27          | 108-2992           | 2           | Pin-Hair               |
| 10          | 1-413088           | 1           | Bushing-Lever, Lift        | 28          | 32180-030          | 1           | Clip-Tie               |
| 11          | 131-1175           | 1           | Arm-Idler                  | 29          | 140-1886           | 2           | Wheel And Tire ASM     |
| 12          | 114-0463           | 2           | Washer-Friction, Composite | 29:1        | 140-1887           | 1           | Rim-8 Inch Black       |
| 13          | 110-9981           | 1           | Washer-Plain               | 29:2        | 120-6466           | 1           | Tire                   |
| 14          | 3234-39            | 1           | Screw-HHF                  | 29:3        | 232-27             | 1           | Stem-Valve             |
| 15          | 93-1622            | 1           | Pulley-Idler               | 30          | 242-50             | 8           | Nut-Lug                |
| 16          | 3231-4             | 1           | Screw-CARR                 | 31          | 132-7584           | 2           | Spacer-Hex             |
| 17          | 138-1104           | 1           | Spring-Extension           | 32          | 104-8300           | 2           | Nut-HF, NI             |
| 18          | 131-1124           | 1           | Belt-V                     | 33          | 3290-250           | 2           | Pin-Cotter             |
| 19          | 132-1135           | 1           | Tank-HYD                   | 34          | 2412-129           | 2           | Clamp-Hose             |
| 19:2        | 133-8677           | 1           | Cap-Vented                 | 35          | 3290-378           | 1           | Tie-Cable              |
| 19:5        | 140-9463           | 1           | Strainer-Neck, Removable ● |             |                    |             |                        |

● Not illustrated

■ Not serviced separately

# LH Transmission Assembly No. 138-5838



8 = Items Included in RH Brake Kit


# LH Transmission Assembly No. 138-5838 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 132-4737           | 1           | Nut-Lock           |
| 2           | 132-4738           | 1           | Fan                |
| 3           | 132-4739           | 1           | Pulley             |
| 5           | 104-3265           | 1           | Pin                |
| 6           | 132-4700           | 1           | Lever-Bypass       |
| 8           | 133-1468           | 1           | Brake Kit,Left     |
| 8:1         |                    | 1           | O-Ring ●           |
| 8:2         |                    | 1           | Arm-Brake ●        |
| 8:3         |                    | 1           | Pin-Roll ●         |
| 8:4         |                    | 1           | Shaft-Brake ●      |
| 8:5         |                    | 1           | Actuator-Brake ●   |
| 8:6         |                    | 1           | Disc-Brake ●       |
| 8:7         |                    | 1           | Shoe-Brake ●       |
| 8:8         |                    | 1           | Shim Kit ●         |
| 9           | 132-4735           | 1           | Cap-Oil            |
| 11          | 136-5401           | 1           | Lever-Control, RH  |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>              |
|-------------|--------------------|-------------|---------------------------------|
| 15          | 144-3842           | 1           | 2 Transmission Filter Kit       |
| 15:1        | 136-5409           | 2           | Filter                          |
| 15:2        | 136-5410           | 2           | O-Ring                          |
| 16          | 137-4109           | 1           | Spring-Torsion                  |
| 17          | 137-9509           | 4           | Stud-Wheel                      |
| 18          | 138-4613           | 1           | Cap-Oil Filter                  |
| 21          | 137-9509           | 1           | Stud-Wheel                      |
| 23          | 139-5587           | 1           | Seal-Axle, Ua                   |
| 24          | 139-5588           | 1           | Axle                            |
| 25          | 139-5589           | 2           | Drain Bolt                      |
| 26          | 139-5590           | 1           | Expansion Fitting               |
| 27          | 139-5591           | 1           | Grommet Seal, Expansion Fitting |
| 28          | 139-7871           | 1           | Expansion Fitting - W/ Seal     |
| 28:3        |                    | 1           | M8*20 Flange Bolt ●             |
| 29          | 138-4628           | 1           | Seal Kit                        |

● Not serviced separately

# RH Transmission Assembly No. 138-5839




## RH Transmission Assembly No. 138-5839 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>              |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|---------------------------------|
| 1           | 132-4737           | 1           | Nut-Lock           | 15          | 144-3842           | 1           | 2 Transmission Filter Kit       |
| 2           | 132-4738           | 1           | Fan                | 15:1        | 136-5409           | 2           | Filter                          |
| 3           | 132-4739           | 1           | Pulley             | 15:2        | 136-5410           | 2           | O-Ring                          |
| 5           | 104-3265           | 1           | Pin                | 16          | 137-4109           | 1           | Spring-Torsion                  |
| 6           | 132-4700           | 1           | Lever-Bypass       | 17          | 137-9509           | 4           | Stud-Wheel                      |
| 8           | 133-1462           | 1           | RH Brake Kit       | 18          | 138-4613           | 1           | Cap-Oil Filter                  |
| 8:1         |                    | 1           | O-Ring ●           | 19          | 139-5587           | 1           | Seal-Axle, Ua                   |
| 8:2         |                    | 1           | Arm-Brake ●        | 20          | 139-5588           | 1           | Axle                            |
| 8:3         |                    | 1           | Pin-Roll ●         | 21          | 139-5589           | 2           | Drain Bolt                      |
| 8:4         |                    | 1           | Shaft-Brake ●      | 22          | 139-5590           | 1           | Expansion Fitting               |
| 8:5         |                    | 1           | Actuator-Brake ●   | 23          | 139-5591           | 1           | Grommet Seal, Expansion Fitting |
| 8:6         |                    | 1           | Disc-Brake ●       | 28          | 139-7871           | 1           | Expansion Fitting - W/ Seal     |
| 8:7         |                    | 1           | Shoe-Brake ●       | 28:3        |                    | 1           | M8*20 Flange Bolt ●             |
| 8:8         |                    | 1           | Shim Kit ●         | 29          | 138-4628           | 1           | Seal Kit                        |
| 9           | 132-4735           | 1           | Cap-Oil            |             |                    |             |                                 |
| 11          | 136-5401           | 1           | Lever-Control, RH  |             |                    |             |                                 |

● Not serviced separately



# Overflow Hose Assembly



## Overflow Hose Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 1           | 145-3444           | 1           | Hose-Hydraulic     | 4           | 147-0201           | 1           | R-Clamp            |
| 2           | 139-4055           | 1           | Fitting Tee        | 5           | 147-0204           | 1           | Hydraulic Hose     |
| 3           | 147-0202           | 1           | Hydraulic Hose     | 6           | 145-3599           | 4           | Hose Clamp         |


# Motion Control Assembly



## Motion Control Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|---------------------------|
| 1           | 132-5157           | 1           | LH Control Handle ASM | 9:5         | 1-603807           | 1           | Spring-Return, Neutral    |
| 2           | 132-5158           | 1           | RH Control Handle ASM | 10          | 138-4620           | 1           | RH Control Rod ASM        |
| 3           | 119-0222           | 2           | Grip                  | 10:1        | 138-4647           | 1           | Ball Joint-LH             |
| 4           | 103-9928           | 2           | Bearing               | 10:2        | 138-4648           | 1           | Ball Joint-RH             |
| 5           | 120-3288           | 1           | Tab-Pivot, LH         | 10:4        | 3219-3             | 1           | Nut-Hex                   |
| 6           | 3229-1             | 4           | Screw-CARR            | 11          | 3231-28            | 2           | Screw-CARR                |
| 7           | 104-7201           | 6           | Nut-HF, NI            | 12          | 104-8301           | 4           | Nut-HF, NI                |
| 8           | 120-3287           | 1           | Tab-Pivot, RH         | 13          | 3256-24            | 2           | Washer-Plain              |
| 9           | 138-4619           | 1           | LH Control Rod ASM    | 14          | 132-7538           | 1           | Bracket-Adjustment, Speed |
| 9:1         | 138-4647           | 1           | Ball Joint-LH         | 15          | 126-1499           | 2           | Cam                       |
| 9:2         | 138-4648           | 1           | Ball Joint-RH         | 16          | 323-7              | 2           | Screw-HH                  |
| 9:4         | 3219-3             | 1           | Nut-Hex               |             |                    |             |                           |

**Control Handle Assembly No. 132-5157**





## Control Handle Assembly No. 132-5157 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 2           | 131-3562           | 1           | Bearing-Sleeve     |
| 4           | 323-10             | 1           | Screw-HH           |
| 5           | 104-8301           | 1           | Nut-HF, NI         |
| 6           | 110-7191           | 2           | Washer-Thrust      |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 7           | 116-2670           | 1           | Screw-Shoulder     |
| 8           | 104-8300           | 1           | Nut-HF, NI         |
| 9           | 132-5146           | 1           | Spring-Extension   |

Control Handle Assembly No. 132-5158




## Control Handle Assembly No. 132-5158 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 3           | 104-8301           | 1           | Nut-HF, NI         |
| 4           | 323-10             | 1           | Screw-HH           |
| 5           | 110-7191           | 2           | Washer-Thrust      |
| 6           | 116-2670           | 1           | Screw-Shoulder     |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 7           | 104-8300           | 1           | Nut-HF, NI         |
| 8           | 131-3562           | 1           | Bearing-Sleeve     |
| 9           | 132-5146           | 1           | Spring-Extension   |


# Parking Brake Assembly



## Parking Brake Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|--------------------|
| 1           | 132-5170           | 1           | Brake Handle ASM     | 7           | 32144-4            | 2           | Screw-HWH          |
| 2           | 3230-23            | 5           | Bolt-CARR            | 8           | 132-1187           | 1           | Clamp-Cable        |
| 3           | 104-8300           | 6           | Nut-HF, NI           | 9           | 132-7582           | 1           | Mount-Cable, Brake |
| 4           | 132-5168           | 1           | RH Brake Caliper ASM | 10          | 1-633268           | 1           | Grip-Lever         |
| 5           | 132-5169           | 1           | LH Brake Caliper ASM | 11          | 131-1195           | 2           | Cable-Brake        |
| 6           | 104-8301           | 2           | Nut-HF, NI           |             |                    |             |                    |


# Deck Lift Assembly



## Deck Lift Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-----------------------------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 120-8405-01        | 1           | Shaft-Cross, Front                      | 25          | 3231-7             | 4           | Screw-CARR              |
| 2           | 109-9409           | 2           | Support-Bearing, Cross<br>Shaft (Front) | 26          | 104-8301           | 7           | Nut-HF, NI              |
| 3           | 109-9410           | 2           | Bearing-Cross Shaft, Front              | 27          | 32128-19           | 4           | Nut-HF Lock, Large Flg  |
| 4           | 116-1700           | 4           | Bolt-CARR                               | 28          | 109-9066           | 4           | Yoke-Adjust, Deck       |
| 5           | 99-5107            | 8           | Nut-Lock                                | 29          | 322-47             | 4           | Screw-HH                |
| 6           | 127-0369           | 6           | Bushing                                 | 30          | 3218-2             | 8           | Nut-Hex Jam             |
| 7           | 10-8110            | 3           | Washer-Thrust                           | 31          | 130-6589           | 2           | Link-Lift               |
| 8           | 3256-62            | 3           | Washer-Flat                             | 32          | 109-9840           | 2           | Screw-Shoulder, HHF     |
| 9           | 120-8411-01        | 1           | Arm-Lift, RH                            | 33          | 109-9065           | 2           | Screw-HH                |
| 10          | 32151-29           | 3           | Ring-Retaining                          | 34          | 116-2428           | 2           | Bushing-Flanged         |
| 11          | 120-8410-01        | 1           | Arm-Lift, LH                            | 35          | 3256-4             | 2           | Washer-Flat             |
| 12          | 161-6735           | 1           | HOC Lever ASM                           | 36          | 3296-48            | 4           | Nut-Hex                 |
| 13          | 119-6223           | 2           | Washer                                  | 37          | 95-6448            | 2           | Spacer                  |
| 14          | 138-4932           | 3           | Nut-Hex Flg                             | 38          | 138-1111           | 1           | Spacer                  |
| 15          | 138-4931           | 3           | Screw-Lock                              | 39          | 132-7581           | 1           | HOC Plate And Decal ASM |
| 16          | 130-6615           | 1           | HOC Link ASM                            | 40          | 138-4887           | 1           | Plate-HOC, Inner        |
| 17          | 3218-6             | 1           | Nut-Jam                                 | 41          | 116-4701           | 3           | Screw-HHF               |
| 18          | 98-5975            | 1           | Washer-Belleville                       | 42          | 121-1760           | 2           | Spacer                  |
| 19          | 323-58             | 1           | Bolt-TAP, HH                            | 43          | 116-5584           | 1           | Pin-HOC                 |
| 20          | 116-0886           | 1           | Spring-Extension                        | 44          | 116-0756           | 2           | Deck Lift Chain ASM     |
| 21          | 116-0780           | 4           | Screw-Shoulder, HHF                     | 44:1        | 1-633447           | 1           | Chain-Lift, Deck        |
| 22          | 3256-28            | 4           | Washer-Flat                             | 44:2        | 109-9065           | 1           | Screw-HH                |
| 23          | 127-1948-03        | 2           | Link-Lift                               | 44:3        | 32128-37           | 1           | Nut-HF                  |
| 24          | 137-4129           | 1           | Deck Strut ASM                          | 45          | 130-0742           | 2           | Bolt-Shoulder           |
| 24:2        | 137-4108           | 4           | Bushing-Rubber                          | 46          | 43-0940            | 2           | Spacer                  |
| 24:3        | 108-6544           | 4           | Spacer                                  | 47          | 133-1431           | 1           | Spacer-Split            |


HOC Lever Assembly No. 161-6735



## HOC Lever Assembly No. 161-6735 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|---------------------|
| 1           | 161-6736-01        | 1           | Lift Lever ASM [red] | 8           | 103-1363           | 4           | Rivet               |
| 2           | 136-0530           | 1           | Rod-Latch, Release   | 9           | 614672             | 1           | Screw-Shoulder, HWH |
| 3           | 114-8187           | 1           | Spring-Compression   | 10          | 110-8982           | 1           | Washer-Spring       |
| 4           | 114-1207           | 1           | Washer-Special       | 11          | 104-7201           | 1           | Nut-HF, NI          |
| 5           | 115-2750           | 1           | Knob                 | 12          | 104-8301           | 1           | Nut-HF, NI          |
| 6           | 115-3592           | 1           | Grip                 | 13          | 138-4888           | 1           | Latch-HOC           |
| 7           | 119-2309           | 1           | Bolt-Shldr,HH        | 14          | 138-4863           | 1           | Plug-Wear           |

# HOC Link Assembly No. 130-6615




## HOC Link Assembly No. 130-6615 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 1           | 1-633029           | 1           | Balljoint-Spherical |
| 2           | 117-5291           | 1           | Balljoint-Spherical |
| 3           | 3220-6             | 1           | Nut-Jam             |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 4           | 117-5293           | 1           | Nut-Jam            |
| 5           | 130-6614           | 1           | Link-Height Of Cut |


# Frame Assembly



## Frame Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|---------------------------|-------------|--------------------|-------------|--------------------------|
| 1           | 161-3497-01        | 1           | Frame-60 [red]            | 24          | 147-6343-01        | 2           | Caster Fork ASM [red]    |
| 8           | 140-4283           | 1           | Tower Decal ASM           | 25          | 1-811010           | 2           | Plug                     |
| 8:2         | 147-7921           | 1           | Decal-Oil Level           | 26          | 1-543509           | 4           | Bearing-Roller, Tapered  |
| 8:4         | 116-8775           | 1           | Decal-Fill, Fuel          | 27          | 116-5647           | 2           | Seal-Grease              |
| 8:5         | 139-2878           | 1           | Decal-Warning             | 28          | 1-633508           | 6           | Washer-Bellville         |
| 8:6         | 131-3526           | 1           | Decal-Controls            | 29          | 103-4882           | 2           | Cap-Grease               |
| 8:7         | 147-0212           | 1           | Decal - Fuse              | 30          | 161-3586           | 1           | Engine Guard ASM         |
| 9           | 3234-42            | 4           | Screw-HHF                 |             |                    |             | W/Decals                 |
| 10          | 104-8301           | 8           | Nut-HF, NI                | 30:2        | 105-8278           | 1           | Decal                    |
| 11          | 131-7455           | 1           | Plate-Striker             | 30:3        | 133-4641           | 2           | Decal-Warning, No Riders |
| 12          | 3229-11            | 1           | Screw-CARR                | 31          | 1-513658           | 4           | Bumper                   |
| 13          | 104-7201           | 1           | Nut-HF, NI                | 33          | 3230-10            | 2           | Bolt-CARR                |
| 14          | 105-4886           | 4           | Nut-Tinnerman             | 34          | 3296-51            | 2           | Nut-Lock, NI             |
| 15          | 3230-5             | 3           | Bolt-CARR                 | 35          | 3290-271           | 2           | Rivet-Pop                |
| 16          | 104-8300           | 9           | Nut-HF, NI                | 38          | 140-4258           | 1           | Decal-Panel, Control     |
| 17          | 107-3844           | 3           | Washer                    | 48          | 107-3002           | 2           | Washer-Nylon             |
| 18          | 140-5485           | 2           | Mf Wheel Tire Bearing ASM | 52          | 132-7578-01        | 1           | Guard-Fan, RH            |
| 18:2        | 103-2768           | 2           | Guard-Seal                | 53          | 132-7598-01        | 1           | Guard-Fan, LH            |
| 18:3        | 3296-45            | 1           | Nut-Hex                   | 64          | 119-4061           | 8           | Screw-HHF                |
| 18:4        | 325-20             | 1           | Screw-HH                  | 77          | 131-3529           | 1           | Decal-Service Aid        |
| 19          | 132-5161-01        | 1           | Tube-Mount, Fuel Tank     | 80          | 133-8062           | 1           | Decal-Spark Arrestor     |
| 20          | 132-1145-03        | 1           | Bracket-Cross             | 86          | 145-3595           | 3           | Dome Panel Plug          |
| 21          | 117-3591           | 2           | Decal-Commercial          | 94          | 161-3580-03        | 1           | Plate-Guard              |
| 23          | 114-1926           | 4           | Bumper-Rubber             | 95          | 130-8451           | 2           | Rivet-Trifold            |

# Wheel and Bearing Assembly




## Wheel and Bearing Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 1           | 1-633585           | 2           | Bearing-Cone, Taper |
| 2           | 103-0063           | 2           | Seal-Caster         |
| 3           | 103-3051           | 1           | Spacer-Nut          |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|
| 4           | 126-5359           | 1           | Caster Axle ASM       |
| 5           | 140-5483           | 1           | Mf Wheel And Tire ASM |


# Platform Assembly



## Platform Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 120-8499-03        | 1           | Hinge-Pad                  | 14          | 3231-2             | 2           | Bolt-CARR          |
| 2           | 117-9739           | 1           | Pad-Cushion                | 15          | 3231-27            | 2           | Screw-CARR         |
| 3           | 3256-23            | 4           | Washer-Plain               | 16          | 120-8475-01        | 1           | Platform           |
| 4           | 121-7999           | 4           | Screw-HH, Patch            | 17          | 126-7157           | 1           | Mat-Platform       |
| 5           | 114-0463           | 4           | Washer-Friction, Composite | 18          | 3345-771           | 1           | Shield Clamp Kit   |
| 6           | 133-1426           | 2           | Knob                       | 19          | 32144-70           | 2           | Screw-HWHTF        |
| 7           | 116-2886           | 2           | Slide-Bushing              | 20          | 119-8650           | 1           | Pin-Latch          |
| 8           | 3253-4             | 2           | Washer-Lock                | 21          | 114-5348           | 1           | Spring             |
| 9           | 137-4808           | 2           | Nut-Acorn                  | 22          | 1-603175           | 1           | Knob-Ball          |
| 10          | 111044             | 4           | Spacer                     | 23          | 132-7583           | 2           | Bushing-Flanged    |
| 11          | 114-1915-01        | 2           | Link-Pad                   | 24          | 104-8301           | 2           | Nut-HF, NI         |
| 12          | 3256-4             | 6           | Washer-Flat                | 25          | 323-45             | 2           | Screw-HH           |
| 13          | 3296-59            | 4           | Nut-Lock, NI               |             |                    |             |                    |

# Engine Assembly




## Engine Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|--------------------|
| 1           |                    | 1           | Engine-Kawasaki Fx1000 ■ | 16:2        | 161-1344           | 1           | Tape-Heat, Shield  |
|             |                    |             | ●                        | 16:3        | 106-5517           | 1           | Decal-Warning      |
| 2           | 33114-020          | 4           | Screw-HH                 | 17          | 98-9940            | 7           | Screw-HHF          |
| 3           | 161-3571           | 1           | Muffler-Kawi             | 18          | 145-1598           | 1           | Throttle ASM       |
| 4           | 133-4659           | 1           | Hose ASM                 | 18:1        | 145-6187           | 1           | Lever-Control      |
| 4:2         | 353-508            | 1           | Plug-HH                  | 18:2        | 145-5189           | 1           | Cable-Throttle     |
| 4:2:1       | 237-42             | 1           | O-Ring                   | 19          | 1-603175           | 1           | Knob-Ball          |
| 5           | 98-5975            | 4           | Washer-Belleville        | 20          | 1-807533           | 2           | Bolt-CARR          |
| 6           | 126-0983           | 2           | Screw-BHTF               | 21          | 32128-17           | 2           | Nut-Lock, Flange   |
| 7           | 131-3586-03        | 1           | Stop-Clutch              | 22          | 145-5188           | 1           | Cable-Choke        |
| 8           | 32144-70           | 2           | Screw-HWHTF              | 23          | 3290-378           | 1           | Tie-Cable          |
| 9           | 161-3565           | 1           | Sheave, W/Hub            | 24          | 161-3499-03        | 1           | Plate-Eng Spacer   |
| 10          | 139-7910           | 1           | Clutch-200Cms            | 25          | 3231-25            | 2           | Bolt-CARR          |
| 11          | 1-807259           | 1           | Key                      | 26          | 104-8301           | 2           | Nut-HF, NI         |
| 12          | 3212-6             | 1           | Screw-HH                 | 27          | 1-303334           | 4           | Washer-Spring      |
| 13          | 107-4136           | 1           | Washer-Flat              | 28          | 32180-030          | 1           | Clip-Tie           |
| 14          | 1-603610           | 1           | Washer-Spring            | 29          | 323-52             | 2           | Screw-HH           |
| 15          | 32128-20           | 7           | Nut-HF                   | 30          | 161-6757-03        | 1           | Shield-Heat        |
| 16          | 161-3572           | 1           | Muffler Guard ASM        |             |                    |             |                    |

● Not serviced separately

■ Obtain parts from [www.kawpower.com](http://www.kawpower.com)


# Fuel Tank Assembly



## Fuel Tank Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|--------------------|
| 1           | 132-7560           | 1           | Fuel Tank ASM         | 2           | 110-8255           | 1           | Hose-Fuel          |
| 1:2         | 46-6560            | 2           | Bushing               | 3           | 98-2952            | 1           | Fitting-Straight   |
| 1:3         | 137-4127           | 1           | Cap-Fuel              | 4           | 132-7576           | 1           | Hose-Fuel          |
| 1:4         | 104-5228           | 1           | Fitting-Elbow, 90 DEG | 5           | 161-6715           | 1           | ASM-Fuel Line      |
| 1:5         | 145-6195           | 1           | ASM, Tube-Fuel        |             |                    |             |                    |

# Electrical Assembly



## Electrical Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|----------------------------|
| 1           | 145-5228           | 1           | Harness-Wire, Grandstand   | 10          | 322-3              | 2           | Screw-HH                   |
| 1:4         | 109101             | 1           | Fuse-Blade, 20 Amp         | 11          | 115-3864           | 1           | Cable-Battery, Positive    |
| 1:8         | 109355             | 2           | Fuse-Blade, 15 Amp         | 12          | 109-5715           | 2           | Nut-HHF, Smooth            |
| 1:9         | 218-578            | 1           | Fuse-Blade, 10 Amp         | 13          | 139-6367           | 1           | Switch-Rocker, (On)-On-Off |
| 1:10        | 116-0053           | 2           | Cap-Plug                   | 14          | 137-4101           | 1           | Switch-Ignition            |
| 1:11        | 110928             | 1           | Fuse-Blade, 5 Amp          | 15          | 63-8360            | 1           | Key-Ignition               |
| 1:12        | 109103             | 1           | Fuse-Blade, 30 Amp         | 16          | 3253-3             | 1           | Washer-Lock                |
| 2           | 82-2190            | 3           | Switch-Bail                | 17          | 3217-5             | 1           | Nut-Hex                    |
| 3           | 104-8162           | 1           | Battery                    | 18          | 3290-500           | 1           | Screw-PPH                  |
| 4           | 130-6635-01        | 1           | Bracket-Hold Down, Battery | 19          | 3256-14            | 1           | Washer-Flat                |
| 5           | 104-7201           | 2           | Nut-HF, NI                 | 20          | 3296-2             | 1           | Nut-Lock, NI               |
| 6           | 1-633651           | 2           | Bolt-Holddown              | 21          | 1-643275           | 1           | Relay                      |
| 7           | 112-7063           | 1           | Cable-Battery, Black       | 22          | 67-1300            | 1           | Decal                      |
| 8           | 140-1884           | 1           | Module-Meter, Hour         | 26          | 33114-016          | 1           | Screw-HH                   |
| 9           | 3256-23            | 2           | Washer-Plain               | 30          | 3290-378           | 2           | Tie-Cable                  |

# Attachments and Accessories

## For 72512 GrandStand Mower HD 60in TURBO FORCE Cutting Unit

| Product Name                                                             | Model/Part  |
|--------------------------------------------------------------------------|-------------|
| Turbo Baffle Kit .....                                                   | 107-1634    |
| 15-Pound Cast Weight.....                                                | 112-7059-01 |
| Hypr-Oil 500 (quart) .....                                               | 114-4713    |
| Hypr-Oil 500 (gallon).....                                               | 114-4714    |
| Hypr-Oil 500-5 (5 gallon).....                                           | 114-4715    |
| Harness Wire Splitter .....                                              | 121-5988    |
| Toro Premium Fuel Treatment 12oz Bottle.....                             | 131-6572    |
| Speed Setting Tool.....                                                  | 132-7595    |
| Stand-On Weight Kit .....                                                | 133-1428    |
| Chute Gate Kit W/ Bag.....                                               | 133-1434    |
| Trash Bag Assembly .....                                                 | 133-1435    |
| Roller Striper Kit.....                                                  | 133-1436    |
| Light Kit.....                                                           | 133-1437    |
| Electric Accessory Port.....                                             | 133-1438    |
| HOC Set Blocks .....                                                     | 133-1439    |
| Trimmer Rack .....                                                       | 133-1441    |
| Hydro Oil Change Kit .....                                               | 133-1457    |
| Strobe Light Kit .....                                                   | 133-1495    |
| 5 Gallon Bucket .....                                                    | 133-2533    |
| Hydraulic Cap Lock Kit.....                                              | 136-5420    |
| Bucket Mount Kit.....                                                    | 136-5681    |
| Bagger Enhancement Kit.....                                              | 139-1529    |
| Recycler Kit .....                                                       | 139-6655    |
| 18x8.5n10 X-Tweel Turf.....                                              | 139-7890    |
| 6in Hose Kit, E-Z Vac Twin Bagger, 2016 and After Grandstand Mower ..... | 139-7930    |
| Blower Upgrade Kit, Twin Bagger, 2016 and After Grandstand Mower .....   | 139-7940    |
| Blade-20.5 High Flow .....                                               | 140-1240    |
| Blade-20.50 Atomic .....                                                 | 140-1241    |
| Pneumatic Castor Wheel Kit .....                                         | 140-4311    |
| Blade-20.50 Medium Flow .....                                            | 140-4853    |
| Blade-20.50, Low Flow .....                                              | 140-4854    |
| Blade-20.50 Recycler .....                                               | 140-4855    |
| 6 Pack-Blade, 20.5 High Flow.....                                        | 140-4877    |
| 6 Pack-Blade, 20.5 Med Flow .....                                        | 140-4878    |
| 6 Pack-Blade, 20.5 Low Flow .....                                        | 140-4879    |
| 6 Pack-Blade, 20.5 Atomic.....                                           | 140-4880    |
| 6 Pack-Blade, 20.5 Recycler.....                                         | 140-4881    |
| 2 Transmission Filter Kit .....                                          | 144-3842    |
| Spark Arrestor, 1.5in .....                                              | 146-0561    |
| 6 Pack-Blade, 20.50 High Flow.....                                       | 147-6256    |
| Soft Bag (3 Bushel).....                                                 | 30104       |
| 10W30 4-Cycle Engine Oil (32oz Bottle).....                              | 38280       |
| Toro 4-Cycle SAE 30 Oil (32oz Bottle) .....                              | 38903       |
| Twin Bagger Kit.....                                                     | 78524       |
| Blower Drive 60-in .....                                                 | 78527       |

**Notes:**



**Count on it.**