



Flow Divider Kit

Groundsmaster® 4500-D/4700-D

Model No. 30830

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers


Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity


In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.



Flow Divider Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	107-1985	1	Manifold-Traction	15:1	237-146	1	O-Ring
2	106-2027	1	Switch-Intermittent	15:2	340-65	1	O-Ring
3	105-9878	1	Tube-HYD	16	340-142	1	Fitting-Hyd, 90 DEG
4	105-9879	1	Tube-HYD	16:1	237-58	1	O-Ring
4:1	237-58	1	O-Ring	16:2	237-81	1	O-Ring
5	105-9880	1	Tube-HYD	17	104-8301	1	Nut-Flange, NI
6	105-9881	1	Tube-HYD	18	323-15	1	Screw-HH
6:1	237-22	1	O-Ring	19	106-2030	2	Plug-Hex, Hollow
7	105-9882	1	Tube-HYD	19:1	237-146	1	O-Ring
8	105-9885	1	Tube-HYD	20	105-9896	1	Harness-Wire
8:1	237-22	1	O-Ring	21	106-2042	1	Decal-Divider, Flow
9	105-9886	1	Tube-HYD	37	32180-035	1	Terminal-T-TAP (Not Illustrated)
10	105-9887-03	1	Bracket-Manifold				
11	105-9888	1	Hose-ASM				
12	340-77	1	Fitting-Hyd, 90 DEG				
12:1	237-22	1	O-Ring				
12:2	237-42	1	O-Ring				
13	340-2	1	Fitting-Hyd, Straight				
13:1	237-22	1	O-Ring				
13:2	237-42	1	O-Ring				
14	340-9	1	Fitting-Hyd, Straight				
14:1	237-58	1	O-Ring				
14:2	237-81	1	O-Ring				
15	340-129	1	Fitting-Hyd, 90 DEG				



Traction Manifold Assembly No. 107-1985

Ref	Part No.	Qty.	Description				
1		1	Manifold (Not Serviced Separately)				
2		13	Plug (Not Serviced Separately)				
3	107-1986	1	Flow-Divider (Used In Groundsmaster 4000 Series)				
4	106-1996	1	Valve-Piloted Directional				
4:1	106-6775	1	Seal Kit (Not Illustrated)				
5	106-1995	1	Valve-3 Way				
5:1	107-1553	1	Seal Kit (Not Illustrated)				
6	105-9333	1	E-Coil, 12v				
7	353-989	6	Plug-Hex, Hollow				
7:1	237-42	1	O-Ring				
8	353-988	3	Plug-Hex, Hollow				
8:1	237-79	1	O-Ring				
9	105-9332	1	Nut-E Coil				
10	107-1987	1	Orifice-0.040				
11	105-9321	3	Valve-Check				
11:1	105-9156	1	Seal Kit (Not Illustrated)				

