Form No. 3464-464 Rev D

TORO®

Count on it.

Parts Catalog

TimeMaster® 76cm

Lawn Mower

Model No. 21815—Serial No. 400000000 and Up

Register at www.Toro.com.
Original Instructions (EN)

CE

3464-464 D

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


Contents

Housing Assembly 4
Spindle and Belt Assembly 6
Side Discharge Chute Assembly 8
Bag Assembly 10
Engine and Belt Assembly 12
Front Wheel and Height-of-Cut Assembly 14
Rear Wheel and Height-of-Cut Assembly 16
Handle Assembly 18
Attachments and Accessories 20

© 2025—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved


Housing Assembly



Housing Assembly (continued)

Ref.	Part Number	Qty.	Description
1	136-5874	1	Housing ASM
3	140-3977-01	1	Frame-30"
4	137-3063	2	Bolt-Car
5	139-5415	1	Rod-Release, Handle
6	120-7018	1	Grip-Lever
7	121-9114	1	Bracket-Door, LH
8	121-9115	1	Bracket-Door, RH
9	120-7048	1	Rear Deflector ASM
9:3	131-4514	1	Decal-Warning
10	115-2859	1	Spring-Torsion
11	114-7924	1	Spring-Torsion
12	137-3099	3	Screw-Plastite, HWH
13	138-3224	2	Bracket-Cable, Traction
14	120-5225	1	Plug-Mulch
15	120-6241	1	Shield-Trailing
16	49-2040	8	Screw-HWHTF
19	139-1692	2	Screw-PTH
21	119-4038	2	Nut-Hex
22	139-5406	1	Cover-Belt
23	121-5793-03	1	Door-Access
24	121-5840	2	Fastener
25	125-2507	1	Decal-Access Panel
26	130-2352-01	1	Baffle-Control
27	125-5081-01	1	Plate-Deck
28	32144-86	1	Screw-HWHTF
29	139-5498	1	Spacer-Shield
30	139-5409	1	Screw-HH
31	137-3087	1	Nut-Hex
32	125-5072	1	Frame Plate Kit
32:1	125-2542	1	Plate-Frame
32:2	3229-3	3	Screw-CARR
32:3	3296-42	3	Nut-Lock, NI
34	140-3901	3	Spacer-Frame, 30 In.
35	108-4862	3	Screw-HWH Thd Roll
36	147-0471	1	Plug-Button
39	133-8177	1	Chute


Spindle and Belt Assembly



Spindle and Belt Assembly (continued)

Ref.	Part Number	Qty.	Description
1	121-9107	2	Spindle ASM
1:2	120-7935	2	Spacer
1:3	138-9770	2	Bearing-Ball
2	139-1731	9	Screw-Thd Roll, HWH
3	139-6612	1	Shaft-Spindle
4	139-6613	1	Shaft-Spindle
5	121-9100	2	Sprocket
6	130-6664	1	Pulley-Brake, Spindle
7	109-9505	2	Washer-Spring
8	139-1725	2	Nut-Hex
9	139-1726	1	Washer-Rebound
10	133-8102	1	Brake Arm ASM
11	121-2305	2	Washer-Friction, Composite
12	138-3244	1	Spacer
13	139-1728	1	Bolt-HH Ft
14	139-1723	4	Washer-Flat
16	119-4038	3	Nut-Hex
17	139-1758	2	Pulley Kit
17:2	131-4504	1	Adapter-Bore
17:3	125-2533	1	Plug-Cap
18	145-4016	1	Bracket-Idler
19	139-1730	2	Screw-Shoulder, HHF
20	120-3335	1	Belt-Synchronous
21	120-5245-03	1	Guide-Belt, Spindle
22	120-5236	2	Adapter-Blade
23	121-5808	1	Spring-Extension, Brake
24	125-2466	2	Bolt-Blade
25	49-2040	2	Screw-HWHTF
26	120-7082	1	Pulley-Idler
27	120-9696	1	Screw-HH
28	137-3089	1	Nut-Hex
29	116-6358-03	2	Blade-Rotary
30	121-2336	1	Spring-Flat
33	139-1719	1	Screw-HH
35	133-1964	1	Spacer


Side Discharge Chute Assembly



Side Discharge Chute Assembly (continued)

Ref.	Part Number	Qty.	Description
1	112-8760	1	Decal-Danger
3	137-4795	2	Screw
6	138-5325	1	Side Deflector Service ASM
6:1	138-5317	1	Deflector-Discharge, Side
6:2	127-0721	1	Spring-Torsion, Cover
6:3	138-3293	1	Bracket-Lockout
6:4	99-5291	1	Rod-Cover
7	139-5416	1	Side Discharge Chute ASM
8	133-9289	1	Fitting-Washout
8:2	133-9290	1	O-Ring
9	139-1700	2	Screw-HWH, Thd Roll
11	95-3270	1	Connector-Hose
12	120-9570	1	Decal-Warning
14	138-3293	1	Bracket-Lockout
15	107-7463	1	Spacer
16	107-7462	1	Spring-Torsion
17	138-3292	1	Lever-Lockout
18	106-9169	1	Screw-HWH
19	139-1712	1	Nut-Hex Flange


Bag Assembly



Bag Assembly (continued)

Ref.	*Part Number*	*Qty.*	*Description*
1	121-5766-03	1	Frame-Bag
2	121-5770	1	Bag-Grass

Engine and Belt Assembly




Engine and Belt Assembly (continued)

Ref.	Part Number	Qty.	Description
1		1	Engine-Briggs, 14D9320112F1 ●■
10	137-9176	1	Pulley-Engine
11	121-5765	1	V-Belt
12	120-9470	1	V-Belt, Traction
13	139-1734	1	Guide-Belt, Wa
14	95-1727	3	Screw-Taptite
15	3290-465	1	Washer-Belleville
16	26-0671	1	Screw-HH
17	139-1713	2	Screw-Thd Roll
18	131-0889-03	1	Guard-Engine
19	126-2713	2	Screw-HHF
30	147-8649	1	Decal-Shroud

● Not serviced separately

■ Obtain parts from www.briggsandstratton.com


Front Wheel and Height-of-Cut Assembly



Front Wheel and Height-of-Cut Assembly (continued)

Ref.	Part Number	Qty.	Description
1	137-3099	3	Screw-Plastite, HWH
2	120-9535	1	Grip-Lever
3	119-4042	2	Nut-HF, NI
4	147-0519	2	Bushing-Pivot, Front
4:1	15-4318	1	Resin-Nylon 66
5	139-1753	1	Front Axle ASM
6	120-7037-03	1	Plate-HOC, LH
7	120-7038-03	1	Plate-HOC, RH
8	120-7043	1	Arm-Spring
9	125-2510	2	8 Inch Wheel ASM
10	125-5027	1	Front Cover ASM
10:2	120-7047	1	Artwork-Toro Timemaster
11	139-1727	1	Screw-HWH, Thd Roll
12	137-3061	6	Bolt-CARR
13	119-4038	6	Nut-Hex
14	130-6658	4	Screw-Flange, Plastic


Rear Wheel and Height-of-Cut Assembly



Rear Wheel and Height-of-Cut Assembly (continued)

Ref.	Part Number	Qty.	Description
1	137-4796	1	Grip-Lever, Lift
2	121-5799	1	Conduit-Convoluted
3	49-2040	2	Screw-HWHTF
4	119-4042	2	Nut-HF, NI
5	104-8699	1	Bearing-Ball
6	106-5681	1	Pin-Stop
7	133-2603	2	Bearing-Ball
8	110-7191	2	Washer-Thrust
9	131-5399	2	Gear-Pinion, 15T
10	120-3342-03	1	Plate-HOC, LH
11	120-3343-03	1	Plate-HOC, RH
12	137-9124	1	Arm-Spring
13	120-5209	1	Key-Arm, Spring
14	136-5929	2	Retainer-Bearing
15	131-9665	1	Transmission Kit
15:1:1	130-2370	1	Transmission Pulley Kit
15:2	130-2369	2	Pin-Snap
15:3	32151-61	1	Ring-Retaining
16	120-6233	2	Cover-Gear
17	139-1747	1	Rear Axle ASM
18	125-2509	2	10 Inch Wheel Gear ASM
19	138-3233	1	Mount-Bearing
20	120-7026	1	Spring-Extension
21	120-7027	1	Spring-Extension
22	121-5800	2	Conduit-Convoluted
23	701243	8	Screw-Thd Roll, HWH
24	32144-4	1	Screw-HWH
25	32151-61	1	Ring-Retaining
26	36-4780	2	Washer-Plain
27	138-5338	1	Bracket-Stop
28	137-3089	1	Nut-Hex
29	125-2497	1	Decal-HOC, Rear
30	130-2369	2	Pin-Snap

Handle Assembly



Handle Assembly (continued)

Ref.	Part Number	Qty.	Description
1	145-4021-05	1	Handle-Lower, ASM
2	145-4004-05	1	Handle-Upper
3	139-1694	2	Bolt-Shoulder, HHF
4	119-4038	2	Nut-Hex
5	140-2367	1	Guide-Curved, LH (Rwd)
6	140-2366	1	Guide-Curved, RH (Rwd)
7	139-5464	1	Rod-Control, Traction
8	139-6554	1	Lever-Traction, Rwd
9	140-4194	1	Spring-Torsion
10	139-6569	1	Handle-Personal Pace, Curved
11	139-6567	1	Bottom-Handle, RH
12	139-6568	1	Bottom-Handle, LH
13	94-4496	10	Screw-PPH
14	161-1162-03	1	Bail-Brake, BBC Welded
15	161-3177	1	Cable-Brake
16	145-4007	1	Cable-Traction
17	117-5975	1	Switch Housing ASM
18	139-6581	1	Anchor-Cable, Rwd
19	106-9169	1	Screw-HWH
20	107-7462	1	Spring-Torsion
21	107-7463	1	Spacer
22	144-3174	1	Lever
23	139-1712	1	Nut-Hex Flange
24	139-6577	2	Pin-Handle, Pp
25	132-4516	2	Plug-Square
26	137-3107	2	Screw-Handle
27	117-5976	2	Knob-Handle
28	114-7988	1	Guide-Cable
29	144-0249	1	Handle-Assist, Steel
30	137-3051	2	Screw-HH
31	136-8682	2	Washer-Lock
32	107-0279	4	Washer
33	120-9683	1	Washer-Plain
48	112-8884	1	Knob
49	138-3634	1	Screw-HH
50	139-1699	1	Washer-Flat
51	137-3094	1	Nut-Hex
52	145-1459	1	Decal - Ads, Handle
53	139-1709	1	Screw-Shoulder
54	137-3085	1	Nut-Hex

Attachments and Accessories

For 21815 TimeMaster 76cm Lawn Mower

Product Name	Model/Part
Fuel Stabilizer .05 oz	130-2393
4-Cycle Fuel, Snow And Lawn 32oz Can	131-3823
Toro Premium Fuel Treatment 12oz Bottle	131-6572
Oil-30/10W-30 Synthetic (Quart)	138-6053
Traction Assist Handle Kit	144-6377
Hi-Lift Replacement Blade Kit	20122P
Lawn Striping Kit with 30in Roller	20602
Toro 4-Cycle SAE 30 Oil (32oz Bottle)	38903
Summer Oil-Case of 24 (20oz Bottles)	38916
Bag-Walk Behind (Toro)	490-7318
Mower Cover	490-7461

For 21815 TimeMaster 76cm Lawn Mower

Product Name	Model/Part
Fuel Stabilizer .05 oz	130-2393
4-Cycle Fuel, Snow And Lawn 32oz Can	131-3823
Toro Premium Fuel Treatment 12oz Bottle	131-6572
Oil-30/10W-30 Synthetic (Quart)	138-6053
Traction Assist Handle Kit	144-6377
Hi-Lift Replacement Blade Kit	20122P
Lawn Striping Kit with 30in Roller	20602
Toro 4-Cycle SAE 30 Oil (32oz Bottle)	38903
Summer Oil-Case of 24 (20oz Bottles)	38916
Bag-Walk Behind (Toro)	490-7318
Mower Cover	490-7461

Notes:

Notes:

Notes:



Count on it.