



Form No. 3464-472 Rev D

**Count on it.**

# Parts Catalog

## TimeMaster® 30in Lawn Mower

Model No. 21219—Serial No. 400000000 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

Housing Assembly ..... 4

Spindle and Belt Assembly ..... 6

Bag Assembly ..... 8

Side Discharge Chute Assembly ..... 10

Engine and Belt Assembly ..... 12


Front Wheel and Height-of-Cut Assembly ..... 14

Rear Wheel and Height-of-Cut Assembly ..... 16

Handle Assembly ..... 18

Attachments and Accessories ..... 20


# Housing Assembly



## Housing Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|----------------------|
| 1           | 136-5873           | 1           | Housing ASM             | 20          | 133-8062           | 1           | Decal-Spark Arrestor |
| 3           | 140-3977-01        | 1           | Frame-30"               | 21          | 3296-29            | 2           | Nut-Lock, NI         |
| 4           | 3230-5             | 2           | Bolt-CARR               | 26          | 130-2352-01        | 1           | Baffle-Control       |
| 5           | 139-5415           | 1           | Rod-Release, Handle     | 28          | 32144-86           | 1           | Screw-HWHTF          |
| 6           | 120-7018           | 1           | Grip-Lever              | 29          | 1-323283           | 1           | Spacer-Shield        |
| 7           | 121-9114           | 1           | Bracket-Door, LH        | 30          | 139-5409           | 1           | Screw-HH             |
| 8           | 121-9115           | 1           | Bracket-Door, RH        | 31          | 137-3087           | 1           | Nut-Hex              |
| 9           | 120-7048           | 1           | Rear Deflector ASM      | 32          | 125-5072           | 1           | Frame Plate Kit      |
| 9:3         | 131-4514           | 1           | Decal-Warning           | 32:1        | 125-2542           | 1           | Plate-Frame          |
| 10          | 115-2859           | 1           | Spring-Torsion          | 32:2        | 3229-3             | 3           | Screw-CARR           |
| 11          | 114-7924           | 1           | Spring-Torsion          | 32:3        | 3296-42            | 3           | Nut-Lock, NI         |
| 12          | 46-8091            | 3           | Screw-HWH               | 34          | 140-3901           | 3           | Spacer-Frame, 30 In. |
| 13          | 138-3224           | 2           | Bracket-Cable, Traction | 35          | 108-4862           | 3           | Screw-HWH Thd Roll   |
| 14          | 120-5225           | 1           | Plug-Mulch              | 36          | 147-0471           | 1           | Plug-Button          |
| 15          | 120-6241           | 1           | Shield-Trailing         | 38          | 139-5408           | 1           | Belt Cover ASM       |
| 16          | 49-2040            | 8           | Screw-HWHTF             | 38:2        | 121-2391           | 1           | Decal-Cover, Belt    |
| 19          | 117-1092           | 2           | Screw-PTH               | 39          | 133-8177           | 1           | Chute                |


# Spindle and Belt Assembly



## Spindle and Belt Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 121-9107           | 2           | Spindle ASM                | 17:2        | 131-4504           | 1           | Adapter-Bore            |
| 1:2         | 120-7935           | 2           | Spacer                     | 17:3        | 125-2533           | 1           | Plug-Cap                |
| 1:3         | 138-9770           | 2           | Bearing-Ball               | 18          | 145-4016           | 1           | Bracket-Idler           |
| 2           | 139-1731           | 9           | Screw-Thd Roll, HWH        | 19          | 120-7024           | 2           | Screw-Shoulder, HWH     |
| 3           | 139-6612           | 1           | Shaft-Spindle              | 20          | 120-3335           | 1           | Belt-Synchronous        |
| 4           | 139-6613           | 1           | Shaft-Spindle              | 21          | 120-5245-03        | 1           | Guide-Belt, Spindle     |
| 5           | 121-9100           | 2           | Sprocket                   | 22          | 120-5236           | 2           | Adapter-Blade           |
| 6           | 130-6664           | 1           | Pulley-Brake, Spindle      | 23          | 121-5808           | 1           | Spring-Extension, Brake |
| 7           | 109-9505           | 2           | Washer-Spring              | 24          | 125-2466           | 2           | Bolt-Blade              |
| 8           | 3296-19            | 2           | Nut-Hex                    | 25          | 49-2040            | 2           | Screw-HWHTF             |
| 9           | 63-7400            | 1           | Washer-Rebound             | 26          | 120-7082           | 1           | Pulley-Idler            |
| 10          | 133-8102           | 1           | Brake Arm ASM              | 27          | 322-6              | 1           | Screw-HH                |
| 11          | 121-2305           | 2           | Washer-Friction, Composite | 28          | 3296-47            | 1           | Nut-Lock,NI             |
| 12          | 138-3244           | 1           | Spacer                     | 29          | 116-6358-03        | 2           | Blade-Rotary            |
| 13          | 9114524            | 1           | Bolt-TAP, HH               | 30          | 121-2336           | 1           | Spring-Flat             |
| 14          | 139-1723           | 4           | Washer-Flat                | 33          | 322-9              | 1           | Screw-HH                |
| 16          | 3296-29            | 3           | Nut-Lock, NI               | 35          | 133-1964           | 1           | Spacer                  |
| 17          | 131-4529           | 2           | Pulley Kit                 |             |                    |             |                         |


# Bag Assembly



## Bag Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 121-5766-03        | 1           | Frame-Bag          |
| 2           | 121-5770           | 1           | Bag-Grass          |

# Side Discharge Chute Assembly




## Side Discharge Chute Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|-----------------------|
| 1           | 94-8072            | 1           | Decal-Danger               | 7           | 121-2319           | 1           | Chute-Discharge, Side |
| 3           | 137-4795           | 2           | Screw                      | 8           | 133-9289           | 1           | Fitting-Washout       |
| 6           | 133-2630           | 1           | Side Deflector Service ASM | 8:2         | 133-9290           | 1           | O-Ring                |
|             |                    |             | ●                          | 9           | 139-1700           | 2           | Screw-HWH, Thd Roll   |
| 6:1         | 125-5091           | 1           | Deflector-Side             | 11          | 95-3270            | 1           | Connector-Hose        |
| 6:2         | 127-0721           | 1           | Spring-Torsion, Cover      | 12          | 120-9570           | 1           | Decal-Warning         |
| 6:3         | 112-6416           | 1           | Bracket-Cover              | 13          | 125-5092           | 1           | Decal-Placement, Foot |
| 6:4         | 99-5291            | 1           | Rod-Cover                  |             |                    |             |                       |

● Not serviced separately

# Engine and Belt Assembly




## Engine and Belt Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>               | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------------------|-------------|--------------------|-------------|--------------------|
| 1           |                    | 1           | Engine-Briggs,<br>14D9320110F1 ● | 14          | 95-1727            | 3           | Screw-Taptite      |
| 10          | 137-9176           | 1           | Pulley-Engine                    | 15          | 3290-465           | 1           | Washer-Belleville  |
| 11          | 121-5765           | 1           | V-Belt                           | 16          | 26-0671            | 1           | Screw-HH           |
| 12          | 120-9470           | 1           | V-Belt, Traction                 | 17          | 32144-1            | 2           | Screw-Taptite      |
| 13          | 139-1734           | 1           | Guide-Belt, Wa                   | 18          | 131-0889-03        | 1           | Guard-Engine       |
|             |                    |             |                                  | 19          | 126-2713           | 2           | Screw-HHF          |

● Not serviced separately


# Front Wheel and Height-of-Cut Assembly



## Front Wheel and Height-of-Cut Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 46-8091            | 3           | Screw-HWH            | 8           | 120-7043           | 1           | Arm-Spring              |
| 2           | 120-9535           | 1           | Grip-Lever           | 9           | 125-2510           | 2           | 8 Inch Wheel ASM        |
| 3           | 119-4042           | 2           | Nut-HF, NI           | 10          | 125-5027           | 1           | Front Cover ASM         |
| 4           | 147-0519           | 2           | Bushing-Pivot, Front | 10:2        | 120-7047           | 1           | Artwork-Toro Timemaster |
| 4:1         | 15-4318            | 1           | Resin-Nylon 66       | 11          | 700057             | 1           | Screw-HWH               |
| 5           | 139-1753           | 1           | Front Axle ASM       | 12          | 3230-23            | 6           | Bolt-CARR               |
| 6           | 120-7037-03        | 1           | Plate-HOC, LH        | 13          | 3296-29            | 6           | Nut-Lock, NI            |
| 7           | 120-7038-03        | 1           | Plate-HOC, RH        | 14          | 130-6658           | 4           | Screw-Flange, Plastic   |


# Rear Wheel and Height-of-Cut Assembly



## Rear Wheel and Height-of-Cut Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|------------------------|
| 1           | 137-4796           | 1           | Grip-Lever, Lift        | 15:3        | 32151-61           | 1           | Ring-Retaining         |
| 2           | 121-5799           | 1           | Conduit-Convoluted      | 16          | 120-6233           | 2           | Cover-Gear             |
| 3           | 49-2040            | 2           | Screw-HWHTF             | 17          | 139-1747           | 1           | Rear Axle ASM          |
| 4           | 119-4042           | 2           | Nut-HF, NI              | 18          | 125-2509           | 2           | 10 Inch Wheel Gear ASM |
| 5           | 104-8699           | 1           | Bearing-Ball            | 19          | 138-3233           | 1           | Mount-Bearing          |
| 6           | 106-5681           | 1           | Pin-Stop                | 20          | 120-7026           | 1           | Spring-Extension       |
| 7           | 133-2603           | 2           | Bearing-Ball            | 21          | 120-7027           | 1           | Spring-Extension       |
| 8           | 110-7191           | 2           | Washer-Thrust           | 22          | 121-5800           | 2           | Conduit-Convoluted     |
| 9           | 131-5399           | 2           | Gear-Pinion, 15T        | 23          | 701243             | 8           | Screw-Thd Roll, HWH    |
| 10          | 120-3342-03        | 1           | Plate-HOC, LH           | 24          | 32144-4            | 1           | Screw-HWH              |
| 11          | 120-3343-03        | 1           | Plate-HOC, RH           | 25          | 32151-61           | 1           | Ring-Retaining         |
| 12          | 137-9124           | 1           | Arm-Spring              | 26          | 36-4780            | 2           | Washer-Plain           |
| 13          | 120-5209           | 1           | Key-Arm, Spring         | 27          | 138-5338           | 1           | Bracket-Stop           |
| 14          | 136-5929           | 2           | Retainer-Bearing        | 28          | 3296-47            | 1           | Nut-Lock,NI            |
| 15          | 131-9665           | 1           | Transmission Kit        | 29          | 125-2497           | 1           | Decal-HOC, Rear        |
| 15:1:1      | 130-2370           | 1           | Transmission Pulley Kit | 30          | 130-2369           | 2           | Pin-Snap               |
| 15:2        | 130-2369           | 2           | Pin-Snap                |             |                    |             |                        |

# Handle Assembly



## Handle Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>              | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|---------------------------------|-------------|--------------------|-------------|----------------------|
| 1           | 145-4021-05        | 1           | Handle-Lower, ASM               | 21          | 107-7463           | 1           | Spacer               |
| 2           | 145-4004-05        | 1           | Handle-Upper                    | 22          | 144-3174           | 1           | Lever                |
| 3           | 139-1694           | 2           | Bolt-Shoulder, HHF              | 23          | 32128-17           | 1           | Nut-Lock, Flange     |
| 4           | 3296-29            | 2           | Nut-Lock, NI                    | 24          | 139-6577           | 2           | Pin-Handle, Pp       |
| 5           | 140-2367           | 1           | Guide-Curved, LH (Rwd)          | 25          | 132-4516           | 2           | Plug-Square          |
| 6           | 140-2366           | 1           | Guide-Curved, RH (Rwd)          | 26          | 137-3107           | 2           | Screw-Handle         |
| 7           | 139-5464           | 1           | Rod-Control, Traction           | 27          | 117-5976           | 2           | Knob-Handle          |
| 8           | 139-6554           | 1           | Lever-Traction, Rwd             | 28          | 114-7988           | 1           | Guide-Cable          |
| 9           | 140-4194           | 1           | Spring-Torsion                  | 29          | 144-0249           | 1           | Handle-Assist, Steel |
| 10          | 139-6569           | 1           | Handle-Personal Pace,<br>Curved | 30          | 137-3051           | 2           | Screw-HH             |
| 11          | 139-6567           | 1           | Bottom-Handle, RH               | 31          | 136-8682           | 2           | Washer-Lock          |
| 12          | 139-6568           | 1           | Bottom-Handle, LH               | 32          | 107-0279           | 4           | Washer               |
| 13          | 94-4496            | 10          | Screw-PPH                       | 33          | 120-9683           | 1           | Washer-Plain         |
| 14          | 161-1162-03        | 1           | Bail-Brake, BBC Welded          | 48          | 112-8884           | 1           | Knob                 |
| 15          | 161-3177           | 1           | Cable-Brake                     | 49          | 321-57             | 1           | Screw-HH             |
| 16          | 145-4007           | 1           | Cable-Traction                  | 50          | 3256-1             | 1           | Washer-Flat          |
| 17          | 117-5975           | 1           | Switch Housing ASM              | 51          | 3296-73            | 1           | Nut-Lock, NI         |
| 18          | 139-6581           | 1           | Anchor-Cable, Rwd               | 52          | 145-5601           | 1           | Decal-Handle, Pp     |
| 19          | 106-9169           | 1           | Screw-HWH                       | 53          | 139-1709           | 1           | Screw-Shoulder       |
| 20          | 107-7462           | 1           | Spring-Torsion                  | 54          | 137-3085           | 1           | Nut-Hex              |

# Attachments and Accessories

## For 21219 TimeMaster 30in Lawn Mower

| Product Name                                 | Model/Part |
|----------------------------------------------|------------|
| Fuel Stabilizer .05 oz .....                 | 130-2393   |
| Engine Maintenance Kit.....                  | 130-8146   |
| 4-Cycle Fuel, Snow And Lawn 32oz Can .....   | 131-3823   |
| Toro Premium Fuel Treatment 12oz Bottle..... | 131-6572   |
| Oil-30/10W-30 Synthetic (Quart).....         | 138-6053   |
| Traction Assist Handle Kit .....             | 144-6377   |
| Hi-Lift Replacement Blade Kit.....           | 20122P     |
| Lawn Striping Kit with 30in Roller.....      | 20602      |
| Toro 4-Cycle SAE 30 Oil (32oz Bottle) .....  | 38903      |
| Summer Oil-Case of 24 (20oz Bottles).....    | 38916      |
| Bag-Walk Behind (Toro).....                  | 490-7318   |
| Mower Cover .....                            | 490-7461   |

## For 21219 TimeMaster 30in Lawn Mower

| Product Name                                 | Model/Part |
|----------------------------------------------|------------|
| Fuel Stabilizer .05 oz .....                 | 130-2393   |
| Engine Maintenance Kit.....                  | 130-8146   |
| 4-Cycle Fuel, Snow And Lawn 32oz Can .....   | 131-3823   |
| Toro Premium Fuel Treatment 12oz Bottle..... | 131-6572   |
| Oil-30/10W-30 Synthetic (Quart).....         | 138-6053   |
| Traction Assist Handle Kit .....             | 144-6377   |
| Hi-Lift Replacement Blade Kit.....           | 20122P     |
| Lawn Striping Kit with 30in Roller.....      | 20602      |
| Toro 4-Cycle SAE 30 Oil (32oz Bottle) .....  | 38903      |
| Summer Oil-Case of 24 (20oz Bottles).....    | 38916      |
| Bag-Walk Behind (Toro).....                  | 490-7318   |
| Mower Cover .....                            | 490-7461   |

**Notes:**

**Notes:**

**Notes:**



**Count on it.**