



Form No. 3474-133 Rev A

**Count on it.**

# Parts Catalog

## **Turf Pro™ 300** **Robotic Mower**

Model No. 30923CAN—Serial No. 325000000 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

Body Assembly . . . . . 4

Charger Housing Assembly . . . . . 6

Base Station Panel Assembly . . . . . 8

Cutting Height Assembly . . . . . 10

Electrical Box and Battery Assembly . . . . . 12

Frame Support Assembly . . . . . 14

Lift Sensors Assembly . . . . . 16

Wheels and Drive Motor Assembly . . . . . 18


Cutting Heads Assembly . . . . . 20

Cutting Disc Assembly No. 163-5579 . . . . . 22

Electrical Parts Assembly . . . . . 24

Attachments and Accessories . . . . . 26


# Body Assembly



## Body Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|----------------------|
| 1           | 163-5591           | 1           | Bumper Kit                 | 14          | 163-5396           | 6           | Screw-Pzfbh, Plastic |
| 1:1         | 163-5375           | 8           | Plate-Nut                  | 15          | 163-5388           | 2           | Screw-Shoulder       |
| 1:2         | 163-5374           | 8           | Screw-HWH, Sems            | 16          | 163-5379           | 1           | Harness-Stop Button  |
| 1:3         | 163-5592           | 1           | Bumper ASM                 | 17          | 163-5380           | 2           | Screw-Pzrh, Plastic  |
| 1:4         | 163-5373           | 2           | End Cap, Bumper            | 18          | 163-5400           | 2           | Washer-Flat          |
| 1:5         | 163-5376           | 2           | Screw-Pzph                 | 19          | 163-3846           | 2           | Screw-Hfh            |
| 2           | 163-5378           | 5           | Sensor-Ultrasonic          | 20          | 163-5399           | 2           | Screw-HH             |
| 3           | 163-5390           | 4           | Spacer                     | 21          | 163-5557           | 1           | Antenna Support ASM  |
| 4           | 163-5389           | 2           | Screw-Shoulder             | 22          | 163-5558           | 1           | Antenna-Rtk          |
| 5           | 163-5391           | 1           | Button-Stop                | 23          | 163-5559           | 2           | Screw-PPH            |
| 6           | 163-5397           | 1           | Bracket-Hinge, Stop Button | 24          | 163-5384           | 32          | Mount-Cable Tie      |
| 7           | 163-5382           | 2           | Screw-HH                   | 25          | 163-5385           | 1           | Mount-Cable Tie      |
| 8           | 163-5402           | 1           | Spacer-Switch, Reed        | 26          | 163-5679           | 1           | Harness-Jae Bodywork |
| 9           | 163-5392           | 1           | Magnet-Bonnet              | 27          | 3290-378           | 33          | Tie-Cable            |
| 10          | 163-5523           | 6           | Screw-Pz, Plastic          | 28          | 163-5401           | 6           | Rivet-Push           |
| 11          | 163-5393           | 2           | Spring-Compression         | 29          | 163-5586           | 1           | Smartbox-Can         |
| 12          | 163-5394           | 2           | Magnet                     | 30          | 163-5554           | 4           | Washer-Flat          |
| 13          | 163-5395           | 2           | Washer-Lock                | 31          | 163-5553           | 4           | Screw-HH             |


# Charger Housing Assembly



## Charger Housing Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|----------------------------|
| 1           | 163-5365           | 1           | Body Service ASM        | 4           | 163-5565           | 6           | Bracket-Mount, Housing     |
| 1:2         | 163-3958           | 1           | Decal-Turf Pro 300, Top | 5           | 163-5566           | 12          | Screw-Tph                  |
| 1:3         | 163-3955           | 1           | Decal-Panel             | 6           | 163-5594           | 1           | Charge Cable ASM           |
| 1:4         | 161-6663           | 2           | Decal-Toro Logo         | 7           | 163-5595           | 2           | Panel-Protection, Contacts |
| 2           | 163-5671           | 1           | Charge Housing ASM, RH  | 8           | 163-5387           | 12          | Rivet-Push                 |
| 3           | 163-5672           | 1           | Charge Housing ASM, LH  |             |                    |             |                            |

# Base Station Panel Assembly




CABLE ASSEMBLY VIEW

## Base Station Panel Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|---------------------|
| 1           | 163-5614           | 1           | Front Plate ASM     | 9           | 163-5620           | 1           | Sensor-Proximity    |
| 2           | 163-5615           | 1           | Front Crossbar ASM  | 10          | 163-5675           | 1           | Cable-Coil, Central |
| 3           | 163-5408           | 13          | Screw-HWH, Sems     | 11          | 163-5418           | 3           | Nut-Cable, Gland    |
| 4           | 163-5455           | 1           | Bracket-Mount, Coil | 12          | 163-5413           | 4           | Screw-Hsbhf         |
| 5           | 163-5404           | 1           | Foam-Mount, Coil    | 13          | 163-5384           | 7           | Mount-Cable Tie     |
| 6           | 163-5405           | 1           | Coil                | 14          | 3290-378           | 7           | Tie-Cable           |
| 7           | 163-5374           | 2           | Screw-HWH, Sems     | 15          | 163-5412           | 1           | Loom-Wire, Spiral   |
| 8           | 163-5619           | 1           | Sensor-Proximity    | 16          | 163-5406           | 1           | Loom-Wire, Split    |


# Cutting Height Assembly



## Cutting Height Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|-----------------------|
| 1           | 163-5415           | 1           | Cover-Motor, Lifting  | 15          | 163-5433           | 10          | Washer-Flat           |
| 2           | 163-5414           | 1           | Motor-Lifting         | 16          | 163-5434           | 5           | Nut-Hex, NI           |
| 3           | 163-5418           | 2           | Nut-Cable, Gland      | 17          | 163-5432           | 5           | Screw-HH              |
| 4           | 163-5383           | 4           | Washer-Flat           | 18          | 163-5429           | 4           | Hub-Strap, Lift       |
| 5           | 163-5382           | 4           | Screw-HH              | 19          | 163-5625           | 1           | Tube-Lift             |
| 6           | 163-5417           | 5           | Washer-Flat           | 20          | 163-5426           | 2           | Plug-Cap, Round       |
| 7           | 163-5416           | 5           | Nut-Hex, NI           | 21          | 163-5435           | 4           | Screw-Pzph            |
| 8           | 163-5436           | 1           | Pulley-Drive, Lift    | 22          | 163-5427           | 2           | Ring-Thrust           |
| 9           | 163-5438           | 1           | Screw-Set             | 23          | 163-5428           | 2           | Screw-HSH             |
| 10          | 163-5437           | 1           | Mount-Magnet, Sensor  | 24          | 163-5430           | 3           | Strap-Nylon, Short    |
| 11          | 163-5421           | 4           | Screw-Hsbhf           | 25          | 163-5627           | 2           | Bracket-Strap, Medium |
| 12          | 163-5419           | 1           | Bracket-Mount, Sensor | 26          | 163-5423           | 1           | Bracket-Strap, Short  |
| 13          | 163-5420           | 1           | Sensor-Angular        | 27          | 163-5439           | 3           | Pin-Locking, Strap    |
| 14          | 163-5626           | 1           | Strap- Nylon, Medium  |             |                    |             |                       |


# Electrical Box and Battery Assembly



## Electrical Box and Battery Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>            | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|-------------------------------|-------------|--------------------|-------------|---------------------------|
| 1           | 163-5597           | 1           | Electrical Box ASM            | 13          | 163-5635           | 4           | Cap-Nut                   |
| 2           | 163-5628           | 1           | Decal-On-Off, Horizontal      | 14          | 163-5452           | 2           | Pad-Rubber, Battery       |
| 3           | 163-5629           | 1           | Seal-Foam, Door               | 15          | 163-5462           | 1           | Battery                   |
| 4           | 163-5630           | 1           | Plate-Door, Electrical Box    | 16          | 163-5636           | 1           | Bracket-Retainer, Battery |
| 5           | 163-5631           | 1           | Guard-Rear                    | 17          | 163-5461           | 1           | Pad-Rubber, Battery       |
| 6           | 163-5448           | 18          | Screw-HWH, Sems               | 18          | 163-5637           | 1           | Guard-Rubber              |
| 7           | 163-5632           | 1           | Battery Mount ASM, RH         | 19          | 163-5638           | 1           | Plate-Guard, Rubber       |
| 8           | 163-5633           | 1           | Mount-Battery, LH             | 20          | 163-5639           | 2           | Base-Tie, Cable           |
| 9           | 163-5634           | 1           | Crossbar Battery Mount<br>ASM | 21          | 163-5469           | 2           | Screw-Pcs                 |
| 10          | 163-5408           | 4           | Screw-HWH, Sems               | 22          | 163-5677           | 1           | Cable-Battery             |
| 11          | 163-5417           | 13          | Washer-Flat                   | 23          | 163-5418           | 1           | Nut-Cable, Gland          |
| 12          | 163-5416           | 13          | Nut-Hex, NI                   | 24          | 3290-378           | 2           | Tie-Cable                 |
|             |                    |             |                               | 25          | 163-5447           | 1           | Clip-Cable                |


# Frame Support Assembly



## Frame Support Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|---------------------------|-------------|--------------------|-------------|-----------------------|
| 1           | 163-5609           | 2           | Bracket-Outside, Frame    | 9           | 163-5468           | 2           | Bearing-Tube, Molded  |
| 2           | 163-5610           | 1           | Bracket-Inside, LH, Frame | 10          | 163-5469           | 6           | Screw-Pcs             |
| 3           | 163-5611           | 1           | Bracket-Inside, RH, Frame | 11          | 163-5470           | 2           | Spacer-Threaded       |
| 4           | 163-5612           | 1           | Frame Tube ASM, LH        | 12          | 163-5482           | 2           | Screw-HH              |
| 5           | 163-5613           | 1           | Frame Tube ASM, RH        | 13          | 163-5384           | 2           | Mount-Cable Tie       |
| 6           | 163-5467           | 2           | Bracket-Mount, Tube       | 14          | 163-5624           | 2           | Plug-Cap, Rectangular |
| 7           | 163-5408           | 20          | Screw-HWH, Sems           | 15          | 3290-378           | 2           | Tie-Cable             |
| 8           | 163-5466           | 8           | Plug-Cap, Round           |             |                    |             |                       |


## Lift Sensors Assembly



## Lift Sensors Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|------------------------|
| 1           | 163-5473           | 2           | Slide-Sensor, Lift  | 12          | 163-5487           | 4           | Screw-Hsbhf            |
| 2           | 163-5478           | 4           | Screw-HH            | 13          | 163-5483           | 2           | Sensor Spring ASM      |
| 3           | 163-5474           | 2           | Bracket-Lift Sensor | 14          | 163-5485           | 4           | Washer-Flat            |
| 4           | 163-5479           | 2           | Front Cushion ASM   | 15          | 163-5489           | 2           | Isolator               |
| 5           | 163-5476           | 2           | Screw-Shoulder      | 16          | 163-5413           | 8           | Screw-Hsbhf            |
| 6           | 163-5477           | 2           | Cap-Sensor, Lift    | 17          | 163-5484           | 8           | Nut-Hex, NI            |
| 7           | 163-5475           | 4           | Magnet              | 18          | 163-5392           | 2           | Magnet-Bonnet          |
| 8           | 163-5421           | 12          | Screw-Hsbhf         | 19          | 163-5471           | 1           | Cable-Sensor, Rear, RH |
| 9           | 163-5486           | 2           | Sensor Bracket ASM  | 20          | 163-5418           | 2           | Nut-Cable, Gland       |
| 10          | 163-5416           | 12          | Nut-Hex, NI         | 21          | 163-5680           | 1           | Cable-Sensor, Rear, LH |
| 11          | 163-5488           | 2           | Pad-Sensor, Rubber  | 22          | 1-303287           | 6           | Tie-Cable              |


# Wheels and Drive Motor Assembly



## Wheels and Drive Motor Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|-----------------------------------|
| 1           | 163-5598           | 2           | Gearmotor Mount ASM     | 11          | 163-5607           | 2           | Plate-Wheel, Rear                 |
| 2           | 163-5600           | 2           | Gearbox                 | 12          | 163-5608           | 12          | Screw-Shoulder                    |
| 3           | 163-5601           | 2           | Motor-Wheel             | 13          | 163-5498           | 2           | Bracket-Mount, Wheel, Front       |
| 4           | 163-5505           | 8           | Screw-HH                | 14          | 163-5408           | 4           | Screw-HWH, Sems                   |
| 5           | 163-5599           | 2           | Plate-Seal, Gearmotor   | 15          | 163-5616           | 2           | Support-Hub, Wheel, Front         |
| 6           | 163-5469           | 8           | Screw-Pcs               | 16          | 163-5497           | 2           | Front Wheel Hub ASM               |
| 7           | 163-5602           | 8           | Plug-Cap, Round         | 17          | 163-5617           | 8           | Washer-Flat                       |
| 8           | 163-5495           | 2           | Rear Wheel Retainer Kit | 18          | 163-5618           | 8           | Screw-HH                          |
| 8:1         | 163-5493           | 1           | Wheel Retainer ASM      | 19          | HDW19425           | 4           | Washer,M8,21MM OD,4MM<br>Th,ST/ST |
| 8:2         | 163-5494           | 1           | Spacer                  | 20          | 163-5501           | 2           | Wheel-Front                       |
| 9           | 163-5603           | 2           | Hub-Wheel, Rear         | 21          | 163-5502           | 2           | Washer-Flat                       |
| 10          | 163-5606           | 2           | Rear Wheel ASM          | 22          | 163-5503           | 2           | Nut-Hex, NI                       |
| 10:1        | 163-5604           | 1           | Wheel-Rear              |             |                    |             |                                   |
| 10:2        | 163-5605           | 1           | Tire-Rear               |             |                    |             |                                   |


# Cutting Heads Assembly



## Cutting Heads Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|-----------------------------|-------------|--------------------|-------------|----------------------------|
| 1           | 163-5510           | 3           | Bracket-Mount, Cutting Head | 6:6         | 163-5519           | 2           | Shaft-Short, Control Arm   |
| 2           | 163-5511           | 3           | Gusset-Mount, Cutting Head  | 6:7         | 163-5417           | 2           | Washer-Flat                |
| 3           | 163-5512           | 3           | Screw-Hph, Sems             | 6:8         | 163-5518           | 2           | Screw-Hsph                 |
| 4           | 163-5408           | 9           | Screw-HWH, Sems             | 6:9         | 163-5521           | 2           | Plug-Cap, Round            |
| 5           | 163-5814           | 3           | Stay Kit, Upper             | 7           | 163-5522           | 3           | Case-Motor, Cutting Head   |
| 5:2         | 163-5514           | 1           | Shaft-Long, Control Arm     | 8           | 163-5524           | 3           | Guard-Motor, Cutting Head  |
| 5:3         | 163-5515           | 1           | Spring-Torsion, LH          | 9           | 163-5589           | 3           | Gasket-Motor, Cutting Head |
| 5:4         | 163-5516           | 1           | Spring-Torsion, RH          | 10          | 163-5590           | 3           | Motor-Cutting Head         |
| 5:5         | 163-5417           | 3           | Washer-Flat                 | 11          | 163-5469           | 12          | Screw-Pcs                  |
| 5:6         | 163-5512           | 2           | Screw-Hph, Sems             | 12          | 163-5621           | 3           | Cushion-Lower, Drive Card  |
| 5:7         | 163-5518           | 2           | Screw-Hsph                  | 13          | 163-5640           | 3           | Card-Drive, Cutting Head   |
| 5:8         | 163-5519           | 2           | Shaft-Short, Control Arm    | 14          | 163-5622           | 3           | Cushion-Upper, Drive Card  |
| 5:9         | 163-5517           | 3           | Cap-Sensor, Lift            | 15          | 163-5525           | 3           | Gasket-Cover, Cutting Head |
| 5:10        | 163-5520           | 2           | O-Ring                      | 16          | 163-5526           | 3           | Cover-Cutting Head         |
| 5:11        | 163-5521           | 2           | Plug-Cap, Round             | 17          | 163-5424           | 18          | Screw-Hph, Sems            |
| 6           | 163-5815           | 3           | Stay Kit, Lower             | 18          | 163-5623           | 3           | Cable-Motor, Cutting Head  |
| 6:2         | 163-5514           | 1           | Shaft-Long, Control Arm     | 19          | 163-5543           | 6           | Nut-Plastic, Gland         |
| 6:3         | 163-5512           | 2           | Screw-Hph, Sems             | 20          | 163-5579           | 3           | Cutting Disc Kit No Blades |
| 6:4         | 163-5517           | 3           | Cap-Sensor, Lift            | 23          | 163-5574           | 1           | 15 Pack Blades             |
| 6:5         | 163-5520           | 2           | O-Ring                      | 23          | 163-5575           | 1           | 50 Pack Blades             |
|             |                    |             |                             | 23          | 163-5576           | 1           | 500 Pack Blades            |



Cutting Disc Assembly No. 163-5579



## Cutting Disc Assembly No. 163-5579 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|--------------------|
| 1           | 163-5816           | 1           | Disc Kit, Free        | 1:2         | 163-5527           | 1           | Cap-Cutting Head   |
| 1:1         | 163-5568           | 1           | Shaft And Bearing Kit | 1:3         | 163-5528           | 1           | Disc-Anti Friction |
| 1:1:1       | 163-5530           | 1           | Shaft-Cutter          | 1:4         | 163-5529           | 4           | Screw-Pzcs         |
| 1:1:2       | 163-5531           | 1           | Spacer-Stepped, Shaft | 1:5         | 163-5538           | 1           | Cap-Hub            |
| 1:1:3       | 163-5532           | 1           | Bearing-Ball          | 1:6         | 163-5539           | 4           | Screw-Pbh          |
| 1:1:4       | 163-3854           | 1           | Washer-Flat           | 2           | 163-5569           | 1           | Kit-Disc, Blade    |
| 1:1:5       | 163-5534           | 1           | Screw-HSBH            | 2:2         | 163-5541           | 3           | Nut-Hex, Thin      |
| 1:1:6       | 163-5535           | 1           | Nut-Hex               | 2:3         | 163-5542           | 3           | Stud-Cutting Head  |
| 1:1:7       | 163-5536           | 1           | Washer-Shim           | 3           | 163-5580           | 1           | Seal-V-Ring        |
| 1:1:8       | 163-5537           | 1           | Screw-Pbh             |             |                    |             |                    |

# Electrical Parts Assembly



## Electrical Parts Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|-------------------------------------|-------------|--------------------|-------------|-----------------------------|
| 1           | 163-5643           | 1           | Foam-Anti-Condensing,<br>Peripheral | 12          | 163-5424           | 2           | Screw-Hph, Sems             |
| 2           | 163-5641           | 3           | Duct-Cable, 15CM                    | 13          | 163-5660           | 1           | Cutting Control Board ASM   |
| 3           | 163-5642           | 1           | Duct-Cable, 23CM                    | 13:1        | 121-8864           | 5           | Fuse-Mini Blade, 5 Amp      |
| 4           | 163-5644           | 2           | Foam-Anti-Condensing,<br>Motor      | 14          | 163-5652           | 2           | Card-Drive, Traction        |
| 5           | 163-5645           | 1           | Foam-Anti-Condensing,<br>Cutting    | 15          | 163-5552           | 4           | Washer-Tooth, EXT           |
| 6           | 163-5545           | 4           | Spacer-Hex, Pcb                     | 16          | 163-5551           | 4           | Screw-HSH                   |
| 7           | 163-5648           | 6           | Spacer-Threaded                     | 17          | 163-5547           | 1           | Switch-Toggle               |
| 8           | 163-5544           | 14          | Support-Pcb                         | 18          | 163-5548           | 1           | Cap-Switch, Rubber          |
| 9           | 163-5650           | 1           | Peripheral Board ASM                | 19          | 163-5676           | 1           | Cable-Power Supply          |
| 9:1         | 121-8861           | 6           | Fuse-Mini Blade, 2 Amp              | 20          | 163-5442           | 2           | Screw-Pz, Plastic           |
| 9:2         | 121-8864           | 1           | Fuse-Mini Blade, 5 Amp              | 21          | 163-5678           | 1           | Cable-Signal, Cutting Board |
| 9:3         | 121-8867           | 2           | Fuse-Mini Blade, 15 Amp             | 22          | 163-5656           | 1           | Cable-Motor, Signal, RH     |
| 10          | 163-5550           | 1           | Seal-Connector                      | 23          | 163-5653           | 1           | Cable-Motor, Signal, LH     |
| 11          | 163-5549           | 2           | Pcb Retainer ASM                    | 24          | 163-5654           | 1           | Cable-Power, LH             |
|             |                    |             |                                     | 25          | 163-5655           | 1           | Cable-Power, RH             |
|             |                    |             |                                     | 26          | 163-5657           | 1           | Cable-Power, Cutting Board  |

# Attachments and Accessories

## For 30923CAN Turf Pro 300 Robotic Mower

| Product Name                        | Model/Part |
|-------------------------------------|------------|
| Kit-Low Height Cut Disc .....       | 163-3850   |
| Cable-Diagnostic .....              | 163-3870   |
| Charger-Mobile.....                 | 163-3871   |
| Cable-Battery/Wake-up .....         | 163-3872   |
| Stops-Calibration .....             | 163-3873   |
| Protector-Range, Cutting Disc ..... | 163-3923   |
| Wire-Spool-1000 FT .....            | 163-3926   |
| Wire-Spool-250 FT .....             | 163-3927   |
| 15 Pack Blades.....                 | 163-5574   |
| 50 Pack Blades.....                 | 163-5575   |
| 500 Pack Blades.....                | 163-5576   |
| Cutting Disc Kit No Blades .....    | 163-5579   |
| 4G RTK Base Can .....               | 30912CAN   |
| Charge Station, Loop Only NA.....   | 30913NA    |
| Charge Station, Two Loop NA .....   | 30914NA    |
| WIFI RTK Base WW .....              | 30915      |

**Notes:**



**Count on it.**