



Form No. 3474-296 Rev A

Count on it.

Parts Catalog

TimeMaster® 30in Lawn Mower

Model No. 21220—Serial No. 418506969 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Housing Assembly 4

Spindle and Belt Assembly 6

Side Discharge Chute Assembly 8

Grass Bag Assembly 10

Engine and Belt Assembly 12


Front Wheel and Height-of-Cut Assembly 14

Rear Wheel and Height-of-Cut Assembly 16

Handle Assembly 18

Attachments and Accessories 20


Housing Assembly



Housing Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	136-5873	1	Housing ASM	20	133-8062	1	Decal-Spark Arrestor
3	140-3900-01	1	Frame-30"	21	3296-29	2	Nut-Lock, NI
4	3230-5	2	Bolt-CARR	26	130-2352-01	1	Baffle-Control
5	139-5415	1	Rod-Release, Handle	28	32144-86	3	Screw-HWHTF
6	120-7018	1	Grip-Lever	29	145-3921	1	Spacer
7	121-9114	1	Bracket-Door, LH	31	137-3087	1	Nut-Hex
8	121-9115	1	Bracket-Door, RH	32	125-5072	1	Frame Plate Kit
9	120-7048	1	Rear Deflector ASM	32:1	125-2542	1	Plate-Frame
9:3	131-4514	1	Decal-Warning	32:2	3229-3	3	Screw-CARR
10	115-2859	1	Spring-Torsion	32:3	3296-42	3	Nut-Lock, NI
11	114-7924	1	Spring-Torsion	34	161-8301	3	Spacer-Frame, 30 In.
12	46-8091	3	Screw-HWH	35	108-4862	1	Screw-HWH Thd Roll
13	138-3224	2	Bracket-Cable, Traction	36	147-0471	1	Plug-Button
14	120-5225	1	Plug-Mulch	38	139-5408	1	Belt Cover ASM
15	120-6241	1	Shield-Trailing	38:2	121-2391	1	Decal-Cover, Belt
16	49-2040	9	Screw-HWHTF	39	133-8177	1	Chute
19	139-1692	2	Screw-PTH				


Spindle and Belt Assembly



Spindle and Belt Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	121-9107	2	Spindle ASM	17	161-4815	2	Idler-Pulley
1:2	120-7935	2	Spacer	18	145-4016	1	Bracket-Idler
1:3	138-9770	2	Bearing-Ball	19	120-7024	2	Screw-Shoulder, HWH
2	139-1731	9	Screw-Thd Roll, HWH	20	120-3335	1	Belt-Synchronous
3	139-6612	1	Shaft-Spindle	21	120-5245-03	1	Guide-Belt, Spindle
4	139-6613	1	Shaft-Spindle	22	120-5236	2	Adapter-Blade
5	121-9100	2	Sprocket	23	121-5808	1	Spring-Extension, Brake
6	130-6664	1	Pulley-Brake, Spindle	24	125-2466	2	Bolt-Blade
7	109-9505	2	Washer-Spring	25	49-2040	2	Screw-HWHTF
8	3296-19	2	Nut-Hex	26	120-7082	1	Pulley-Idler
9	63-7400	1	Washer-Rebound	27	322-6	1	Screw-HH
10	133-8102	1	Brake Arm ASM	28	3296-47	1	Nut-Lock,NI
11	121-2305	2	Washer-Friction, Composite	29	116-6358-03	2	Blade-Rotary
12	138-3244	1	Spacer	30	121-2336	1	Spring-Flat
13	9114524	1	Bolt-TAP, HH	33	322-9	1	Screw-HH
14	139-1723	4	Washer-Flat	35	133-1964	1	Spacer
16	3296-29	3	Nut-Lock, NI				


Side Discharge Chute Assembly



Side Discharge Chute Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	94-8072	1	Decal-Danger	7	121-2319	1	Chute-Discharge, Side
3	137-4795	2	Screw	8	133-9289	1	Fitting-Washout
6	133-2630	1	Side Deflector Service ASM	8:2	133-9290	1	O-Ring
6:1	125-5091	1	Deflector-Side	9	139-1700	2	Screw-HWH, Thd Roll
6:2	127-0721	1	Spring-Torsion, Cover	11	95-3270	1	Connector-Hose
6:3	112-6416	1	Bracket-Cover	12	120-9570	1	Decal-Warning
6:4	99-5291	1	Rod-Cover	13	125-5092	1	Decal-Placement, Foot


Grass Bag Assembly



Grass Bag Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	121-5766-03	1	Frame-Bag
2	161-8188	1	Bag ASM-Grass

Engine and Belt Assembly




Engine and Belt Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1		1	Engine-Briggs,14D9350111F1 ●■	14	95-1727	3	Screw-Taptite
10	137-9176	1	Pulley-Engine	15	3290-465	1	Washer-Belleville
11	121-5765	1	V-Belt	16	26-0671	1	Screw-HH
12	120-9470	1	V-Belt, Traction	17	32144-1	2	Screw-Taptite
13	139-1734	1	Guide-Belt, Wa	18	131-0889-03	1	Guard-Engine
				19	126-2713	2	Screw-HHF

● Not serviced separately

■ Obtain parts from www.briggsandstratton.com


Front Wheel and Height-of-Cut Assembly



Front Wheel and Height-of-Cut Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	46-8091	3	Screw-HWH	8	120-7043	1	Arm-Spring
2	120-9535	1	Grip-Lever	9	125-2510	2	8 Inch Wheel ASM
3	119-4042	2	Nut-HF, NI	10	125-5027	1	Front Cover ASM
4	147-0519	2	Bushing-Pivot, Front	10:2	120-7047	1	Artwork-Toro Timemaster
4:1	15-4318	1	Resin-Nylon 66	11	700057	1	Screw-HWH
5	139-1753	1	Front Axle ASM	12	3230-23	6	Bolt-CARR
6	120-7037-03	1	Plate-HOC, LH	13	3296-29	6	Nut-Lock, NI
7	120-7038-03	1	Plate-HOC, RH	14	130-6658	4	Screw-Flange, Plastic


Rear Wheel and Height-of-Cut Assembly



Rear Wheel and Height-of-Cut Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	137-4796	1	Grip-Lever, Lift	15:3	32151-61	1	Ring-Retaining
2	121-5799	1	Conduit-Convoluted	16	147-0404	2	Cover-Gear
3	49-2040	2	Screw-HWHTF	17	139-1747	1	Rear Axle ASM
4	119-4042	2	Nut-HF, NI	18	125-2509	2	10 Inch Wheel Gear ASM
5	104-8699	1	Bearing-Ball	19	138-3233	1	Mount-Bearing
6	106-5681	1	Pin-Stop	20	120-7026	1	Spring-Extension
7	133-2603	2	Bearing-Ball	21	120-7027	1	Spring-Extension
8	110-7191	2	Washer-Thrust	22	121-5800	2	Conduit-Convoluted
9	131-5399	2	Gear-Pinion, 15T	23	701243	8	Screw-Thd Roll, HWH
10	120-3342-03	1	Plate-HOC, LH	24	32144-4	1	Screw-HWH
11	120-3343-03	1	Plate-HOC, RH	25	32151-61	1	Ring-Retaining
12	137-9124	1	Arm-Spring	26	36-4780	2	Washer-Plain
13	120-5209	1	Key-Arm, Spring	27	138-5338	1	Bracket-Stop
14	136-5929	2	Retainer-Bearing	28	3296-47	1	Nut-Lock,NI
15	131-9665	1	Transmission Kit	29	125-2497	1	Decal-HOC, Rear
15:1:1	130-2370	1	Transmission Pulley Kit	30	130-2369	2	Pin-Snap
15:2	130-2369	2	Pin-Snap				

Handle Assembly



Handle Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	145-4021-05	1	Handle-Lower, ASM	30	99-6005	2	Bolt-Carriage
2	145-4004-05	1	Handle-Upper	31	137-4808	2	Nut-Acorn
3	139-1694	2	Bolt-Shoulder, HHF	33	120-9683	1	Washer-Plain
4	3296-29	2	Nut-Lock, NI	34	140-4357	1	Decal-Battery Charging
5	140-2367	1	Guide-Curved, LH (Rwd)	35	136-5912	1	Anchor-Cable
6	140-2366	1	Guide-Curved, RH (Rwd)	36	23-0660	1	Switch-Starter
7	139-5464	1	Rod-Control, Traction	36:1	218-461	1	Nut-HH
8	139-6554	1	Lever-Traction, Rwd	36:2	3254-5	1	Washer-Lock
9	140-4194	1	Spring-Torsion	37	108-3795	1	Housing-Switch, Key
10	139-6569	1	Handle-Personal Pace, Curved	38	108-3796	1	Cover-Swch
11	139-6567	1	Bottom-Handle, RH	39	700918	1	Key
12	139-6568	1	Bottom-Handle, LH	40	136-9126	1	Charger, Battery (12V)
13	94-4496	10	Screw-PPH	41	139-1703	2	Screw-Plastic, PPH
14	161-1162-03	1	Bail-Brake, BBC Welded	42	108-9751	1	Decal-Switch, Ignition
15	161-3177	1	Cable-Brake	43	32144-1	1	Screw-Taptite
16	145-4007	1	Cable-Traction	44	136-5895	1	Harness-Wire
19	106-9169	1	Screw-HWH	44:4	99-6124	1	Fuse-40 Amp
20	107-7462	1	Spring-Torsion	45	108-0987	1	Foam-Battery
21	107-7463	1	Spacer	46	120-3329	1	Cover-Battery
22	161-4788	1	Lever	48	112-8884	1	Knob
23	32128-17	1	Nut-Lock, Flange	49	321-57	1	Screw-HH
24	139-6577	2	Pin-Handle, Pp	50	3256-1	1	Washer-Flat
25	132-4516	2	Plug-Square	51	3296-73	1	Nut-Lock, NI
26	137-3107	2	Screw-Handle	52	145-5601	1	Decal-Handle, Pp
27	117-5976	2	Knob-Handle	53	139-1709	1	Screw-Shoulder
28	114-7988	1	Guide-Cable	54	137-3085	1	Nut-Hex
29	144-0220	1	Handle-Assist	55	106-8397	1	Battery-Wet, 12V 3Ah, Sealed

Attachments and Accessories

For 21220 TimeMaster 30in Lawn Mower

Product Name	Model/Part
Hi-Lift Replacement Blade Kit	20122P
Traction Assist Handle Kit	144-6377
Bag-Walk Behind (Toro).....	490-7318
Summer Oil-Case of 24 (20oz Bottles).....	38916
Mower Cover	490-7461
4-Cycle Fuel, Snow And Lawn 32oz Can	131-3823
Lawn Striping Kit with 30in Roller	20602
Fuel Stabilizer .05 oz	130-2393
Toro Premium Fuel Treatment 12oz Bottle.....	131-6572
Toro 4-Cycle SAE 30 Oil (32oz Bottle)	38903
Engine Maintenance Kit.....	130-8146
Oil-30/10W-30 Synthetic (Quart).....	138-6053

Notes:

Notes:

Notes:



Count on it.