Form No. 3401-544 Rev B

TORO®

Count on it.

Parts Catalog

21in Heavy-Duty

Recycler®/Rear Bagger Lawn Mower

Model No. 22296—Serial No. 316000001 and Up

Register at www.Toro.com.
Original Instructions (EN)

3401-544 B

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


Contents

Housing Assembly 4
Grass Bag Assembly 6
Engine and Blade Assembly 8
Height-of-Cut and Wheel Assembly 10
Transmission and Rear Wheel Assembly 12
Transmission Assembly No. 131-5350 14
Handle and Control Assembly 16
Attachments and Accessories 18

© 2025—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved


Housing Assembly



Housing Assembly (continued)

Ref.	Part Number	Qty.	Description
1	125-8400	1	Housing ASM
1:2	94-8072	1	Decal-Danger
1:3	130-9670	1	Decal-Warning, Blade
2	125-1002-01	1	Floor-Chute
3	3229-2	4	Screw-CARR
4	104-7201	4	Nut-HF, NI
5	125-5041	2	Kicker
6	49-2040	6	Screw-HWHTF
7	125-5038	1	Cover-Belt, Front
8	125-5039	1	Cover-Belt, Rear
9	125-1003-03	1	Guard-Engine
10	104-8300	2	Nut-HF, NI
11	3230-3	2	Screw-CARR
12	125-1047-03	2	Guard-Side, Deck
13	125-8387	1	Clamp-Cable
19	119-2368	2	Decal-Recycler


Grass Bag Assembly



Grass Bag Assembly (continued)

Ref.	Part Number	Qty.	Description
1	125-1017	1	Rod-Door, Bag
2	125-8402	1	Bag Door ASM
2:2	116-7583	1	Decal-Warning
3	125-1019	1	Spring-Torsion
4	1-513658	2	Bumper
5	121-1399-03	1	Frame-Bag
6	125-1030	1	Bag-Grass
7	125-1008	1	Plug-Mulch
8	125-1007	1	Shield-Trailing
9	125-8413	1	Rod-Shield, Trailing
10	125-1013-03	1	Bracket-Mount, LH Handle
11	125-1014-03	1	Bracket-Mount, RH Handle
12	49-2040	4	Screw-HWHTF


Engine and Blade Assembly



Engine and Blade Assembly (continued)

Ref.	Part Number	Qty.	Description
1	125-1095	1	Engine-Honda, Gxv160 Gas
2	125-8405	1	Decal-Engine, Honda
3	125-1074	2	Screw-HH
4	103-2678	1	Screw-Shoulder
5	104-7201	2	Nut-HF, NI
6	130-2377	2	Bushing-Flange
7	130-2375	1	Plate-Anchor
8	3231-25	1	Bolt-CARR
9	117-2718	1	Decal-Arrester, Spark
10	42-3560	1	Bolt-Shoulder
11	125-8446	1	Plate-Guide, BBC
12	110-1790	1	Belt
13	605256	1	Spacer
14	108-3790	1	Retainer-Belt
15	38-7820	3	Bearing-Ball
16	107-0758	1	Spacer-Bearing
17	130-9699	1	Bolt-Shoulder
18	125-1063	1	Plate-Brake
19	125-5069	2	Nut-Hex
20	108-3792	1	Spring-Tension, Brake
21	117-5970	1	Pulley
22	3211-42	2	Screw-HH
23	107-0754	1	Drum
24	108-9342	1	Nut-Hex
25	125-1006	1	Cover
26	32144-86	3	Screw-HWHTF
27	108-3787	1	Disc
28	130-6404-01	1	Spacer-Driver, Blade
29	107-7487	1	Support-Blade
30	108-3762-03	1	Blade-Recycling
31	125-1069-03	1	Accelerator-Blade
32	127-6852	2	Nut-Flange, Lock
33	114-0280	1	Tank-Fuel
34	115-7788	1	Cap-Fuel
35	115-0962	1	Hose-Vent, Canister
36	119-7837-03	1	Mount-Tank
37	3210-2	1	Screw-HH
38	46-8091	2	Screw-HWH
39	104-8300	1	Nut-HF, NI
40	119-7856	1	Hose-Fuel
41	2412-98	2	Clamp-Hose
42	3230-7	1	Bolt-CARR
43	139-0717	1	Filter-Fuel
44	2412-108	1	Clamp-Worm


Height-of-Cut and Wheel Assembly



Height-of-Cut and Wheel Assembly (continued)

Ref.	Part Number	Qty.	Description
1	121-1439	2	Plate-HOC, Front
2	49-2040	4	Screw-HWHTF
3	121-1427	2	Bushing-Axle, Front HOC
4	121-1442	2	Retainer-Bushing, Front Axle
5	321-37	4	Screw-HH
6	104-7201	4	Nut-HF, NI
7	121-1428	2	Axle-Wheel
8	104-8301	4	Nut-HF, NI
9	125-1093	2	Knob-Lever, HOC
10	131-5377	2	Key-Arm, Spring
11	121-1431-03	2	Arm-Spring
12	104-2065	2	Screw-HWH
13	130-6420	2	Arm-Pivot, Front
14	99-5107	2	Nut-Lock
15	323-13	2	Screw-HH
16	74-1671	2	Spacer-Cover, Wheel
17	125-1080	2	Wheel
17:3	52-2450	2	Bearing-Wheel
17:4	125-1077	1	Spacer

Transmission and Rear Wheel Assembly




Transmission and Rear Wheel Assembly (continued)

Ref.	Part Number	Qty.	Description
1	131-5350	1	Transmission
2	125-5090-03	1	Guide-Belt
3	125-5040	1	Lever-Shift
4	130-9681	1	Cover-Shaft, Transmission
5	125-1011	1	Belt-V
6	127-6848	2	Cover-Bearing
7	32151-10	2	Ring-Retaining
8	98-1452	2	Washer-Thrust
9	130-6422	2	Plate-HOC, Rear
10	49-2040	9	Screw-HWHTF
11	323-13	2	Screw-HH
12	133-2641	2	Arm-Pivot, Rear
13	131-5377	2	Key-Arm, Spring
14	125-1093	2	Knob-Lever, HOC
15	104-2065	2	Screw-HWH
16	121-1448-03	2	Arm-Spring, Rear
17	133-2604	2	Bearing Retainer ASM
17:2	133-2603	4	Bearing-Ball
18	130-9692	2	Screw-HWH
19	125-1082	2	Cover-Wheel
20	32151-61	4	Ring-Retaining
21	131-5399	2	Gear-Pinion, 15T
22	74-1671	2	Spacer-Cover, Wheel
23	133-2634	2	Wheel ASM
23:1		1	Wheel ●
23:1:2	133-2603	2	Bearing-Ball
23:1:3	125-1077	1	Spacer
24	104-8301	2	Nut-HF, NI
25	104-7201	1	Nut-HF, NI

● Not serviced separately


Transmission Assembly No. 131-5350



Transmission Assembly No. 131-5350 (continued)

Ref.	Part Number	Qty.	Description
1	130-2301	1	Nut-Flange
2	130-2326	2	Flange-Pulley
3	130-2336	1	Case-Upper, Transmission
4	130-2318	1	Bearing-Ball
5	130-2311	1	Gear-Bevel, 53 Tooth
6	130-2327	1	Fork-Shift
7	133-2611	1	Shaft-Output, Short
8	130-2322	1	Spring-Retaining
9	130-9708	2	Bearing-Ball
10	130-2325	2	Seal
11	130-2333	2	Bushing-Shaft, Output
12	133-2615	2	Spring
13	130-2328	2	Key-Shift
14	130-2329	1	Ring-Shift
15	130-2315	1	Gear-Output, 22 Tooth
16	130-2316	1	Gear-Output, 25 Tooth
17	130-2321	1	Spring-Indexing, Shifter
18	130-2332	1	Pin-Indexing, Shifter
19	130-2331	1	Lever-Indexing, Shifter
20	130-2337	1	Case-Lower, Transmission
21	130-2302	10	Screw
22	130-2317	1	Gear-Output, 32 Tooth
23	133-2614	2	Key
24	133-2612	1	Shaft-Output, Long
25	133-2617	1	Spacer-Long
26	133-2616	2	Pin
27	133-2613	1	Hub-Gear, Output
28	130-2306	1	Shaft-Shift
29	130-2304	1	Ring-Retaining
30	130-2319	1	Bearing-Ball
31	130-2314	1	Gear-Intermediate, 14 Tooth
32	130-2313	1	Gear-Intermediate, 15 Tooth
33	130-2312	1	Gear-Intermediate, 17 Tooth
34	130-2307	1	Shaft-Intermediate
35	130-2303	1	Nut-Shaft, Input
36	130-2310	1	Gear-Bevel, 12 Tooth
37	130-2324	2	Seal
38	130-2300	1	Shaft-Input
39	130-9708	2	Bearing-Ball
40	133-2618	1	Spacer-Short

Handle and Control Assembly



Handle and Control Assembly (continued)

Ref.	Part Number	Qty.	Description
1	125-1016-03	1	Handle
2	3230-4	2	Screw-CARR
3	104-8300	6	Nut-HF, NI
4	115-1794	2	Screw-HHF
5	125-8421	1	Decal-Toro, Commercial
6	125-8350-01	1	Panel-Control
7	125-8358-03	1	Bracket-Control
8	117-7737	2	Screw-Handle
9	104-7201	3	Nut-HF, NI
10	322-19	1	Screw-HH
11	125-8424	1	Spacer
12	85-6750	1	Spring-Control
13	125-8357-03	1	Bar-Control
14	125-8352	1	Lever-Control
15	125-8354	1	Lever-Traction
16	125-8408	1	Screw-Handle
17	125-8359	1	Spacer-Flange
18	130-9702	1	Cable-BBC
19	130-9703	1	Cable-Traction, BBC
20	84-9040	2	Pin-Cable
21	3272-1	2	Pin-Cotter
22	127-6897-03	1	Guard-Cable, Handle
23	108-0988	2	Screw-CARR
24	114-3778	2	Nut-HF
25	94-2691	1	Screw-HWH Taptite
26	130-6722	1	Decal-Adjust Self Propel Drive
27	125-8374	1	Control-Throttle/Choke
27:1	130-6400	1	Cable-Throttle
27:2	130-6401	1	Control-Throttle
28	321-10	1	Screw-HH
29	3256-22	1	Washer-Flat
30	130-9656	1	Decal-Throttle, Choke

Attachments and Accessories

For 22296 21in Heavy-Duty Recycler/Rear Bagger Lawn Mower

Product Name	Model/Part
Blade-Bagging, 21in	125-1072-03
Cup-Anti Scalp	125-8440
Rear Discharge Kit	130-9734

Notes:



Count on it.