



Count on it.

Parts Catalog

21in Heavy-Duty Recycler®/Rear Bagger

Lawn Mower

Model No. 22296—Serial No. 404330000 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Housing Assembly 4

Grass Bag Assembly 6

Engine and Blade Assembly 8

Height-of-Cut Assembly 10


Transmission and Rear Wheel Assembly 12

Transmission Assembly No. 131-5350 14

Handle and Control Assembly 16

Attachments and Accessories 18


Housing Assembly



Housing Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	136-5896	1	Housing ASM	7	125-5038	1	Cover-Belt, Front
1:2	94-8072	1	Decal-Danger	8	125-5039	1	Cover-Belt, Rear
1:3	130-9670	1	Decal-Warning, Blade	9	125-1003-03	1	Guard-Engine
2	125-1002-01	1	Floor-Chute	10	104-8300	2	Nut-HF, NI
3	3229-2	4	Screw-CARR	11	3230-3	2	Screw-CARR
4	104-7201	4	Nut-HF, NI	12	125-1047-03	2	Guard-Side, Deck
5	125-5041	2	Kicker	13	125-8387	1	Clamp-Cable
6	49-2040	6	Screw-HWHTF	19	119-2368	2	Decal-Recycler


Grass Bag Assembly



Grass Bag Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	125-1017	1	Rod-Door, Bag	7	125-1008	1	Plug-Mulch
2	125-8402	1	Bag Door ASM	8	125-1007	1	Shield-Trailing
2:2	116-7583	1	Decal-Warning	9	125-8413	1	Rod-Shield, Trailing
3	125-1019	1	Spring-Torsion	10	133-8193-03	1	Bracket-Mount, Handle (LH)
4	1-513658	2	Bumper	11	133-8194-03	1	Bracket-Mount, Handle (RH)
5	121-1399-03	1	Frame-Bag	12	32144-70	4	Screw-HWHTF
6	125-1030	1	Bag-Grass				

Engine and Blade Assembly




Engine and Blade Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1		1	Engine-Honda, Gxv160 Gas ●■	23	126-8108	1	Drum
2	125-8405	1	Decal-Engine, Honda	24	108-9342	1	Nut-Hex
3	125-1074	2	Screw-HH	25	125-1006	1	Cover
4	103-2678	1	Screw-Shoulder	26	32144-86	3	Screw-HWHTF
5	104-7201	2	Nut-HF, NI	27	108-3787	1	Disc
6	130-2377	2	Bushing-Flange	28	130-6404-01	1	Spacer-Driver, Blade
7	130-2375	1	Plate-Anchor	29	107-7487	1	Support-Blade
8	3231-25	1	Bolt-CARR	30	133-8183-03	1	Blade-Recycling 21In (Bagging)
9	133-8062	1	Decal-Spark Arrestor	31	125-1069-03	1	Accelerator-Blade
10	42-3560	1	Bolt-Shoulder	32	127-6852	2	Nut-Flange, Lock
11	125-8446	1	Plate-Guide, BBC	33	114-0280	1	Tank-Fuel
12	110-1790	1	Belt	34	137-4127	1	Cap-Fuel
13	605256	1	Spacer	35	115-0962	1	Hose-Vent, Canister
14	138-3217	1	Retainer-Belt	36	119-7837-03	1	Mount-Tank
15	38-7820	3	Bearing-Ball	37	3210-2	1	Screw-HH
16	107-0758	1	Spacer-Bearing	38	46-8091	2	Screw-HWH
17	130-9699	1	Bolt-Shoulder	39	104-8300	1	Nut-HF, NI
18	125-1063	1	Plate-Brake	40	119-7856	1	Hose-Fuel
19	125-5069	2	Nut-Hex	41	2412-98	2	Clamp-Hose
20	108-3792	1	Spring-Tension, Brake	42	3230-7	1	Bolt-CARR
21	117-5970	1	Pulley	43	139-0717	1	Filter-Fuel
22	3211-42	2	Screw-HH	44	2412-108	1	Clamp-Worm

● Not serviced separately

■ Obtain parts from www.honda-engines.com

Height-of-Cut Assembly



Height-of-Cut Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	121-1439	2	Plate-HOC, Front	11	121-1431-03	2	Arm-Spring
2	49-2040	4	Screw-HWHTF	12	104-2065	2	Screw-HWH
3	136-5871	2	Bushing-Axle, Front (HOC)	13	130-6420	2	Arm-Pivot, Front
4	130-6434	2	Retainer-Bushing, Axle	14	99-5107	2	Nut-Lock
5	321-37	4	Screw-HH	15	323-13	2	Screw-HH
6	104-7201	4	Nut-HF, NI	16	74-1671	2	Spacer-Cover, Wheel
7	133-2644	2	Axle-Front HOC	17	133-2639	2	Wheel
8	104-8301	2	Nut-HF, NI	17:2	133-2603	2	Bearing-Ball
9	125-1093	2	Knob-Lever, HOC	17:3	125-1077	1	Spacer
10	131-5377	2	Key-Arm, Spring	18	104-8300	2	Nut-HF, NI

This technical drawing is an exploded view of a mechanical assembly, likely a pump or motor component. The main housing is shown at the bottom left, with a circular opening and a 'COMMERCIAL' logo. The assembly consists of the following numbered parts:

- 1**: A central shaft or rotor assembly.
- 2**: A mounting bracket or support plate.
- 3**: A small pin or screw.
- 4**: A long, thin rectangular component, possibly a seal or gasket.
- 5**: A long, thin U-shaped component, possibly a spring or a guide.
- 6**: A small circular component, possibly a washer or a seal.
- 7**: A small circular component, possibly a washer or a seal.
- 8**: A small circular component, possibly a washer or a seal.
- 9**: A small circular component, possibly a washer or a seal.
- 10**: A small circular component, possibly a washer or a seal.
- 11**: A small cylindrical component, possibly a pin or a screw.
- 12**: A small cylindrical component, possibly a pin or a screw.
- 13**: A small rectangular component, possibly a washer or a seal.
- 14**: A small rectangular component, possibly a washer or a seal.
- 15**: A small rectangular component, possibly a washer or a seal.
- 16**: A small rectangular component, possibly a washer or a seal.
- 17**: A small rectangular component, possibly a washer or a seal.
- 17:2**: A small rectangular component, possibly a washer or a seal.
- 18**: A small rectangular component, possibly a washer or a seal.
- 19**: A small rectangular component, possibly a washer or a seal.
- 20**: A small rectangular component, possibly a washer or a seal.
- 21**: A small rectangular component, possibly a washer or a seal.
- 22**: A small rectangular component, possibly a washer or a seal.
- 23**: A small rectangular component, possibly a washer or a seal.
- 23:1**: A small rectangular component, possibly a washer or a seal.
- 23:1:2**: A small rectangular component, possibly a washer or a seal.
- 23:1:3**: A small rectangular component, possibly a washer or a seal.
- 24**: A small rectangular component, possibly a washer or a seal.
- 25**: A small rectangular component, possibly a washer or a seal.


The diagram uses dashed lines to indicate the assembly path and the relative positions of the components. The 'COMMERCIAL' logo is visible on the main housing.

Transmission and Rear Wheel Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	131-5350	1	Transmission	16	121-1448-03	2	Arm-Spring, Rear
2	125-5090-03	1	Guide-Belt	17	136-5894	2	Bearing Retainer ASM
3	125-5040	1	Lever-Shift	17:2	133-2606	2	Bearing-Ball, Custom
4	130-9681	1	Cover-Shaft, Transmission	18	133-2668	2	Screw-HH
5	125-1011	1	Belt-V	19	133-2635	2	Cover-Wheel
6	127-6848	2	Cover-Bearing	20	32151-61	4	Ring-Retaining
7	32151-10	2	Ring-Retaining	21	131-5399	2	Gear-Pinion, 15T
8	98-1452	2	Washer-Thrust	22	74-1671	2	Spacer-Cover, Wheel
9	130-6422	2	Plate-HOC, Rear	23	133-2640	2	9-Inch Wheel ASM
10	49-2040	9	Screw-HWHTF	23:1		1	Wheel ●
11	323-13	2	Screw-HH	23:1:2	133-2603	2	Bearing-Ball
12	133-2641	2	Arm-Pivot, Rear	23:1:3	125-1077	1	Spacer
13	131-5377	2	Key-Arm, Spring	24	104-8301	2	Nut-HF, NI
14	125-1093	2	Knob-Lever, HOC	25	104-7201	1	Nut-HF, NI
15	104-2065	2	Screw-HWH				

● Not serviced separately


Transmission Assembly No. 131-5350



Transmission Assembly No. 131-5350 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	130-2301	1	Nut-Flange	21	130-2302	10	Screw
2	130-2326	2	Flange-Pulley	22	130-2317	1	Gear-Output, 32 Tooth
3	130-2336	1	Case-Upper, Transmission	23	133-2614	2	Key
4	130-2318	1	Bearing-Ball	24	133-2612	1	Shaft-Output, Long
5	130-2311	1	Gear-Bevel, 53 Tooth	25	133-2617	1	Spacer-Long
6	130-2327	1	Fork-Shift	26	133-2616	2	Pin
7	133-2611	1	Shaft-Output, Short	27	133-2613	1	Hub-Gear, Output
8	130-2322	1	Spring-Retaining	28	130-2306	1	Shaft-Shift
9	130-9708	2	Bearing-Ball	29	130-2304	1	Ring-Retaining
10	130-2325	2	Seal	30	130-2319	1	Bearing-Ball
11	130-2333	2	Bushing-Shaft, Output	31	130-2314	1	Gear-Intermediate, 14 Tooth
12	133-2615	2	Spring	32	130-2313	1	Gear-Intermediate, 15 Tooth
13	130-2328	2	Key-Shift	33	130-2312	1	Gear-Intermediate, 17 Tooth
14	130-2329	1	Ring-Shift	34	130-2307	1	Shaft-Intermediate
15	130-2315	1	Gear-Output, 22 Tooth	35	130-2303	1	Nut-Shaft, Input
16	130-2316	1	Gear-Output, 25 Tooth	36	130-2310	1	Gear-Bevel, 12 Tooth
17	130-2321	1	Spring-Indexing, Shifter	37	130-2324	2	Seal
18	130-2332	1	Pin-Indexing, Shifter	38	130-2300	1	Shaft-Input
19	130-2331	1	Lever-Indexing, Shifter	39	130-9708	2	Bearing-Ball
20	130-2337	1	Case-Lower, Transmission	40	133-2618	1	Spacer-Short

Handle and Control Assembly



Handle and Control Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	137-4817-03	1	Handle	27:2	130-6401	1	Control-Throttle ●
2	3230-4	2	Screw-CARR	28	321-10	1	Screw-HH
3	104-8300	5	Nut-HF, NI	29	3256-22	1	Washer-Flat
4	115-1794	2	Screw-HHF	30	130-9656	1	Decal-Throttle, Choke
8	117-7737	1	Screw-Handle	31	137-4810	1	Bail-BBC, Coated
9	104-7201	3	Nut-HF, NI	32	137-4811	1	Bail-Traction, Coated
22	127-6897-03	1	Guard-Cable, Handle	33	137-4766-03	1	Bracket-Cable
23	108-0988	2	Screw-CARR	34	137-4768	1	Cable-Traction
24	114-3778	2	Nut-HF	35	137-4769	1	Cable-BBC
25	94-2691	1	Screw-HWH Taptite	36	42-3560	1	Bolt-Shoulder
26	130-6722	1	Decal-Adjust Self Propel Drive	37	112-8876	1	Screw-Handle
27	125-8374	1	Control-Throttle/Choke	38	116-2690	1	Bushing-Stepped
27:1	130-6400	1	Cable-Throttle ●	39	109-9318	1	Spring-Lever, BBC
				40	116-2998	1	Lever-BBC

● Not illustrated

Attachments and Accessories

For 22296 21in Heavy-Duty Recycler/Rear Bagger Lawn Mower

Product Name	Model/Part
Blade-Bagging, 21in	125-1072-03
Cup-Anti Scalp.....	125-8440
Rear Discharge Kit.....	130-9734

Notes:



Count on it.