



Form No. 3409-628 Rev B

**Count on it.**

# Parts Catalog

## 21in Heavy-Duty Recycler®/Rear Bagger Lawn Mower

Model No. 22295—Serial No. 400000000 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

Housing Assembly ..... 4

Grass Bag Assembly ..... 6

Engine, Fuel-Tank and Blade Assembly ..... 8

Height-of-Cut and Wheel Assembly ..... 10


Transmission and Rear Wheel Assembly ..... 12

Transmission Assembly No. 131-5350 ..... 14

Handle and Control Assembly ..... 16

Attachments and Accessories ..... 18


# Housing Assembly



## Housing Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|--------------------|
| 1           | 136-5896           | 1           | Housing ASM          | 7           | 125-5038           | 1           | Cover-Belt, Front  |
| 1:2         | 94-8072            | 1           | Decal-Danger         | 8           | 125-5039           | 1           | Cover-Belt, Rear   |
| 1:3         | 130-9670           | 1           | Decal-Warning, Blade | 9           | 125-1003-03        | 1           | Guard-Engine       |
| 2           | 125-1002-01        | 1           | Floor-Chute          | 10          | 104-8300           | 2           | Nut-HF, NI         |
| 3           | 3229-2             | 4           | Screw-CARR           | 11          | 3230-3             | 2           | Screw-CARR         |
| 4           | 104-7201           | 4           | Nut-HF, NI           | 12          | 125-1047-03        | 2           | Guard-Side, Deck   |
| 5           | 125-5041           | 2           | Kicker               | 18          | 119-2368           | 2           | Decal-Recycler     |
| 6           | 49-2040            | 5           | Screw-HWHTF          |             |                    |             |                    |


# Grass Bag Assembly



## Grass Bag Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|----------------------------|
| 1           | 125-1017           | 1           | Rod-Door, Bag      | 7           | 125-1008           | 1           | Plug-Mulch                 |
| 2           | 125-8402           | 1           | Bag Door ASM       | 8           | 125-1007           | 1           | Shield-Trailing            |
| 2:2         | 116-7583           | 1           | Decal-Warning      | 9           | 125-8413           | 1           | Rod-Shield, Trailing       |
| 3           | 125-1019           | 1           | Spring-Torsion     | 10          | 133-8193-03        | 1           | Bracket-Mount, Handle (LH) |
| 4           | 1-513658           | 2           | Bumper             | 11          | 133-8194-03        | 1           | Bracket-Mount, Handle (RH) |
| 5           | 121-1399-03        | 1           | Frame-Bag          | 12          | 32144-70           | 4           | Screw-HWHTF                |
| 6           | 125-1030           | 1           | Bag-Grass          |             |                    |             |                            |


# Engine, Fuel-Tank and Blade Assembly



## Engine, Fuel-Tank and Blade Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|------------------------------|-------------|--------------------|-------------|-----------------------|
| 1           | 119-7831           | 1           | Engine-Honda, Gxv160Uh2 A1Tt | 13          | 117-2718           | 1           | Decal-Arrester, Spark |
| 2           | 125-8405           | 1           | Decal-Engine, Honda          | 14          | 119-7837-03        | 1           | Mount-Tank            |
| 3           | 125-1074           | 3           | Screw-HH                     | 15          | 3230-5             | 1           | Bolt-CARR             |
| 4           | 125-8396           | 1           | Pulley-Driver                | 16          | 104-8300           | 1           | Nut-HF, NI            |
| 5           | 125-1004           | 1           | Driver-Blade                 | 17          | 3210-2             | 1           | Screw-HH              |
| 6           | 125-8370           | 1           | Protector-Crankshaft         | 18          | 114-0280           | 1           | Tank-Fuel             |
| 7           | 32144-70           | 3           | Screw-HWHTF                  | 19          | 115-7788           | 1           | Cap-Fuel              |
| 8           | 108-3762-03        | 1           | Blade-Recycling              | 20          | 115-0962           | 1           | Hose-Vent, Canister   |
| 9           | 125-1069-03        | 1           | Accelerator-Blade            | 21          | 46-8091            | 2           | Screw-HWH             |
| 10          | 125-2466           | 1           | Bolt-Blade                   | 22          | 2412-98            | 2           | Clamp-Hose            |
| 11          | 125-1024           | 1           | Cover-Belt                   | 23          | 119-7856           | 1           | Hose-Fuel             |
| 12          | 49-2040            | 1           | Screw-HWHTF                  | 24          | 139-0717           | 1           | Filter-Fuel           |
|             |                    |             |                              | 25          | 2412-108           | 1           | Clamp-Worm            |


# Height-of-Cut and Wheel Assembly



## Height-of-Cut and Wheel Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------------|-------------|--------------------|-------------|---------------------|
| 1           | 121-1439           | 2           | Plate-HOC, Front          | 11          | 121-1431-03        | 2           | Arm-Spring          |
| 2           | 49-2040            | 4           | Screw-HWHTF               | 12          | 104-2065           | 2           | Screw-HWH           |
| 3           | 136-5871           | 2           | Bushing-Axle, Front (HOC) | 13          | 130-6420           | 2           | Arm-Pivot, Front    |
| 4           | 130-6434           | 2           | Retainer-Bushing, Axle    | 14          | 99-5107            | 2           | Nut-Lock            |
| 5           | 321-37             | 4           | Screw-HH                  | 15          | 323-13             | 2           | Screw-HH            |
| 6           | 104-7201           | 4           | Nut-HF, NI                | 16          | 74-1671            | 2           | Spacer-Cover, Wheel |
| 7           | 133-2644           | 2           | Axle-Front HOC            | 17          | 125-1080           | 2           | Wheel               |
| 8           | 104-8301           | 2           | Nut-HF, NI                | 17:3        | 133-2603           | 2           | Bearing-Ball        |
| 9           | 125-1093           | 2           | Knob-Lever, HOC           | 17:4        | 125-1077           | 1           | Spacer              |
| 10          | 131-5377           | 2           | Key-Arm, Spring           | 18          | 104-8300           | 2           | Nut-HF, NI          |

# Transmission and Rear Wheel Assembly




## Transmission and Rear Wheel Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|---------------------------|-------------|--------------------|-------------|----------------------|
| 1           | 131-5350           | 1           | Transmission              | 16          | 121-1448-03        | 2           | Arm-Spring, Rear     |
| 2           | 125-5090-03        | 1           | Guide-Belt                | 17          | 136-5894           | 2           | Bearing Retainer ASM |
| 3           | 125-5040           | 1           | Lever-Shift               | 17:2        | 133-2606           | 2           | Bearing-Ball, Custom |
| 4           | 130-9681           | 1           | Cover-Shaft, Transmission | 18          | 133-2668           | 2           | Screw-HH             |
| 5           | 125-1011           | 1           | Belt-V                    | 19          | 133-2635           | 2           | Cover-Wheel          |
| 6           | 127-6848           | 2           | Cover-Bearing             | 20          | 32151-61           | 4           | Ring-Retaining       |
| 7           | 32151-10           | 2           | Ring-Retaining            | 21          | 131-5399           | 2           | Gear-Pinion, 15T     |
| 8           | 98-1452            | 2           | Washer-Thrust             | 22          | 74-1671            | 2           | Spacer-Cover, Wheel  |
| 9           | 130-6422           | 2           | Plate-HOC, Rear           | 23          | 133-2640           | 2           | 9-Inch Wheel ASM     |
| 10          | 49-2040            | 9           | Screw-HWHTF               | 23:1        |                    | 1           | Wheel ●              |
| 11          | 323-13             | 2           | Screw-HH                  | 23:1:2      | 133-2603           | 2           | Bearing-Ball         |
| 12          | 133-2641           | 2           | Arm-Pivot, Rear           | 23:1:3      | 125-1077           | 1           | Spacer               |
| 13          | 131-5377           | 2           | Key-Arm, Spring           | 24          | 104-8301           | 2           | Nut-HF, NI           |
| 14          | 125-1093           | 2           | Knob-Lever, HOC           | 25          | 104-7201           | 1           | Nut-HF, NI           |
| 15          | 104-2065           | 2           | Screw-HWH                 |             |                    |             |                      |

● Not serviced separately


# Transmission Assembly No. 131-5350



## Transmission Assembly No. 131-5350 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|-----------------------------|
| 1           | 130-2301           | 1           | Nut-Flange               | 21          | 130-2302           | 10          | Screw                       |
| 2           | 130-2326           | 2           | Flange-Pulley            | 22          | 130-2317           | 1           | Gear-Output, 32 Tooth       |
| 3           | 130-2336           | 1           | Case-Upper, Transmission | 23          | 133-2614           | 2           | Key                         |
| 4           | 130-2318           | 1           | Bearing-Ball             | 24          | 133-2612           | 1           | Shaft-Output, Long          |
| 5           | 130-2311           | 1           | Gear-Bevel, 53 Tooth     | 25          | 133-2617           | 1           | Spacer-Long                 |
| 6           | 130-2327           | 1           | Fork-Shift               | 26          | 133-2616           | 2           | Pin                         |
| 7           | 133-2611           | 1           | Shaft-Output, Short      | 27          | 133-2613           | 1           | Hub-Gear, Output            |
| 8           | 130-2322           | 1           | Spring-Retaining         | 28          | 130-2306           | 1           | Shaft-Shift                 |
| 9           | 130-9708           | 2           | Bearing-Ball             | 29          | 130-2304           | 1           | Ring-Retaining              |
| 10          | 130-2325           | 2           | Seal                     | 30          | 130-2319           | 1           | Bearing-Ball                |
| 11          | 130-2333           | 2           | Bushing-Shaft, Output    | 31          | 130-2314           | 1           | Gear-Intermediate, 14 Tooth |
| 12          | 133-2615           | 2           | Spring                   | 32          | 130-2313           | 1           | Gear-Intermediate, 15 Tooth |
| 13          | 130-2328           | 2           | Key-Shift                | 33          | 130-2312           | 1           | Gear-Intermediate, 17 Tooth |
| 14          | 130-2329           | 1           | Ring-Shift               | 34          | 130-2307           | 1           | Shaft-Intermediate          |
| 15          | 130-2315           | 1           | Gear-Output, 22 Tooth    | 35          | 130-2303           | 1           | Nut-Shaft, Input            |
| 16          | 130-2316           | 1           | Gear-Output, 25 Tooth    | 36          | 130-2310           | 1           | Gear-Bevel, 12 Tooth        |
| 17          | 130-2321           | 1           | Spring-Indexing, Shifter | 37          | 130-2324           | 2           | Seal                        |
| 18          | 130-2332           | 1           | Pin-Indexing, Shifter    | 38          | 130-2300           | 1           | Shaft-Input                 |
| 19          | 130-2331           | 1           | Lever-Indexing, Shifter  | 39          | 130-9708           | 2           | Bearing-Ball                |
| 20          | 130-2337           | 1           | Case-Lower, Transmission | 40          | 133-2618           | 1           | Spacer-Short                |

## Handle and Control Assembly



## Handle and Control Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>             |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|--------------------------------|
| 1           | 136-5861-03        | 1           | Handle                  | 17:2        | 130-6401           | 1           | Control-Throttle               |
| 2           | 3230-4             | 2           | Screw-CARR              | 18          | 321-10             | 1           | Screw-HH                       |
| 3           | 104-8300           | 7           | Nut-HF, NI              | 19          | 3256-22            | 1           | Washer-Flat                    |
| 4           | 115-1794           | 2           | Screw-HHF               | 20          | 125-8433           | 1           | Spacer-Stepped                 |
| 5           | 116-1056           | 1           | Guide,Rope              | 21          | 321-13             | 1           | Screw-HH                       |
| 6           | 133-2626           | 1           | Cable-Brake             | 22          | 125-8408           | 1           | Screw-Handle                   |
| 7           | 92-2270            | 1           | Screw-Handle            | 23          | 42-3560            | 1           | Bolt-Shoulder                  |
| 8           | 104-7201           | 6           | Nut-HF, NI              | 24          | 133-8180           | 1           | Spacer                         |
| 9           | 130-9689           | 1           | Cable-Traction          | 25          | 94-2691            | 1           | Screw-HWH Taptite              |
| 10          | 17-9428            | 1           | Screw-Handle            | 26          | 125-8406           | 1           | Decal-Throttle, Choke          |
| 11          | 49-1630            | 2           | Spacer-Support          | 27          | 130-6722           | 1           | Decal-Adjust Self Propel Drive |
| 12          | 256-276            | 2           | Spacer-Nylon            | 28          | 127-6897-03        | 2           | Guard-Cable, Handle            |
| 13          | 125-1067-03        | 1           | Lever-Control, Brake    | 29          | 108-0988           | 4           | Screw-CARR                     |
| 14          | 125-8355-03        | 1           | Bar-Control, Zone Start | 30          | 114-3778           | 4           | Nut-HF                         |
| 15          | 125-1068-03        | 1           | Lever-Control, Traction | 31          | 133-8199           | 1           | Anchor-Cable                   |
| 16          | 321-3              | 1           | Screw-HH                | 32          | 95-4453            | 1           | Screw                          |
| 17          | 125-8374           | 1           | Control-Throttle/Choke  |             |                    |             |                                |
| 17:1        | 130-6400           | 1           | Cable-Throttle          |             |                    |             |                                |

# Attachments and Accessories

## For 22295 21in Heavy-Duty Recycler/Rear Bagger Lawn Mower

| Product Name              | Model/Part  |
|---------------------------|-------------|
| Blade-Bagging, 21in ..... | 125-1072-03 |
| Cup-Anti Scalp.....       | 125-8440    |
| Rear Discharge Kit.....   | 130-9734    |

**Notes:**



**Count on it.**