



**Count on it.**

# Parts Catalog

## **Proline Commercial Walk-Behind Mower with 60in Floating Cutting Unit**

**Model No. 44430—Serial No. 400000000 and Up**



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

60 Inch Deck Assembly ..... 4

Deck Decal Assembly No. 138-1049 ..... 6

Spindle Assembly No. 139-2357 ..... 8

Transmission Assembly ..... 10

LH Transmission Assembly No. 138-4871 ..... 12

RH Transmission Assembly No. 138-4872 ..... 14

Idler Arm Assembly No. 139-2899 ..... 16

Operator Control Assembly ..... 18

Reference Bar Assembly No. 139-1475 ..... 20

RH Control Handle Assembly No. 139-1532 ..... 22

LH Control Handle Assembly No. 139-1487 ..... 24

Brake Assembly ..... 26

Brake Assembly No. 138-5844 ..... 28

Deck Lift Assembly ..... 30

Hood Assembly ..... 32

Frame Assembly ..... 34


Engine Assembly ..... 36

Fuel System Assembly ..... 38

Electrical Harness and Battery Assembly ..... 40

Attachments and Accessories ..... 42


# 60 Inch Deck Assembly



## 60 Inch Deck Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|------------------------------|-------------|--------------------|-------------|---------------------|
| 1           | 138-1049           | 1           | Deck ASM-60"                 | 22          | 132-4718           | 1           | Pulley-Idler, Flat  |
| 2           | 139-2357           | 3           | Spindle ASM                  | 23          | 126-8043           | 3           | Shield-Dust         |
| 3           | 32144-41           | 18          | Screw-Taptite                | 24          | 3234-19            | 2           | Screw-HHF           |
| 4           | 115-2642           | 3           | Shaft-Spindle                | 25          | 1-323071           | 1           | Spring-Extension    |
| 5           | 138-7221           | 3           | Shield-Bearing               | 26          | 133-9283           | 1           | Cover-Belt, RH      |
| 6           | 138-7222           | 3           | Pulley                       | 27          | 133-9282           | 1           | Cover-Belt, LH      |
| 7           | 7-4150             | 3           | Washer                       | 28          | 32144-4            | 8           | Screw-HWH           |
| 8           | 3219-7             | 3           | Nut-Hex                      | 29          | 3230-23            | 2           | Bolt-CARR           |
| 9           | 138-8890-03        | 3           | Blade - High Flow, 20.50 In. | 30          | 119-3388-03        | 1           | Baffle-Cutoff       |
| 10          | 125-1736           | 3           | Washer-Belleville            | 31          | 104-8300           | 2           | Nut-HF, NI          |
| 11          | 51-4060            | 3           | Screw-Blade                  | 32          | 1-603299           | 3           | Roller-Scalp, Anti  |
| 12          | 138-4916           | 1           | Belt-V                       | 33          | 138-7229           | 3           | Tube-Spanner        |
| 13          | 110-9981           | 3           | Washer-Plain                 | 34          | 104-0892           | 3           | Spacer-Axle, Rear   |
| 14          | 139-7933           | 1           | Bushing-Idler                | 35          | 323-23             | 3           | Screw-HH            |
| 15          | 139-7932           | 2           | Washer-Friction, Composite   | 36          | 138-7230           | 1           | Spacer-Fender       |
| 16          | 139-7915           | 1           | Idler Arm ASM                | 37          | 323-9              | 1           | Screw-HH            |
| 17          | 323-11             | 1           | Screw-HH                     | 38          | 133-1212           | 1           | Deflector-Discharge |
| 18          | 104-8301           | 6           | Nut-HF, NI                   | 39          | 138-7231           | 1           | Pin-Chute           |
| 19          | 138-7227           | 3           | Bushing-Idler                | 40          | 138-7232           | 1           | Spring-Torsion      |
| 20          | 3231-6             | 1           | Screw-CARR                   | 41          | 1-803037           | 8           | Nut-Retaining       |
| 21          | 132-9425           | 2           | Pulley-Idler, Flat           | 42          | 139-2614           | 1           | Pin-Cotter          |


Deck Decal Assembly No. 138-1049



## Deck Decal Assembly No. 138-1049 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|---------------------|
| 2           | 130-0731           | 1           | Decal-Danger             | 6           | 138-8829           | 1           | Decal-Deck, 60 Inch |
| 3           | 133-4604           | 2           | Decal-Danger             | 7           | 117-1194           | 1           | Decal-Routing, Belt |
| 4           | 130-0765           | 1           | Decal-Scalp, Anti        | 8           | 323-4              | 7           | Screw-HH            |
| 5           | 93-7818            | 1           | Decal-Torque, Blade Bolt | 9           | 104-8301           | 7           | Nut-HF, NI          |

# Spindle Assembly No. 139-2357






## Spindle Assembly No. 139-2357 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 2           | 116-0720           | 2           | Bearing-Ball       |
| 3           | 138-7220           | 1           | Spacer-Bearing     |

## Transmission Assembly




## Transmission Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|--------------------------|
| 1           | 138-4871           | 1           | Transmission, Zt-2800 LH | 16          | 92-7101            | 1           | Pulley-Idler, Flat       |
| 2           | 138-4872           | 1           | Transmission, Zt-2800 RH | 17          | 3234-19            | 1           | Screw-HHF                |
| 3           | 139-5849           | 2           | Tire ASM                 | 18          | 3230-10            | 1           | Bolt-CARR                |
| 3:1         | 133-9293           | 1           | Tire                     | 19          | 104-8301           | 1           | Nut-HF, NI               |
| 3:3         | 232-27             | 1           | Stem-Valve               | 20          | 138-6814           | 1           | Spring-Extension         |
| 3:99        | 105-4070           | 1           | Tube-Inner ●             | 21          | 139-7914-03        | 1           | Bracket - Expansion Tank |
| 4           | 242-50             | 8           | Nut-Lug                  | 22          | 109-2250           | 1           | Tank-HYD                 |
| 5           | 139-5592           | 2           | Rod-Bypass               | 22:1        | 109-3320           | 1           | Cap-Reservoir, HYD       |
| 6           | 3256-22            | 2           | Washer-Flat              | 23          | 136-4182           | 1           | Hose-Hydro               |
| 7           | 1-806003           | 2           | Pin-Cotter               | 24          | 121-2952           | 1           | Hose-Overflow            |
| 8           | 117-8585           | 1           | Shaft-Cross, Hydro       | 25          | 240-12             | 2           | Grommet-Rubber           |
| 9           | 138-5803           | 2           | Spacer - Transmission    | 26          | 117-1193           | 4           | Clamp-Hose               |
| 10          | 3230-9             | 6           | Screw-CARR               | 27          | 32180-030          | 1           | Clip-Tie                 |
| 11          | 104-8300           | 10          | Nut-HF, NI               | 28          | 99-8445            | 2           | Screw-HWH                |
| 12          | 94-7972            | 2           | Screw-HH, Patch          | 29          | 3230-6             | 1           | Bolt-CARR                |
| 13          | 1-800286           | 2           | Screw-HH                 | 30          | 119-8822           | 1           | Pulley-Idler             |
| 14          | 112-3799           | 1           | Belt-V                   | 31          | 98-4695            | 1           | Spacer                   |
| 15          | 139-2899           | 1           | Idler Arm ASM            |             |                    |             |                          |

● Not illustrated


# LH Transmission Assembly No. 138-4871



# LH Transmission Assembly No. 138-4871 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                 |
|-------------|--------------------|-------------|------------------------------|-------------|--------------------|-------------|------------------------------------|
| 1           | 139-4069           | 1           | Kit, Main Housing RH, Charge | 82          | 114-1693           | 1           | Gear-11T                           |
| 2           | 139-4070           | 1           | Kit, Side Cover RH, Control  | 83          | 104-5329           | 1           | Pin-Jackshaft                      |
| 7           | 117-5359           | 16          | Screw-HHF                    | 90          | 104-2169           | 1           | Ring-Retaining                     |
| 11          | 135-1140           | 1           | Plug-Straight                | 91          | 114-1694           | 1           | Gear-54T                           |
| 23          | 109-3321           | 1           | Element-Oil Filter, HYD      | 92          | 120-7975           | 1           | Spacer                             |
| 30          | 106-8676           | 1           | Seal-Lip                     | 93          | 135-1361           | 1           | Bearing-Ball                       |
| 31          | 106-8677           | 1           | Ring-Retaining, External     | 95          | 130-8477           | 1           | Bearing-Ball                       |
| 32          | 114-1685           | 1           | Rod-Bypass                   | 96          | 104-2144           | 1           | Seal                               |
| 33          | 106-8679           | 1           | Ring-Retaining, Internal     | 97          | 109-5939           | 1           | Hub Kit                            |
| 34          | 107-2490           | 1           | Arm-Bypass                   | 102         | 125-0021           | 1           | Handle-Brake                       |
| 35          | 106-8681           | 1           | Ring-Retaining, External     | 103         | 131-0906           | 1           | Ring-Retaining, EXT                |
| 40          | 104-5304           | 1           | Swashplate-Trunnion          | 106         | 120-7981           | 1           | Guard-Filter, RH                   |
| 41          | 104-5313           | 1           | Seal-Lip                     | 111         | 109-3278           | 1           | Adapter-Straight                   |
| 42          | 104-2116           | 1           | Stud                         | 130         | 126-3251           | 2           | Tube-Charge                        |
| 48          | 139-4073           | 1           | Spacer                       | 157         | 115-5057           | 1           | Cover-Nut, Axle                    |
| 55          | 104-5308           | 1           | Spacer                       | 158         | 126-1930           | 1           | Gerotor Seal Kit                   |
| 56          | 104-5310           | 1           | Seal-Lip                     | 159         | 126-2290           | 1           | Spring, Torsion CCW                |
| 57          | 104-5309           | 1           | Ring-Retaining               | 164         | 121-5745           | 1           | Spacer                             |
| 60          | 112-4154           | 1           | Bearing-Thrust               | 200         | 109-3537           | 1           | Seal Kit                           |
| 64          | 139-4074           | 1           | Cylinder Block ASM Kit       | 201         | 114-8463           | 1           | RH Center Section Kit              |
| 65          | 94-6922            | 1           | Bearing-Thrust               | 202         | 114-8464           | 1           | Charge Relief Kit                  |
| 69          | 110-8561           | 1           | Pump Block ASM               | 203         | 114-8465           | 1           | Charge Kit                         |
| 70          | 104-5339           | 1           | Washer-Flat                  | 207         | 135-7348           | 1           | Fan And Pulley Kit                 |
| 71          | 104-5340           | 1           | Ring-Retaining               | 209         | 130-8482           | 1           | Hub Puller Kit                     |
| 72          | 121-5749           | 1           | Gear-16T                     | 210         | 139-7502           | 1           | Input Shaft Kit                    |
| 73          | 114-1691           | 1           | Shaft-Motor                  | 211         | 139-4094           | 1           | Kit, Control Arm                   |
| 74          | 104-5360           | 1           | Washer                       | 212         | 114-8470           | 1           | Axle Shaft Kit                     |
| 80          | 119-5541           | 2           | *obs* Washer                 | 215         | 139-4095           | 1           | Kit, Outboard, RH Rot A / LH Rot B |
| 81          | 125-0000           | 1           | Gear-43T                     |             |                    |             |                                    |


# RH Transmission Assembly No. 138-4872



## RH Transmission Assembly No. 138-4872 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>               |
|-------------|--------------------|-------------|------------------------------|-------------|--------------------|-------------|----------------------------------|
| 1           | 139-4096           | 1           | Kit, Main Housing LH, Charge | 82          | 114-1693           | 1           | Gear-11T                         |
| 2           | 139-4097           | 1           | Kit, Side Cover LH, Control  | 83          | 104-5329           | 1           | Pin-Jackshaft                    |
| 7           | 117-5359           | 16          | Screw-HHF                    | 90          | 104-2169           | 1           | Ring-Retaining                   |
| 11          | 135-1140           | 1           | Plug-Straight                | 91          | 114-1694           | 1           | Gear-54T                         |
| 23          | 109-3321           | 1           | Element-Oil Filter, HYD      | 92          | 120-7975           | 1           | Spacer                           |
| 30          | 106-8676           | 1           | Seal-Lip                     | 93          | 135-1361           | 1           | Bearing-Ball                     |
| 31          | 106-8677           | 1           | Ring-Retaining, External     | 95          | 120-7976           | 1           | Bearing-Ball                     |
| 32          | 114-1685           | 1           | Rod-Bypass                   | 96          | 104-2144           | 1           | Seal                             |
| 33          | 106-8679           | 1           | Ring-Retaining, Internal     | 97          | 109-5939           | 1           | Hub Kit                          |
| 34          | 112-9852           | 1           | Arm-Bypass                   | 102         | 125-0021           | 1           | Handle-Brake                     |
| 35          | 106-8681           | 1           | Ring-Retaining, External     | 103         | 131-0906           | 1           | Ring-Retaining, EXT              |
| 40          | 104-5304           | 1           | Swashplate-Trunnion          | 106         | 120-7979           | 1           | Guard-Filter, LH                 |
| 41          | 104-5313           | 1           | Seal-Lip                     | 111         | 109-3278           | 1           | Adapter-Straight                 |
| 42          | 104-2116           | 1           | Stud                         | 130         | 126-3251           | 2           | Tube-Charge                      |
| 48          | 139-4073           | 1           | Spacer                       | 157         | 115-5057           | 1           | Cover-Nut, Axle                  |
| 55          | 104-5308           | 1           | Spacer                       | 158         | 126-1930           | 1           | Gerotor Seal Kit                 |
| 56          | 104-5310           | 1           | Seal-Lip                     | 159         | 139-4099           | 1           | Spring, Torsion, CW              |
| 57          | 104-5309           | 1           | Ring-Retaining               | 164         | 121-5745           | 1           | Spacer                           |
| 60          | 112-4154           | 1           | Bearing-Thrust               | 200         | 109-3537           | 1           | Seal Kit                         |
| 64          | 139-4074           | 1           | Cylinder Block ASM Kit       | 201         | 114-8476           | 1           | LH Center Section Kit            |
| 65          | 94-6922            | 1           | Bearing-Thrust               | 202         | 114-8464           | 1           | Charge Relief Kit                |
| 69          | 110-8561           | 1           | Pump Block ASM               | 203         | 114-8465           | 1           | Charge Kit                       |
| 70          | 104-5339           | 1           | Washer-Flat                  | 207         | 135-7348           | 1           | Fan And Pulley Kit               |
| 71          | 104-5340           | 1           | Ring-Retaining               | 209         | 130-8482           | 1           | Hub Puller Kit                   |
| 72          | 121-5749           | 1           | Gear-16T                     | 210         | 139-7502           | 1           | Input Shaft Kit                  |
| 73          | 114-1691           | 1           | Shaft-Motor                  | 211         | 139-7866           | 1           | Kit, Arm, Control                |
| 74          | 104-5360           | 1           | Washer                       | 212         | 114-8470           | 1           | Axle Shaft Kit                   |
| 80          | 119-5541           | 2           | *obs* Washer                 | 215         | 139-7867           | 1           | Kit, Outboard, RH Rot B/LH Rot A |
| 81          | 125-0000           | 1           | Gear-43T                     |             |                    |             |                                  |

**Idler Arm Assembly No. 139-2899**






## Idler Arm Assembly No. 139-2899 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|----------------------------|
| 1           | 138-6819           | 1           | Mount-Idler                |
| 2           | 110-9981           | 3           | Washer-Plain               |
| 3           | 114-8549           | 1           | Bushing                    |
| 4           | 114-0463           | 2           | Washer-Friction, Composite |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 5           | 104-8300           | 1           | Nut-HF, NI         |
| 6           | 139-2900           | 1           | Arm-Idler          |
| 7           | 126-0699           | 1           | Bolt-CARR          |


# Operator Control Assembly



## Operator Control Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 139-2850           | 1           | Tower ASM                | 15          | 103-5752           | 4           | Stud-Ball          |
| 1:3         | 138-8816           | 1           | Decal-OPC Control, Left  | 16          | 3296-72            | 4           | Nut-Lock, NI       |
| 1:4         | 138-8818           | 1           | Decal-Warning, Control   | 17          | 121-2608           | 2           | Spacer             |
| 1:5         | 139-2874           | 1           | Decal-OPC Control, Right | 18          | 323-29             | 2           | Screw-HH           |
| 2           | 139-1475           | 1           | Reference Bar Assembly   | 19          | 3296-59            | 2           | Nut-Lock, NI       |
| 3           | 139-1532           | 1           | Control Handle ASM, RH   | 20          | 104-7201           | 2           | Nut-HF, NI         |
| 4           | 139-1487           | 1           | Control Handle ASM, LH   | 21          | 3229-1             | 2           | Screw-CARR         |
| 5           | 126-2107           | 1           | Cable, Choke             | 22          | 126-1499           | 2           | Cam                |
| 6           | 109-3958           | 1           | Control-Throttle         | 23          | 49-2040            | 2           | Screw-HWHTF        |
| 7           | 1-807513           | 2           | Bolt-CARR                | 24          | 82-2190            | 2           | Switch-Bail        |
| 8           | 3296-2             | 2           | Nut-Lock, NI             | 25          | 139-2913           | 2           | Control Rod ASM    |
| 9           | 3231-22            | 4           | Screw-CARR               | 27          | 140-4253           | 1           | Decal-Proline, LH  |
| 10          | 104-8301           | 4           | Nut-HF, NI               | 28          | 140-4254           | 1           | Decal-Proline, RH  |
| 11          | 119-1065           | 2           | Screw-Lock,HF            | 31          | 140-4251-03        | 1           | Plate-Cover        |
| 13          | 138-9753           | 6           | Screw                    | 32          | 1-303335           | 4           | Tie-Plastic        |
| 14          | 139-1523           | 2           | Damper                   |             |                    |             |                    |

# Reference Bar Assembly No. 139-1475




## Reference Bar Assembly No. 139-1475 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 139-2855-01        | 1           | Reference Bar      |
| 2           | 121-1431-03        | 1           | Arm-Spring         |
| 3           | 131-5377           | 1           | Key-Arm, Spring    |
| 4           | 104-2065           | 1           | Screw-HWH          |
| 5           | 125-1093           | 1           | Knob-Lever, HOC    |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|------------------------|
| 6           | 99-8445            | 1           | Screw-HWH              |
| 7           | 117-5991           | 1           | Washer-Stepped, Baffle |
| 8           | 119-6903           | 1           | Screw-HSBH             |
| 9           | 120-9683           | 1           | Washer-Plain           |
| 10          | 3296-72            | 1           | Nut-Lock, NI           |


# RH Control Handle Assembly No. 139-1532



## RH Control Handle Assembly No. 139-1532 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|----------------------|
| 1           | 139-2852           | 1           | Bracket-Mount, RH     | 14          | 139-2863           | 1           | Grip-Handle          |
| 2           | 139-1486           | 1           | Pin-Pivot             | 15          | 139-2869           | 1           | Bushing              |
| 3           | 139-1535           | 1           | Motion Control ASM RH | 16          | 139-2917           | 1           | Control Rod Assembly |
| 4           | 139-1540           | 1           | RH Lever ASM          | 17          | 139-2859           | 1           | Spring-Extension     |
| 5           | 103-9928           | 2           | Bearing               | 18          | 139-2875           | 1           | Bushing              |
| 6           | 139-2903           | 1           | Motion Control ASM RH | 19          | 1-806003           | 1           | Pin-Cotter           |
| 7           | 139-1525           | 2           | Bushing-Flanged Nylon | 20          | 3256-23            | 1           | Washer-Plain         |
| 8           | 139-1513           | 2           | Plate-Spring          | 21          | 9114524            | 1           | Bolt-TAP, HH         |
| 9           | 104-8301           | 1           | Nut-HF, NI            | 22          | 3290-456           | 2           | Washer-Belleville    |
| 10          | 323-10             | 1           | Screw-HH              | 23          | 139-7876           | 1           | Spacer               |
| 11          | 131-3562           | 1           | Bearing-Sleeve        | 24          | 3296-47            | 2           | Nut-Lock,NI          |
| 12          | 139-1538           | 1           | Spring-Torsion        | 25          | 139-7883           | 2           | Washer-Rubber        |
| 13          | 3234-13            | 1           | Screw-HHF             |             |                    |             |                      |

# LH Control Handle Assembly No. 139-1487






# LH Control Handle Assembly No. 139-1487 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|
| 1           | 139-2851           | 1           | Bracket-Mount, LH     |
| 2           | 139-1486           | 1           | Pin-Pivot             |
| 3           | 139-1490           | 1           | Motion Control ASM LH |
| 4           | 139-1495           | 1           | LH Lever ASM          |
| 5           | 103-9928           | 2           | Bearing               |
| 6           | 139-2865           | 1           | Motion Control ASM LH |
| 7           | 139-1525           | 2           | Bushing-Flanged Nylon |
| 8           | 139-1513           | 2           | Plate-Spring          |
| 9           | 104-8301           | 1           | Nut-HF, NI            |
| 10          | 323-10             | 1           | Screw-HH              |
| 11          | 131-3562           | 1           | Bearing-Sleeve        |
| 12          | 139-1508           | 1           | Spring-Torsion        |
| 13          | 3234-13            | 1           | Screw-HHF             |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------|
| 14          | 139-2863           | 1           | Grip-Handle          |
| 15          | 139-2869           | 1           | Bushing              |
| 16          | 139-2859           | 1           | Spring-Extension     |
| 17          | 139-2875           | 1           | Bushing              |
| 18          | 1-806003           | 1           | Pin-Cotter           |
| 19          | 139-2917           | 1           | Control Rod Assembly |
| 20          | 3256-23            | 1           | Washer-Plain         |
| 21          | 9114524            | 1           | Bolt-TAP, HH         |
| 22          | 3290-456           | 2           | Washer-Belleville    |
| 23          | 139-7876           | 1           | Spacer               |
| 24          | 3296-47            | 2           | Nut-Lock, NI         |
| 25          | 139-7883           | 2           | Washer-Rubber        |


# Brake Assembly



## Brake Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|----------------------|
| 1           | 138-5841           | 1           | Cable-Brake        | 8           | 283-75             | 2           | Pin-Clevis           |
| 2           | 138-5842           | 1           | Cable-Brake        | 9           | 1-806003           | 2           | Pin-Cotter           |
| 3           | 138-5844           | 1           | Brake Assembly     | 10          | 3256-23            | 2           | Washer-Plain         |
| 4           | 132-7582           | 1           | Mount-Cable, Brake | 11          | 138-9753           | 2           | Screw                |
| 5           | 3230-28            | 2           | Screw-CARR         | 12          | 116-5988           | 1           | Decal-Park Brake, CE |
| 6           | 104-8300           | 3           | Nut-HF, NI         | 13          | 82-2190            | 1           | Switch-Bail          |
| 7           | 132-1187           | 1           | Clamp-Cable        |             |                    |             |                      |

# Brake Assembly No. 138-5844




## Brake Assembly No. 138-5844 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 138-5845           | 1           | Handle-Brake       |
| 2           | 77-3180            | 1           | Spacer             |
| 3           | 138-6870           | 1           | Yoke-Cable         |
| 4           | 93-6079            | 1           | Spacer-Nylon       |
| 5           | 138-8815           | 1           | Bracket ASM-Brake  |
| 6           | 1-806003           | 1           | Pin-Cotter         |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 7           | 114-4681           | 1           | Screw-HHF          |
| 8           | 1-633268           | 1           | Grip-Lever         |
| 9           | 32128-21           | 1           | Nut-HF Lock        |
| 10          | 87-8460            | 2           | Bumper-Rubber      |
| 11          | 139-2942           | 1           | Bearing-Sleeve     |
| 12          | 3218-3             | 1           | Nut-Jam            |


# Deck Lift Assembly



## Deck Lift Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|------------------------|
| 1           | 138-5858           | 1           | Deck Strut ASM     | 9:5         | 237-21             | 3           | O-Ring                 |
| 2           | 138-5861           | 1           | Pivot ASM-Front    | 10          | 138-7203           | 1           | Pin-HOC                |
| 3           | 138-6869           | 1           | Pivot ASM          | 11          | 138-7205           | 4           | Chain-Decklift, 4-Link |
| 4           | 104-8300           | 8           | Nut-HF, NI         | 13          | 130-0742           | 5           | Bolt-Shoulder          |
| 5           | 104-8301           | 13          | Nut-HF, NI         | 14          | 115-4986           | 1           | Spacer                 |
| 6           | 108-3742           | 2           | Screw-HHF          | 15          | 138-5860           | 1           | Lever-Lock             |
| 7           | 139-5872           | 4           | Bearing-Flange     | 16          | 138-5863-03        | 1           | Link - HOC             |
| 8           | 138-7204           | 4           | Gusset-Deck Lift   | 17          | 3230-3             | 8           | Screw-CARR             |
| 9           | 138-6890           | 1           | HOC Standoff ASM   | 18          | 3231-4             | 1           | Screw-CARR             |
| 9:1         | 138-1009           | 1           | Plate - HOC        | 19          | 3231-7             | 2           | Screw-CARR             |
| 9:2         | 138-7201           | 3           | Spacer-Double Step | 20          | 138-7207           | 5           | Spacer-Hub, Blower     |
| 9:3         | 48-9220            | 3           | Washer-Flat        | 21          | 48-9220            | 1           | Washer-Flat            |
| 9:4         | 95-3857            | 3           | Screw-HSBH         | 22          | 138-8821           | 1           | Decal-HOC              |

# Hood Assembly






## Hood Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           |
|-------------|--------------------|-------------|---------------------------|-------------|--------------------|-------------|------------------------------|
| 1           |                    | 1           | Frame Assembly ●          | 10          | 104-7201           | 2           | Nut-HF, NI                   |
| 2           | 140-0183           | 1           | Decal-Emissions, Epa 2020 | 11          | 3253-3             | 2           | Washer-Lock                  |
| 6           | 140-4331-03        | 1           | Cover-Deck, Wide          | 14          | 65-5220            | 2           | Screw-HSH, Thread<br>Forming |
| 7           | 99-4693            | 1           | Decal                     | 15          | 126-4424           | 2           | Screw-Shoulder               |
| 8           | 1-513658           | 4           | Bumper                    | 16          | ST47182            | 2           | Latch-Rubber                 |
| 9           | 125-1122           | 2           | Screw                     |             |                    |             |                              |

● Not serviced separately


# Frame Assembly



## Frame Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|---------------------|
| 1           | 140-1866           | 1           | Frame ASM               | 9           | 1-633508           | 6           | Washer-Bellville    |
| 1:2         | 138-8820           | 1           | Decal - Bypass          | 10          | 3296-51            | 2           | Nut-Lock, NI        |
| 1:3         | 126-1400           | 1           | Decal-Warning, Sulky    | 11          | 103-4882           | 2           | Cap-Grease          |
| 1:4         | 98-1977            | 1           | Decal-Warning           | 12          | 138-5881-03        | 1           | Tube, Muffler Guard |
| 2           | 121-7988-01        | 2           | Fork-Caster             | 13          | 3274-18            | 4           | Screw-HSH           |
| 3           | 140-4286           | 2           | Wheel And Tire ASM      | 14          | 139-2938-03        | 2           | Guard-Transmission  |
| 3:1         | 1-513810           | 2           | Bushing                 | 15          | 3230-10            | 4           | Bolt-CARR           |
| 3:2         | 1-513809           | 1           | Bearing                 | 16          | 104-8300           | 8           | Nut-HF, NI          |
| 3:3         | 161-9925           | 1           | Fitting-Grease, 45      | 17          | 1-811010           | 2           | Plug                |
| 4           | 1-513547           | 2           | Spacer                  | 18          | 133-7088           | 4           | Guard-Seal          |
| 5           | 325-20             | 2           | Screw-HH                | 19          | 117-9971           | 2           | Bolt-Carriage       |
| 6           | 3296-45            | 2           | Nut-Hex                 | 20          | 104-8301           | 2           | Nut-HF, NI          |
| 7           | 1-543509           | 4           | Bearing-Roller, Tapered | 21          | 114-2754           | 2           | Spacer              |
| 8           | 1-543511           | 2           | Seal-Grease             | 22          | 1-543286           | 1           | Grommet             |

# Engine Assembly




## Engine Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|---------------------------|-------------|--------------------|-------------|---------------------------|
| 1           | 140-1906           | 1           | Engine-Kawasaki, Fs651V ■ | 8           | 116-3736           | 1           | Muffler,Horizontal        |
| 2           | 139-2879           | 1           | Pulley                    | 9           | 116-5052           | 1           | Asm-Oil Drain Hose W/Plug |
| 3           | 127-3410           | 1           | Clutch-PTO                | 9:1         | 353-508            | 1           | Plug-HH ●                 |
| 4           | 120-2217           | 1           | Isolator-Clutch           | 9:1:1       | 237-42             | 1           | O-Ring                    |
| 5           | 94-2701            | 1           | Washer-Hardened           | 10          | 98-5975            | 3           | Washer-Belleville         |
| 6           | 126-7198           | 1           | Screw-HH W/Loctite        | 11          | 323-8              | 4           | Screw-HH                  |

● Torque to 20-24 ft-lb

■ Obtain parts from [www.kawpower.com](http://www.kawpower.com)


# Fuel System Assembly



## Fuel System Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-------------------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 140-4343           | 1           | Fuel Tank ASM, 5 Gal                | 5           | 114-4428           | 1           | Hose-Fuel          |
| 1:2         | 137-4119           | 1           | Cap-Fuel, Ratcheting                | 6           | 1-603770           | 1           | Valve-Fuel         |
| 1:3         | 114-0284           | 1           | Grommet                             | 7           | 110-1876           | 1           | Hose-Fuel          |
| 1:4         | 119-3547           | 1           | Valve-Vent, Fuel                    | 8           | 2412-98            | 4           | Clamp-Hose         |
| 1:5         | 46-6560            | 1           | Bushing                             | 9           | 138-8837           | 1           | Hose, Emissions    |
| 1:6         | 109-9364           | 1           | Fitting-Fuel (W/Line And<br>Screen) | 11          | 32180-030          | 2           | Clip-Tie           |
| 2           | 107-4543           | 2           | Clamp                               | 21          | 1-303335           | 4           | Tie-Plastic        |
| 3           | 104-8300           | 2           | Nut-HF, NI                          | 22          | 116-5464           | 1           | Tee And Check      |
| 4           | 322-10             | 2           | Screw-HH                            | 23          | 120-2235           | 1           | Filter-Fuel        |
|             |                    |             |                                     | 24          | 119-6074           | 1           | Hose-Fuel          |

# Electrical Harness and Battery Assembly





## Electrical Harness and Battery Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|------------------------|
| 1           | 138-8840           | 1           | Harness-Wire, Wasp         | 11          | 126-0624           | 1           | Harness-Clutch Pigtail |
| 1:1         | 109355             | 1           | Fuse-Blade, 15 Amp         | 12          | 139-5561           | 1           | Module, Hour Meter     |
| 1:2         | 109102             | 1           | Fuse-Blade, 25 Amp         | 13          | 137-4100           | 1           | Switch-Ignition        |
| 1:3         | 116-0053           | 1           | Cap-Plug                   | 14          | 1-303335           | 3           | Tie-Plastic            |
| 1:11        | 100-4918           | 1           | Diode                      | 15          | 99-8445            | 2           | Screw-HWH              |
| 3           | 63-8360            | 1           | Key-Ignition               | 16          | 3220-2             | 1           | Nut-Hex Jam            |
| 4           | 104-8300           | 2           | Nut-HF, NI                 | 17          | 3230-1             | 2           | Bolt-CARR              |
| 5           | 105-1692           | 1           | Battery- Dry, 12V, 230 CCA | 18          | 33003-00           | 1           | Nut-HF                 |
| 6           | 139-6367           | 1           | Switch-Rocker, (On)-On-Off | 19          | 104-2466           | 1           | Holddown-Battery       |
| 7           | 117-1197           | 1           | Solenoid                   | 20          | 3290-134           | 1           | Screw                  |
| 8           | 139-6350           | 1           | Cable-Battery, Pos ASM     | 21          | 120-4578           | 1           | Nut-HF                 |
| 9           | 139-6354           | 1           | Cable-Battery, Pos ASM     | 23          | 33094-00           | 1           | Washer-Plain           |
| 10          | 139-6358           | 1           | Cable-Battery, Neg ASM     | 24          | 33114-016          | 1           | Screw-HH               |

## Attachments and Accessories

### For 44430 Proline Commercial Walk-Behind Mower with 60in Floating Cutting Unit

| Product Name                           | Model/Part |
|----------------------------------------|------------|
| 60in Recycler Kit.....                 | 140-1916   |
| Two-Wheel Sulky, Proline Midsize ..... | 44401      |

### For 44430 Proline Commercial Walk-Behind Mower with 60in Floating Cutting Unit

| Product Name                                 | Model/Part  |
|----------------------------------------------|-------------|
| Hypr-Oil 500 (quart).....                    | 114-4713    |
| Hypr-Oil 500 (gallon).....                   | 114-4714    |
| Hypr-Oil 500-5 (5 gallon).....               | 114-4715    |
| Toro Premium Fuel Treatment 12oz Bottle..... | 131-6572    |
| Electric Accessory Port.....                 | 133-1438    |
| Weight Kit .....                             | 138-6866    |
| Blade - Mulch, 20.50 In .....                | 138-8886-03 |
| Blade - High Flow, 20.50 In. ....            | 138-8890-03 |
| Blade - Hi Lift, 20.50 In.....               | 138-8893-03 |
| HOC Brackets Kit.....                        | 139-4063    |
| Light Kit.....                               | 139-5595    |
| Soft Side Bagger.....                        | 139-7860    |
| 60in Recycler Kit.....                       | 140-1916    |
| Rubber Deflector Kit .....                   | 140-4300    |
| Leaf Bagging Enhancement Kit .....           | 140-5122    |
| 6 Pack-blade, 20.5 Recycler .....            | 140-7732    |
| 6 Pack-blade, 20.50 Hi-flow .....            | 140-7736    |
| 6 Pack-blade, 20.50 Hi-lift.....             | 140-7740    |
| 10W30 4-Cycle Engine Oil (32oz Bottle).....  | 38280       |
| Toro 4-Cycle SAE 30 Oil (32oz Bottle) .....  | 38903       |
| Two-Wheel Sulky, Proline Midsize .....       | 44401       |
| Spark Arrestor .....                         | 98-9099     |

**Notes:**



**Count on it.**