



Service Stand

GrandStand® Multi Force Mower

Model No. 163-7340

Installation Instructions

Safety

Safety-Alert Symbol

The safety-alert symbol (Figure 1) shown in this manual and on the machine identifies important safety messages that you must follow to prevent accidents.



g000502

Figure 1
Safety-alert symbol

The safety-alert symbol appears above information that alerts you to unsafe actions or situations and is followed by the word **DANGER**, **WARNING**, or **CAUTION**.

DANGER indicates an imminently hazardous situation which, if not avoided, **will** result in death or serious injury.

WARNING indicates a potentially hazardous situation which, if not avoided, **could** result in death or serious injury.


CAUTION indicates a potentially hazardous situation which, if not avoided, **may** result in minor or moderate injury.

This manual uses two other words to highlight information. **Important** calls attention to special mechanical information and **Note** emphasizes general information worthy of special attention.

Safety and Instructional Decals



Safety decals and instructions are easily visible to the operator and are located near any area of potential danger. Replace any decal that is damaged or missing.



163-3499

decal163-3499

1. Warning—read the *Operator's Manual*.
2. Crushing hazard—1) engage the parking brake, shut off the engine, and remove the key; 2) support the machine with jack stands.



* 3 4 7 5 - 1 3 9 *

Installation

Loose Parts

Use the chart below to verify that all parts have been shipped.

Procedure	Description	Qty.	Use
1	No parts required	—	Prepare the machine.
2	Receiver assembly Leg assembly Gusset plate Attach pin Hitch pin Cotter pin Hair pin (1/2 inch shaft) Bolt (1/2 x 3-1/2 inches) Washer Nut	1 1 2 1 1 1 1 4 4 4	Assemble the kit.
3	No parts required	—	Install the service stand onto the machine.

1

Preparing the Machine

No Parts Required

Procedure

Note: Determine the left and right sides of the machine from the normal operating position.

1. Park the machine on a level surface.
2. Disengage the blade-control switch.
3. Move the motion-control levers to the NEUTRAL-LOCK position.
4. Engage the parking brake.
5. Shut off the machine and remove the key.
6. Wait for all moving parts to stop.

2


Assembling the Kit

Parts needed for this procedure:

1	Receiver assembly
1	Leg assembly
2	Gusset plate
1	Attach pin
1	Hitch pin
1	Cotter pin
1	Hair pin (1/2 inch shaft)
4	Bolt (1/2 x 3-1/2 inches)
4	Washer
4	Nut

Procedure

1. Install the 2 gusset plates to the leg assembly by loosely installing the bolts (1/2 x 3-1/2 inches), washers, and nuts.



g546690

Figure 2

1. Nut	4. Washer
2. Gusset plate	5. Bolt (1/2 x 3-1/2 inches)
3. Leg assembly	

2. Install the receiver to the gusset plates by loosely installing the bolts, washers, and nuts.




Figure 3

1. Receiver assembly

3. Torque the fasteners to 91 to 112.5 N·m (67 to 83 ft-lb).

4. Install the hitch pin to the gusset plates and secure it with a hair pin (1/2 inch shaft).




Figure 4

1. Hair pin (1/2 inch shaft) 2. Hitch pin

5. Install the attach pin to the receiver assembly and secure it with a cotter pin.




Figure 5

1. Cotter pin

2. Attach pin

3

Installing the Service Stand onto the Machine

No Parts Required

Procedure

Lift the A-frame and insert the service stand into the frame. Secure the kit with the attach and cotter pins.




Figure 6

g546783

Operation Using the Service Stand

⚠ WARNING

The machine could fall onto someone and cause serious injury or death.


- Do not keep the machine raised on the service stand for extended periods of time.
- Always use the service stand on a level surface.
- Ensure that the service stand is secured properly to the mount using the pins.
- Do not rely solely on the service stand for support. Use adequate jack stands or equivalent support.
- Do not mount or dismount the mower while the service stand is raised.
- Before each use, ensure that the service stand works properly and that there are no signs of damage.

⚠ WARNING

Raising the machine could cause a fuel leak. Fuel is extremely flammable and highly explosive.

- Check for any fuel leaks before performing maintenance.
- If you see a fuel leak, immediately lower the machine, drain the fuel, and wipe up the spill.

1. Park the machine on a level surface, disengage the blade-control switch, move the operator platform to the storage position, and engage the parking brake.
2. Raise the mower deck to the TRANSPORT position.
3. Attach the service stand to the A-frame using the attach and cotter pins.




g546783

Figure 7

6. Support the machine with jack stands; refer to the machine *Operator's Manual* for jack stand placement.
7. When finished, raise the A-frame and remove the service stand.

Note: Do not operate the machine with the service stand attached except to raise or lower the A-frame.



g551143

Figure 8

5. Shut off the engine, remove the key, and wait for all moving parts to stop.

Notes:



Count on it.