



TOROModel-No.: 21013
Serial-No.: 9900001 & up**Recycler®**
43cm Mower SP**Teileliste****Housing Assembly**

Ref.No.	Part-No.	Description	Qty.	Ref.No.	Part-No.	Description	Qty.
1	95-6839	Decal -Deck	1	20	93-3720	Baffle	1
2	93-3730	Kicker – Right Front	1	21	3250-13	Screw PPH	1
3	32144-111	Screw - Kicker	6	22	32112-11	Cap	1
4	106-4750	Cover - Belt	1	23	98-3216	Retainer - Axle	2
5	93-4095	Screw - Baffle	4	24	93-4080	Axle - Front	1
6	93-4054	Grip - Lower	1	25	99-1711	Nut - Lock	2
7	98-3236	Trigger - HOC	1	26	40-1940	Washer	4
8	3284-5	Pin - Groove	1	27	99-1712	Bolt - Wheel	2
9	93-3790	Plug	1	28	93-4081	Wheel – Front (incl. Ref. No. 30)	2
10	99-1700	Door Discharge	1	29	99-1713	Washer - Wave	2
11	99-1708	Decal - Danger	1	30	93-7024	Bushing	4
12	93-3794	Bushing - Door	1	31	93-3793	Screw - Retainer	2
13	98-1429	Cover - Shield	1	32	94-1864	Screw - Baffle	1
14	93-3750	Deflektor – Left Rear	1	33	98-3222	Cap – Front Axle	2
15	106-4751	Housing –Deck (Incl.Ref # 2,14 +16)	1	34	95-2747	Fitting- Washout	1
16	93-3740	Kicker – Left Front	1	35	46-6290	O-Ring	1
17	3296-2	Nut - Lock	1	36	46-6811	Screw - HWH	2
18	3256-21	Washer - Flat	1				
19	93-4110	Baffle - Chute	1				


Rear Axle Assembly



Ref.No	Part No.	Description	Qty.
1	93-3793	Screw-Retainer	2
2	93-4118	V-belt	1
3	98-3232	Rod-Trigger	1
4	93-4062	Spring-Trigger Return	1
5	93-4066	Saddle-HOC	1
7	93-4095	Screw-Baffle	2
8	93-4077	Rear Axle-Left	1
9	93-4067	Cover-Wheel	2
10	106-4788	Screw-Wheel Gear	6
11	93-4068	Gear-Wheel	2
12	93-3792	Washer-Cover	4
13	93-3791	Ring-Secure	2
14	93-4099	Washer	2
15	93-4098	Nut-Wheel	2
16	93-4097	Washer-Wheel	2
17	93-7023	Bushing	4
18	93-3783	Wheel Rear (incl.Ref # 17)	1
19	99-1715	Freewheel Assy. Left	1

Ref. No	Part No.	Description	Qty.
20	99-1716	Freewheel Assy. Right	1
21	93-4072	Gear	2
22	71-7740	Spring	1
23	71-8450	Cover-Spring	1
24	98-3216	Retainer-Axle	2
25	98-3226	Cap-rear Axle	2
26	93-4065	Rod-Link	1
27	71-7980	Indicator-HOC	1
28	93-4116	Screw-Bracket	1
29	93-4115	Washer-Bracket	1
30	93-4112	Bracket-Gear Box	1
31	93-4114	Screw-Bracket	1
32	93-7018	Holder-Cable	1
33	93-4078	Rear Axle-Right	1
34	93-4113	Pin-Roll	1
35	93-4111	Pulley-Gear Box	1
36	93-7019	Washer	2
37	93-4073	ASM - Gear Case	1
38	93-9836	Smartwheel Rear (Incl. Ref # 17)	1


Gear Case Assembly 93-4073



Ref. No.	Part No.	Description	Qty.
1	99-1735	Transmission-Cover-ASM	1
1.2	99-1736	Nut	1
1.3	99-1737	Washer	1
1.4	99-1738	Arm-Pivot	1
1.5	99-1739	Washer-AL	1
1.6	99-1740	O-Ring	1
7	93-4111	Pulley-Gear Box	1
8	93-4113	Pin-Roll	1
10	99-1744	Bushing-Worm Shaft	1
11	99-1745	Seal-Worm Shaft	1
12	99-1746	Bearing-Worm Shaft	1
14	99-1747	Pin-Spring	1
15	99-1748	Clutch Plate Set	1
16	99-1749	Spacer Set	1


Ref. No.	Part No.	Description	Qty.
17	99-2507	Thrust Bearing Set	1
18	99-2508	Pin-String	1
19	99-2509	Bushing-Gear	1
20	99-2511	Lever-Clutch	1
21	99-2512	Washer	1
22	99-2513	Seal-Drive Shaft	2
23	99-2514	Bearing-Needle	2
24	99-2516	Case-Transmission	1
25	99-2517	Screw-Cover	4
26	99-2518	Shaft-Drive	1
27	99-2519	Arm-Pivot	1
28	99-1743	Gasket-Transmission	1
32	99-1742	Shaft-Worm	1
33	99-1741	Gear-Worm	1

Blade Assembly



Ref.No.	Part-No.	Description	Qty.	Ref.No.	Part-No.	Description	Qty.
1	62-7550	Pulley-Driver	1	6	26-0672	Bolt - Blade	1
2	93-4091	Retainer - Blade	1	7	93-8718	Cover - Belt	1
3	98-1430	Blade - 43 cm	1	8	93-9837	Screw – Belt Cover	1
5	3253-22	Washer - Lock	1				


Engine Assembly



Ref-No.	Part-No.	Description	Qty.
1	95-6838	Decal - Shroud	1
2	32144-121	Screw	2
3		Engine Model 127802-1741-B1-A7096	1
4	93-0243	Shroud - Engine	1
5	3290-378	Tie - Cable	1
6	32144-73	Screw	

Ref-No.	Part-No.	Description	Qty.
7	82-8550	Shield - Muffler	
8	32144-102	Screw	3
9	92-2289	Decal	1
10	93-8470	Screw-Clamp	1
11	2210-249	Clamp-Casing	1
12	92-2289	Plate-Logo	1
13	2210-316	Rope-Stop	1


Grass Bag Assembly



Ref.No.	Part No.	Description	Qty.
1	93-4087	Grass Bag-Remover	1
2	93-4085	Frame-Bag	1


Ref.No	Part No.	Description	Qty.
3	93-4086	Bag-grass	1

Handle Assembly



Ref.	Part No.	Description	Qty.		Ref.	Part No.	Description	Qty.
1	94-6026	Decal-Instruction	1		17	32144-98	Screw-PPH	4
2	93-1117	Control-Throttle	1		18	71-8130	Bracket-Control	1
3	32144-97	Screw-PPH	7		19	71.8040	Plate-Throttle	1
4	93-0339	Cover-Throttle	1		20	99-1710	Mount-Handle RH (Incl. Ref . # 13)	1
5	71-7630	Cap-Throttle	1		*	99-1705	Mount-Handle LH (Incl. Ref . # 13)	1
6	32144-99	Screw-PPH	2		21	19-4050	Knob	2
7	99-1718	Cable-Traction	1		22	93-4058	Bolt-Long	1
8	99-1719	Cable-Brake	1		23	93-4057	Spring-Door	1
9	93-4056	Cap-Bolt	1		24	71-7860	Gripp-Upper	1
10	93-4094	Screw	2		25	98-1440	Handle-SP	1
11	93-4060	Bolt-Short	1		26	3296-73	Nut-Lock	1
12	93-4084	Cable-Retainer	1		27	3256-1	Washer-Flat	1
13	99-1717	Spacer	2		28	17-4319	Panel-Control	1
14	95-4457	Rope-Guide	1		29	92-7865	Decal-Panel	1

Control Assembly



Ref. No.	Part No.	Description	Qty.
1	98-1431	Bail-Brake	1
2	98-1432	Bail-Traction	1

Ref. No.	Part No.	Description	Qty.
3	99-1701	Grommet-Bail	2