


TORO


Model-No.: 21014

Serial-No.: 210000101 and up

43 cm Recycler Automatic-Drive**Partslist****Housing Assembly**

Ref.No.	Part-No.	Description	Qty.
1	95-6839	Decal -Deck	1
2	93-3730	Kicker – Right Front	1
3	32144-111	Screw - Kicker	6
4	106-4750	Cover - Belt	1
5	93-4095	Screw - Baffle	4
6	93-4054	Grip - Lower	1
7	98-3236	Trigger - HOC	1
8	3284-5	Pin - Groove	1
9	93-3790	Plug	1
10	99-1700	Door Discharge	1
11	99-1708	Decal - Danger	1
12	93-3794	Bushing - Door	1
13	98-1429	Cover - Shield	1
14	93-3750	Deflektor – Left Rear	1
15	106-4751	Housing – Deck (Incl. Ref# 2,14 + 16)	1
16	93-3740	Kicker – Left Front	1
17	3296-2	Nut - Lock	1
18	3256-21	Washer - Flat	1
19	93-4110	Baffle - Chute	1


Ref.No.	Part-No.	Description	Qty.
20	93-3720	Baffle	1
21	3250-13	Screw PPH	1
22	32112-11	Cap	1
23	98-3216	Retainer - Axle	2
24	93-4080	Axle - Front	1
25	99-1711	Nut - Lock	2
26	40-1940	Washer	4
27	99-1712	Bolt - Wheel	2
28	93-4081	Wheel – Front (incl. Ref. No. 30)	2
29	99-1713	Washer - Wave	2
30	93-7024	Bushing	4
31	93-3793	Screw - Retainer	2
32	94-1864	Screw - Baffle	1
33	98-3222	Cap – Front Axle	2
34	95-2747	Fitting- Washout	1
35	46-6290	O-Ring	1
36	46-6811	Screw - HWH	2



Rear Axle Assembly


Ref.No	Part-No.	Description	Qty.
1	93-3793	Screw - Retainer	2
2	93-4118	V-Belt	1
3	98-3232	Rod - Trigger	1
4	93-4062	Spring – Trigger Return	1
5	93-4066	Saddle - HOC	1
7	93-4095	Screw - Saddle	2
8	93-4077	Rear Axle - Left	1
9	93-4067	Cover - Wheel	2
10	106-4788	Screw – Wheel Gear	6
11	93-4068	Gear - Wheel	2
12	93-3792	Washer	4
13	93-3791	Ring - Secure	2
14	93-4099	Washer	2
15	93-4098	Nut - Wheel	2
16	93-4099	Washer - Wheel	2
18	93-3783	Wheel – Rear (incl. Ref. 40:1)	1
19	99-1715	Freewheel Assy. - Left	1
20	99-1716	Freewheel Assy. - Right	1
21	93-4072	Gear	2

Ref.No.	Part-No.	Description	Qty.
22	71-7740	Spring	1
23	71-8450	Cover - Spring	1
24	98-3216	Retainer - Axle	2
25	106-4789	Nut	2
26	93-4065	Rod - Link	1
27	71-7980	Indicator - HOC	1
28	93-4116	Screw - Bracket	1
29	106-4758	Nut - Cable	1
30	106-4759	Guide - Belt	1
31	106-4760	Cable – Drive (incl. Ref. 29)	1
32	106-4761	Retainer - Cable	1
33	93-4078	Rear Axle - Right	1
34	106-4762	Pin - Roll	1
35	106-4763	Pulley – Gear Box	1
36	106-4764	Spring - Clutch	1
37	106-4765	Gearbox Ass. (Incl.Ref # 34+35)	1
40	93-9836	Wheel - Rear (incl. SmartWheel)	1
40:1	93-7023	Bushing	4
41	98-3226	Cap – Rear Axle	2
42	106-4790	Washer	1




Gearbox Assembly p/n 106-4765

Ref.No.	Part-No.	Description	Qty.	Ref.No.	Part-No.	Description	Qty.
1	106-4766	Lever	1	14	106-4776	Sleeve - Clutch	1
2	106-4767	Snap ring	1	16	106-4778	Gear	1
3	106-4768	Seal	1	17	106-4779	Shaft	1
4	106-4769	Screw	4	18	106-4780	Seal	2
5	106-4770	Housing - Upper	1	19	106-4781	Housing - Bottom	1
6	106-4771	Seal	1	20	106-4782	Gasket - Gearbox	1
8	106-4772	Driver	1	24	106-4785	Worm gear	1
9	106-4777	Pin	3	25	106-4786	Bearing	1
10	106-4773	Spring	1	26	106-4762	Pin-Roll	1
11	106-4774	Shim (*qty. variable)	*	27	106-4763	Pulley-Gear	1
12	106-4775	Washer	2				



Blade Assembly


Ref.No.	Part-No.	Description	Qty.	Ref.No.	Part-No.	Description	Qty
1	106-4752	Pulley-Driver	1	5	3253-22	Washer - Lock	1
2	93-4091	Retainer - Blade	1	6	26-0672	Bolt - Blade	1
3	98-1430	Blade - 43 cm	1	7	93-8718	Cover - Belt	1
4	106-4791	Screw-Worm	1	8	93-9837	Screw - Belt Cover	1



Engine Assembly

Ref-No.	Part-No.	Description	Qty.
1	95-6838	Decal - Shroud	1
2	32144-121	Screw	2
3		Engine Model 127802-1741-B1-A7092	1
4	93-0243	Shroud - Engine	1
5	3290-378	Tie - Cable	1


Ref-No.	Part-No.	Description	Qty.
6	32144-73	Screw	
7	82-8550	Shield - Muffler	
8	32144-102	Screw	3
9	92-2289	Plate - Logo	1
10	2210-316	Rope-Stop	1



Grass Bag Assembly

Ref.No.	Part-No.	Description	Qty.
1	93-4087	Grass Bag - Remover	1
2	93-4085	Frame - Bag	1

Ref.No.	Part-No.	Description	Qty.
3	93-4086	Bag - Grass	1



Handle Assembly

Ref.No.	Part-No.	Description	Qty.	Ref.No.	Part-No.	Description	Qty.
1	95-6845	Handle - Control	1	16	95-6851	Handle - Lower	1
*	106-4792	Decal - Control	1	17	99-1591	Handle Assist	1
*	106-4793	Decal - Drive	1	18	106-4755	Screw	2
2	99-1590	Guide – Handle Control	2	19	99-1705	Mount.Handle LH (incl. 20:1)	1
3	94-4496	Screw - PPH	10	20	99-1710	Mount-Handle RH (incl.20:1)	1
4	95-6846	Handle - Upper	1	20:1	99-1717	Spacer	2
5	95-6847	Bar – Control, Traction	1	21	19-1450	Knob - Handle	2
6	95-6849	Spring - Torsion	1	22	93-4058	Bolt RH – Handle Screw	1
7	99-6008	Retainer – Control Rod	1	23	93-4057	Spring - Torsion	1
8	106-4754	Cable - Brake	1	24	71-7860	Cover	1
9	93-4056	Cap-Bolt	2	25	106-4756	Washer	2
10	93.4094	Screw-Cap Hinge	2	26	106-4757	Nut	2
11	93-4060	Bolt LH – Handle Screw	1	27	95-6718	Screw Assy. - Handle	2
12	3290-378	Tie - Cable	1	28	95-6858	Bail - Brake	1
13	3296-73	Nut-Lock	1	29	99-5239	Anchor-Cable	1
14	3256-1	Washer-Flat	1	30	3296-73	Nut	1
15	32144-97	Screw-PPH	2	31	95-4453	Screw	1
				42	95-4457	Guide - Rope	1