



TORO

Model-No.: 21014

Serial-No.: 230000101 and up


Recycler®
43 cm Automatic-Drive**Parts
Catalog****Housing Assembly**

Ref.No.	Part-No.	Description	Qty.	Ref.No.	Part-No.	Description	Qty.
1	95-6839	Decal -Deck	1	20	93-3720	Baffle	1
2	93-3730	Kicker – Right Front	1	21	3250-13	Screw PPH	1
3	32144-111	Screw - Kicker	6	22	32112-11	Cap	1
4	106-4750	Cover - Belt	1	23	98-3216	Retainer - Axle	2
5	93-4095	Screw - Baffle	4	24	93-4080	Axle - Front	1
6	93-4054	Grip - Lower	1	25	99-1711	Nut - Lock	2
7	98-3236	Trigger - HOC	1	26	40-1940	Washer	4
8	3284-5	Pin - Groove	1	27	99-1712	Bolt - Wheel	2
9	93-3790	Plug	1	28	93-4081	Wheel – Front (incl. Ref. No. 30)	2
10	99-1700	Door Discharge	1	29	99-1713	Washer - Wave	2
11	99-1708	Decal - Danger	1	30	93-7024	Bushing	4
12	93-3794	Bushing - Door	1	31	93-3793	Screw - Retainer	2
13	98-1429	Cover - Shield	1	32	94-1864	Screw - Baffle	1
14	93-3750	Deflektor – Left Rear	1	33	98-3222	Cap – Front Axle	2
15	106-4751	Housing-Deck (Incl. Ref# 2, 14,+ 16)	1	34	95-2747	Fitting- Washout	1
16	93-3740	Kicker – Left Front	1	35	46-6290	O-Ring	1
17	3296-2	Nut - Lock	1	36	46-6811	Screw - HWH	2
18	3256-21	Washer - Flat	1	37	95-6908	Cap-Cover	
19	93-4110	Baffle - Chute	1				




Rear Axle Assembly

Ref.No	Part-No.	Description	Qty.	Ref.No.	Part-No.	Description	Qty.
1	93-3793	Screw - Retainer	2	22	71-7740	Spring	1
2	93-4118	V-Belt	1	23	71-8450	Cover - Spring	1
3	98-3232	Rod - Trigger	1	24	98-3216	Retainer - Axle	2
4	93-4062	Spring – Trigger Return	1	25	106-4789	Nut	2
5	93-4066	Saddle - HOC	1	26	93-4065	Rod - Link	1
6	95-6909	Locking Plate	2	27	71-7980	Indicator - HOC	1
7	93-4095	Screw - Saddle	2	28	93-4116	Screw - Bracket	1
8	95-6912	Rear Axle - Left	1	29	106-4758	Nut - Cable	1
9	93-4067	Cover - Wheel	2	30	106-4759	Guide - Belt	1
10	95-6925	Screw – Wheel Gear	6	31	106-4760	Cable – Drive (incl. Ref. 29)	1
11	93-4068	Gear - Wheel	2	32	106-4761	Retainer - Cable	1
12	93-3792	Washer	4	33	95-6913	Rear Axle - Right	1
13	93-3791	Ring - Secure	2	34	106-4762	Pin - Roll	1
14	93-4099	Washer	2	35	106-4763	Pulley – Gear Box	1
15	93-4098	Nut - Wheel	2	36	106-4764	Spring - Clutch	1
16	93-4099	Washer - Wheel	2	37	106-4765	Gearbox Ass. (Incl. Ref # 34+35)	1
17	94-6723	Cuppedwasher	2	40	93-9836	Wheel - Rear (incl. SmartWheel)	1
18	93-3783	Wheel – Rear (incl. Ref. 40:1)	1	40:1	93-7023	Bushing	4
19	99-1715	Freewheel Assy. - Left	1	41	98-3226	Cap – Rear Axle	2
20	99-1716	Freewheel Assy. - Right	1	42	106-4790	Washer	1
21	93-4072	Gear	2				




Gearbox Assembly p/n 106-4765

Ref.No.	Part-No.	Description	Qty.	Ref.No.	Part-No.	Description	Qty.
1	106-4766	Lever	1	14	106-4776	Sleeve - Clutch	1
2	106-4767	Snap ring	1	16	106-4778	Gear	1
3	106-4768	Seal	1	17	106-4779	Shaft	1
4	106-4769	Screw	4	18	106-4780	Seal	2
5	106-4770	Housing - Upper	1	19	106-4781	Housing - Bottom	1
6	106-4771	Seal	1	20	106-4782	Gasket - Gearbox	1
8	106-4772	Driver	1	24	106-4785	Worm gear	1
9	106-4777	Pin	3	25	106-4786	Bearing	1
10	106-4773	Spring	1	26	106-4762	Pin-Roll	1
11	106-4774	Shim (*qty. variable)	*	27	106-4763	Pulley-Gear	1
12	106-4775	Washer	2				



Blade Assembly


Ref.No.	Part-No.	Description	Qty.	Ref.No.	Part-No.	Description	Qty
1	106-4752	Pulley-Driver	1	5	3253-22	Washer - Lock	1
2	93-4091	Retainer - Blade	1	6	26-0672	Bolt - Blade	1
3	98-1430	Blade - 43 cm	1	7	93-8718	Cover - Belt	1
4	106-4791	Worm Screw	1	8	93-9837	Screw – Belt Cover	1



Engine Assembly

Ref-No.	Part-No.	Description	Qty.
1	95-6838	Decal - Shroud	1
2	32144-121	Screw	2
3	95-6923	Engine Model Quantum X50	1
4	93-0243	Shroud - Engine	1
5	3290-378	Tie - Cable	1


Ref-No.	Part-No.	Description	Qty.
6	32144-73	Screw	
7	82-8550	Shield - Muffler	
8	32144-102	Screw	3
9	92-2289	Plate - Logo	1
10	2210-316	Rope-Stop	1



Grass Bag Assembly

Ref.No.	Part-No.	Description	Qty.
1	93-4087	Grass Bag - Remover	1
2	93-4085	Frame - Bag	1

Ref.No.	Part-No.	Description	Qty.
3	93-4086	Bag - Grass	1



Handle Assembly

Ref.No.	Part-No.	Description	Qty.	Ref.No.	Part-No.	Description	Qty.
1	95-6845	Handle - Control	1	15	32144-97	Screw-PPH	2
*	106-4792	Decal - Control	1	16	95-6851	Handle - Lower	1
*	106-4793	Decal - Drive	1	17	100-5971	Cover-Handle	1
2	99-1590	Guide – Handle Control	2	19	99-1705	Mount.Handle LH (incl. 20:1)	1
3	94-4496	Screw - PPH	10	20	99-1710	Mount-Handle RH (incl.20:1)	1
4	95-6846	Handle - Upper	1	20:1	99-1717	Spacer	2
5	95-6847	Bar – Control, Traction	1	21	19-1450	Knob - Handle	2
6	95-6849	Spring - Torsion	1	22	93-4058	Bolt RH – Handle Screw	1
7	99-6008	Retainer – Control Rod	1	23	93-4057	Spring - Torsion	1
8	106-4754	Cable - Brake	1	24	71-7860	Cover	1
9	93-4056	Cap-Bolt	2	26	106-4760	Cable-Drive	1
10	93.4094	Screw-Cap Hinge	2	27	95-6718	Screw Assy. - Handle	2
11	93-4060	Bolt LH – Handle Screw	1	28	95-6858	Bail - Brake	1
12	3290-378	Tie - Cable	1	30	3296-73	Nut	1
13	3296-73	Nut-Lock	1	31	95-4453	Screw	1
14	3256-1	Washer-Flat	1	42	95-4457	Guide - Rope	1