



Form No. 3476-109 Rev A

Count on it.

Parts Catalog

Sand Pro® 3040 Traction Unit

Model No. 08743—Serial No. 418769124 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Frame and Shroud Assembly 4

Frame Assembly No. 140-0295SP 6

Body and Seat Assembly 8

Seat Assembly No. 144-1350 10

Fuel System Assembly 12

Hydraulic Pump, Tank and Cooler Assembly 14

Variable Piston Pump Assembly No. 138-9132 16

Traction Control Assembly 18

Rear Lift and Lift Circuit Assembly 20

Hydraulic Lift Cylinder Assembly No. 115-5647 22

Hydraulic Valve Assembly No. 121-9070 24

Lift Hydraulic Routing Assembly 26

Rear Wheel Assembly 28

Hydraulic Motor Assembly No. 108-2947 30

Hydraulic Motor Assembly No. 108-2949 32

Front Wheel Assembly 34

Hydraulic Motor Assembly No. 108-2948 36

Steering Assembly 38

Steering Box Assembly No. 107-3526 40

Engine Installation Assembly 42


Air Cleaner Assembly No. 93-2190 44

Electrical and Console Assembly 46

Vehicle Tracker Assembly 48

Attachments and Accessories 50


Frame and Shroud Assembly



Frame and Shroud Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	140-0295SP	1	Frame ASM	20	3256-1	2	Washer-Flat
2	108-6898	1	Shroud-Dash	21	321-5	2	Screw-HH
3	3290-321	4	Screw-HWH	22	56-7976	6	Clamp-Tube
4	108-6895-01	1	Bracket-Mount, Tank	23	110-1333	1	Bracket-Clamp
5	112-1443-01	1	Panel-Front	24	2412-4	1	Clamp-R
6	120-3491-01	1	Screen-Panel, LH	25	322-10	3	Screw-HH
7	120-3492-01	1	Screen-Panel, RH	26	3296-29	4	Nut-Lock, NI
8	32115-15	2	Nut-Push	27	56-7973	2	Clamp-Tube
9	108-6859-01	1	Shroud-Center	28	69-9760	1	Plate-Cover
10	3256-23	6	Washer-Plain	29	53-6380	1	Washer-Flat
11	108-7965	2	Clamp-Tank, HYD	30	323-34	1	Screw-HH
12	108-7903	1	Clamp-Tank	31	107-4543	2	Clamp
13	322-12	5	Screw-HH	32	321-18	2	Screw-HH
14	104-8300	5	Nut-HF, NI	33	108-8420	2	Decal
16	3256-78	4	Washer-Flat	34	110-1332	1	Bracket-Clamp
17	32144-10	7	Screw-HWH	35	32180-030	1	Clip-Tie
18	3229-2	2	Screw-CARR	36	322-7	1	Screw-HH
19	104-7201	4	Nut-HF, NI				

Frame Assembly No. 140-0295SP




Frame Assembly No. 140-0295SP (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1		1	Frame ASM ●
2	32148-11	5	Nut-Clinch
3	93-7272	2	Decal-Warning
4	256-219	2	Bushing

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
5	302-58	1	Fitting-Straight
6	107-1997	1	Fitting-Grease
99	107-1998	1	Nozzle-Grease

● Not serviced separately


Body and Seat Assembly



Body and Seat Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	107-7590	2	Cup-Bearing	19	104-7201	1	Nut-HF, NI
2	107-7589	2	Cone-Bearing (W/ Seal)	20	322-2	2	Screw-HH
3	140-0262-0P	1	Panel-Cooler	21	104-8300	10	Nut-HF, NI
4	108-5477	1	Shroud-Fan	22	32144-10	11	Screw-HWH
5	108-6856	1	Shroud-Wheel, LH	23	112-7153	2	Pin
6	108-6855	1	Shroud-Wheel, RH	24	99-7830	1	Receptical-Rubber
7	121-9081-01	1	Cover-Rear	25	3290-412	1	Rivet-Blind
8	2412-133	2	Clamp-R	26	322-3	4	Screw-HH
9	104-7050	1	Tube-Manual	27	3256-23	2	Washer-Plain
10	104-7048	1	Cap-Housing	28	322-11	2	Screw-HH
11	144-1375	1	Base-Seat	29	85-9550	2	Rubber Clamp ASM
12	363-1571	1	Screw-PFH	29:1	85-9670	1	Nut-T
13	144-1350	1	Seat ASM	30	108-7941	1	Plate-Guide, Lever
14	32144-14	5	Screw-HWHTF	31	3256-1	2	Washer-Flat
15	3218-1	4	Nut-Jam	32	3234-33	2	Screw-HHF
16	1-523420	2	Bumper	38	107-1998	1	Nozzle-Grease
17	609588	1	Spacer	39	138-9101	1	Decal-Service
18	99-7833	1	Post-Holding	40	32180-030	1	Clip-Tie

Seat Assembly No. 144-1350




Seat Assembly No. 144-1350 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	144-7068	1	Track ASM
2	144-7069	1	Cushion Cover
3	144-7070	1	Back Cover

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
4	82-2190	1	Switch-Bail
5	140-3468	1	Cap-Switch, Actuator


Fuel System Assembly



Fuel System Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	144-7092	1	Fuel Tank ASM	13	3256-57	1	Washer-Flat
1:2	144-7080	1	Shield-Vent	14	3218-1	1	Nut-Jam
1:3	114-0284	1	Grommet	15	114-0292	1	Bracket-Canister, Carbon
1:4	114-0285	1	Valve-Rollover	16	32111-7	1	Nut-Cap
1:5	126-1789	1	Cap-Fuel, Ratcheting	18	3234-33	1	Screw-HHF
2	110-3371	1	Hose-Fuel	19	127-8685	1	Canister-Carbon
3	83-1390	1	Valve-Shut-Off, Fuel	20	106-5317	1	Hose-Fuel
4	94-2690	1	Filter-Fuel	21	115-7854	1	Filter-Fuel, Inline
5	110-3372	1	Hose-Fuel	22	117-9569	1	Hose-Fuel
6	109-0660	1	Hose-Fuel	23	92-6064	1	Clamp-R
7	2412-36	2	Clamp-Hose	24	240-11	1	Bushing-Flange
8	2412-98	2	Clamp-Hose	25	63-8410	1	Washer
9	38-3400	2	Guard-Rubber	26	323-5	1	Screw-HH
10	117-9568	1	Hose-Fuel	27	3290-379	2	Tie-Cable
11	133-8499	1	Valve-Check, Vacuum	28	145-4564	2	Clamp-Band, Screw
12	2412-108	2	Clamp-Worm				

Hydraulic Pump, Tank and Cooler Assembly




Hydraulic Pump, Tank and Cooler Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	140-0319	1	HYD Tank W/Decal
1:2	108-8452	1	Decal-Logo
2	46-6560	1	Bushing
3	110-1372	1	Fitting-Vent, Tank
4	75-4704	1	Hose-Fuel
5	110-8162	1	Dipstick
6	237-101	1	O-Ring
7	93-7498	1	Plug-Plastic
8	108-8457	1	Cooler-Oil
9	138-9132	1	Pump-Piston, Variable
10	163-2553	1	Bracket-Filter, Mount
11	68-8990	1	Head-Filter
12	54-0110	1	Filter-Oil, Transmission
13	108-8468	1	Plug-HH
13:1	237-101	1	O-Ring
14	340-98	2	Fitting-Elbow, 90 DEG
14:1	237-79	1	O-Ring
14:2	237-30	1	O-Ring
15	353-987	2	Fitting-Elbow, 90
15:1	237-81	1	O-Ring
16	354-73	1	Fitting
16:1	237-81	1	O-Ring
17	353-550	1	Plug-HYD, HH
17:1	237-79	1	O-Ring
18	354-121	1	Fitting-STR
18:1	237-79	1	O-Ring
19	140-0328	1	Hose - HYD, LP
20	140-0265	1	Hose-Return
21	121-1583	1	Hose-HYD
22	140-0264	1	Hose-Suction
23	2412-129	4	Clamp-Hose

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
24	2412-36	2	Clamp-Hose
25	3234-33	2	Screw-HHF
26	33114-016	2	Screw-HH
27	3290-378	1	Tie-Cable
28	340-18	1	Fitting-HYD, 90 DEG
28:1	237-79	1	O-Ring
28:2	237-22	1	O-Ring
29	140-0344	1	Fitting-Tee
29:1	237-80	1	O-Ring
30	340-77	2	Fitting-Elbow, 90 DEG
30:1	237-22	1	O-Ring
30:2	237-42	1	O-Ring
31	108-5316	1	Fitting-Elbow, 90 DEG
31:1	237-79	1	O-Ring
32	340-6	1	Fitting-Straight
32:1	237-30	1	O-Ring
32:2	237-80	1	O-Ring
33	130-8775	1	Fitting-HYD
33:1	237-80	1	O-Ring
33:2	237-30	2	O-Ring
34	100-7210	1	Check Valve
34:1	237-42	1	O-Ring
34:2	237-22	1	O-Ring
35	140-0335	1	Fitting-Check
35:1	237-30	1	O-Ring
35:2	237-79	1	O-Ring
37	340-115	1	Fitting-Tee
37:1	237-22	2	O-Ring
38	32180-030	1	Clip-Tie

Variable Piston Pump Assembly No. 138-9132




Variable Piston Pump Assembly No. 138-9132 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	144-1389	1	Overhaul Seal Kit	11	136-1020	2	Ring-Retaining
1:1	136-1010	1	Seal Overhaul Kit	12	144-1390	1	Shaft
1:1:1	136-1021	1	Seal-Lip, Shaft	13	136-1017	1	Bearing-Ball
1:1:2	136-1023	1	Gasket-Cap, End	14	136-1018	1	Ring-Retaining
1:1:3	136-1031	1	O-Ring	15	136-1019	2	Ring-Retaining
1:1:4	136-1032	1	O-Ring	16	136-1021	1	Seal-Lip, Shaft
1:1:5		1	Seal-Lip, Journal Bearing ●	17	136-1027	5	Plug ASM
1:1:6		2	O-Ring, Journal Bearing ●	18	136-1030	1	Bearing-Journal
1:1:7		1	O Ring-Valve, Bypass ●	19	136-1029	1	Gerotor ASM
1:1:8		1	Ring-Back Up ●	20	136-1028	1	Plug ASM
1:1:9		1	O Ring-Valve, Bypass ●	20:1		1	O-Ring ●
1:1:10		2	O Ring-Plug ●	20:2		1	Plug ●
1:1:11		1	O Ring-Plug ●	21	136-1031	1	O-Ring
1:2	144-1385	1	Seal-Lip	22	136-1032	1	O-Ring
2	144-1384	1	Plate-Valve, CCW	23	136-1037	1	Bypass Valve ASM
3	136-1011	1	Cylinder Block Kit	23:1		1	O-Ring ●
4	136-1023	1	Gasket-Cap, End	23:2		1	Back Up Ring ●
5	136-1013	1	Plate-Thrust	23:3		1	O-Ring ●
6	136-1022	1	Bearing-Needle	23:4		1	Plug ●
7	136-1024	4	Pin	24	136-1025	2	Plug ASM
8	74-9450	3	Plug	24:1		1	O-Ring ●
9	136-1014	1	Journal Bearing Carrier	24:2		1	Plug ●
			ASM	25	136-1035	2	Spring
9:1		1	O-Ring ●	26	110-6343	1	Valve-Scr
9:2		1	Seal-Lip ●	27	131-3800	1	Pin-Slotted
9:3		1	Body ●	28	136-1033	1	Cone-Valve, Relief
9:4		1	Race-Inner ●	29	144-1387	1	Spring
10	136-1015	1	Journal Bearing Carrier	30	144-1385	1	Seal-Lip
			ASM	31	144-1386	1	Ring-Retaining
10:1		1	O-Ring ●	32	144-1388	1	Valve-Scr (230 Bar/3335
10:2		1	Body ●				PSI)
10:3		1	Race-Inner ●				

● Not serviced separately


Traction Control Assembly



Traction Control Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	140-0258	1	Fan-Cooling, Pump	21	108473	1	Washer-Wave
2	120-4559	1	Screw-BHCS	22	32128-20	2	Nut-HF
3	140-0257-0P	1	Plate-Pump	23	17-9420	1	Screw-Handle
4	140-0287	1	Cam-Input, Pump	24	75-5470	1	Spacer-Bearing
5	93-2111	1	Stud-Traction	25	251-259	1	Bearing-Ball
6	3-6498	1	Washer-Thrust	26	87-7270	2	Washer-Thrust
7	140-0291	1	Neutral Arm ASM	27	3274-5	2	Screw-HSH
7:4	94-9609	1	Bushing-Straight	28	3296-23	2	Nut-Lock, NI
8	120-6385	1	Sensor-Ferrous Proximity, No	29	3296-4	1	Nut-Lock
9	100-4872	1	Plate-Switch, Neutral	30	33114-016	3	Screw-HH
10	18-6380	1	Pin-Adjustment, Steering	31	323-7	1	Screw-HH
11	115-4712	1	Spring-Extension	32	3296-47	2	Nut-Lock,NI
12	140-6248	1	Damper	33	3229-20	1	Screw-CARR
13	93-9051	1	Decal-Bolt, Eccentric	34	3296-2	1	Nut-Lock, NI
14	85-8960	1	Spacer	35	3256-23	1	Washer-Plain
15	108-5498-01	1	Pedal	36	322-14	1	Screw-HH
16	117-9564	1	Traction Rod ASM	37	104-8300	1	Nut-HF, NI
16:1	115-5626	1	Rod ASM	38	117-4698	1	Screw-Shoulder, HH
16:1:2	23-2270	1	Bushing-Rubber	39	106-9888	2	Washer-Flat
16:2	3220-3	1	Nut-HJ	40	3272-10	1	Pin-Cotter
16:3	115-5623	1	Isolated Rod End ASM	41	3230-2	1	Bolt-CARR
16:3:2	23-2270	1	Bushing-Rubber	42	3218-1	1	Nut-Jam
17	117-9507	1	Pedal-Accelerator	43	321-43	1	Capscrew
18	32121-45	1	Pin-Spring	44	3296-39	1	Nut-Lock, NI
19	74-9100	1	Pad-Pedal, Forward	45	116-0648	1	Screw-HH, Thd Lock
20	74-9110	1	Pad-Pedal, Reverse	46	3290-379	1	Tie-Cable


Rear Lift and Lift Circuit Assembly



Rear Lift and Lift Circuit Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	120-3465-03	1	Frame-Hitch	17	3256-3	6	Washer-Flat
2	115-5618	2	Pivot-Hub	18	323-10	4	Screw-HH
3	120-3457	1	Rear Hitch ASM	19	104-8301	6	Nut-HF, NI
3:2	95-3577	2	Bushing	20	323-12	2	Screw-HH
3:3	302-5	4	Fitting-Grease	21	32144-10	1	Screw-HWH
3:4	33-3090	4	Bushing	22	121-9070	1	Valve ASM
4	110-1368-03	1	Roller Plate ASM	23	88-8480	1	Bracket-Pivot
5	130-7879	1	Adapter Frame ASM	24	2710-20	1	Link-Offset
6	108-2282	1	Pin-Clevis	25	125-1944	1	Pivot-Hinge
7	108-5472	1	Tube ASM	26	108-7942	1	Lever-Rear
7:2	256-311	2	Bushing-Split	27	3290-477	1	Washer-Curved
8	161-3217	1	Pin-Flag	28	3290-360	2	Screw-HH
9	138-6484	2	Pin .875 DIA. X 4.40 Lg.	29	3296-2	2	Nut-Lock, NI
10	115-5647	1	HYD Lift Cylinder ASM	30	321-23	3	Screw-HH
11	340-132	2	Fitting-Elbow, 90 DEG	31	3296-8	3	Nut-Hex
11:1	237-78	1	O-Ring	32	98-0152	1	Knob-Tapered
11:2	237-21	1	O-Ring	33	32121-73	1	Pin-Roll
12	302-5	1	Fitting-Grease	34	340-92	2	Fitting-Straight
13	3272-23	1	Pin-Cotter	34:1	237-78	1	O-Ring
14	137-4795	2	Screw	34:2	237-21	1	O-Ring
15	3256-26	4	Washer-Flat	35	95-8837	1	Hose ASM
16	325-5	4	Screw-HH	36	100-3833	1	Hose-HYD

Hydraulic Lift Cylinder Assembly No. 115-5647




Hydraulic Lift Cylinder Assembly No. 115-5647 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
6	108-4597	1	Seal Kit
6:1		1	O-Ring ●
6:2		1	O-Ring ●
6:3		1	Ring-Back Up ●

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
6:4	302-5	1	Seal-Psp ●
6:5		1	Seal-Rod ●
6:6		1	Seal-Dust ●
8		1	Fitting-Grease

● Not serviced separately

Hydraulic Valve Assembly No. 121-9070




Hydraulic Valve Assembly No. 121-9070 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	22-8370	2	Seat-Valve
3	22-8500	2	O-Ring
4	22-8420	1	Spool
5	22-8380	1	Retainer
6	22-8400	1	Spacer
7	22-8390	1	Retainer
8	22-8410	1	Spring
9	22-8480	1	Ring-Snap

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
10	22-8490	1	Ring-Snap
11	22-8360	2	Pin
12	22-8350	2	Ball
13	22-8340	2	Spring
14	22-8330	2	Plug
16	138-2229	1	Cap
17	237-42	2	O-Ring


Lift Hydraulic Routing Assembly



Lift Hydraulic Routing Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	340-94	1	Adapter	5:1	237-21	1	O-Ring
1:1	237-22	2	O-Ring	5:2	237-42	1	O-Ring
1:2	237-42	1	O-Ring	6	144-1367	1	HYD Hose ASM
2	340-115	1	Fitting-Tee	7	115-0383	1	Hose ASM
2:1	237-22	2	O-Ring	8	340-86	1	Fitting-Tee
3	104-3779	1	Connector-Swivel, Straight	8:1	237-22	2	O-Ring
3:1	237-42	1	O-Ring	8:2	237-42	1	O-Ring
4	144-1399	1	Valve-Relief	9	140-0293	1	Hydraulic Conductor ASM
4:1	105-9155	1	Valve-Relief	10	140-0271	1	Hydraulic Tube ASM
4:1:1	105-9156	1	Seal Kit	11	3290-379	1	Tie-Cable
5	340-1	1	Fitting-Straight				


Rear Wheel Assembly



Rear Wheel Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	121-2520	1	Bracket-Lever, Brake	33	26-3790	2	Nut-Lock
2	3256-23	2	Washer-Plain	34	147-3670	2	Wheel And Tire ASM
3	322-11	2	Screw-HH	34:1	114-4643	1	Wheel
4	108-7913	1	Cable-Brake, Park	34:2	147-3671	1	Tire
5	108-7994	1	Bushing-Pivot, Lever	34:3	5108	1	Valve
6	108-7991-03	1	Lever-Brake	34:3	147-3689	1	Valve-Tubeless Tire
7	21-1880	1	Grip-Handle	35	139-2564	8	Nut-Lug
8	3256-3	3	Washer-Flat	36	340-89	4	Fitting-HYD, 45 DEG
9	323-7	1	Screw-HH	36:1	237-30	1	O-Ring
10	104-8301	1	Nut-HF, NI	36:2	237-80	1	O-Ring
11	108-2947	1	HYD Motor ASM (CCW)	37	108-8406	1	Tube ASM
12	108-2949	1	HYD Motor ASM (CW)	37:1	237-30	1	O-Ring
13	125-1967	2	Bracket-Brake, Park	38	110-1323	1	Tube ASM
14	108-7986-0P	2	Bar-Latch, Parking	38:1	237-30	1	O-Ring
15	108-7987	2	Link-Latch, Parking	39	110-1322	1	HYD Hose ASM
16	108-7979-0P	1	Bellcrank	40	340-87	1	Fitting-Elbow, 45 DEG
17	114-0631	2	Clevis-Latch, Parking	40:1	237-22	1	O-Ring
18	66-4270	1	Spring-Extension	40:2	237-42	1	O-Ring
20	19-1470	1	Screw-Shoulder	41	140-0269	1	HYD Hose ASM
21	19-1471	1	Screw-Shoulder	42	3290-379	1	Tie-Cable
22	256-257	2	Bushing-Nyliner	44	108-8460-01	1	Bracket-Valve
23	32120-47	2	Ring-Retaining, External	45	32144-11	2	Screw-HWH
24	108-7983	1	Bushing-Cable	46	3296-42	2	Nut-Lock, NI
25	104-8300	4	Nut-HF, NI	47	321-10	2	Screw-HH
26	3253-7	8	Washer-Lock	48	144-1391	1	Valve-Relief
27	325-10	8	Screw-HH	48:1	144-1398	1	Valve-Relief
28	32151-47	1	Ring-Retaining	48:1:1	105-9156	1	Seal Kit
29	121-4605	2	Washer-Spring	49	340-82	2	Fitting-Elbow, 90 DEG
30	3290-307	4	Pin-Cotter	49:1	237-42	1	O-Ring
31	107-3376	2	Spring-Compression	49:2	237-21	1	O-Ring
32	144-1373	2	Wheel Hub ASM	50	163-2551	1	HYD Hose ASM
32:2	10-6830	4	Stud-Type, Drive	51	144-1395	1	HYD Hose ASM

Hydraulic Motor Assembly No. 108-2947




Hydraulic Motor Assembly No. 108-2947 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	110-6459	1	Seal Kit
1:1		1	Seal-Shaft ●
1:2		5	Seal-Body ●
1:3		1	Seal-Dirt/Water ●
1:4		1	Seal-Commutator ●

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	3257-42	1	Key-Woodruff
3	110-3381	1	End Cover ASM
3:1	353-990	1	Plug ASM
3:1:1	237-78	1	O-Ring

● Not serviced separately

Hydraulic Motor Assembly No. 108-2949




Hydraulic Motor Assembly No. 108-2949 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	110-6459	1	Seal Kit
1:1		1	Seal-Shaft ●
1:2		5	Seal-Body ●

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1:3		1	Seal-Dirt/Water ●
1:4		1	Seal-Commutator ●
2	3257-42	1	Key-Woodruff

● Not serviced separately


Front Wheel Assembly



Front Wheel Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	108-2948	1	HYD Motor ASM (CW)	20	340-89	2	Fitting-HYD, 45 DEG
2	144-1381	1	Front Wheel Hub ASM	20:1	237-30	1	O-Ring
2:2	10-6830	4	Stud-Type, Drive	20:2	237-80	1	O-Ring
3	26-3790	1	Nut-Lock	21	108-8433	1	HYD Hose ASM
4	110-6314	1	Spindle	22	110-6303	1	HYD Hose ASM
5	147-3670	1	Wheel And Tire ASM	23	140-0315	1	Hydraulic Tube ASM
5:1	114-4643	1	Wheel	23:1	237-30	1	O-Ring
5:2	147-3671	1	Tire	24	108-8411	1	Tube ASM
5:3	5108	1	Valve	24:1	237-30	2	O-Ring
5:3	147-3689	1	Valve-Tubeless Tire	25	340-104	1	Fitting-Tee
6	139-2564	2	Nut-Lug	25:1	237-30	2	O-Ring
7	107-3399	2	Adapter-Weight, Wheel	26	140-0323	1	HYD Hose ASM
8	110-6312-03	1	Weight	27	144-1393	1	HYD Hose ASM
9	87-7270	2	Washer-Thrust	28	108-8455-01	1	Bracket-Clamp
10	110-6311	2	Stud	29	56-7976	2	Clamp-Tube
11	3296-45	2	Nut-Hex	30	32144-14	2	Screw-HWHTF
12	85-8950	1	Flangette-Standard	31	3230-6	1	Bolt-CARR
13	251-352	1	Bearing	32	69-9760	1	Plate-Cover
14	85-8940	1	Flangette-Relube	33	3296-29	1	Nut-Lock, NI
14:1	302-5	1	Fitting-Grease	34	108-8432	1	Tube ASM
15	88-8350	1	Tab-Bearing	34:1	237-30	1	O-Ring
16	323-8	3	Screw-HH	35	108-8431	1	Tube ASM
17	104-8301	3	Nut-HF, NI	35:1	237-30	1	O-Ring
19	3274-93	2	Screw-HSH	36	3296-23	2	Nut-Lock, NI

Hydraulic Motor Assembly No. 108-2948




Hydraulic Motor Assembly No. 108-2948 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	110-6459	1	Seal Kit
1:1		1	Seal-Shaft ●
1:2		5	Seal-Body ●
1:3		1	Seal-Dirt/Water ●
1:4		1	Seal-Commutator ●
2	3257-42	1	Key-Woodruff
3	99-3538	1	End Cover ASM

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
3:1		1	Spring Cap And O-Ring ASM ●
3:2	99-3541	1	Spring
3:3	99-3540	1	Ball
4	99-3540	1	Ball
5	99-3541	1	Spring
6	132-4421	1	O-Ring

● Not serviced separately


Steering Assembly



Steering Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	98-1471	1	Wheel-Steering	13	3257-5	1	Key-Woodruff
1:1	98-1468	1	Cover-Wheel, Steering	14	107-3526	1	Steering Box ASM
2	98-1459	1	Decal	15	32128-54	1	Nut-HF
3	3296-33	1	Nut-Lock, NI	16	107-3533	1	Shaft-Steering
4	3256-27	1	Washer-Flat	17	107-3540-03	1	Tube
5	138-9139	1	Guide-Hose	18	106-8448	1	Bearing-Race, Extended
6	322-7	3	Screw-HH	19	93-5429	1	Collar-Foam
7	104-8300	8	Nut-HF, NI	20	322-5	4	Screw-HH
8	108-5432	1	Spacer-Bearing	21	107-3532	1	Grommet
9	144-7075-01	1	Fork ASM	22	56-7976	2	Clamp-Tube
10	115-5639	1	Washer-Steering	23	69-9760	1	Plate-Cover
11	3272-37	1	Pin-Cotter	24	322-12	1	Screw-HH
12	32136-9	1	Nut-Hex, Slotted				

Steering Box Assembly No. 107-3526




Steering Box Assembly No. 107-3526 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	108-4520	1	Steering Cover ASM	7		1	Pinion Gear ASM ●
1:1	92-6869	1	Bushing	7:1	107-3527	1	Gear-Pinion
2	107-3520	1	Gear-Sector	7:2	38-7820	2	Bearing-Ball
3	107-3529	1	Gasket-Steering	7:3	108-4502	1	Spacer
4	107-3524	1	Steering Plate ASM	7:4	32151-12	1	Ring-Retaining
4:1	92-6869	1	Bushing	10	107-3530	1	Ring-Retaining
5	322-2	8	Screw-HH	12	108-8442	3	Shim-Plate, Steering

● Not serviced separately

Engine Installation Assembly




Engine Installation Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	120-3461-01	1	Mount-Engine	21	104-8300	18	Nut-HF, NI
2	125-1954	2	Mount-Front	22	323-11	4	Screw-HH
3	121-9076	4	Mount-Engine	23	3256-24	4	Washer-Plain
4	108-2809-0P	1	Support-Engine	24	104-8301	4	Nut-HF, NI
5	140-0282	1	Engine ●	25	322-4	12	Screw-HH
7	94-3449	2	Gasket-Manifold, Exhaust	26	323-5	4	Screw-HH
8	120-3476	1	Muffler-Dual Inlet	27	3210-2	2	Screw-HH
9	94-5300	4	Screw-HHF	29	32128-25	4	Nut-HF
10	95-0632-03	1	Cover	30	3234-14	4	Screw-HHF
11	119-7191	1	Muffler Shield ASM	31	322-6	2	Screw-HH
11:2	95-0645	1	Plate-Surface, Hot	32	110-5236	1	Hub-Engine
11:3	3269-32	2	Rivet-Pop	33	119-0652	1	Coupler-Rubber
12	110-6348-03	1	Shield-Exhaust	34	110-5227	1	Hub-Pump
14	107-7817	1	Filter-Oil, Engine	35	3296-47	4	Nut-Lock,NI
15	117-9576	1	Hose-Air	36	3241-7	2	Screw-SQH
16	93-2190	1	Air Cleaner ASM	37	3241-6	2	Screw-SQH
17	95-5806	1	Bracket-Mounting, Air Cleaner	38	322-9	4	Screw-HH
18	2412-92	1	Clamp-Hose	39	85-9020	2	Key-Square
19	2412-3	1	Clamp-Hose	40	136-7859	1	Rain Cap Kit
20	322-10	4	Screw-HH	40:1	1-643009	1	Clamp-Hose

● Obtain parts from www.briggsandstratton.com

Air Cleaner Assembly No. 93-2190




Air Cleaner Assembly No. 93-2190 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	108-3811	1	Filter-Air V-Twin HD
3	94-3652	1	Cover ASM
3:1	1-643283	2	Latch-Cleaner, Air

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
4	87-9400	1	Valve-Vacuator
5	285-17	1	Plug-Pipe


Electrical and Console Assembly



Electrical and Console Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	106948	1	Tray-Battery	24	119-7178	1	Choke Cable ASM
2	99-7421	1	Battery- Wet, 12V, 300 CCA	25	147-3652	1	Cable ASM
3	100-6435	2	Post-Battery	27	32105-13	4	Screw-HWH
4	100-6434	1	Rod-Hold Down, Battery	28	322-3	2	Screw-HH
5	3256-22	2	Washer-Flat	29	122-1403	1	Harness-Wire
6	32103-22	2	Nut-Wing	29:3	218-578	2	Fuse-Blade, 10 Amp
7	112-1444-01	1	Bracket-Relay	29:4	109101	1	Fuse-Blade, 20 Amp
8	32144-10	7	Screw-HWH	29:5	100-4918	2	Diode
9	99-7430	3	Relay-Mini	30	3256-23	2	Washer-Plain
10	321-3	3	Screw-HH	31	32144-14	1	Screw-HWHTF
11	3296-42	3	Nut-Lock, NI	32	110-3314	1	Cable-Positive, Battery
12	3250-13	2	Screw-PPH	33	110-3315	1	Cable-Positive, Starter
13	3296-2	6	Nut-Lock, NI	35	54-3093	1	Cable-Battery, Negative
14	28-4210	1	Solenoid	36	3290-378	6	Tie-Cable
15	3254-1	2	Washer-Lock, Int	37	119-2494	1	Seal-Strip
16	3219-14	2	Nut-Hex	38	108-2936	1	Console
17	3253-4	2	Washer-Lock	39	140-0320	1	Lift Panel W/Decal
18	110-3380	1	Nut-Standoff	39:2	108-8484	1	Decal-Lift, Rear
19	3218-13	3	Nut-Jam, Brass	40	108-7995-0P	1	Plate-Support, Console
20	137-3388	1	Control Panel ASM	41	120-2244	1	Hourmeter
20:2	137-3387	1	Decal-Dash	42	3256-51	4	Washer-Flat
21	99-7420	2	Plug-Hole	43	3290-321	4	Screw-HWH
22	83-0020	1	Switch-Ignition	44	3256-78	7	Washer-Flat
22:1	218-461	1	Nut-HH	45	3254-8	3	Washer-Lock
22:2	3254-5	1	Washer-Lock	46	321-5	7	Screw-HH
23	63-8360	2	Key-Ignition	47	32128-33	4	Nut-HF

Vehicle Tracker Assembly



Vehicle Tracker Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	122-3876	1	Gateway-Telematics Lite	3	163-1624-01	1	Bracket-Telematic
2	122-2161	1	Harness-Wire	4	137-3030	2	Screw-HWH
2:3	121-8861	1	Fuse-Mini Blade, 2 Amp	5	138-0719	2	Nut-HF
2:4	32180-101	1	Cover-Fuse, Single	6	3290-378	2	Tie-Cable

Attachments and Accessories

For 08743 Sand Pro 3040 Traction Unit

Product Name	Model/Part
Manual Blade.....	08714
LED Light Kit.....	08740
Tooth Rake	08751
Spring Rake.....	08752
Rear Broom	08753
Finish Grader.....	08754
Spiker	08755
Drag Mat Carrier System	08756
QAS Nail Drag	08761
QAS Bunker Pump	08765
QAS Flex Tooth Rake	08767
Rear Remote Hydraulic Kit	08781
Midmount Toolbar System	08838
Weight Kit, Greensmaster and Sand Pro/Infield Pro Traction Unit.....	100-6442
Yellow Hydraulic Cap.....	107-1576
Yellow Hydraulic Fluid Cap (Tethered)	107-2174
Premium All Purpose Grease (Tube)	108-1190
Premium Engine Oil SAE 30 (Drum)	108-1196
Premium Engine Oil SAE 30 (Pail).....	108-1197
Speed Limiter Kit	110-1371
Draw Bar Hitch Assembly	110-1375
Smooth Wheel and Tire Assembly	112-0034
Drag Mat Assembly	112-1424
Variable Orifice Kit	112-1433
Wireless Hourmeter.....	115-4754
Infield Pro 3040 Decal Kit	115-5619
Spark Arrestor Screen	119-7185
Tire-Turf Tread.....	121-9072
Armrest Kit.....	126-2058
PX Hydraulic Fluid (5 Gal)	133-8086
PX Hydraulic Fluid (55 Gal).....	133-8087
MVP Filter Kit.....	30035
New Red Paint - Gallon	361-11
Dark Metallic Gray Aerosol Paint	361-12
Semi-Gloss Black Spray Paint.....	361-9
MVP Kit 1000 Hour	44957
Air Dry Red Paint - Qt	5340
Knobby 2 Ply Tire.....	85-8290

Notes:



Count on it.