



Count on it.

Form No. 3476-125 Rev A

Parts Catalog

EU Road Light Kit

**Groundsmaster® 3200 or 3300 Series
Traction Unit**

Model No. 31992



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Cab Unit Front Light Assembly..... 4

Light Mount Kit Assembly No. 140-6698 6


ROPS Unit Front Light Assembly..... 8

Rear Light Assembly 10

Accessory Control Assembly 12

Wire Harness Assembly 14

Cab Unit Front Light Assembly




Cab Unit Front Light Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	140-1466-03	1	Light-Base, RH
2	140-1467-03	1	Light-Base, LH
5	3234-1	4	Screw-HHF
6	104-8301	4	Nut-HF, NI
7	140-6772	1	RH Light ASM
7:1		1	Light-Drive ●
7:2	140-6698	1	Light Mount Kit
8	140-6773	1	LH Light ASM
8:1		1	Light-Drive ●

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
8:2	140-6698	1	Light Mount Kit
9	3274-31	6	Screw-HSBH
10	163-0325	1	RH Light Mount ASM
10:1	145-7739-03	1	Mount-Light, RH
10:2	107069	3	Clip
11	163-0324	1	LH Light Mount ASM
11:1	145-7741-03	1	Mount-Light, LH
11:2	107069	3	Clip

● Not serviced separately

Light Mount Kit Assembly No. 140-6698




Light Mount Kit Assembly No. 140-6698 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	139-2092	1	Mount-Light
2	107-7983	1	Screw-HH
3	33116-030	1	Screw-HH

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
4	48-8070	2	Washer-Lock
5	33026-00	2	Nut-Hex

ROPS Unit Front Light Assembly




ROPS Unit Front Light Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	140-1507-03	1	Mount-Cross, Light
2	140-1475	1	Light-Mount, LH
2:2	107069	3	Clip

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
3	140-1474	1	Light-Mount, RH
3:2	107069	3	Clip


Rear Light Assembly



Rear Light Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	140-1483-03	1	Mount-LH, Wa	18	139-2340	2	Mount-Back
2	140-1484-03	1	Mount-RH, Wa	19	3234-4	4	Screw-HHF
3	140-1620-03	1	Mount-LH, Short	20	138-3027-03	1	Lic-Speed, Mount
4	140-1621-03	1	Mount-RH, Short	21	107-1013	2	Nut-Speed
6	3230-23	4	Bolt-CARR	22	119-8091	1	Light-Plate
7	104-8300	4	Nut-HF, NI	22:1	120-7564	1	Bulb-12W
8	3229-11	4	Screw-CARR	23	116-5611	5	Bolt-Carriage
9	104-7201	8	Nut-HF, NI	24	3296-56	5	Nut-Lock, NI
10	140-6835	2	Inner Mount ASM	25	104-2408	2	Screw-HSBH
10:2	107-1013	2	Nut-Speed	26	139-2217	1	Bracket-Mount, Horn
10:3	138-2760	4	Nut-Clinch, Hex	27	110-2594	1	Horn
11	139-2071	2	Light-Rear Tail/Stop/Turn	28	140-1519	3	Decal-Speed (20Kpm)
12	3250-23	4	Screw-PPH	29	140-1523	3	Decal-Speed (24Kpm)
14	3274-69	8	Screw-HSBH	30	140-1622-03	1	Mount-RH, Long
15	323-14	4	Screw-HH	31	140-6828-03	1	Housing-Light, LH
16	104-8301	4	Nut-HF, NI	32	140-6829-03	1	Housing-Light, RH
17	139-2338-03	1	Mount-Marker	33	3290-378	4	Tie-Cable

Accessory Control Assembly




Accessory Control Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	140-6606	1	Switch Mount ASM
1:2	140-1623	1	Decal-Control, LH
1:3	140-1531	1	Decal-Control, RH
2	107069	6	Clip
3	140-1505-03	2	Bracket-Mount
4	140-1506-03	1	Mount-Fuse, Plate
5	3230-33	4	Screw-CARR
6	104-7201	4	Nut-HF, NI
7	107-1013	4	Nut-Speed
8	3290-199	2	Nut-Speed
9	139-2080	1	Flasher-Dual Rate
10	99-7435	1	Relay
11	32105-13	2	Screw-HWH
12	3290-379	1	Tie-Cable

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
13	140-1502-03	1	Cover-Fuse
14	125-7438	2	Knob-Screw, Thumb
15	32115-15	2	Nut-Push
16	139-1950	1	Switch-Multifunction
17	99-7420	3	Plug-Hole
18	119-7769	1	Switch-Rocker, On/None/On
20	104-2065	2	Screw-HWH
21	139-2291	1	Control-Cover
22	32105-15	6	Screw-HWH
23	140-1587	1	Decal-Fuse Panel
24	139-2247	1	Clip-Switch
25	139-2248	1	Clip-Switch
26	114-4899	2	Rivet-Push

Wire Harness Assembly



WIRE HARNESS ROUTING

LICENSE PLATE LIGHT WIRE ROUTING

Wire Harness Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	3256-1	3	Washer-Flat	5	122-3556	1	Harness-Wire, Road Light Kit
2	3274-65	3	Screw-HSBH	6	122-1434	1	Harness-Wire, Pod
3	2412-89	3	Clamp-R	99	3290-378	8	Tie-Cable ●
4	104-7201	3	Nut-HF, NI				

● Not illustrated



Count on it.