Form No. 3476-342 Rev A

TORO®

Count on it.

Parts Catalog

Flex-Force Power System™ 60V MAX Snowthrower

Model No. 39902—Serial No. 418000000 and Up

Register at www.Toro.com.
Original Instructions (EN)

3476-342 A

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


Contents

Frame Assembly 4
Drive Belt and Rotor Assembly 6
Chute Assembly 8
Handle Assembly 10
Electrical Assembly 12
Attachments and Accessories 14

© 2026—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved


Frame Assembly



Frame Assembly (continued)

Ref.	Part Number	Qty.	Description
1	137-2276	1	Housing
2	137-2280	1	Bulkhead
3	137-9425	1	Container-Battery
4	137-2277	1	Scraper
5	137-9426	1	Skirt-Container, Battery
6	137-9391	1	Plate-Frame Assembly, LH
7	137-9393	1	Plate-Frame Assembly, RH
8	137-2256-03	1	Axle
9	137-9428	2	Wheel ASM
10	32112-14	2	Nut-Push
11	94-4496	25	Screw-PPH
12	137-3101	4	Screw-Plastic, HWH
13	256-257	2	Bushing-Nyliner
14	137-2333	1	Decal-Power Edge
16	3256-77	6	Washer-Flat


Drive Belt and Rotor Assembly



Drive Belt and Rotor Assembly (continued)

Ref.	Part Number	Qty.	Description
1	137-9385	1	Rotor ASM
1:1	132-9198	1	Shaft-Rotor
1:2	132-9161	1	LH Rotor Blade ASM
1:3	132-9162	1	RH Rotor Blade ASM
1:4	137-9386	2	Rotor-Center
1:5	137-9387	2	Paddle-Center
1:6	137-9471	8	Screw-CARR
1:8	137-9473	8	Nut-Lock, NI
1:9	132-9169	2	Pin-Spiral
1:12	137-9468	1	Ring-Snap, External
1:13	137-9472	8	Washer-Flat
1:14	137-9478	1	Screw-HHF
1:15	137-9477	1	Nut-Flg NI Use 137-3016
2	161-3850	2	Bearing-Ball
3	137-9389	1	Extension-LH
4	137-9388	1	Extension-RH
5	117-7720	1	Cap-Sideplate, RH
6	32144-85	6	Screw-HWH Thd Form
7	137-2320	1	Rotor Pulley ASM (6 Groove)
8	3290-456	1	Washer-Belleville
9	110-9381	1	Screw-HH
10	137-9427	1	Belt-V, Ribbed


Chute Assembly



Chute Assembly (continued)

Ref.	Part Number	Qty.	Description
1	137-2278	1	Chute-Rear
2	139-5239	1	Chute
2:2	114-9035	1	Decal-Danger, Discharge
3	139-5240	1	Deflector-Chute
3:2	114-9034	1	Decal-Danger
3:3	117-2314	1	Trigger-Deflector
3:4	136-7136	2	Spring-Compression
5	137-2271	1	Gear-Chute
6	137-2270	1	Bracket-Gear
7	139-5234	1	Gear-Sector
8	137-2279	1	Shroud
9	137-9431	1	Cover-Belt
10	139-5238	1	Cover-Battery
11	137-2283	1	Cover-Controller
12	94-4496	14	Screw-PPH
13	110-3143	1	Screw-Plastic, PPH
15	137-2332	1	Decal-Battery, 60V Snow
18	139-5229	1	Clip-Handle


Handle Assembly



Handle Assembly (continued)

Ref.	Part Number	Qty.	Description
1	132-9183	1	Handle-Lower
2	132-9184	1	Handle-Middle
3	137-2326	1	Upper Handle ASM
5	137-9479	2	Screw-Handle
6	3256-70	4	Washer-Flat
7	3296-72	2	Nut-Lock, NI
8	107-3844	4	Washer
9	3296-73	8	Nut-Lock, NI
10	3256-1	6	Washer-Flat
11	117-7737	6	Screw-Handle
12	137-9390	2	Knob-Handle
13	117-5976	2	Knob-Handle
14	92-2260	2	Screw-Handle
15	137-9303	1	Guide-Rod, Chute
16	3-7501	2	Washer
17	75-9040	2	Washer-Square
18	3229-5	2	Screw-CARR
22	114-7988	1	Guide-Cable
23	94-4496	2	Screw-PPH
24	139-5244	1	Handle ASM

Electrical Assembly



Electrical Assembly (continued)

Ref.	Part Number	Qty.	Description
1	137-9424	1	Motor-Driver, Snow (60V)
4		1	Dash Panel Assembly, Generic Snow ●
4:1	137-2346	1	Dash Panel ASM
4:2	137-2258	1	Decal-Operation
4:3	137-2257	1	Decal-Caution
4:4	139-5255	1	Key-Bail
5	137-9404	1	Battery Track ASM
7	117-7737	4	Screw-Handle
8	104-7201	4	Nut-HF, NI
9	32144-85	3	Screw-HWH Thd Form
10	94-4496	8	Screw-PPH
11	88902	1	Charger-Battery 60V 2.0Amp
12	139-5245	1	Motor ASM
13	139-5255	1	Key-Bail

● Not serviced separately

Attachments and Accessories

For 39902 — Flex-Force Power System 60V MAX Snowthrower

Product Name	Model/Part
60V Battery Charger 2 AMP	88602
60V Rapid Battery Charger 5.4 AMP	88605
60V Battery Charger 1 AMP	88610
60V Battery 2.0 AH	88620
60V LI-ION Battery 2.5 AH	88625
60V LI-ION, Battery 4.0 AH	88640
60V LI-ION Battery 5.0 AH	88650
60V LI-ION Battery 6.0 AH	88660
60V LI-ION Battery 7.5 AH	88675

Notes:



Count on it.