



**Count on it.**

# Parts Catalog

**E-Z Vac™**

**Complete Twin Bagger TITAN®  
Zero-Turn-Radius Riding Mower**

**Model No. 79346—Serial No. 408863220 and Up**



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

Bagger and Weight Assembly ..... 4


Bag Assembly No. 112-3994 ..... 6

Bagger Hood Assembly No. 140-5031 ..... 8

Blower and Tube Assembly ..... 10

Blower Assembly No. 140-5032 ..... 12


# Bagger and Weight Assembly



## Bagger and Weight Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|------------------------|-------------|--------------------|-------------|----------------------|
| 1           | 136-4231-03        | 1           | Frame-Pivot            | 17          | 32144-70           | 4           | Screw-HWHTF          |
| 2           | 140-2086-03        | 1           | Support-Upper          | 18          | 139-2630           | 2           | Bolt-CARR            |
| 3           | 140-0444           | 2           | Rod-Support            | 19          | 119-4041           | 8           | Nut-HF               |
| 4           | 131-4189           | 1           | Rod-Hood, Down         | 20          | 139-2596           | 2           | Screw-HHF            |
| 5           | 112-3994           | 2           | Bag ASM                | 21          | 139-2611           | 2           | Washer-Flat          |
| 6           | 140-5016           | 2           | Bracket-Hopper Pivot   | 22          | 139-2562           | 3           | Pin-Hair             |
| 7           | 140-5031           | 1           | Bagger Hood ASM        | 23          | 120-7127           | 1           | Pin-Cotter, Circular |
| 9           | 136-7461-03        | 1           | Bracket-Weight, RH     | 24          | 112-3993           | 1           | Screen-Bagger        |
| 10          | 136-7462-03        | 1           | Bracket-Weight, LH     | 25          | 116-4992           | 1           | Latch-Rubber         |
| 11          | 120-5491-03        | 1           | Channel-Weight, Bagger | 26          | 137-3073           | 2           | Washer-Plain         |
| 12          | 109-9742-05        | 1           | Weight-35 Pound        | 27          | 137-9137           | 2           | Screw-PPH            |
| 13          | 109-9759           | 1           | Pin-Weight             | 29          | 116-4126           | 1           | Seal                 |
| 14          | 119-4042           | 4           | Nut-HF, NI             | 30          | 116-4127-03        | 1           | Plate-Backing        |
| 15          | 137-3064           | 2           | Bolt-CARR              | 31          | 139-1702           | 4           | Bolt-Carriage        |
| 16          | 119-4061           | 2           | Screw-HHF              | 32          | 137-3083           | 2           | Pin-Hair             |

# Bag Assembly No. 112-3994




## Bag Assembly No. 112-3994 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 114972-03          | 1           | Frame-Bag          |
| 2           | 114973-03          | 1           | Hanger-Bag         |
| 3           | 114974-03          | 1           | Clamp              |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 4           | 3230-1             | 2           | Bolt-CARR          |
| 5           | 3296-29            | 2           | Nut-Lock, NI       |
| 6           | 110-6674           | 1           | Bag                |

# Bagger Hood Assembly No. 140-5031






## Bagger Hood Assembly No. 140-5031 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|
| 2           | 99-4693            | 1           | Decal                 |
| 3           | 114439             | 12          | Rivet-Blind           |
| 4           | 109-6809           | 1           | Decal-Caution, Bagger |
| 5           | 116-5071-03        | 1           | Stiffener-Bagger, Top |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 6           | 137-3073           | 4           | Washer-Plain       |
| 7           | 116-4478           | 1           | Gasket             |
| 8           | 112-4000-03        | 1           | Ring-Retainer      |


# Blower and Tube Assembly



## Blower and Tube Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>             | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|--------------------------------|-------------|--------------------|-------------|-----------------------|
| 1           | 136-4152           | 1           | Pivot-Blower                   | 9           | 136-4151           | 1           | Cover-Belt, RH        |
| 2           | 110-9380           | 2           | Screw-HWH                      | 10          | 133-7022-03        | 1           | Baffle-Outer          |
| 3           | 125-0085           | 1           | Pulley-Bagger                  | 11          | 133-7021-03        | 1           | Baffle-Inner          |
| 4           | 125-0086           | 1           | Pulley-Bagger                  | 12          | 119-4041           | 4           | Nut-HF                |
| 5           | 140-5032           | 1           | Blower ASM - Powered<br>Bagger | 13          | 137-3061           | 4           | Bolt-CARR             |
| 6           | 127-0074           | 1           | Belt-V                         | 14          | 136-4172           | 1           | Cover-Bagger, Powered |
| 7           | 127-0075           | 1           | Belt-V                         | 15          | 140-5030           | 1           | Tube ASM-Lower        |
| 8           | 127-0076           | 1           | Belt-V                         | 16          | 140-5029           | 1           | Tube ASM-Upper        |

# Blower Assembly No. 140-5032



## Blower Assembly No. 140-5032 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 133-9287-03        | 1           | Frame-Blower       |
| 2           | 121-0751           | 1           | Spindle ASM        |
| 2:2         | 120-7935           | 2           | Spacer             |
| 2:3         | 136-5441           | 2           | Bearing-Ball       |
| 3           | 32144-70           | 4           | Screw-HWHTF        |
| 4           | 137-7009           | 1           | Shaft-Spindle      |
| 5           | 133-4492           | 1           | Pulley-Blower      |
| 6           | 133-4336           | 1           | Fan-Blower         |
| 7           | 3290-465           | 1           | Washer-Belleville  |
| 8           | 108-8823           | 1           | Screw-HH           |
| 9           | 3219-16            | 1           | Nut-Hex            |
| 10          | 140-5015           | 1           | Spacer-Idler Arm   |
| 11          | 140-5019           | 1           | Idler Arm, Blower  |
| 12          | 138-7597           | 1           | Pulley-Idler, Flat |
| 13          | 5-4460             | 1           | Washer-Pivot       |
| 14          | 119-4041           | 3           | Nut-HF             |
| 15          | 139-1723           | 1           | Washer-Flat        |
| 16          | 120-2779           | 1           | Screw-HH           |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------|
| 17          | 140-5020           | 1           | Bolt Shoulder        |
| 18          | 137-7040           | 1           | Spring-Return, Pedal |
| 19          | 139-1719           | 1           | Screw-HH             |
| 20          | 137-5004           | 1           | Blower Chute ASM     |
| 21          | 120-7950           | 10          | Screw-Torx           |
| 22          | 136-9187           | 5           | Insert-T-Nut         |
| 23          | 137-5003           | 1           | Blower Cover ASM     |
| 23:2        | 136-4164           | 1           | Decal-Danger         |
| 24          | 3258-166           | 5           | Screw-PRH            |
| 25          | 139-2560           | 1           | Bolt-Shoulder        |
| 26          | 133-7058           | 1           | Latch-Blower         |
| 27          | 119-4042           | 1           | Nut-HF, NI           |
| 28          | 133-7048           | 1           | Spring-Torsion       |
| 30          | 98-8332            | 1           | Knob                 |
| 31          | 103-4080           | 2           | Latch-Rubber         |
| 32          | 137-3073           | 4           | Washer-Plain         |
| 33          | 3274-39            | 4           | Screw-HSBH           |
| 34          | 136-9213-03        | 1           | Guard-Blower         |

**Notes:**

**Notes:**



**Count on it.**