



21in Heavy-Duty Recycler[®]/Rear Bagger Lawnmower

Model No. 22166 - 240000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR.	as required	HYD.	hydraulic
ASM.	assembly	INC.	incorporated
CARR.	carriage	LH.	left hand
DEG.	degrees	NI.	nylon insert
FH.	flat head	PPH.	phillips pan head
GA.	gauge	PTH.	phillips truss head
HF.	hex flange	PTO.	power take off
HH.	hex head	RH.	right hand
HHF.	hex head flange	SFH.	slotted fillister head
HHFTF.	hex head flange thread forming	SHH.	slotted hex head
HJ.	hex jam	SHWH.	slotted hex washer head
HLH.	hex lag head	SPH.	slotted pan head
HOC.	height-of-cut	SQH.	square head
HS.	hex	SRH.	slotted round head
HSBH.	hex socket button head	STD.	standard
HSFH.	hex socket flat head	TAP.	self tapping
HSH.	hex socket head	TTH.	torx truss head
HWH.	hex washer head	WH.	wing head
HWHTF.	hex washer head thread forming		

Footnotes

- ❶

Not illustrated
- ❷


Not serviced separately
- ❸

Obtain Parts From Honda
- ❹

See following pages

Contents


Description	Page	Description	Page
Deck, Discharge Door and Wheel Assembly	 3	Carburetor Assembly Honda GXV160K1 A12	 16
Housing Assembly No. 98-7139	 5	Air Cleaner Assembly Honda GXV160K1 A12	 17
Wheel and Tire Assembly No. 100-2870	 6	Muffler Assembly Honda GXV160K1 A12	 18
Engine and Blade Assembly	 7	Control Assembly Honda GXV160K1 A12	 19
Handle Assembly	 8	Label Assembly and Gasket Kits Honda GXV160K1 A12	 20
Grass Bag Assembly No. 106-0975	 9		
Cylinder Head Assembly Honda GXV160K1 A12	 10		
Cylinder Barrel Assembly Honda GXV160K1 A12	 11		
Crankshaft and Piston Assembly Honda GXV160K1 A12	 12		
Camshaft Assembly Honda GXV160K1 A12	 13		
Recoil Starter Assembly Honda GXV160K1 A12	 14		
Fan Cover Assembly Honda GXV160K1 A12	 15		



Deck, Discharge Door and Wheel Assembly


Ref	Part No.	Qty.	Description
1	98-7139	1	Housing
2	3296-6	2	Nut-Lock, NI
3	40-1940	4	Washer
4	32152-2	4	Nut-Hex
5	66-7560	2	Front Spring Arm ASM
6	61-8300	2	Arm-Pivot, Front
7	52-2480	4	Spacer-Wheel
8	27-6232	2	Bolt-Wheel
9	100-2870	4	Wheel And Tire ASM
10	323-12	4	Screw-HH
12	25-7740	4	Knob-Arm
13	49-8760	1	Quadrant-Front, LH
14	104-8589	1	Decal-Warning
15	105-2625	1	Decal-Std, Safety
16	44-0580	1	Shield-Trailing
17	33-3208	1	Rod-Shield
18	42-3510	2	Pivot Arm ASM
18:2	47-2900	1	Bushing
18:3	47-2890	1	Bushing
18:4	302-56	1	Fitting-Grease
19	32121-108	2	Pin-Spirol
20	49-8790	1	Shaft-Axle, Rear
21	36-4780	4	Washer
23	66-7561	2	Rear Spring Arm ASM

Ref	Part No.	Qty.	Description
24	48-2170	2	Cap-End
25	49-8740	1	Quadrant-Rear, LH
26	63-9441	1	Cover-Belt
27	37-7260	2	Screw-HH
28	3296-42	2	Nut-Lock, NI
29	49-8750	1	Quadrant-Rear, RH
30	3256-22	2	Washer-Flat
31	321-7	2	Screw-HH
32	46-8090	2	Screw-Plastite
33	77-0500	1	Discharge Plug ASM
33:1	3295-35	1	Rivet-Head, Flat
33:3	76-4640	1	Latch-Plug, Discharge
33:4	76-4650	1	Grip-Latch
34	93-3154	1	Latch-Plate
35	93-7351	1	Discharge Door ASM
36	46-6811	1	Screw-HWH
37	80-3770	1	Retainer-Door
38	76-4660	1	Spring-Door
39	71-9350	1	Bracket-Spring
40	82-9152	1	Tunnel-Discharge
41	52-2610	1	Label-Grease, Hp
45	46-6810	1	Screw And Washer ASM
48	49-2040	4	Screw-Tapping
49	49-8770	1	Quadrant-Front, RH




Deck, Discharge Door and Wheel Assembly (continued)

Ref	Part No.	Qty.	Description
50	257-3	2	Washer-Thrust
52	106-0689	1	Decal
54	99-6722	1	Guard-Engine
55	32144-86	4	Screw-Hwh, Thread Forming
56	323-6	2	Screw-HH
57	3296-39	2	Nut-Lock, NI
58	68-7410	1	Decal-Blade
59	2412-72	1	Clip-Closed, Insulated


**Housing Assembly No. 98-7139**

Ref	Part No.	Qty.	Description
2	92-1750	1	Kicker-Rear
3	92-1720	1	Kicker-Front
4	92-1730	1	Kicker-RH
5	32144-111	6	Screw-PPH
6	39-5770	1	Decal-Danger
7	93-0248	1	Decal-Warning
8	92-1779	1	Decal-Warning




Wheel and Tire Assembly No. 100-2870

Ref	Part No.	Qty.	Description				
1	53-7740	1	Tire				
2	53-7780-06	2	Plate-Wheel, Half				
3	321-2	4	Screw-HH				
4	3296-42	4	Nut-Lock, NI				
25		1	Hub And Bearing ASM				
5:1	52-2410	1	Hub-Bearing				
5:2	52-2440	1	Spacer-Bearing				
5:3	52-2450	2	Bearing-Wheel				



Engine and Blade Assembly


Ref	Part No.	Qty.	Description				
1		1	Engine-Honda, Gxv 160k1a1t				
3	322-10	1	Screw-HH				
4	3296-29	1	Nut-Lock, NI				
5	3256-23	2	Washer-Flat				
7	103-2678	3	Screw-Shoulder				
8	7-0036	1	Key-Square				
9	103-3795	1	Spacer-Retainer, Blade				
10	105-8579	1	Bolt-Blade				
12	92-1599-03	1	Stiffener-Blade				
13	91-2256-03	1	Blade				
14	52-2170	1	Retainer-Blade				
15	32144-70	3	Screw-HH				
16	3254-6	3	Washer-Lock, Internal				
17	48-2591	1	Protector-Crankshaft				



Handle Assembly


Ref	Part No.	Qty.	Description
1	98-2000-03	1	Handle
2	46-8081	1	Guide-Rope
3	321-9	1	Screw-HH
4	48-2810	1	Rod-Support, Bag
5	100-3297-03	1	Latch-Handle, RH
6	3290-456	4	Washer-Belleville
7	3296-29	4	Nut-Lock, NI
8	27-7210	1	Screw-Shoulder
9	3-3287	2	Spacer-Latch, Handle
10	3296-47	2	Nut-Lock, NI
11	322-6	2	Screw-HH
12	322-7	2	Screw-HH
13	100-3298-03	1	Latch-Handle, LH
14	3290-378	3	Tie-Cable
15	103-2684	1	Cable-Brake
16	106-0888	1	Throttle Cable ASM
17	321-13	2	Screw-HH
18	3-7501	3	Washer
19	322-11	2	Screw-HH
20	103-5296	1	Control-Throttle
21	3296-58	2	Nut-Lock NI
22	49-1630	2	Spacer-Support
23	321-4	1	Screw-HH
24	66-5350	1	Lever-Control

Ref	Part No.	Qty.	Description
25	3296-42	2	Nut-Lock, NI
26	61-8270-03	1	Bar-Control
27	32111-7	3	Nut-Cap
28	32151-86	2	E-Ring
29	256-276	2	Spacer-Nylon
31	98-4387	1	Decal-Protection, Ear
32	27-7211	1	Screw-Shoulder
33	3256-23	2	Washer-Flat
34	104-1326	1	Plate-Aligning, Bag
35	3229-3	1	Screw-CARR
1499	106-0975	1	Grass Bag ASM



Grass Bag Assembly No. 106-0975


Ref	Part No.	Qty.	Description
1	33-4820	1	Hinge-Door, Bag
2	42-4030	1	Frame-Bag, Upper
3	3290-422	2	Nut-Push
4	36-6910	2	Spring
5	42-4020	1	Frame-Bag
6	106-0926	1	Bag-Grass
7	48-2840	1	Door-Bag, Grass



Cylinder Head Assembly Honda GXV160K1 A12

Ref	Part No.	Qty.	Description
❸1	12200-ZE7-010	1	Head-Cylinder
❸2	12204-ZE1-306	1	Guide-Valve
❸3	12205-ZE1-315	1	Guide-Valve
❸4	12216-ZE5-300	1	Clip-Valve, Guide
❸5	12251-ZE7-000	1	Gasket-Cylinder, Head
❸6	12311-ZG9-800	1	Cover-Head
❸7	12391-ZE7-T00	1	Gasket-Cylinder Head Cover
❸8	90048-ZC3-000	2	Bolt-Stud
❸9	90013-883-000	2	Bolt-Flange
❸10	90013-883-000	2	Bolt-Flange
❸11	90043-ZE6-000	2	Bolt-Stud
❸12	94301-10160	2	Pin-Dowel
❸13	95701-08050-00	4	Bolt-Flange
❸14	98079-54846	1	Spark Plug (Bpr4es)(Ngk)
❶❸	98079-54855	1	Spark Plug (W14epu)(Denso)


Ref	Part No.	Qty.	Description
❶❸	98079-55846	1	Spark Plug (Bpr5es)(Ngk)
❶❸	98079-55855	1	Spark Plug (W16epu)(Denso)
❶❸	98079-56846	1	Plug-Spark
❶❸	98079-56855	1	Spark Plug (W20epu)(Denso)



Cylinder Barrel Assembly Honda GXV160K1 A12


Ref	Part No.	Qty.	Description
2	11300-ZE7-W00	1	Oil Pan Assembly
4	11381-ZE7-M10	1	Gasket-Pan, Oil
5	12000-ZE7-405	1	Cylinder Assembly
6	12125-ZE7-000	1	Plate-Guide
7	12126-ZE7-W00	1	Plate A-Guide
8	12367-883-003	1	Filter-Breather
9	12370-ZE7-000	1	Cover-Breather
10	12372-ZE7-000	1	Breather-Valve
11	12373-ZE7-000	1	Gasket-Breather, Cover
12	15355-ZE7-000	1	Rubber-Oil, Return
13	15620-ZE6-810	1	Dipstick-Oil
14	15630-ZE6-810	1	Extension-Oil, Filler
15	16510-ZE6-000	1	Governor Assembly

Ref	Part No.	Qty.	Description
16	16511-ZE1-000	2	Weight-Governor
17	16512-ZE6-000	2	Holder-Governor, Weight
18	16513-ZE1-000	2	Pin-Governor Weight
19	16515-ZE6-010	1	Shaft-Governor, Holder
20	16525-ZE6-010	1	Plate-Governor Shaft Holder
21	16531-ZE1-000	1	Slider-Governor
22	16541-ZE7-000	1	Shaft-Governor, Arm
23	17240-ZE6-000	1	Collar-Extension
27	90013-883-000	2	Bolt-Flange
29	90017-883-000	1	Bolt-Flange (6x32)
30	90022-888-010	2	Bolt-Flange
31	90131-ZE1-000	1	Bolt-Drain Plug
32	90451-ZE1-000	1	Washer-Thrust




Cylinder Barrel Assembly
Honda GXV160K1 A12 (continued)

Ref	Part No.	Qty.	Description				
35	90601-ZE1-000	1	Washer-Plug, Drain (10.2mm)				
36	30602-ZE1-000	1	Clip-Governor Holder				
40	91231-891-003	1	Seal-Oil (6x11x4)				
41	91201-ZG9-U71	1	Seal-Oil (25x38x7)				
1 5	91252-888-003	1	Seal-Oil (25x38x7)(Arai)				
42	91252-894-004	1	Seal-Oil (25.4x40x7)				
43	91301-ZE9-003	1	O-Ring (22.5x2.2)				
44	91301-805-000	1	O-Ring (26x2.7)				
45	94101-06800	2	Washer-Plain				
46	94251-08000	1	Pin-Lock				
47	94301-08140	2	Pin A-Dowel (8x14)				
48	95701-06012-08	1	Bolt-Flange (6x12)				
49	95701-08050-00	6	Bolt-Flange				
50	96100-62050-00	1	Bearing-Ball, Radial (6025)				
52	90014-952-000	2	Bolt-Flange				



Crankshaft and Piston Assembly
Honda GXV160K1 A12


Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	13010-ZF1-023	1	Ring Set-piston(Std)	12	90401-ZE7-W00	1	Washer-Thrust (25.6mm)
1	13011-ZF1-023	1	Ring Set-piston(Os 0.25)	13	90551-ZE1-000	2	Clip-Piston, Pin (18mm)
1	13012-ZF1-023	1	Ring Set-Piston (Os 0.50)				
1	13013-ZF1-023	1	Ring Set-Piston (0.75)				
2	13101-ZE7-010	1	Piston (Std)				
1	13102-ZE7-010	1	Piston (Os 0.25)				
1	13103-ZE7-010	1	Piston (Os 0.50)				
1	13104-ZE7-010	1	Piston (0.75)				
3	13111-ZE1-000	1	Pin-Piston				
4	13200-ZE7-000	1	Connecting Rod Assembly				
1	13200-ZE7-305	1	Connecting Rod Assembly				
6	13310-ZE7-010	1	Crankshaft (N1 Type)				
11	90001-ZE1-000	2	Bolt-Connecting Rod				



Camshaft Assembly
Honda GXV160K1 A12


Ref	Part No.	Qty.	Description
❶1	14100-ZE7-000	1	Camshaft Assembly
❷2	144100-ZE1-010	2	Rod-Push
❸3	14431-ZE1-000	2	Valve-Rocker, Arm
❹4	14441-ZE1-010	2	Lifter-Valve
❺5	14451-ZE1-013	2	Pivot-Rocker, Arm
❻6	14568-ZE1-000	1	Spring-Weight, Return
❼7	14711-ZF1-000	1	Valve-Intake
❽8	14721-ZE7-000	1	Valve-Exhaust
❾9	14751-ZE1-000	2	Spring-Valve
❿10	14771-ZE1-000	2	Retainer-Intake Valve Spring
⓫11	14791-ZE1-010	1	Plate-Push Rod Guide
⓬12	90012-ZE0-010	2	Bolt-Pivot (8mm)
⓭13	90206-ZE1-000	2	Nut-Pivot, Adjust

Ref	Part No.	Qty.	Description
❿14	12209-ZE6-003	1	Seal-Valve, Stem




Recoil Starter Assembly
Honda GXV160K1 A12

Ref	Part No.	Qty.	Description				
❶	28400-ZG9-803	1	Recoil Starter Assembly				
❷	28402-ZG9-802	1	Housing Assembly				
❸	28415-ZG9-802	1	Pulley And Spring Assembly				
❹	28419-ZG9-802	1	Pin-Center				
❺	28431-ZG9-802	1	Plate A-Friction				
❻	28432-ZG9-802	1	Plate-Friction				
❼	28441-ZG9-802	1	Spring-Friction				
❽	28444-ZG9-802	1	Retainer				
❾	28461-ZE6-T02	1	Handle				
❾	28462-ZG9-802	1	Rope-Recoil, Starter				
❿	28463-ZE6-T02	1	Handle-Reinforcement				
⓫	28485-ZE6-T02	2	Ratchet-Starter				
⓫	28486-ZE6-T02	2	Spring-Dog				



Fan Cover Assembly
Honda GXV160K1 A12


Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	15721-ZE7-000	1	Tube-Breather	17	46392-SC2-003	1	Clamp-Brake, Pipe
2	17216-PE2-003	3	Collar-Air, Cleaner	18	90015-883-000	1	Bolt-Flange (6x28)
3	17410-ZE7-W00	1	Elbow-Air, Cleaner	19	90041-ZE7-W10	2	Bolt-Stud
4	17620-ZE7-000	1	Fuel Tank Cap Assembly	20	90042-ZE7-W00	1	Bolt-Stud (Ign Coil)
5	17622-888-010	1	Sponge-Fuel Cap Breather	21	90402-ZE7-W00	2	Collar-Special
6	17624-ZE7-000	1	Gasket-Fuel, Cap	23	91301-ZG9-800	1	O-Ring (33.3x3.5)
7	17700-ZE7-W00	1	Tube-Fuel Tank Assembly	24	93891-06035-10	1	Washer-Screw (6x35)
8	19610-ZE7-W11ZA	1	Cover-Fan (Black)	25	93913-24580	1	Screw-Tapping (4x20)
9	19610-ZE7-W11ZB	1	Cover-Fan (Bright Red)	26	94050-06000	5	Nut-Flange
10	19615-ZG9-801ZA	1	Hood-Fan, Cover *Nh1* (Black)	27	95002-02080	1	Clip-Tube
11	19615-ZG9-801ZB	1	Hood-Fan, Cover *r8* (Bright Red)	28	95002-02100	1	Clip-Tube
12	30500-ZG9-801	1	Ignition Coil Assembly	13	95002-50000	1	Clip-Tube
13	36103-ZE1-000	1	Stop Switch Wire Holder				



Carburetor Assembly Honda GXV160K1 A12

Ref	Part No.	Qty.	Description
❶1	16010-ZE0-025	1	Gasket, Set
❶2	16011-ZE0-005	1	Float-Valve, Set
❶3	16013-ZE0-005	1	Float Set
❶4	16015-ZE0-831	1	Chamber, Set-Float
❶6	16016-ZH7-W01	1	Screw-Set
❶7	16024-ZE1-811	1	Screw-Set, Drain
❶8	16028-ZE0-005	1	Screw-Set
❶9	16045-ZE7-005	1	Choke Set
❶10	16100-ZE7-W21	1	Carburetor Assembly
❶11	16124-ZE0-005	1	Screw-Throttle, Stop
❶12	16166-ZE7-W10	1	Nozzle-Main
❶13	16211-ZE7-000	1	Insulator-Carburetor
❶14	16212-ZE7-M10	1	Gasket-Insulator


Ref	Part No.	Qty.	Description
❶15	16220-ZE6-010	1	Spacer-Carburetor
❶16	16221-ZE7-M11	1	Gasket-Carburetor
❶17	16953-ZE1-406	1	Lever-valve(Engine Serial Number Up To Be66c A)
❶❶	16953-ZE1-811	1	Lever-valve(Engine Serial Number Up To Be66c A)
❶❶	16953-ZE1-812	1	Lever-valve(Engine Serial Number From Be66c B)
❶18	16954-ZE1-811	1	Plate-Lever, Setting(Engine Serial Number Up To Be66c A)
❶❶	16954-ZE1-812	1	Plate-Lever, Setting(Engine Serial Number From Be66c B)
❶19	16956-ZE1-811	1	Spring-Valve, Lever
❶20	16957-ZE1-812	1	Gasket-Valve
❶21	93500-03006	2	Screw-Pan (3x6)(Engine Serial Number From Be66c B)
❶❶	93500-03008	2	Screw-Pan (3x8)(Engine Serial Number Up To Be66c A)
❶22	99101-ZH8-0600	1	Jet- Main (No.60)
❶❶	99101-ZH8-0620	1	Jet-Main (No.62)



Carburetor Assembly


Honda GXV160K1 A12 (continued)

Ref	Part No.	Qty.	Description
① ③	99101-ZH8-0650	1	Jet-Main (No.65)
③ 23	99204-ZE0-0350	1	Jet Set-Pilot (No.35)




Air Cleaner Assembly Honda GXV160K1 A12

Ref	Part No.	Qty.	Description				
③2	17218-ZE7-W02	1	Filter (Outer)				
③3	17231-ZE7-W00ZA	1	Cover-Air, Cleaner (Black)				
③4	90004-ZE7-W00	2	Bolt-Air, Cleaner (6x73)				
③5	17211-ZE7-W03	1	Element-Air, Cleaner				
③6	17217-ZE7-W00	1	Gasket-Element				
③7	17232-ZE7-W00	2	Grommet-Air, Cleaner				




Muffler Assembly
Honda GXV160K1 A12

Ref	Part No.	Qty.	Description				
1	06180-ZE6-820	1	Arrester-Spark				
4	18310-ZG9-J01	1	Muffler				
6	18320-ZG9-M01	1	Protector-Muffler				
8	06180-888-505	1	Arrester Kit-Spark				
9	06180-888-810	1	Arrester Kit-Spark				
9	18381-ZE6-820	1	Gasket-Muffler				
12	18381-ZG9-M00	1	Gasket-Muffler				
14	90343-ZE6-000	2	Nut-Self, Lock (6mm)				



Control Assembly Honda GXV160K1 A12

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
②	16551-ZE7-000	1	Arm-Governor	②2	93500-04008-0A	1	Screw-Pan (4x8)
③	16555-ZE7-000	1	Rod-Governor	②3	93500-05016-0A	1	Screw-Pan (5x16)
④	16561-ZE7-020	1	Spring-Governor (Std)	②4	93500-05020-0A	1	Screw-Pan (5x20)
⑤	16562-ZE6-000	1	Spring-Throttle, Return	②5	93500-05028-0A	1	Screw-Pan (5x28)
⑥	16570-ZE7-020	1	Control Assembly	②6	94050-06000	1	Nut-Flange
⑧	16573-ZE7-000	1	Rod-Choke	②7	95701-06010-00	1	Bolt-Flange (6x10)
⑨	16576-ZE7-300	1	Spring-Lever				
⑩	16576-891-000	1	Holder-Cable				
⑪	16584-883-300	2	Spring-Control, Adjusting				
⑫	16585-ZE7-000	1	Protector-Control				
⑱	90013-883-000	2	Bolt-Flange				
⑲	90015-ZE5-010	1	Bolt-Governor Arm				
⑳	90659-680-013	1	Clip-Wire, Harness				



Label Assembly and Gasket Kits

Honda GXV160K1 A12

Ref	Part No.	Qty.	Description				
③2	87101-ZE7-W12	1	Mark, Emblem (5.5)(Es)engine S/n Up To 6154807				
①③	87101-ZE7-W30	1	Mark, Emblem (5.5)(Ah)engine S/n From6154808				
③6	87531-ZG9-800	1	Mark, Honda				
③9	99004-21003	1	Wrench-Box (P21)				
③19	87601-ZE7-W30	1	Mark, Type (A12)				
①③	061A1-ZE7-801	1	Gasket Kit				
①③	06111-ZE7-406	1	Gasket Kit				

NOTES

