



Mid-Size ProLine T-Bar Gear 13 HP with 32in Side Discharge Mower

Model No. 30150 - 240000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Engine and Fuel System Assembly	 3	Cooling Equipment Assembly Kawasaki FH381V-AS25	 16
Transmission and Drive Pulley Assembly	 4	Electric-Equipment Assembly Kawasaki FH381V-AS25	 17
Wheel Drive Assembly	 6	Control-Equipment Assembly Kawasaki FH381V-AS25	 18
Upper Handle Assembly	 7	Carburetor Assembly Kawasaki FH381V-AS25	 19
Deck Assembly	 8	Air-Filter and Muffler Assembly Kawasaki FH381V-AS25	 20
Front Caster and Blade Brake Assembly	 9	Starter Assembly Kawasaki FH381V-AS25	 21
Spindle Assembly	 11	Decal Assembly Kawasaki FH381V-AS25	 22
Cylinder and Crankcase Assembly Kawasaki FH381V-AS25	 12		
Piston and Crankshaft Assembly Kawasaki FH381V-AS25	 13		
Valve and Camshaft Assembly Kawasaki FH381V-AS25	 14		
Lubrication-Equipment Assembly Kawasaki FH381V-AS25	 15		


Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR. as required	INC. incorporated
ASM. assembly	LH. left hand
CARR. carriage	NI. nylon insert
DEG. degrees	PPH. phillips pan head
FH. flat head	PTH. phillips truss head
GA. gauge	PTO. power take off
HF. hex flange	RH. right hand
HH. hex head	SFH. slotted fillister head
HHF. hex head flange	SHH. slotted hex head
HHFTF. hex head flange thread forming	SHWH. slotted hex washer head
HJ. hex jam	SPH. slotted pan head
HLH. hex lag head	SQH. square head
HOC. height-of-cut	SRH. slotted round head
HS. hex	STD. standard
HSBH. hex socket button head	TAP. self tapping
HSFH. hex socket flat head	TTH. torx truss head
HSH. hex socket head	WH. wing head
HWH. hex washer head	
HWHTF. hex washer head thread forming	
HYD. hydraulic	

Footnotes


- | | |
|--|---------------------------|
| ❶ Not illustrated | ❷ Not serviced separately |
| ❸ Obtain parts from your local Kawasaki dealer | |



Engine and Fuel System Assembly

Ref	Part No.	Qty.	Description
1	1-633023	2	Stud
2	3256-23	4	Washer-Flat
3	1-633349	2	Spring-Tank, Fuel
4	3296-47	2	Nut-Lock, NI
5	1-303077	5	Clamp
9		1	Engine-Kawasaki, Fh381v-As25
10	106-0699	1	Decal-Warning, Hot Surfaces
11	3290-357	2	Nut-HHF
12	323-13	1	Screw-HH
13	322-7	3	Screw-HH
14	1-303334	3	Washer-Spring
15	103-1966	1	Adapter
16	103-1965	1	Valve-Drain, Oil
18	1-303022	1	Hose-Fuel
19	1-603770	1	Valve-Fuel
20	1-603955	1	Hose-Fuel
22	322-3	2	Screw-HH
24	1-805005	2	Washer-Lock
26	106-0730	1	Fuel Tank ASM
26:2	103-2605	1	Fitting-Fuel, Bulkhead
27	88-3980	1	Gas Cap ASM
27:3	88-4010	1	Gasket-Cap, Gas
28	32128-20	5	Nut-HF
30	322-9	1	Screw-HH

Ref	Part No.	Qty.	Description
31	3254-2	1	Washer-Lock, Int
32	100-6467	1	Muffler
33	103-5465	1	Clamp-Muffler
99	1-303287	1	Tie-Plastic
99	1-303335	1	Tie-Plastic




Transmission and Drive Pulley Assembly

Ref	Part No.	Qty.	Description
1	103-2923-01	1	Deck-Rear
2	1-323252	2	Bearing-Shaft
3	1-323254	2	Flange-Output
4	1-803310	3	Screw-Set
5	103-6512	2	Sheave-Transmission
6	321-3	6	Screw-HH
7	103-4177	1	Key-Machine
8	3242-4	2	Screw-Set, SQH
9	3296-39	1	Nut-Lock, NI
10	3256-24	1	Washer-Flat
11	1-323285	1	Idler-Drive, Transmission
12	3256-5	2	Washer-Flat
13	322-3	4	Screw-HH
14	1-805005	4	Washer-Lock
15	1-633181	1	Plate-Tapped
16	1-513152	1	Switch-Closed, Normally
17	32151-62	2	Ring-Retaining
18	3257-5	3	Key-Woodruff
19	1-323502	2	Shaft-Transmission
20	51-4220	2	Guard-Coupler
21	1-323680	2	Coupler
22	1-323630	1	V-Belt
23	3245-41	2	Screw-HSH
24	1-323278	1	Sheave-Transmission

Ref	Part No.	Qty.	Description
25	302-19	2	Fitting-Grease
26	1-323500	1	Transmission
27	3230-1	2	Bolt-CARR
28	1-323387-03	1	Plate-Shift
29	98-3256	1	Decal-Speed, Ground
30	1-303020	1	Grip-Lever
31	98-3274-03	1	Lever-Shift
32	98-5975	1	Washer-Belleville
33	3296-6	1	Nut-Lock, NI
35	1-323379	1	Washer
36	32128-20	2	Nut-HF
37	9264964	4	Screw-Hwh, Thd Cut
38	1-603403	1	Bolt-Shoulder
39	1-323389-03	2	Bracket-Plate, Shift
40	1-806003	1	Pin-Hair
41	1-303186	1	Bellcrank
42	3290-357	1	Nut-HHF
43	95-2814	1	Decal-Shut Off, Fuel
44	3290-500	2	Screw-PPH
45	1-543296	1	Grommet
46	3231-6	1	Screw-CARR
47	3296-42	4	Nut-Lock, NI
48	98-0776	1	Decal-Caution
49	1-323256	1	Sheave-Transmission


5



Wheel Drive Assembly

Ref	Part No.	Qty.	Description
1	98-3273	2	Spring-Extension
2	323-10	2	Screw-HH
3	32151-47	2	Ring-Retaining
4	1-806003	4	Pin-Hair
5	3256-23	2	Washer-Flat
6	104-1321-03	1	RH Idler Arm ASM
7	104-1322-03	1	LH Idler Arm ASM
8	74-0521	2	Fitting-Rod
9	283-6	2	Pin-Clevis
10	1-323296	2	Rod-Brake
11	1-322125	2	Swivel-Brake
12	1-513959	2	Wingnut-Nylock
13	3290-357	14	Nut-HHF
14	323-16	4	Screw-HH
16	98-5131-01	2	Shield-Wheel, Drive
17	1-323694	4	Spacer-Shield
18	1-323634	2	Idler-Drive, Wheel
19	302-19	2	Fitting-Grease
21	1-323307	4	Pin-Clevis
22	1-322209-03	2	Arm-Brake
23	32120-47	2	Ring-Retaining, External
24	1-803051	4	Nut-Push
25	1-323595	2	Band-Brake
26	1-322232-03	1	Axle ASM


Ref	Part No.	Qty.	Description
27	1-523157	6	Washer-Spacer
27	1-543436	8	Washer-Spacer
28	1-323261	2	Drum-Brake
29	1-323349	2	Sheave-Wheel, Drive
30		2	Wheel And Tire ASM
30:1	1-323361	1	Tire
30:2	1-323360	1	Wheel And Hub ASM
30:2:1	1-323329	2	Bearing-Flanged
30:2:2		1	Rim ASM
30:2:3		1	Fitting-Grease
30:2:4		1	Valve Stem And Cap
34	1-808519	2	Ring-Snap
36	322-5	8	Screw-HH
37	1-603430	2	Scraper
38	1-323744	2	Belt-Drive, Wheel
39	3296-29	2	Nut-Lock, NI
40	2412-104	2	R-Clamp
41	98-3259	1	Shield-Trailing
42	322-3	2	Screw-HH
43	98-5975	4	Washer-Belleville
44	323-6	4	Screw-HH
45	1-373034	8	Washer
46	1-805005	8	Washer-Lock



Upper Handle Assembly


Ref	Part No.	Qty.	Description
1	98-3282	2	Rod-Control
2	95-5522-03	1	Control Bar ASM
3	3296-2	5	Nut-Lock
4	82-2290	1	Decal
5	32105-1	1	Screw-SHH
6	82-7680-03	1	Bail
7	82-2280	1	Decal
8	3272-11	2	Pin-Cotter
9	99-8501-03	1	Control-Pivot
10	218-595	1	Connector-Body
11	98-3261-03	1	Lever-Brake, Parking
12	98-3266	1	Decal
13	740275	1	Switch-Seat
14	1-806003	3	Pin-Hair
15	237-141	2	Grommet-Rubber
16	98-3267-03	1	Upper Handle ASM
17	283-55	2	Pin-Clevis
18	100-6450	1	Control-Throttle
19	2412-120	2	R-Clamp
20	95-5537	1	Decal-Engage, Deck
21	1-303335	1	Tie-Plastic
22	1-303160	1	Spring-Compression
23	3256-24	2	Washer-Flat
24	3296-39	5	Nut-Lock, NI

Ref	Part No.	Qty.	Description
25	106-0678	1	Harness-Wire
26	98-3279	1	Linkage-Drive, Blade
27	98-3287-03	1	Lever-Engagement, Blade
28	323-6	4	Screw-HH
29	32104-76	2	Screw
30	106-0677	1	Control Panel ASM
31	104-7050	1	Housing-Manual
32	32105-14	4	Screw-SHH
33	106-0841	1	Decal-Control Panel
34	99-8509	1	Spacer
35	1-303020	1	Grip-Lever
36	323-10	1	Screw-HH
37	98-4387	1	Decal-Protection, Ear
38	105-0884	1	Decal-Danger
39	1-403121	1	Switch-Key
40	63-8360	1	Key-Ignition
41	104-7048	1	Cap-Housing



Deck Assembly


Ref	Part No.	Qty.	Description				
1	1-324407	1	Shield-Belt				
1:2	106-0710	1	Decal				
3	106-4161	4	Knob-Handle				
4	1-323417	4	Washer				
5	1-303536	2	Stud-Shield, Belt (Long)				
6	1-303537	2	Stud-Shield, Belt (Short)				
9	105-4675	1	Deck ASM				
9:1	1-302189-01	1	Baffle				
9:3	1-403005	1	Decal-Danger				
9:5	322-2	7	Screw-HH				
9:6	32128-20	7	Nut-HF				
9:10	66-1340	1	Decal-Danger				
9:11	98-5954	1	Decal-Missing, Cover				
9:13	98-3296	1	Decal-Routing, Belt				
9:14	98-5130	1	Decal-Torque, Bolt				
15	1-304256	1	Chute-Discharge				
15:2	54-9220	1	Decal-Danger				
17	98-3281	1	Spacer-Spring				
18	98-3280	1	Spring-Deflector				
19	3296-29	1	Nut-Lock, NI				
20	323-8	6	Screw-HH				
21	98-5975	6	Washer-Belleville				
22	3290-357	6	Nut-HHF				
25	322-50	1	Screw-HH				



Front Caster and Blade Brake Assembly


Ref	Part No.	Qty.	Description
3	1-513338	2	Washer-Flat
5	1-303314	8	Spacer-Caster
6	1-809020	2	Pin
7	1-322145-01	2	Fork
8	325-20	2	Screw-HH
9	1-513648	2	Wheel And Tire ASM
9:2	1-513808	1	Tire
9:3	1-513809	1	Bearing
9:4	1-513810	2	Bushing
10	1-513547	2	Spacer
11	3217-9	2	Nut-Hex
12	3253-7	2	Washer-Lock
15	323-4	8	Screw-HH
16	3290-357	8	Nut-HHF
17	3296-42	2	Nut-Lock, NI
18	302-19	1	Fitting-Grease
19	32128-20	3	Nut-HF
20	1-323071	1	Spring-Extension
21	322-6	1	Screw-HH
22	103-3600	1	Idler Arm ASM
22:2	1-323729	2	Sleeve-Bearing
24	1-303348	1	Eyebolt-Thread, LH
25	1-303434	1	Bushing-Engagement
26	1-603843	1	Pulley-Idler

Ref	Part No.	Qty.	Description
27	98-5975	1	Washer-Belleville
28	702809	1	Screw-Cap
29	1-808280	1	Pin-Clevis
30	1-303105	1	Yoke-Adjustable
31	1-806003	3	Pin-Hair
32	1-323303	1	Linkage-Arm
33	1-322235	1	Arm-Assist
34	1-303238	1	Eyebolt-Thread, RH
35	1-303236	1	Body-Turnbuckle
36	32151-103	1	Ring-Snap
37	3296-29	1	Nut-Lock, NI
38	3256-3	1	Washer-Flat
39	1-403179	1	Tube-Pivot
40	3256-23	1	Washer-Flat
41	32120-35	1	E-Ring
42	1-323718	1	Rod-Brake
43	321-4	2	Screw-HH
44	1-323747	1	Spring-Compression
45	1-323746	1	Spacer-Flanged
46	1-324372	1	Pad / Spring ASM
47	1-303334	1	Washer-Spring
48	322-10	1	Screw-HH
49	1-303352	1	Washer-Spindle
50	1-323748	1	Ring-Push On




Front Caster and Blade Brake Assembly (continued)

Ref	Part No.	Qty.	Description
51	1-302203	2	Support ASM
51:1		1	Support-Caster
51:1:1	302-52	1	Fitting-Grease
51:2	1-303514	2	Bearing-Flanged
52	3296-56	1	Nut-Lock, NI



Spindle Assembly


Ref	Part No.	Qty.	Description				
1	1-800861	2	Screw-Cap, HH				
2	1-513208	2	Washer-Spring				
3	103-2527	2	Blade-Notched				
3	103-2507	2	Blade-Lift, Low				
4	1-323539	8	Spacer-Drive, Blade				
5	1-323529	2	Tube-Spindle, Short				
6	1-807267	2	Key				
7	103-2535	2	Spacer-Guard, Bottom				
13	103-2533	2	Cutter Housing ASM				
13:1	1-323532	1	Housing-Spindle				
13:2	103-2477	2	Bearing-Ball				
13:3	103-2534	1	Spacer-Bearing				
13:4	32120-8	1	Ring-Snap				
14	32128-20	8	Nut-HF				
15	1-303334	8	Washer-Spring				
16	322-6	8	Screw-HH				
17	1-403183	2	Sheave				
18	1-803310	2	Screw-Set				
19	1-323339	2	Washer-Retainer, Sheave				
20	3219-6	2	Nut-Hex				
21	1-323745	1	Belt-Blade, Drive				
22	103-1330	2	Guard-Bearing, Top				



Cylinder and Crankcase Assembly


Kawasaki FH381V-AS25

Ref	Part No.	Qty.	Description
⑤11004	11004-7008	2	Gasket-Head
⑤11008	11008-7011	1	Head-Comp-Cylinder, No.2
⑤11008A	11008-7017	1	Head-Comp-Cylinder, No.1
⑤11008B	11008-7021	1	Head-Comp-Cylinder, #2
⑤11008C	11008-7022	1	Head-Comp-Cylinder, #1
⑤11022	11022-7003	2	Case-Rocker
⑤11060	11060-7001	2	Gasket-Rocker Case
⑤11061	11061-7007	1	Gasket-Cover, Crankcase
⑤11061A	11061-7008	1	Gasket-Breather
⑤14091	14091-7007	1	Cover
⑤49015	49015-7032	1	Cover-Crankcase
⑤49120	49120-7015	1	Crankcase-Comp
⑤59071	59071-2079	1	Joint
⑤92043	92043-7001	6	Pin
⑤92049	92049-7001	4	Seal-Oil-Rvc2 6x11x10.2
⑤92049A	92049-7005	1	Seal-Oil-So 8x14x5 HS
⑤92049B	92049-7015	1	Seal-Oil, Sd
⑤92049C	92049-7016	1	Seal-Oil, Sd
⑤92049D	92049-7019	1	Seal-Oil, So
⑤92139	92139-7002	1	Bushing
⑤130	130B0612	4	Bolt-Flanged
⑤130A	130B0640	4	Bolt-Flanged
⑤130B	130T0850	17	Bolt-Flanged
⑤130C	130T0875	2	Bolt-Flanged




Piston and Crankshaft Assembly
Kawasaki FH381V-AS25

Ref	Part No.	Qty.	Description				
13001	13001-7009	2	Piston-Engine				
13002	13002-7001	2	Pin-Piston				
13008	13008-7001	2	Ring-Set-Piston				
13025	13025-7003	1	Ring-Set-Piston				
13029	13029-7005	1	Piston-Engine				
13031	13031-7033	1	Crankshaft-Comp				
13251	13251-7007	2	Connecting Rod ASM				
13251A	13251-7008	2	Connecting Rod Asm, U/s=0.50				
92033	92033-7005	4	Ring-Snap				
130	130G0630	4	Bolt-Flanged				




Valve and Camshaft Assembly Kawasaki FH381V-AS25

Ref	Part No.	Qty.	Description				
③12004	12004-7003	2	Valve-Intake				
③12005	12005-7003	2	Valve-Exhaust				
③12009	12009-7001	4	Retainer-Valve Spring				
③12011	12011-2056	8	Collet				
③12016	12016-7001	4	Arm-Rocker				
③12032	12032-7001	4	Tappet				
③13070	13070-7001	2	Guide				
③13070A	13070-7004	1	Guide				
③13116	13116-2057	4	Rod-Push				
③13271	13271-7007	1	Plate				
③13271A	13271-7021	1	Plate-Governor				
③42036	42036-7009	1	Sleeve				
③49078	49078-7001	4	Spring-Engine Valve				
③49118	49118-7009	1	Camshaft-Comp				
③92009	92009-2341	4	Screw				
③92015	92015-2253	4	Nut				
③92033	92033-7001	2	Ring-Snap				
③92140	92140-7002	6	Ball				
③92145	92145-7001	1	Spring				
③92153	92153-7019	4	Bolt				
③92200	92200-7001	1	Washer				




Lubrication-Equipment Assembly
Kawasaki FH381V-AS25

Ref	Part No.	Qty.	Description				
⑤13107	13107-7009	1	Shaft				
⑤13271	13271-7017	1	Plate				
⑤14075	14075-7009	1	Cap-Assy				
⑤16154	16154-2053	1	Rotor-Pump-In				
⑤16154A	16154-2054	1	Rotor-Pump-Out				
⑤49065	49065-2078	1	Filter-Oil				
⑤49065A	49065-7004	1	Filter-Oil				
⑤59051	59051-7011	1	Gear-Spur				
⑤59231	59231-7003	1	Filler				
⑤92043	92043-7003	2	Pin				
⑤92066	92066-7003	2	Plug				
⑤92140	92140-7003	1	Ball				
⑤92145	92145-7002	1	Spring				
⑤130	130B0612	3	Bolt-Flanged				
⑤670	670D2016	3	O Ring-16mm				




Cooling Equipment Assembly
Kawasaki FH381V-AS25

Ref	Part No.	Qty.	Description				
③13270	13270-7007	1	Plate				
③14037	14037-7021-9H	1	Screen				
③14091	14091-7009	1	Cover				
③49089	49089-7044	1	Shroud-Engine				
③49089A	49089-7045	1	Shroud-Engine				
③59041	59041-7010	1	Fan				
③59066	59066-7023	1	Housing-Fan				
③92004	92004-7007	2	Stud				
③92153	92153-7007	3	Bolt				
③92153A	92153-7008	1	Bolt				
③130	130B0612	4	Bolt-Flanged				
③130A	130B0616	2	Bolt-Flanged				
③130B	130B0816	1	Bolt-Flanged				
③311	311F0600	2	Nut-Hex				




Electric-Equipment Assembly Kawasaki FH381V-AS25

Ref	Part No.	Qty.	Description				
⑨21171	21171-7013	1	Coil-Assy-Ignition				
⑨21171A	21171-7014	1	Ignition Coil ASM				
⑨21194	21194-7013	1	Flywheel-Comp				
⑨26030	26030-7001	1	Harness				
⑨92004	92004-7008	2	Stud				
⑨92009	92009-2308	2	Screw				
⑨92066	92066-7002	1	Plug				
⑨92066A	92066-7005	1	Plug				
⑨92070	92070-7003	2	Plug-Spark-Rcj8y-Solid				
⑨92151	92151-2097	1	Bolt-12x30				
⑨92200	92200-7002	1	Washer				
⑨130	130B0620	2	Bolt-Flanged				
⑨311	311F0600	2	Nut-Hex				
⑨510	510A5100	1	Key-Woodruff				



Control-Equipment Assembly
Kawasaki FH381V-AS25

Ref	Part No.	Qty.	Description				
13107	13107-7010	1	Shaft				
13271	13271-7018	1	Plate				
16169	16169-7012	1	Link-Choke				
16171	16171-7007	1	Link				
39129	39129-7003	1	Spring-Governor				
49103	49103-7004	1	Arm-Governor				
49113	49113-7024	1	Panel-Comp-Control				
92009	92009-7007	1	Screw-4x35				
92145	92145-7003	1	Spring				
92145A	92145-7005	1	Spring				
92150	92150-2182	2	Bolt-5x18				
92153	92153-7005	1	Bolt-6x35				
92170	92170-7001	2	Clamp				
130	130B0612	2	Bolt-Flanged				
214	214B0408	2	Screw-Pan+-				
311	311B0600	1	Nut-Hex				
411	411b0600	1	Washer-Plain				




Carburetor Assembly

Kawasaki FH381V-AS25


Ref	Part No.	Qty.	Description
⑨11061	11061-7004	1	Gasket-Insulator
⑨11061A	11061-7009	1	Gasket-Chamber
⑨11061B	11061-7010	1	Gasket-Screw
⑨11061C	11061-7018	1	Gasket-Air Cleaner
⑨13107	13107-7018	1	Shaft
⑨15003	15003-7054	1	Carburetor-ASM
⑨16014	16014-7002	1	Screw-Pilot
⑨16020	16020-7003	1	Chamber-Float
⑨16025	16025-7006	1	Valve-Throttle
⑨16030	16030-7003	1	Valve-Float
⑨16031	16031-7002	1	Float
⑨16041	16041-7016	1	Shaft-Carburetor-Choke
⑨16041A	16041-7018	1	Shaft-Carburetor-Throttle
⑨16186	16186-7002	1	Choke Valve ASM
⑨39076	39076-7001	1	Limiter
⑨49121	49121-7002	1	Nozzle-Main
⑨59076	59076-7005	1	Manifold-Intake
⑨92009	92009-2083	2	Screw
⑨92009A	92009-2349	1	Screw
⑨92055	92055-2174	1	Ring-O
⑨92055A	92055-7007	2	Ring-O, Id=31
⑨92063	92063-7027	1	Jet-Main-#78
⑨92063A	92063-7030	1	Jet-Main-#75
⑨92063B	92063-7031	1	Jet-Main-#72

Ref	Part No.	Qty.	Description
⑨92081	92081-2234	1	Spring
⑨92093	92093-2100	1	Seal
⑨92093A	92093-7003	1	Seal
⑨92145	92145-7015	1	Spring
⑨92153	92153-7009	4	Bolt
⑨92172	92172-7002	1	Screw
⑨92200	92200-7014	1	Washer



Air-Filter and Muffler Assembly
Kawasaki FH381V-AS25

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
③11011	11011-7035	1	Case-Air Filter	③220	220B0614	2	Screw-Pan (Cross)
③11013	11013-7025	1	Element-Filter, Air	③233	233B0416	1	Screw-Pan, Wp
③11013A	11013-7031	1	Element-Filter, Air	③311	311B0400	1	Nut-Hex
③11051	11051-7005-9H	1	Bracket	③317	317R0800	4	Nut-Hex-Small
③11053	11053-7022	1	Bracket	③461	461F0800	4	Washer-Spring
③11060	11060-7021	2	Gasket-Muffler	③670	670B2010	1	O-Ring
③13271	13271-7022	1	Plate				
③16060	16060-7016	1	Pipe-Intake				
③18088	18088-7001	1	Pipe-Exhaust				
③32154	32154-7006	1	Pipe				
③49070	49070-7015	1	Muffler-Comp				
③92015	92015-1193	2	Nut				
③92026	92026-7001	2	Spacer, 6.2x7.9x5				
③92055	92055-7015	1	O-Ring				
③92072	92072-7008	1	Band				
③92170	92170-7002	1	Clamp				
③92192	92192-7010	1	Tube				
③92200	92200-2070	2	Washer				
③92210	92210-7004	2	Nut				
③92210A	92210-7019	1	Nut				
③130	130B0610	1	Bolt-Flanged				
③130A	130B0612	2	Bolt-Flanged				
③130B	130B0816	2	Bolt-Flanged				



Starter Assembly
Kawasaki FH381V-AS25

Ref	Part No.	Qty.	Description				
❸13165	13165-7001	2	Pawl-Recoil, Starter				
❸13271	13271-7003-9H	1	Plate				
❸14020	14020-7001	1	Retainer				
❸32099	32099-7002	1	Case-Recoil, Starter				
❸46075	46075-7001	1	Grip-Recoil, Starter				
❸49080	49080-7001	1	Pulley-Starting				
❸49088	49088-7013	1	Starter-Recoil				
❸59101	59101-7001	1	Reel-Recoil, Starter				
❸59106	59106-7001	1	Rope				
❸92145	92145-7006	1	Spring				
❸92145A	92145-7007	2	Spring				
❸92145B	92145-7008	1	Spring				
❸92151	92151-7008	1	Bolt				
❸92200	92200-7004	1	Washer				
❸92200A	92200-7005	1	Washer				
❸92210	92210-0003	4	Nut				
❸130	130B0608	3	Bolt-Flanged				

56033 -



56070



56080



56080A



Decal Assembly Kawasaki FH381V-AS25

Ref	Part No.	Qty.	Description
⑤56033	56033-7001	1	Label-Manual
⑤56070	56070-7001	1	Label-Warning
⑤56080	56080-2077	1	Label-Brand
⑤56080A	56080-7025	1	Label-Brand

NOTES

