

LAWN-BOY®

Silver Series® Lawnmower

Model No. 10356 - 240000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR.	as required	HYD.	hydraulic
ASM.	assembly	INC.	incorporated
CARR.	carriage	LH.	left hand
DEG.	degrees	NI.	nylon insert
FH.	flat head	PPH.	phillips pan head
GA.	gauge	PTH.	phillips truss head
HF.	hex flange	PTO.	power take off
HH.	hex head	RH.	right hand
HHF.	hex head flange	SFH.	slotted fillister head
HHFTF.	hex head flange thread forming	SHH.	slotted hex head
HJ.	hex jam	SHWH.	slotted hex washer head
HLH.	hex lag head	SPH.	slotted pan head
HOC.	height-of-cut	SQH.	square head
HS.	hex	SRH.	slotted round head
HSBH.	hex socket button head	STD.	standard
HSFH.	hex socket flat head	TAP.	self tapping
HS.	hex socket head	TTH.	torx truss head
HWH.	hex washer head	WH.	wing head
HWHTF.	hex washer head thread forming		

Footnotes

- ❶

Not illustrated
- ❷

Not serviced separately
- ❸


Included in Repair Kit No. 632809
- ❹

Obtain parts from your local Tecumseh dealer
- ❺

Included in Repair Kit No. 37613

Contents


Description	Page	Description	Page
Housing Assembly	 3	Carburetor Assembly No. 640303 Tecumseh Model No. LV195EA-362005B	 12
Gear Case Assembly No. 104-7671	 4	Recoil Starter Assembly No. 590739 Tecumseh Model No. LV195EA-362005B	 13
Gear Case and Wheel Assembly	 5	Recoil Starter Assembly No. 590702 (Optional) Tecumseh Model No. LV195EA-362005B	 14
Engine and Blade Assembly	 6		
Handle Assembly	 7		
Engine Assembly No. 1 Tecumseh Model No. LV195EA-362005B	 8		
Engine Assembly No. 2 Tecumseh Model No. LV195EA-362005B	 10		



Housing Assembly


Ref	Part No.	Qty.	Description
1	40-1940	2	Washer
2	95-7403-03	2	Bracket-Height Adjustment, Wheel
3	92-7731	2	Plate-Baffle
4	92-4890	2	Washer-Wheel
5	92-4881-03	2	Plate-Height, Adjustment
10	98-4477	1	Deck ASM
10:3	43-8480	1	Decal-Danger
10:4	613765	1	Nut-Cage
10:6	99-6018	1	Decal-Warning
10:7	92-2914	1	Decal-Hoc, LH
10:8	92-2915	1	Decal-Hoc, RH
10:9	93-7250	1	Decal-Warning
10:10	94-1610	2	Nut-Clip
14	614677	2	Screw-Sems
17	92-8630	1	Plate-Mulch
18	98-8332	1	Knob
19	105-8602	1	RH Bracket ASM
21	95-7068	1	Cover-Drive
22	92-9665	1	Screw
23	65-5221	2	Screw-HWHTF
24	92-7728-03	1	Guide-Transmission
25	605120	1	Nut-Clip
26	104-7671	1	Gear Case ASM
27	105-8604	1	LH Bracket ASM

Ref	Part No.	Qty.	Description
28	322-3	6	Screw-HH
29	92-8647	1	Shield-Trailing
30	3296-29	6	Nut-Lock, NI
32	92-1008	2	Knob-Lever, Height Adjustment
33	614687	2	Arm-Front Spring
34	614672	2	Bolt-Shoulder
35	92-1099	2	Bolt-Shoulder
36	684776	2	Wheel And Tire ASM
99	95-7052	1	Plate-Opening, Chute



Gear Case Assembly No. 104-7671


Ref	Part No.	Qty.	Description				
1	104-7619	1	Case-Gear				
2	614668-03	1	Cover-Case, Gear				
3	32144-4	4	Screw-HWH				
4	32151-68	1	Ring-Retaining				
5	3256-24	1	Washer-Flat				
6	3285-19	2	Pin-Groove				
7	3296-5	1	Nut-Lock, NI				
8	36-4780	2	Washer				
9	36-4791	2	Washer-Thrust				
10	60-8750	2	Bushing				
11	60-8850	2	Bushing				
12	614696	1	Shaft-Intermediate				
13	614669	2	Half-Pulley				
14	100-1048	1	Bearing-Ball				
15	62-6660	1	Spacer				
16	104-7668	1	Gear-15t Spur, 37t Bevel				
17	104-7667	1	Gear-Pinion, Bevel				
18	614596	1	Gear				
19	104-7670	1	Shaft-Output				



Gear Case and Wheel Assembly


Ref	Part No.	Qty.	Description
1	92-1057	2	Bolt-Shoulder
2	92-1042	2	Wheel And Tire ASM
2:3		1	Wheel ASM
2:3:1	27-6250	2	Bushing
3	65-2720	4	Klipring-Locking
4	65-4740	4	Washer-Thrust, Keyed
5	66-6050	1	Key-Rocking, LH
6	66-6040	1	Key-Rocking, RH
7	65-4710	2	Ring-Friction
8	92-7746	2	Rear Height Adjustment Arm ASM
8:2	70-9760	1	Bushing
8:3	47-2900	1	Bushing
8:4	302-56	1	Fitting-Grease
9	92-1008	2	Knob-Lever, Height Adjustment
10	614447	2	Spacer-Axle Shaft
11	32144-85	2	Screw-HWH
12	92-1004	2	Rear Spring Arm ASM
13	603773	2	Nut
14	65-4730	2	Washer-Arm, Pivot
15	65-4760	2	Washer-Clutch
16	65-4750	2	Gear-Pinion
17	65-4720	2	Spring-Compression
18	94-1609	2	Cover-Wheel
19	614426	2	Washer-Stepped

Ref	Part No.	Qty.	Description
20	93-7381	1	V-Belt



Engine and Blade Assembly

Ref	Part No.	Qty.	Description				
1	105-8579	1	Bolt-Blade				
2	612543-03	1	Blade				
3	92-1024-03	1	Guide-Belt				
4	104-7955	1	Decal-Deck				
5	106-8346-03	1	Guard-Muffler				
7	32144-85	1	Screw-HWH				
8	98-1593	1	Applique				
9	106-8375	1	Decal-Recoil				
10	92-1701	1	Stop-Rope				
11		1	Engine-Tecumseh, Lv195ea-362005b				
12	93-4196-03	1	Shield-Grass				
13	95-1726	3	Screw-Taptite				
14	106-3950	1	Driver-Blade				
15	106-6826	1	Spacer				




Handle Assembly

Ref	Part No.	Qty.	Description				
1	104-1013	1	Guard-Cable				
2	614643-05	1	Handle-Lower				
3	100-5989	1	Brake Cable ASM				
4	106-8330	1	Guide-Rope				
6	100-2888-05	1	Handle-Upper				
7	107-0757	2	Stop-Pivot				
8	93-4184-03	1	Bail-Brake				
10	92-1001-03	1	Bail-Control				
11	3296-73	2	Nut-Lock, NI				
12	3256-1	1	Washer-Flat				
13	100-5982	1	Cable-Ground Speed				
14	92-7729	1	Anchor-Cable, Upper				
15	92-2266	1	Screw-Handle				
16	106-4161	2	Knob-Handle				
17	614697	2	Screw				
18	93-7380	1	Anchor-Cable				

Engine Assembly No. 1

Tecumseh Model No. LV195EA-362005B




Engine Assembly No. 1

Tecumseh Model No. LV195EA-362005B

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
④1	37465	1	Cylinder(Incl. Ref. #2, 20 And 150)	④125	37288	1	Exhaust Valve (Std.) (Incl. Ref. #151)
④2	26727	2	Pin-Dowel	④126	37289	1	Intake Valve (Std.) (Incl. Ref. #151and 151a)
④6	33734	1	Element-Breather	④130	6021A	8	Screw, 5/16-18 X 1-7/16in
④7	36557	1	Breather ASM (Incl. Ref. #6 And 12a)	④135	35395	1	Resistor-Spark Plug (Rj19lm)
④12	36775	1	Tube-Breather	④150	31672	2	Spring-Valve
④12A	36558	1	Breather Cover And Tube (Incl. Ref. #12b)	④151	31673	2	Cap-Valve Spring
④12B	36694	1	Elbow-Tube, Breather	④151A	40017	1	Seal-Intake Valve
④14	28277	1	Washer	④166	37813	1	Engine Shroud (Green)
④15	30589	1	Governor Rod (Incl. Ref. #14)	④169	36783	1	Gasket-Valve Cover
④16	34839A	1	Lever-Governor	④172	36784	1	Cover-Valve
④17	31335	1	Clamp-Governor Lever	④174	30200	2	Screw, 10-24 X 9/16in
④18	651018	1	Screw, T-15, 8-32 X 19/64in	④178	29752	2	Nut And Lock Washer, 1/4-28
④19	36281	1	Spring-Extension	④182	6201	2	Screw, 1/4-28 X 7/8in
④20	32600	1	Seal-Oil	④184	26756	1	Gasket-Carburetor To Intake Pipe
④30	37692	1	Crankshaft	④185	37466	1	Pipe-Intake
④40	40027	1	Piston, Pin And Ring Set (Std.)	④186	32653	1	Link-Governor
④41	40042	1	Piston And Pin ASM (Std.) (Incl. Ref. #43)	④189	650839	2	Screw, 1/4-20 X 3/8in
④42	40006	1	Ring Set (Std.)	④191	36559A	1	S.e. Brake Bracket (Incl. Ref. #195)
④43	20381	2	Retaining Ring-Piston Pin	④195	610973	1	Terminal
④45	36777	1	Connecting Rod ASM (Incl. Ref. #46)	④207	34336A	1	Link-Throttle
④46	32610A	2	Bolt-Connecting Rod	④216	33086	1	Lever-R.p.m. Adjusting
④48	27241	2	Lifter-Valve	④223	650451	2	Screw, 1/4-20 X 1in
④50	37460	1	Camshaft (Exhaust Mcr) (Incl. Ref. #104)	④224	36786	1	Gasket-Intake Pipe
④52	29914	1	Oil Pump ASM	④238	650932	2	Screw, 10-32 X 49/64in
④569	37609	1	Gasket-Mounting Flange	④239	34338	1	Gasket-Air Cleaner
④70	37608	1	Mounting Flange (Incl. Ref. #72-83, 306, 309a And 311a)	④241	36919	1	Collar-Air Cleaner
④72	37614	1	Plug-Oil Drain	④245	36905	1	Filter-Air Cleaner
④75	27897	1	Seal-Oil	④250	37122	1	Cover-Air Cleaner
④80	30574A	1	Shaft-Governor	④260	37696A	1	Housing-Blower
④81	30590A	1	Washer	④261	30200	2	Screw, 10-24 X 9/16in
④82	30591	1	Governor Gear ASM (Incl. Ref. #81)	④262	650831	2	Screw, 1/4-20 X 1/2in
④83	30588A	1	Spool-Governor	④275	37498	1	Muffler
④86	650488	6	Screw, 1/4-20 X 1-1/4in	④277	650988	2	Screw, 1/4-20 X 2-9/32in
④89	611298	1	Key-Flywheel	④285	35000A	1	Cup-Starter
④90	611299	1	Flywheel	④287	650926	2	Screw, 8-32 X 21/64in
④92	650815	1	Washer-Belleville	④290	29774	1	Line-Fuel
④93	650816	1	Nut-Flywheel	④292	26460	2	Clamp-Fuel Line
④100	34443C	1	Ignition-Solid State	④298	28763	2	Screw
④101	610118	1	Cover-Spark Plug				
④103	651007	2	Screw, T-15, 10-24 X 15/16in				
④104	37480	1	Bushing-Cam				
④110	37047	1	Wire-Ground				
④5119	37796	1	Gasket-Cylinder Head				
④120	37714	1	Sprocket Assembly				
④125	36780	1	Exhaust Valve (1/32" Os) (Incl. Ref. #151)				

Engine Assembly No. 2


Tecumseh Model No. LV195EA-362005B



Engine Assembly No. 2


Tecumseh Model No. LV195EA-362005B

Ref	Part No.	Qty.	Description				
④300	37947	1	Fuel Tank (Incl. Ref. #292 And 301)				
④301	37844	1	Fuel Cap ASM				
④305	35647	1	Tube-Oil Fill				
④⑤306	37610	1	O-Ring				
④307	35499	1	O-Ring				
④309	650562	1	Screw, 10-32 X 1/2in				
④309A	650783	1	Screw, 10-24 X 3/4in				
④310	35648	1	Dipstick				
④311A	37611	1	Bracket-Hold Down				
④313	34080	1	Spacer				
④347	650898A	1	Screw, 10-32 X 27/32in				
④370A	36261	2	Decal-Lubrication				
④370C	37695	1	Decal-Primer (3 X)				
④370D	35977	1	Decal-Warning				
④380	640303	1	Carburetor (Incl. Ref. #184)				
④390	590739	1	Starter-Rewind				
④400	37613	1	Gasket Set (Incl. Items Marked Pk In Notes)				
④416	37530	1	Kit-Spark Arrestor (Optional)				
④	750876	1	Short Block Asm				




Carburetor Assembly No. 640303 Tecumseh Model No. LV195EA-362005B

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
④0	640303	1	Carburetor (Incl. Ref. #184 Of Engine Parts List)	④40	640087	1	High Speed Bowl Nut
④1	631615	1	Throttle Shaft And Lever ASM	③④44	27110A	1	Washer-Bowl Nut
④2	631767	1	Spring-Throttle Return	③④47	630748	1	Welch Plug-Idle Mixture Well
③④4	631184	1	Washer-Dust Seal	③④48	631027	2	Welch Plug-Atmospheric Vent
③④5	631183	1	Dust Seal	③④60	632809	1	Repair Kit
④6	640070	1	Shutter-Throttle				
③④7	650506	1	Screw-Shutter				
④16	631807	1	Fitting-Fuel				
④17	651025	1	Throttle Crack Screw/Idle Speedscrew				
④18	630766	1	Spring-Tension				
④20	640018	1	Screw-Idle Restrictor				
③④20A	640200	1	Cap-Idle Restrictor Screw				
④25	631867	1	Bowl-Float				
③④27	631024	1	Shaft-Float				
④28	632802	1	Float (Plastic)				
③④29	631028	1	O-Ring-Float Bowl				
③④30	632807	1	Inlet Needle, Seat, And Clip (Incl. Ref. #31)				
③④31	631022	1	Clip-Spring				
④35	640259	1	Retainer Ring-Primerbulb (Red)				
④36	640019	1	Tube-Main Nozzle				
④36A	632766	1	Extension-Bowl Vent Tube				
③④37	632547	2	O-Ring-Main Nozzle Tube				



Recoil Starter Assembly No. 590739
Tecumseh Model No. LV195EA-362005B

Ref	Part No.	Qty.	Description				
0	590739	0	Starter-Rewind				
3	590740	1	Retainer				
6	590616	2	Dog-Starter				
7	590617	2	Spring-Dog				
8	590618A	1	Pulley And Rewind Spring ASM				
11	590638	1	Housing Assembly-Starter				
12	590535	1	Rope-Starter (Length 98in X 9/64in Dia.)				
13	590701	1	Handle-Starter				
14	590760	1	Spring Clip				



Recoil Starter Assembly No. 590702 (Optional)
Tecumseh Model No. LV195EA-362005B

Ref	Part No.	Qty.	Description				
0	590702	0	Starter-Recoil				
1	590599A	1	Spring Pin (Incl. Ref. #4)				
2	590600	1	Washer				
3	590696	1	Retainer				
4	590601	1	Washer				
5	590697	1	Spring-Brake				
6	590698	2	Dog-Starter				
7	590699	2	Spring-Dog				
8	590700	1	Pulley & Rewind Spring ASM				
11	590703A	1	Starter Housing ASM (40 Degree Grommet)				
12	590535	1	Rope-Starter (Length 98in X 9/64in Dia.)				
13	590701	1	Handle-Starter				

NOTES

LAWN-BOY®